# Polaris Vega Application Program Interface Guide

IL-1070259 R06 February, 2020

### **Revision Status**

Revision Number	Date	Description
1	August 2016	First release
2	August 2017	Updated to document the optional video camera.
3	April 2018	The video camera is no longer supported so related content has been removed. Updated content on device names, starting on page 20. Added content on the frame timestamp and PTP clock scheme, on page 65.
4	June 2019	Updated to document the optional video camera and support for serial communications via the optional LEMO connector.  Several chapters are reorganized. This document release coincides with the release of Polaris Vega Firmware Package 006.
Param.Tracking.Track Frequency, Info.Status.Tracking.Measured Frame Fi		Documented Param.Tracking.Frame Frequency, Param.Tracking.Track Frequency, Info.Status.Tracking.Measured Frame Frequency, and Info.Status.Tracking.Measured Track Frequency.
		Documented Event 6 "PTP Master has changed".
		Changed WARNING references to WARNING01 in the PINIT command.
		Added WARNING06 to Table 6-2 on page 179.
6	February 2020	Updated Figure 2-1 on page 6 and Figure 2-3 on page 9 for improved readability, no content changes.

Part Number: IL-1070259

Copyright 2016-2020, Northern Digital Inc. All Rights Reserved. Manufacture, use and/or sale covered by one or more US and other registered patents. Our patented technological innovations can be found at: <a href="https://www.ndigital.com/about/patents">www.ndigital.com/about/patents</a>

### Published by:

Northern Digital Inc. 103 Randall Dr.

Waterloo, Ontario, Canada N2V 1C5

Telephone: + (519) 884-5142
Toll Free: + (877) 634-6340
Global: + (800) 634 634 00
Facsimile: + (519) 884-5184
Website: www.ndigital.com

Copyright 2016-2020 Northern Digital Inc.

All rights reserved. No part of this document may be reproduced, transcribed, transmitted, distributed, modified, merged or translated into any language in any form by any means - graphic, electronic, or mechanical, including but not limited to photocopying, recording, taping or information storage and retrieval systems - without the prior written consent of Northern Digital Inc. Certain copying of the software included herein is unlawful. Refer to your software license agreement for information respecting permitted copying.

### DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITIES

Northern Digital Inc. has taken due care in preparing this document and the programs and data on the electronic media accompanying this document including research, development, and testing.

This document describes the state of Northern Digital Inc.'s knowledge respecting the subject matter herein at the time of its publication, and may not reflect its state of knowledge at all times in the future. Northern Digital Inc. has carefully reviewed this document for technical accuracy. If errors are suspected, the user should consult with Northern Digital Inc. prior to proceeding. Northern Digital Inc. makes no expressed or implied warranty of any kind with regard to this document or the programs and data on the electronic media accompanying this document.

Northern Digital Inc. makes no representation, condition or warranty to the user or any other party with respect to the adequacy of this document or accompanying media for any particular purpose or with respect to its adequacy to produce a particular result. The user's right to recover damages caused by fault or negligence on the part of Northern Digital Inc. shall be limited to the amount paid by the user to Northern Digital Inc. for the provision of this document. In no event shall Northern Digital Inc. be liable for special, collateral, incidental, direct, indirect or consequential damages, losses, costs, charges, claims, demands, or claim for lost profits, data, fees or expenses of any nature or kind.

Product names listed are trademarks of their respective manufacturers. Company names listed are trademarks or trade names of their respective companies.

The Polaris Vega System includes software that is distributed under the GPL v2 licence. For details on the GPL v2 licence refer to http://www.gnu.org/licenses/old-licenses/gpl-2.0.en.html

# **Table of Contents**

About This Guide .	ii
Warnings	and Cautionsii
	formation
1 List of Command	ls′
2 Important Conce	pts !
2.1 Gener	al Binary Format
2.2 Exten	ded Binary Header
2.3 Opera	ting Roles for Host Connections
2.4 Data 9	Streaming
3 Communicating	with an NDI System
3.1 Conne	ection Requirements
3.2 Comm	nunication Overview
3.3 Opera	ting Modes
3.4 Gener	al Syntax11
3.5 Recei	ving System Replies
3.6 Best I	Practices
3.7 Port F	Iandles
4 User Parameters	
4.1 Abou	User Parameters
4.2 User l	Parameter Commands
4.3 Devic	e Names
4.4 Alerts	User Parameters
4.5 Comp	lete List of User Parameters

5 Command Details 44				
6 Error and	Warning Code Definitions 1	76		
6.1	Error Code Definitions	76		
6.2	Warning Code Definitions	79		
Appendix A	Keyed Features 1	80		
Appendix B	Sample C Routines 1	84		
Appendix C	Changes in Implementation between Spectra and Vega 1	92		
6.3	Changed Commands	93		
6.4	New Concepts	94		
Appendix D	Vega Video Camera Parameter Supplement	95		
Appendix E	Vega Video Camera Alignment	∣99		
Abbreviation	ns and Acronyms	206		
Glossarv		207		

# **About This Guide**

This guide describes the Polaris Vega Application Program Interface, including the commands and parameters supported by the Position Sensor, Video Camera and System Control Unit. For information about which versions of the API, and which devices in the system, support a particular command, refer to the command's description in the Command Details chapter, starting on page 44.

The recommended way to query the firmware and API revisions is by using the following command/parameter combination:

### **GET Features.Firmware.API Revision**

For backwards compatibility, the APIREV (page 50) command is still supported.

Note For information on previous revisions of the API, refer to the Polaris Application Program Interface Guide (IL-1070101) available on the NDI support site at https://support.ndigital.com.

# **Warnings and Cautions**

### Warnings



In all NDI documentation, warnings are marked by this symbol. Follow the information in the accompanying paragraph to avoid personal injury.

- 1. Do not connect the Polaris Vega System to a host computer or network that is not IEC 60950 and/or IEC 60601 approved. If you connect the system to a non-approved host computer or network you may increase leakage currents beyond safe limits and cause personal injury.
- 2. When using reply option 0800 with the BX (page 53) or TX (page 150) commands, you must take appropriate action to detect the following events: the tool or marker is out of volume, the bump sensor has been tripped, or the system is outside of the optimal operating temperature range. You must determine whether these events are detrimental to your application. If one or more of the events listed occurs, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.
- 3. No options exist for filtering data returned from the BX2 (page 64) command on the basis of system or tool status or location in the volume. Complete system and tool status information is always included in the reply and it is the application's responsibility to interpret this data and ignore those measurements that fall outside of application requirements and constraints. Failure to do so may lead to inaccurate conclusions that may cause personal injury.

## **Contact Information**

If you have any questions regarding the content of this guide or the operation of this product, please contact us:



### Head Office

Waterloo, ON Canada

Shelburne, VT USA

Radolfzell, Germany

- Waterloo, ON Canada
   Shelburne, VT USA
   Radoirzeii, Germany
   nong kong, China

   ☎ +1 (877) 634-6340
   ☎ +1 (802) 985-1114
   ☎ +49 7732 8234 0
   ☎ + (852) 2802-2205

   ☒ support@ndigital.com
   ☒ support@ndieurope.com
   ☒ support@ndieurope.com
   ☒ support@ndigital.com

   ✅ www.ndigital.com
   ✅ www.ndieurope.com
   ✅ www.ndigital.com

Hong Kong, China

NDI is committed to continuous improvements in the quality and versatility of its software and hardware. To obtain the best results with your NDI system, check the NDI Support Site regularly for updated information: https://support.ndigital.com.

# 1 List of Commands

- Table 1-1 lists the API commands supported by the Vega Position Sensor.
- Table 1-2 lists the API commands supported by the Vega System Control Unit.
- Table 1-3 lists the API commands supported by the Vega Video Camera.

.

Table 1-1 List of Commands - Vega Position Sensor

Command Page [		Description		
3D	45	Returns the latest 3D position of either a single marker or multiple markers.		
APIREV	50	Returns the API revision number that functions with your system.		
BEEP	51	Sounds the system beeper.		
BX	53	Returns the latest tool transformations, individual marker positions, and system status in binary format.		
BX2	64	Returns various levels of data on the latest tool transformations, individual marker positions, and system status in binary format.		
COMM	74	Sets the serial communication settings of the system. (Serial communication only.)		
DFLT	77	Restores the user parameters to factory default values.		
DSTART	79	Starts Diagnostic mode.		
DSTOP	80	Stops Diagnostic mode.		
ЕСНО	81	Returns exactly what is sent with the command.		
GET	82	Returns the user parameter values.		
GETINFO	84	Returns descriptive information about the user parameters.		
GETLOG	87	Returns the contents of a system log file.		
INIT	89	Initializes the system.		
IRATE	91	Sets the illuminator rate.		
IRED	93	Turns the markers on a wired tool on or off.		
LED	95	Changes the state of visible LEDs on a wired tool.		
PDIS	97	Disables the reporting of transformations for a particular port handle.		
PENA	98	Enables reporting of transformations for a particular port handle.		
PFSEL	100	Sets which tool faces to use to track a multi-faced tool.		
PHF	102	Releases system resources from an unused port handle.		
PHINF	103	Returns port handle status, and information about the tool associated with the port handle, including physical port location.		
PHRQ	109	Assigns a port handle to a tool.		
PHSR	111	Returns the number of assigned port handles and the port status for each one. Assigns a port handle to a wired tool.		

Table 1-1 List of Commands (Continued)- Vega Position Sensor

Command	Page	Description		
PINIT	114	Initializes a port handle.		
PPRD	116	Reads data from the SROM device in a wired tool. (Only applicable to the System Control Unit.)		
PPWR	118	Writes data to the SROM device in a wired tool. (Only applicable to the System Control Unit.)		
PSEL	120	Selects an SROM device as the target for reading or writing with PPRD or PPWR.		
PSRCH	121	Returns a list of valid SROM device IDs for a wired tool or GPIO device.		
PURD	123	Reads data from the user section of the SROM device in a wired tool. (Only applicable to the System Control Unit.)		
PUWR	125	Writes data to the user section of a tool SROM device in a wired tool. (Only applicable to the System Control Unit.)		
PVWR	127	Assigns a tool definition file to a wireless tool, overrides a tool definition file in a wired tool, and can be used to test a tool definition file before permanently recording the tool definition file onto the SROM device.		
RESET	129	Resets the system (can specify either a hard reset or a soft reset).		
SAVE	130	Saves all non-volatile user parameters that have been changed.		
SET	131	Sets user parameter values.		
SFLIST	133	Returns information about the supported features of the system.		
STREAM	140	Initiates a streaming response to a specified command.		
SYSLOG	142	Writes data to the device log file.		
TCTST	144	Returns diagnostics on the active markers of a wired tool.		
TSTART	144	Starts Tracking mode.		
TSTOP	147	Stops Tracking mode.		
TTCFG	148	Sets up a configuration for a wired tool so that you can test the tool without using a tool definition file.		
TX	150	Returns the latest tool transformations, individual marker positions, and system status in text format.		
USTREAM	162	Stops streaming of the indicated command		
VCAP	163	Captures IR image data from the sensors and/or video camera image data.		
VGET	169	Retrieves data previously captured with VSNAP.		
VER	167	Returns the firmware revision number of critical processors installed in the system.		
VSEL	173	Selects a characterized measurement volume.		
VSNAP	174	Captures one complete frame sequence of video data from the sensors.		

Table 1-2 List of Commands - Vega System Control Unit

Command	Page	Description	
APIREV	50	Returns the API revision number that functions with your system.	
BEEP	51	Sounds the system beeper.	
ЕСНО	81	Returns exactly what is sent with the command.	
GET	82	Returns the user parameter values.	
GETINFO	84	Returns descriptive information about the user parameters.	
GETLOG	87	Returns the contents of a system log file.	
PPRD	116	Reads data from the SROM device in a wired tool. (Only applicable to the System Control Unit.)	
PPWR	118	Writes data to the SROM device in a wired tool. (Only applicable to the System Control Unit.)	
PSEL	120	Selects an SROM device as the target for reading or writing with PPRD or PPWR.	
PSRCH	121	Returns a list of valid SROM device IDs for a wired tool or GPIO device.	
PURD	123	Reads data from the user section of the SROM device in a wired tool. (Only applicable to the System Control Unit.)	
PUWR	125	Writes data to the user section of a tool SROM device in a wired tool. (Only applicable to the System Control Unit.)	
RESET	129	Resets the system (can specify either a hard reset or a soft reset).	
SAVE	130	Saves all non-volatile user parameters that have been changed.	
SET	131	Sets user parameter values.	
SYSLOG	142	Writes data to the device log file.	
VER	167	Returns the firmware revision number of critical processors installed in the system.	

Table 1-3 List of Commands - Vega Video Camera

Command	Page	Description	
APIREV	50	Returns the API revision number that functions with your system.	
DFLT	77	Restores the user parameters to factory default values.	
ЕСНО	81	Returns exactly what is sent with the command.	
GET	82	Returns the user parameter values.	
GETINFO	84	Returns descriptive information about the user parameters.	
GETLOG	87	Returns the contents of a system log file.	
INIT	89	Initializes the system.	
RESET	129	Resets the system (can specify either a hard reset or a soft reset).	
SAVE	130	Saves all non-volatile user parameters that have been changed.	
SET	131	Sets user parameter values.	
SYSLOG	142	Writes data to the device log file.	
VCAP	163	Captures video camera image data.	
VER	167	Returns the firmware revision number of critical processors installed in the system.	

# 2 Important Concepts

With the introduction of Polaris Vega, the following programming concepts should be understood:

- "General Binary Format" on page 5
- "Operating Roles for Host Connections" on page 7
- "Extended Binary Header" on page 6
- "Data Streaming" on page 7

# 2.1 General Binary Format

The General Binary Format (GBF) is used consistently in all new commands for Polaris Vega to return tracking and video data. Its advantage is that the host does not need to keep the context of the request to be able to parse it correctly. It can also contain various levels of detail corresponding to the reported tracking frame. It is structured as a list of individual, well-defined components. Each component holds the information on its unique type and its options that define the process of parsing its content. It uses little endian byte order and all size byte values are interpreted as unsigned values. The general structure of the format is illustrated in Figure 2-1.

All numeric values are 4 bytes (32 bits) unless otherwise specified. The first field in the payload is a 2 byte integer that indicates the number of components contained in the payload.

Each component starts with a unique 2 byte value defining its type, followed by 4 bytes specifying the size of the component, including the 12 bytes for the header. If the parsing software cannot parse this component, it can use the size information to skip to the beginning of the next component.

Item Format Option (2 bytes) is specific to the component type. Each type will have its own set of options that provide all the information needed to parse the content of the component. The Item Format Option implies the Item's size.

Item Count (4 bytes) describes the number of following items to parse. After parsing all the specified items, a new component starts with its definition of the component type and the parsing process repeats.

Component ID's are as follows:

- 01 Frame Component
- 02 6D Data Component
- 03 3D Data Component
- 04 1D Data Component buttons
- 05 2D Data Component
- 06 reserved
- 07 reserved
- 08 reserved
- 09 reserved
- 10 Image Data Component

- 11 to 16 reserved
- 17 Sensor U,V Component
- 18 System Alert Component

An example of the GBF structure, with an example of the BX2 command is shown in Figure 2-1.




Figure 2-1 General Binary Format structure and BX2 example

# 2.2 Extended Binary Header

To facilitate binary replies that have a binary payload greater than  $2^{16}$ -1 bytes long, a new binary header type is introduced. This header has a 32 bit length field and allows for reply lengths up to  $2^{32}$ -1 bytes long. Either binary header may be used in response to any of the "new" binary commands, such as BX2 and VCAP.

This extended binary reply header is intended for use with very large replies. If the reply length is less than  $2^{16}$ -1 bytes long, then the original binary header is used. Since TCP packets already include data checksums and to reduce processing time and allow for more efficient memory-to-memory transfer techniques, no CRC will be included in the header or at the end of the data. Thus, the extended header is the same length as the original header.

The format of an extended binary header reply is as follows:

A5C8<4 byte Reply Length><command reply>

# 2.3 Operating Roles for Host Connections

With support for the multi-host option, there is a need to ensure only one connection to the Vega device has the capability of changing configuration options and the mode of the device. That connection will hold the Master role and other connections will be in a Monitor role. The Master connection will have full control of the system. If a connection in a Monitor role issues a command that would change the operation of the system then error code 0x39 (Permission Denied) will be returned.

Initially a connection will be granted the Monitor role. When it issues a command that would require it to become the Master, the system assigns it the Master role, if the host is in the list of allowed Masters and there is not already another Master.


There is a Master Time Out setting that tracks the activity on the Master connection. If the period of inactivity on the Master connection exceeds the threshold set in the Master Time Out parameter, then the Monitor can become the Master.

If a serial and ethernet connection are established with the Vega, the serial connection will always regain the Master role immediately from the ethernet connection. The Master Time Out setting does not apply in this case.

# 2.4 Data Streaming

Prior to the introduction of Vega, the host and the system communicated in a strict Request-Response pattern. Polaris Vega introduces an option to continuously stream command responses for each new frame of data. For an application to make use of streaming, its communication drivers will have to be modified because most legacy applications expect the response to come after the request. Once streaming is enabled on the communication channel, the host can no longer assume that a given response received from the system belongs to the last request. The host addresses this in its parsing by always investigating the kind of reported data. Each streaming response will be clearly

identified in its header then host processing routes each response to its corresponding process. See Figure 2-2 on page 8.






Figure 2-2 Streaming Response Pattern

This Vega platform introduces two new streaming commands: STREAM (initiates a streaming response to a command) and USTREAM (terminates a stream).

Newly introduced streamed replies will be wrapped in the Streaming Reply Format in a similar way to how the BX binary data is currently wrapped in the Binary Data Format. Both are shown in Figure 2-3 on page 9.

Structures of both formats are similar. Both start with the header, followed by the binary data content and both are concluded by the CRC, ensuring correct content. Streaming reply starts with a new 2 byte identification sequence. The new parsing process checks for this sequence at the start of each reply. The header of the streaming message contains a unique string of bytes "Stream ID" which the host will use to identify which stream the response belongs to (in the case where more than one stream is initiated). If the reply is not a streaming reply, it belongs to the last pending non-streaming

request. All of the tracking data is delivered in the new General Binary Format, see "General Binary Format" on page 5.




Figure 2-3 Binary and Streaming Reply Format

# 3 Communicating with an NDI System

- "Connection Requirements" on page 10
- "Communication Overview" on page 10
- "Operating Modes" on page 11
- "General Syntax" on page 11
- "Receiving System Replies" on page 12
- "Best Practices" on page 14
- "Port Handles" on page 15

# 3.1 Connection Requirements

The system must communicate with a host computer to pass measurement information to another application running on the host computer. Connection requirements are detailed below.

The ethernet connection must handle the bandwidth of data being sent. The bandwidth is dependent on the amount of data being requested from the Vega System.

The ethernet connection must be compliant with IEEE 802.3at type 2 and secure from any unauthorized connections.

The severity of all connection-related hazardous situations is the responsibility of the system integrator because there is no essential performance of the Vega System.



Do not connect the Polaris Vega System to a host computer or network that is not IEC 60950 and/or IEC 60601 approved. If you connect the system to a non-approved host computer or network you may increase leakage currents beyond safe limits and cause personal injury.

Note

Operation on an open or uncontrolled network could limit communication bandwidth, increase latency or otherwise interfere with the normal operation of the Vega System and introduce risks which should be analyzed. Changes to the network including connection, disconnection or updates to any equipment may also affect operation of the system.

### 3.2 Communication Overview

There are two methods of communication with the Polaris systems; request-response and streaming. Both methods are described below.

### **Request-Response Communication**

In request-response communication, from the application perspective, the Polaris Vega System is a serial device, which is listening for incoming commands. Upon receiving a command, the system performs some action and returns the status of this action. The system never initiates communication with the application.

Immediately after sending a command, the application can begin to poll the serial buffer for a reply. Most commands reply almost instantly. After reaching the end of the reply, the application can send another command. There may be some delay in the response of the <a href="INIT">INIT</a> command, and the commands used to read from and write to an SROM device in a wired tool.

### **Streaming Communication**

The Polaris Vega System introduces an option to continuously stream command responses for each new frame of data. The STREAM command initiates streaming response and the USTREAM command terminates the streaming response. For details, see "Data Streaming" on page 7.

# 3.3 Operating Modes

The system has three modes of operation: Setup, Tracking, and Diagnostic. Some commands will only work if they are sent while the system is in a specific mode of operation. If a command is sent when the system is in a mode not valid for that command, the system returns ERROROC.

### **Setup**

Setup mode allows you to configure the system and tools. Tasks done while the system is in Setup mode may include initializing the system, writing to the SROM on a tool, or checking the system revision.

A wireless tool must have a port handle assigned to it (PHRQ) before the application can load a tool definition file (PVWR) Both conditions must be satisfied before the tool can be enabled (PENA).

The system enters the Setup mode either on successful power up, on sending a reset, or on exiting from Tracking or Diagnostic modes.

# **Tracking**

In Tracking mode, the system measures the positions and orientations of tools in real time and returns the information to the host computer when requested. The BX2 and BX commands are the most commonly used commands in Tracking mode.

The system enters Tracking mode on successful TSTART command and exits Tracking mode on TSTOP command.

### **Diagnostic**

Diagnostic mode allows you to control and observe active tools, but not track them.

The system enters Diagnostic mode on successful DSTART command and exits Diagnostic mode on DSTOP command.

# 3.4 General Syntax

Commands must be sent from the host computer to the system in one of the two following formats. To ensure the integrity of data transmission, NDI recommends using format 1, as well as verifying the returned CRC on the host computer.

### Format 1

```
<Command><:><Parameter1><Parameter2>...<ParameterN><CRC16><CR>
```

A <:> must be sent with every command even if no parameters are required. There are no characters or spaces separating the parameters or the individual parts of the commands, except in user parameter names and string values used with the SET, GET, GETINFO, DFLT, and SYSLOG commands. Commands and parameters are not case-sensitive, except for user parameter names and string values used with the SET, GET, GETINFO, DFLT, and SYSLOG commands and in POSIX-style parameters (which must be separated from each other by one or more spaces).

This format requires a 16-bit CRC (Cyclic Redundancy Check) value and therefore may be more useful in application software. The application software can incorporate a CRC calculation and add it to the command each time a command is sent to the system. Including a CRC provides a communications check to ensure that there are no communication problems between the system and the host computer. The CRC is used in both the commands and replies. It is based on all the characters in the command, up to the CRC itself. It is calculated using the polynomial  $x^{16} + x^{15} + x^2 + 1$ . See "Sample C Routines" on page 184 for sample code to calculate the CRC.

### Format 2

```
<Command><SPACE><Parameter1><Parameter2>...<ParameterN><CR>
```

A <SPACE> may be sent with every command; it need not be sent if no parameters are required. There are no characters or spaces separating the parameters or the individual parts of the commands, except in user parameter names and string values used with the SET, GET, GETINFO, DFLT, SYSLOG commands and in POSIX-style parameters (which must be separated from each other by one or more spaces). Commands and parameters are not case-sensitive, except for user parameter names and string values used with the SET, GET, GETINFO, DFLT, and SYSLOG commands.

It is not necessary to calculate a CRC value when using this format, so this format is useful for sending commands to the system in an application such as a terminal program.

# 3.5 Receiving System Replies

### **Binary Replies**

Commands BX, BX2, GETLOG, and VCAP return binary replies. All other commands return ASCII replies.

If a complete command is received by the system, replies are sent back in the format:

```
<A5C4><Reply Length 2bytes><Header CRC 2 bytes><command reply><CRC16>
```

The system always returns <CRC16> in the reply regardless of whether the command was sent in format 1 or format 2 unless the reply is an Extended Binary Reply. The <Reply> will be either the requested data, or ERROR<error code>. The <error code> is a two-digit hexadecimal error number. See "Error Code Definitions" on page 176 for a listing of all the error messages associated with error numbers.

Binary replies are returned in little endian format. For example, a 32-bit reply is returned in the format:

Reply byte	n	n+1	n+2	n + 3

### **Extended Binary Reply**

In order to facilitate binary replies that have a binary payload greater than 65535 bytes long, a new binary header type is introduced. This header has a 32 bit length field and allows for reply lengths up to 2^32-1 bytes long. Either binary header may be used in response to any of the "new" binary commands, currently BX2 and VCAP.

This extended binary reply is intended for use with very large replies. If the reply length is less than 65535 bytes long, then the original binary header is used. Since TCP packets already include data checksums and to reduce processing time and allow for more efficient memory-to-memory transfer techniques, no CRC will be included in the header or at the end of the data. Thus, the extended header is the same length as the original header.

The format of an extended binary reply is as follows:

A5C8<4 byte Reply Length><command reply>

### **ASCII Replies**

All commands return ASCII replies except BX, BX2, GETLOG, and VCAP, which return binary replies.

If a complete command is received by the system, replies are sent back in the format:

```
<Reply><CRC16><CR>
```

The system always returns <CRC16> in the reply regardless of whether the command was sent in format 1 or format 2. The <Reply> will be either the requested data, OKAY, WARNING<warning code>, or ERROR<error code>.

The <error code> is a two-digit hexadecimal error number. See "Error Code Definitions" on page 176 for a listing of all the error messages associated with error numbers.

See "Warning Code Definitions" on page 179 for a listing of warning codes and definitions.

### 3.6 Best Practices

This section provides guidelines on how to write an application in order to minimize updates required when there are changes to the API. If your application is written correctly, it will still work when additions are made to the API; you will only need to update your application if you wish to take advantage of the new features.

- Ignore the value of any returned field that is listed as "reserved" in the API guide. The values of reserved fields may change in future API releases.
- Program the application to allow all possible values of a returned field, not only the values that are currently defined. This allows for future expansion. For example, if a field returns one character, but currently only characters 0 and 1 are defined, do not write your application such that 0 and 1 are the only acceptable values; more values may be defined in the future.
- Use the frame number, and not the host computer clock, to identify when data was collected. The frame number is incremented by 1 at the base frame rate. Associating a time from the host computer clock to replies from the system assumes that the duration of time between raw data collection and when the reply is received by the host computer is constant. This is not necessarily the case. The frame number is returned with the command BX (page 53), TX (page 150), BX2 (page 64), and VCAP (page 163).
- Use both the shape type and the shape parameters to represent the characterized
  measurement volume graphically. There may be multiple volumes with the same shape
  type. All volumes of the same shape type use the shape parameters the same way. The shape
  type and shape parameters are returned with the command SFLIST (page 133). See also
  C.2.
- When checking the firmware revision, check only the combined firmware revision, not the firmware revision of the individual components. The combined firmware revision ensures that all components in a system have compatible firmware. To check the combined firmware revision, read the value of the user parameter Config.Combined Firmware Revision or use the command VER 5 (page 167). See "User Parameters" on page 19 for information on reading user parameters.
- When checking for protocol compatibility, check for the API revision instead of the combined firmware revision. An application written for a particular API revision will function with any system that supports that API revision. See the command APIREV (page 50) for details.
- Use GET Device.\* to determine which devices are in the system configuration, instead of programming device names directly into the application. This will allow the addition or removal of devices without breaking the application. When setting or reading a user parameter value for every hardware device in the system, create a loop to repeat the action for every device name determined using GET Device.\*. See "Device Names" on page 20 for instructions on how to determine the device names of the hardware devices in your system and how to access user parameters using device names.
- Read the timeout values of the API commands from the user parameter Info.Timeout.<command name>; do not program the timeout values directly into the application. See "User Parameters" on page 19 for information on user parameters.

• Do not use the system log to record minor system events. The system log is intended for major milestones only, and may not have enough space to accommodate numerous minor entries. For minor entries, use the user parameters Param.User.String0 to Param.User.String4 as required. These parameters can be used for any purpose; the system does not make use of them. For example, an incoming inspection result might be a major milestone to be saved in the system log; a cleaning schedule might be a minor entry to be saved in a user parameter. See "User-Defined User Parameters" on page 30 for information on these user parameters.

### 3.7 Port Handles

### **About Port Handles**

The system assigns each tool a port handle. Using the commands below, port handles are two characters in hexadecimal format, 0x01 to 0xFF. (BX2, for example, returns port handles as 4 characters.)

Port handles can be assigned to tools only while the system is in Setup mode.

### **Port Handle Commands**

The following commands are used for port handles:

Command	Description
PHSR (page 111)	Returns the number of assigned port handles and the port status for each one. Assigns a port handle to a wired tool.
PHRQ (page 109)	Assigns a port handle to a tool. PHRQ is followed by PVWR.
PVWR (page 127)	Assigns a tool definition file to a tool, overrides a tool definition file in a wired tool, and can be used to test a tool definition file before permanently recording the tool definition file onto the SROM device of a wired tool.
PINIT (page 114)	Initializes a port handle. PENA calls PINIT.
PHINF (page 103)	Returns port handle status, and information about the tool associated with the port handle, including physical port location.
PHF (page 102)	Releases system resources from an unused port handle. This is required if a tool is disconnected. If a tool is disconnected and then reconnected, the system assigns it a new port handle. The old handle is reported as disabled and should be freed using PHF.
PENA (page 98)	Enables reporting of transformations for a particular port handle.
PDIS (page 97)	Disables the reporting of transformations for a particular port handle.

The order in which these commands are used is detailed in Figure 3-1 on page 17 (for wired tools) and Figure 3-2 on page 18 (for wireless tools).

### **Disabled Transformations**

A transformation may be reported as DISABLED if:

- the port handle was not enabled with PENA (page 98),
- the port handle has been disabled with PDIS (page 97), or
- a wired tool has been disconnected and the port handle has not been freed.

## **Unoccupied Port Handle**

A port handle may be reported as UNOCCUPIED if:

- the tool has been disconnected and port handle information is requested using PHINF (page 103), or
- you have requested a port handle with PHRQ (page 109) but you have not yet used PVWR (page 127) to associate a tool definition file with the port handle.

# Flow Charts for Port Handle Usage

Figure 3-1 details the logic for using port handles with wired tools.




Figure 3-1 Flow Chart for Port Handle Usage - Wired Tools

Get port handles that need to be freed (PHSR 01) Are there port Free port handle handles to be (PHF) freed? no Do I need a Request port handle yes handle for a port? (PHRQ) no Do I need to no load a tool definition file? yes Load tool Get port handles that definition file need to be initialized (PVWR) (PHSR 02) Are there Initialize handles yes port handles (PINIT) to be initialized? Optional no Get port handles to be enabled (PHSR 03) Are there **Enable port** yes port handles handles (PENA) to be enabled? no Start tracking (TSTART)

Figure 3-2 details the logic for using port handles with wireless tools.

Figure 3-2 Flow Chart for Port Handle Usage - Wireless Tools

# 4 User Parameters

The following sections provide detailed information on the parameter system used by the Polaris Vega API:

- "About User Parameters" on page 19
- "User Parameter Commands" on page 20
- "Device Names" on page 20
- "Alerts User Parameters" on page 22
- "Complete List of User Parameters" on page 30

### 4.1 About User Parameters

User parameters store values for different aspects of the Polaris Vega System. Some user parameters store values for the full system configuration; others store values pertaining to a particular hardware device in the system. Some user parameters are read-only parameters that store useful information about the system; some user parameter values can be changed to allow you to configure the system.

For a full list of user parameters, see page 30.

User parameters fall into the following categories:

- Image Capture User Parameters: These user parameters are used in conjunction with the VSNAP or VGET commands to store settings and values related to image capture. For example, background or illuminated frame.
- Settings User Parameters: These user parameters store settings for each hardware device in the system. For example, the illuminator rate and the available characterized measurement volumes are stored in the settings user parameters.
- Information User Parameters: These user parameters store status information for each hardware device in the system and command timeout values.
- Features User Parameters: These user parameters store information about the features of each hardware device in the system.
- System Configuration User Parameters: These user parameters store information about the configuration of the system. These user parameters describe the configuration of the entire system, not a particular device.
- Hardware Device Information User Parameters: These user parameters store information about which hardware devices are part of the system.
- Network User Parameters: These user parameters store information about the network settings of the system.
- Clock User Parameters: These parameters store information about the system clock, including the day, month, year, hour, minutes and seconds.
- Volume User Parameters: These parameters store information about the Vega volume, including the volume shapes and supported wavelengths.

- Video Camera Parameters: These parameters store information about the configuration of the optional Vega Video Camera Unit.
- Bump Sensor User Parameters: These parameters store information about the bump sensor.

### 4.2 User Parameter Commands

The following commands are used with the user parameters:

Command	Description
DFLT (page 77)	Restores the user parameters to factory default values.
GET (page 82)	Returns user parameter values.
GETINFO (page 84)	Returns user parameter values and descriptive information about the user parameters, including use details, possible values and access rules.
SET (page 131)	Sets user parameter values.
SAVE (page 130)	Saves all non-volatile user parameters that have been changed.

See the individual commands for more details.

### 4.3 Device Names

Each device in the system configuration has a unique device name, its own set of user parameters, and its own log file.

Noto

For information on the log files, see GETLOG (page 87) and SYSLOG (page 142).

### **Determining the Devices in the System Configuration**

Use the GET command to determine which hardware devices are in your system. To ensure future compatibility if more devices are integrated into your system, your application should read the list of devices every time you connect to a system, or whenever a component is connected or disconnected.

Note

The list of devices does not update while the system is in tracking mode. The list of devices will not show changes until the system exits tracking mode.

The most general method of reading the list of devices to ensure consistent behaviour in the future is as follows:

### Command:

GET Device.\*

### Reply:

Device.Type.0=PS Device.Type.1=VCU Device.Instance.0=0

```
Device.Instance.1=0
Device.Address.0=local
Device.Address.1=
Device.Port.0=8765
Device.Port.1=0
```

The reply gives information about every device in the system configuration. For each device, there are four parameters, as shown in the reply example above.

**Device.Type.X** describes the type of connected device:

Device.Type Parameter	Hardware Device
PS	Position Sensor
VCU	Video Control Unit

**Device.Instance.X** describes the instance of that type of device in the configuration.

Parameters with the same X index value (for example, Device.Type.0 and Device.Instance.0) describe the same device. For more information, refer to table Table 4-10.

### **Constructing Device Names**

To construct the device name for a particular device, use the following syntax:

```
<Device.Type.X>-<Device.Instance.X>
```

For the configuration in the example above, the device names are PS-0 and VCU-0.

### **Accessing User Parameters Using Device Names**

To ensure that the user parameters for the correct device are accessed, prefix the parameter with the device name. All references to user parameters for a device can be made using the device name. If you omit the device name, the system will default to the parameters for the first Position Sensor in the configuration (PS-0). To access the user parameters for a particular device, use the following syntax:

```
<Device.Type.X>-<Device.Instance.X>.<User Parameter>
```

For example, use GET PS-0. Param. Tracking. Frame Frequency to check the frame frequency of the Position Sensor.

To view information about the parameters supported by the device, use the following commands:

```
GET PS-0.*
GETINFO PS-0.*
```

Note See "GET" on page 82 and "GETINFO" on page 84 for command details.

The system configuration user parameters (beginning with Config) and the hardware device user parameters (beginning with Device) describe the configuration of the entire system. Do not prefix these user parameters with a device name.

### 4.4 Alerts User Parameters

The alerts user parameters describe the status of a particular hardware device in the system.

### **Alerts User Parameters**

Table 4-1 describes the alerts user parameters.

### Table 4-1 Alerts User Parameters

User	Description
Parameter	Description

### Info.Status.Alerts

This user parameter describes the current state of the hardware device. See the alerts listed in Table 4-2 for the Position Sensor. For System Control Unit alerts, see Table 4-3. For Video Camera alerts, see Table 4-4.

The bit corresponding to a particular alert is set when the system first detects the condition. This is accompanied by system response in Table 4-2 or Table 4-3. The bit is cleared when the condition no longer exists. Note: the "bump detected" bit will be cleared only when you set the "Param.Bump Detector.Clear" Position Sensor user parameter to "1".

### Info.Status.New Alerts

Read this user parameter when the diagnostic pending bit is set (bit 8 in the BX or TX System Status component). This user parameter lists the current alerts status whenever an alert is set or cleared. The act of reading this parameter clears both this parameter and the diagnostic pending bit.

The bit corresponding to a particular alert is set when the system first detects the condition, and is cleared when the system first detects that the condition has been resolved. This is accompanied by system response in Table 4-2 or Table 4-3. The act of reading this user parameter clears it.

### Param.Simulated Alerts

Simulates the **Info.Status.Alerts** parameter, for the hardware device specified, for testing purposes. To test the response of a particular alert, set the value of this parameter to the value of the alert. See <u>Table 4-2</u>, <u>Table 4-3</u>, or <u>Table 4-4</u>.

### **Position Sensor Alerts**

Table 4-2 describes the Position Sensor alerts that are returned by the **Info.Status.Alerts** and **Info.Status.New Alerts** user parameters. The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Table 4-2 Position Sensor Alerts

Hexadecimal Value	Alert	System Response	Log to File	Position Sensor LED Indication	BX2 Code
0x00000001	Non-recoverable parameter fault The system parameter file or some other critical file is missing or has been corrupted (CRC check failed).	INIT returns ERROR15 See page 176.	yes	Error LED: on Power LED: off	Fault 1
0x00000002	Sensor parameter fault The sensor parameters were not programmed properly, or cannot be read by the system. Not in use.	INIT returns ERROR15 See page 176.	yes	Error LED: on Power LED: off	Fault 2
0x00000004	Not in use.				
0x00000008	Not in use.				
0x00000010	Illuminator voltage fault The illuminator voltage is outside of operating range. This may be caused by a hardware failure.	Sets diagnostic pending bit (bit 8) in TX or BX system status.	yes	Error LED: on Power LED: off	Fault 5
0x00000020	Illuminator current fault The illuminator current is outside of operating range. This may be caused by a hardware failure.	Sets diagnostic pending bit (bit 8) in TX or BX system status.	yes	Error LED: on Power LED: off	Fault 6
0x00000040	Left sensor temperature fault The left sensor temperature cannot be read.	INIT returns ERROR15 See page 176. Sets diagnostic pending bit (bit 8) in TX or BX system status. The system will not return tracking data, even if reply option 0800 in TX/BX is used.	yes	Error LED: on Power LED: off	Fault 7
0x00000080	Right sensor temperature fault The right sensor temperature cannot be read.	INIT returns ERROR15 See page 176. Sets diagnostic pending bit (bit 8) in TX or BX system status. The system will not return tracking data, even if reply option 0800 in TX/BX is used.	yes	Error LED: on Power LED: off	Fault 8

Table 4-2 Position Sensor Alerts (Continued)

Hexadecimal Value	Alert	System Response	Log to File	Position Sensor LED Indication	BX2 Code
0x0000100	Main temperature fault The main board temperature cannot be read.	INIT returns ERROR15 See page 176. Sets diagnostic pending bit (bit 8) in TX or BX system status. The system will not return tracking data, even if reply option 0800 in TX/BX is used.	yes	Error LED: on Power LED: off	Fault 9
0x00000200	One of the image sensors on the Position Sensor is not functioning. This may be caused by an internal hardware failure.	INIT returns ERROR15 See page 176. Sets diagnostic pending bit (bit 8) in TX or BX system status. The system will not return tracking data, even if reply option 0800 in TX/BX is used.	yes	Error LED: on Power LED: off	Fault 10
0x00000400	Reserved				
0x00010000	Firmware is running in Safe Mode. The system has not been able to boot properly two or more times in a row.	INIT returns ERROR15 See page 176.	no	Error LED: flashing Power LED: on	Alert 17
0x00020000	System Control Unit fault or alert detected. There is a fault or alert present in the System Control Unit's Info.Status.Alerts parameter.	INIT returns OKAY Sets diagnostic pending bit (bit 8) in TX or BX system status.	no	Error LED: on Power LED: on	Alert 16
0x00040000	A Type 1 low power PSE is detected and there is insufficient power for tracking. A Type 2 PSE compliant with the 802.3at standard that outputs up to 30W must be used.	INIT returns ERROR15 See page 176.	no	Error LED: on Power LED: on	N/A
0x00080000	System Control Unit is configured but not present. This may mean that the System Control Unit is not functioning, has not powered up yet, or has been disconnected. It can also mean that the system is misconfigured. Active tools will not be available for tracking.		no	Error LED: on Power LED: on	Alert 10

Table 4-2 Position Sensor Alerts (Continued)

Hexadecimal Value	Alert	System Response	Log to File	Position Sensor LED Indication	BX2 Code
0x00100000	System battery fault The system battery power is too low. This may be caused by a depleted or disconnected battery. This battery powers the bump sensor and the system clock.	Sets diagnostic pending bit (bit 8) in TX or BX system status.  Need reply option 0800 in TX or BX to return data.	yes	Error LED: on Power LED: on	Alert 1
0x00200000	Bump detected The bump sensor has detected a bump.	Sets diagnostic pending bit (bit 8) in TX or BX system status.  Need reply option 0800 in TX or BX to return data.	yes	Error LED: on Power LED: on	Alert 2
0x00400000	Video camera not functioning. The video camera unit signals a fault or fails to respond to the Position Sensor. If this alert is raised you must restart the system.		yes	Error LED: on Power LED: on	Alert 15
0x00800000	Incompatible firmware.  The combination of firmware on the Position Sensor is not compatible. This may be caused by a failed attempt to update the firmware.	INIT returns ERROR2E See page 176.	yes	Error LED: flashing Power LED: on	Alert 3
0x01000000	Recoverable parameter fault.  The user parameter file has been corrupted (CRC check failed) or is missing. To correct this problem, check that the settings of the user parameters are set correctly, and save them (use SAVE (page 130)).	INIT returns ERROR15 See page 176.	yes	Error LED: on Power LED: on	Alert 4
0x02000000	Not in use.				
0x08000000	PTP clock is not synced. Position Sensor's PTP clock is not synced with other devices on the same network.		no	Error LED: on Power LED: on	Alert 14
0x20000000	Temperature characterized high. The Position Sensor temperature is above the optimal operating range (see the user guide for details).	Sets temperature bit (bit 9) in TX or BX system status.  Need reply option 0800 in TX or BX to return data.	no	Error LED: on Power LED: on	Alert 8

Table 4-2 Position Sensor Alerts (Continued)

Hexadecimal Value	Alert	System Response	Log to File	Position Sensor LED Indication	BX2 Code
0x40000000	Temperature characterized low. The Position Sensor temperature is below the optimal operating range (see the user guide for details).	Sets temperature bit (bit 9) in TX or BX system status.  Need reply option 0800 in TX or BX to return data.	no	Power LED: flashes during warm-up when system is first pow- ered on. Error LED: on	Alert 9
0x80000000	Reserved				

### **System Control Unit Alerts**

Table 4-3 describes the System Control Unit alerts that are returned by the Info.Status.Alerts and Info.Status.New Alerts user parameters. The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Note The Polaris Vega System Control Unit only incorporates one (Status) LED located on the rear of the System **Control Unit.** 

**Table 4-3 System Control Unit Alerts** 

Hexadecimal Value	Alert	System Response	Log to File	System Control Unit LED Indication
0x00000001	Non-recoverable parameter fault.  The system parameter file or some other critical file is missing or has been corrupted (CRC check failed).	INIT returns ERROR15 See page 176.	yes	Rear LED: amber
0x00000002 to 0x00000008	Reserved			
0x00000010	Internal strober communication fault. The System Control Unit can detect the internal strober, but cannot communicate with it.	Sets diagnostic pending bit (bit 8) in TX or BX system status.	yes	Rear LED: amber
0x00000020 to 0x00000040	Reserved			
0x00000080	Not in use.			
0x00000100	Strober fault raised.  The System Control Unit has detected a fault raised by the strober. There could be a voltage monitor fault or an active marker current monitor fault.	INIT returns ERROR15 See page 176.	yes	Rear LED: amber
0x00000200 to 0x00400000	Reserved			
0x00010000	Firmware is running in Safe Mode.  The system has not been able to boot properly two or more times in a row.	INIT returns ERROR15 See page 176.	no	Rear LED: amber flash
0x00800000	Incompatible firmware.  The combination of firmware on the System Control Unit is not compatible.  This may be caused by a failed attempt to update the firmware.	INIT returns ERROR2E See page 176.	yes	Rear LED: amber flash

Table 4-3 System Control Unit Alerts (Continued)

Hexadecimal Value	Alert	System Response	Log to File	System Control Unit LED Indication
0x01000000	Recoverable parameter fault The user parameter file has been corrupted (CRC check failed) or is missing. To correct this problem, check that the settings of the user parameters are set correctly, and save them (use SAVE (page 130)).	INIT returns ERROR15 See page 176.	yes	Rear LED: amber flash
0x02000000	Not in use.			
0x04000000	Reserved			
0x08000000	PTP clock not synced. The System Control Unit's PTP clock is not synced with other devices on the same network.		no	Rear LED: amber flash
0x10000000	System Control Unit fan not functioning as expected.		no	Rear LED: amber flash
0x20000000	System Control Unit battery voltage low.  This may be caused by a depleted or disconnected battery.		yes	Rear LED: amber flash
0x40000000	Strober alert raised. A strober parameter is missing.		yes	Rear LED: amber flash
0x80000000	Not in use.			

### **Video Camera Alerts**

Table 4-4 describes the Video Camera Unit alerts that are returned by the Info.Status.Alerts and Info.Status.New.Alerts user parameters. When connected directly to the Video Camera Unit (port 8766), no prefix is required. If connected through the Position Sensor (port 8765), use the prefix "VCU-0.". The returned value is an integer, which you must convert to an 8-character hexadecimal number. The hexadecimal number is made up of the following individual alert values OR'd together:

Table 4-4 Video Camera Alerts

Hexadecimal Value	Alert	System Response	Log to File	PSU LED Indication
0x00000001 0x00000002	Internal video camera error	If this condition persists for more than 10 seconds, the system will reboot the video camera.	no	None

## 4.5 Complete List of User Parameters

The following tables list the user parameters for the Polaris Vega System. To view a complete list of user parameters for your system, use the command GET \* (for parameter names and values) or GETINFO \* (for parameter names, values, and usage details).

### **User-Defined User Parameters**

There are five user parameters, **Param.User.String0** to **Param.User.String4**, that can be used to store user-defined information. For example, these parameters could be used to keep track of the system maintenance or cleaning schedule. These parameters can be used for any purpose; the system does not make use of them.

## **Image Capture User Parameters**

The following user parameters are used in conjunction with the VSNAP or VGET commands. These parameters apply to the Position Sensor only.

Table 4-5 Image Capture User Parameters used with VSNAP or VGET

User Parameter Name	Description	Access Rules
Cmd.VSnap.Illuminated F	rame	Read, write
Forces the collection of	a frame with illuminators on.	
Can only be set in Setup	mode.	
Cmd.VSnap.Background	Frame	Read, write
Forces the collection of	a background frame with illuminators off.	
Can only be set in Setup	mode.	
Cmd.VSnap.Manual Shut	ter	Read, write
Exposure time for illumi	nated and background frames [usec]	
Cmd.VSnap.Frame Types		Read
Enumeration of tool class	ses reported in a frame sequence	
Cmd.VGet.Threshold.Shu	tter Time	Read, write
Exposure time for thresh	old calculations [usec]	
Cmd.VGet.Threshold.Trig	ger	Read
Spot detection trigger th	reshold [% full scale]	
Cmd.VGet.Threshold.Bac	kground	Read
Background suppression	threshold [% full scale]	
Cmd.VGet.Sensor.Color D	epth	Read
Number of bits per pixel	on the video sensor	
Cmd.VGet.Sensor.Width		Read
Number of horizontal pi	xels on the video sensor	
Cmd.VGet.Sensor.Height		Read
Number of vertical pixel	s on the video sensor	
Cmd.VGet.Start X		Read, write
Image capture start colu	nn	

Cmd.VGet.End X	Read, write
Image capture end column	
Cmd.VGet.Color Depth	Read, write
Image capture returned bits per pixel	
Cmd.VGet.Stride	Read, write
Image capture horizontal pixel step	
Cmd.VGet.Sample Option	Read, write
Image capture sample option for the stride; see VGET for details.	
Cmd.VGet.Compression	Read, write
Image capture returned data compression	

## **Settings User Parameters**

The following user parameters store settings for the hardware devices indicated in the Hardware Device column.

Table 4-6 System Settings User Parameters

User Parameter	Access Rules	Hardware Device
Param.Laser.Laser Status  Starts/stops firing the positioning laser. Use this parameter when the Positioning Laser keyed feature is enabled. See "Positioning Laser" on page 182 for details. The laser will turn off automatically after 35 s.	Read, write	Position Sensor
Param.User.String0 User-defined string (up to 63 chars).	Read, write, save	Position Sensor, System Control Unit
Param.User.String1 User-defined string (up to 63 chars).	Read, write, save	Position Sensor, System Control Unit
Param.User.String2 User-defined string (up to 63 chars).	Read, write, save	Position Sensor, System Control Unit
Param.User.String3 User-defined string (up to 63 chars).	Read, write, save	Position Sensor, System Control Unit
Param.User.String4 User-defined string (up to 63 chars).	Read, write, save	Position Sensor, System Control Unit
Param.Tracking.Available Volumes  Available characterized measurement volumes.	Read	Position Sensor
Param.Tracking.Selected Volume Selects a characterized measurement volume. Can only be set in Setup mode.	Read, write, save	Position Sensor

Table 4-6 System Settings User Parameters (Continued)

Read, write, save	Position Senso
Read, write, save	Position Senso
Read	Position Senso
Vega XT: Read,	
write, save	
Read, write, save	Position Senso
, ,	
Read	Position Senso
Read, write	Position Senso
,	
Read write	Position Senso
read, write	1 osttion bense
D1 '	D:4. C
Kead, Write	Position Senso
Read, write, save	Position Senso
Read, write	Position Senso
	Vega XT: Read, write, save  Read, write, save  Read  Read, write  Read, write  Read, write  Read, write

**Table 4-6 System Settings User Parameters (Continued)** 

Param.Exposure.Shutter Time.Other	Read, write, save	Position Sensor
Exposure time for illuminated and background frames [us].		
Param.Simulated Alerts Simulates the 'Info.Status.Alerts' parameter, for testing purposes.	Read, write, save	System Control
		Unit
Param.System Beeper Enables/disables the beeper sequence on system reset.	Read, write, save	Position Sensor, System Control Unit
Param.Serial Break Option	Read, write, save	Position Sensor
Desired action upon a serial break. Only used for serial communications.		
Param.Video Camera.PSU Control	Read, write, save	Position Sensor
Determines whether the video camera should be logically tied to the Position Sensor or treated as a separate device. When enabled, the video camera is registered in the Position Sensor's device table. The following commands sent to the Position Sensor are relayed to the VCU: INIT, DFLT *, SAVE, GET *, GETINFO *, VCAP. Also, VCU parameters may be accessed via the Position Sensor by using a "VCU-0." prefix.		
When disabled, the video camera is not registered in the Position Sensor's device table. The above-listed commands are no longer relayed to the video camera, and video camera parameters cannot be accessed via the Position Sensor.		
Note that regardless of this setting, if a RESET 0/1 is issued to the Position Sensor, it is always relayed to the video camera.		
Param.Video Camera.Direct Connection  Determines whether port 8766 should be opened for direct API communication to the video camera.	Read, write, save	Position Sensor

## **Information User Parameters**

The following user parameters store status information for the hardware devices indicated in the Hardware Device column, and command time out values.

**Table 4-7 Information User Parameters** 

User Parameter	Access Rules	Hardware Device
Info.Timeout. <command/> Time out for the specified command (sec). For the SCU, only the following commands have timeout values: APIREV, COMM, DFLT, ECHO, GET, GETINFO, GETLOG, INIT, SYSLOG, RESET, SAVE, SET, VER.	Read	Position Sensor, System Control Unit
Info.Status.System Mode System operating mode.	Read	Position Sensor

Table 4-7 Information User Parameters (Continued)

Info.Status.Alerts	Read	Position Sensor,
System hardware and operating status flags; see "Alerts User Parameters" on page 22 for details.		System Control Unit, Video Camera Unit
Info.Status.New Alerts  System hardware and operating status flags; see "Alerts User Parameters" on page 22 for details.	Read	Position Sensor, System Control Unit, Video Camera Unit
Info.Status.Bump Detected	Read	Position Sensor
Indicates if the system has detected a bump.		
Info.Status.PTP.Clock State PTP Clock Master/Slave state.	Read	Position Sensor, System Control Unit
Info.Status.PTP.Sync State PTP Clock sync state.	Read	Position Sensor, System Control Unit
Info.Status.PTP.Master Offset PTP Clock master offset in μs.	Read	Position Sensor, System Control Unit
Info.Status.New Log Entry Indicates a new system log entry has been made; set to 'False' (0) to clear.	Read, write	Position Sensor, System Control Unit
Info.Status.Gravity Vector Gravity directional vector reported in Position Sensor coordinate space.	Read	Position Sensor
Info.Status.Tracking.Measured Frame Frequency  The actual frame rate at which the system takes images of the measurement volume, in Hz.	Read	Position Sensor
Info.Status.Tracking.Measured Track Frequency  The actual tracking rate at which the system reports transformations for all the tools being tracked, in Hz.	Read	Position Sensor
Info.Status.Bits Per Second  The data rate of the video camera in bits per second, when streaming video.	Read	Video Camera Unit
Info.Status.Frames Per Second  The current frame rate of the video camera in frames per second when streaming video.	Read	Video Camera Unit
Info.Partitions.Update In Progress Indicates that a firmware upgrade is in progress.	Read	Position Sensor, System Control Unit, Video Camera Unit
Info.Video Connections.Address.0  The IP address of the client that is receiving the video image stream. Only valid when streaming.	Read	Video Camera Unit

## **Features User Parameters**

The following user parameters store information about the features for the hardware devices indicated in the Hardware Device column.

**Table 4-8 Features User Parameters** 

User Parameter	Access Rules	Hardware Device
Features.Keys.Installed Keys 'Value' is the name of the installed feature.	Read	Position Sensor, Video Control Unit, System Control Unit
Features.Keys.Active Keys  List of active feature keys; See page 180 for details.	Read	Position Sensor, Video Control Unit, System Control Unit
Features.Keys.Disabled Keys  List of disabled keys; change takes effect on next reset. See page 180 for details.	Read, write, save	Position Sensor, Video Control Unit, System Control Unit
Features.Tools.Enabled Tools	Read	Position Sensor
Maximum number of tools that can be enabled simultaneously.		
<b>Features.Tools.Active Ports</b> Maximum number of wired active tools that can be enabled simultaneously.	Read	Position Sensor
Features.Tools.Passive Ports  Maximum number of passive tools that can be enabled simultaneously.	Read	Position Sensor
Features.Tools.Wireless Ports	Read	Position Sensor
Maximum number wireless active tools that can be enabled simultaneously.		
Features.Firmware.Bootloader Version Current bootloader revision number.	Read	Position Sensor, Video Control Unit, System Control Unit
Features.Volumes.*	Read	Position Sensor
Volume information from camera parameter files.		
Features.Firmware.API Revision Current API revision information.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Firmware.Version  Current firmware revision number.	Read	Position Sensor, System Control Unit, Video Camera Unit

Table 4-8 Features User Parameters (Continued)

Features.Firmware.Major Version	Read	Position Sensor,
Current firmware major revision number.		System Control Unit, Video Camera Unit
Features.Firmware.Minor Version  Current firmware minor revision number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Firmware.Build Number  Current firmware build revision number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Firmware.Available Versions List of firmware revisions loaded in the device.	Read	Position Sensor, System Control Unit
Features.Firmware.Maximum Versions  Number of firmware revisions that may be stored in the device simultaneously.	Read	Position Sensor, System Control Unit
Features.Firmware.Configuration Check System configuration checksum (for NDI use only).	Read	Position Sensor, System Control Unit
Features.Firmware.Package Number Current firmware package number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.Serial Number Hardware device serial number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.Part Number Product part number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.OEM Number Hardware device customer number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.Model  Hardware device model name.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Firmware.Safeloader Version  Current safeloader firmware revision number.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Firmware.Available Combined Firmware Revisions List of combined firmware revisions loaded in the device.	Read	Position Sensor, System Control Unit

Table 4-8 Features User Parameters (Continued)

Features.Firmware.Combined Firmware Revision Current combined firmware revision of the device.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.Manufacture Date Date of manufacture.	Read	Position Sensor, System Control Unit, Video Camera Unit
Features.Hardware.Characterization Date Date of characterization.	Read	Video Camera Unit

## **System Configuration User Parameters**

The following user parameters store information about the configuration of the system. These user parameters describe the configuration of the entire system, not a particular device.

**Table 4-9 System Configuration User Parameters** 

User Parameter	Access Rules
Config.Multi Firmware.Load Combined Firmware Revision	Read, write
Combined firmware revision to load on next reset (selection automatically saves when set). Use this parameter when the Multi Firmware keyed feature is enabled. See "Multi Firmware Feature" on page 181 for details.	
Config.Multi Firmware.Update Combined Firmware Revision	Read, write, save
Combined firmware revision to replace on next upgrade or downgrade. Use this parameter when the Multi Firmware keyed feature is enabled. See "Multi Firmware Feature" on page 181 for details.	
Config.Multi Firmware.Available Combined Firmware Revisions	Read
List of combined firmware revisions loaded in the system.	
Config.Combined Firmware Revision	Read
Current combined firmware revision of the system.	

#### **Hardware Device Information User Parameters**

The following user parameters store information about the hardware devices in the system. See "Device Names" on page 20 for information on how to use the hardware device user parameters.

Table 4-10 Hardware Device User Parameters

User Parameter	Access Rules
Device.Type	Read
Type of device in the system configuration.	
<b>Device.Instance</b>	Read
Instance of this type of device in the system configuration.	

Table 4-10 Hardware Device User Parameters (Continued)

Device.Address	Read
The network address of the device (or "local" if that is the device you are talking to).	
Device.Port	Read
The network port to connect to the device.	

## **Network User Parameters**

The following user parameters store information about the system network settings.

**Table 4-11 Network User Parameters** 

User Parameter	Access Rules	Hardware Device	
Param.Network.IP Method	Read, write, save	Position Sensor	
Method of receiving IP address.			
Param.Network.Static.IP Address	Read, write, save	Position Sensor	
Requested ethernet interface IPv4 address.			
Param.Network.Static.Subnet Mask	Read, write, save	Position Sensor	
Requested ethernet interface IPv4 subnet mask.			
Param.Network.Static.Gateway	Read, write, save	Position Sensor	
Requested interface IPv4 gateway.			
Param.Network.DNS Servers	Read, write, save	Position Sensor	
DNS Server list. Space separated.			
Param.Network.Host Name	Read, write, save	Position Sensor	
Ethernet interface hostname, blank for default.			
Param.Network.MAC Address	Read, write, save	Position Sensor	
Ethernet interface MAC address.			
Param.Network.Service Name	Read, write, save	Position Sensor	
Service name advertised in DNS-SD. m=model h=host name, n=serial number, t=tracking group.			
Param.Network.Tracking Group	Read, write, save	Position Sensor,	
Tracking group name. Enables discovery of group members.		System Control Unit, Video Camera Unit	
Param.Connect.Master Hosts	Read, write, save	Position Sensor,	
List of hosts allowed to become configuration masters, blank=unrestricted.		System Control Unit, Video Camera Unit	
Param.Connect.Monitor Hosts	Read, write, save		
List of hosts allowed to connect, blank=unrestricted, none=no monitor hosts.		System Control Unit, Video Camera Unit	
Param.Connect.Host Port	Read, write, save	Position Sensor	
TCP port to listen for host connections.			

Param.Connect.Master Timeout	Read, write, save	Position Sensor,	
Seconds of inactivity before another connection is allowed to become master (0=never).		System Control Unit, Video Camera Unit	
Param.Connect.Idle Timeout	Read, write,	Position Sensor,	
Seconds of inactivity before a connection is automatically closed ( $0 = \text{never}$ ).	save	System Control Unit, Video Camera Unit	
Info.Connections. Address	Read	Position Sensor,	
Remote IP address.		System Control Unit, Video Camera Unit	
Info.Connections.Port	Read	Position Sensor,	
Remote IP port.		System Control Unit, Video Camera Unit	
Info.Connections.Rx Bytes	Read	Position Sensor,	
Received byte count.		System Control Unit, Video Camera Unit	
Info.Connections.Tx Bytes	Read	Position Sensor,	
Transmitted byte count.		System Control Unit, Video Camera Unit	
Info.Connections.Requests	Read	Position Sensor,	
Number of API requests.		System Control Unit, Video Camera Unit	
Info.Connections.Replies	Read	Position Sensor,	
Number of API replies.		System Control Unit, Video Camera Unit	
Info.Connections.Streams	Read	Position Sensor,	
Number of active streams.		System Control Unit, Video Camera Unit	
Info.Connect.isMaster	Read	Position Sensor,	
True if this connection is master.		System Control Unit, Video Camera Unit	
Info.Connect.isAuth	Read	Position Sensor,	
True if this connection is authenticated.		System Control Unit, Video Camera Unit	
Info.Connect.Index	Read	Position Sensor,	
Index of this connection in connection table.		System Control Unit, Video Camera Unit	

Param.Connect.SCU Port TCP port for SCU connections.	Read, write, save	Position Sensor
Param.Connect.SCU Hostname	Read, write, save	Position Sensor
Host name or address for SCU connection.		

#### **Clock User Parameters**

The following user parameters store information about the system clock.

**Table 4-12 Clock User Parameters** 

User Parameter Name Description	Access Rules
Param.Clock.Date Time	Read, write, save
Numerical value for the day, month, year, day, In ISO 8601 format (UTC)	

#### **Volume User Parameters**

The following user parameters describe the volume shapes and supported wavelengths for the measurement volumes.

Table 4-13 Volume User Parameters

User Parameter	Access Rules
Features.Volumes.Index	Read
Indicates the volume that is being referred to.	
Features.Volumes.Name	Read
The volume name.	
Features.Volumes.Shape	Read
The shape type.	
Features.Volumes.Wavelengths	Read
Which wavelengths are supported in the volume.	
Features.Volumes.Paramn	Read
Shape parameters as described in SFLIST.	

#### **Video Camera Parameters**

The following user parameters store information about the optional Vega Video Camera Unit. For details on the video camera, see the user guide that accompanied your system.

Table 4-14 Video Camera User Parameters

Note The prefix "VCU-0." is required before the following parameters when issuing commands for VCU parameters through the Position Sensor (i.e. when Param.Video Camera.PSU Control = Enabled). The prefix "VCU-0." is not

required when connected directly to the VCU on port 8766 (i.e. when Param.Video Camera.Direct Connection = Enabled).

User Parameter	Access Rules
Param.Allow Streaming	Read, write, save
Enables or disables video output when a direct connection to the video camera is enabled. Video output is disabled by default.	
Param.[Binning X   Binning Y]	Read
The binning factor in the X and Y direction used to produce the image. The 1024x768 resolution uses binning.	
Param.[Left   Top]	Read
Different resolutions use different areas of the image sensor to produce a video. These parameters report the left and top offset of the sensor area.	
Param.Frame Rate	Read, write, save
The sensor's output frame rate in frames per second.	
Param.Disconnect Clients	Write
Set to "1" to force the current streaming client to disconnect.	
Param.Resolution	Read, write, save
1024x768	
1920x1088	
2048x1536	
Changing the resolution will only take effect when not streaming.	
Param.Effects.Brightness	Read, write, save
The brightness parameter is an integer added to all of the pixels equally (i.e. not based on color).	
Param.Effects.Contrast	Read, write, save
The contrast parameter is a floating point gain multiplier and is applied to all colors.	
Param.Effects.Gamma Correction	Read, write, save
Gamma correction applies a non-linear gain to increase the gain in dark areas of an image while keeping the light areas relatively untouched. Additionally, the user can select a user defined mode and specify their own gamma correction value. Values:	
Off – no Gamma correction	
Built-in – use built-in hardware gamma correction	
User Defined – uses the Gamma Value to create a correction table	
User-Defined Enhanced – uses the Gamma Value to create a correction table	
Refer to "Gamma Correction" on page 195 for details on the Gamma Correction and Gamma Value parameters.	
Param.Effects.Gamma Value	Read, write, save
The value used to generate the User-Defined (i.e. output = input(1/gamma)) or User-Defined Enhanced (i.e. output = input(1/gamma) * $(1 - (3/(input+3))+input*0.01)$ gamma curve.	
Param.Effects.Color Saturation	Read, write, save
A multiplier to control the color saturation. A value of 0 will create a black and white image, while a value greater than 1 will increase the intensity of the colors.	

Param.Effects.Edge Enhancement Enable/Disable the edge enhancement. 0= disabled, 1=enabled.	Read, write, save
Param.Effects.Edge Enhancement Sharpness	Read, write, save
Controls the sharpness of the edge enhancement algorithm. Edge Enhancement is applied to the Luminance (Y) or black and white component of the image. Edges in the image are detected and the luminance is adjusted to make the edges appear sharper.	Reau, write, save
Param.Effects.Noise Filter	Read, write, save
Enable/Disable the noise filter. 0= disabled, 1=enabled.	
Param.Effects.Noise Filter Smoothness	Read, write, save
Controls the amount of smoothing provided by the noise filter.	
Param.White Balance.Auto	Read, write, save
Enable/Disable auto white balance.	
0=Disable – use fixed color gains	
1=Enable – automatically adjust color gains	
Param.White Balance.[Auto Blue Green Factor   Auto Red Green Factor]	Read, write, save
Multiplier to skew the image more or less blue/red when auto white balance is enabled. Values > 1 will make the image more blue/red, values <1 make it less blue/red.	
Param.White Balance. [Red Gain Green Gain Blue Gain]	Read, write, save
The gains applied to the red, green, and blue channels. The parameters are read-only while auto white balance is enabled.	
Param.White Balance. [Red Offset Green Offset Blue Offset]	Read, write, save
The offsets applied to the red, green, and blue channels. The parameters are read-only while auto white balance is enabled.	
Param.Exposure And Gain.Exposure Time	Read, write, save
Exposure time in microseconds.	
The parameter is read-only while auto exposure/gain is enabled.	
Param.Exposure And Gain.System Gain	Read, write, save
Each gain component can range from 0 to 128 in steps of 0.125 if gain is between 1 and 4, 0.250 if gain is between 4.25 and 8, and 1.000 if gain is between 8 and 128	
The parameter is read-only while auto exposure/gain is enabled.	
Param.Exposure And Gain.Auto	Read, write, save
Enable/disables the auto exposure/gain mode.	
Param.Exposure And Gain.Auto Brightness Target	Read, write, save
The desired level of brightness of the image. Expressed as a percentage of the maximum pixel value.	,,
Param.Exposure And Gain. Auto Maximum Exposure	Read, write, save
The maximum exposure at which point the system starts increasing gain. Lower values limit motion-blur at the cost of increased noise.	, ,
Param.Exposure And Gain.Meter.Mode  Choose either Weighted ROI, Segmented, Spotlight, or Center Weighted. Refer to  "Exposure and Gain Control - Meter Modes" on page 196 for detailed information about each mode.	Read, write, save
Param.Exposure And Gain.Meter.ROI Weighting	Read, write, save
The percentage weighting applied to Region 0 when using Weighted ROI metering method. The remaining percentage is applied to Region 1.	roud, witte, save

Param.Exposure And Gain.Meter.ROI [Center X Center Y Width Height]	Read, write, save
Defines the rectangle of interest (Region 0) when using Weighted ROI metering method. The Width and Height are used to define the size of Region 3 when using Segmented metering method. These values are ignored in Spotlight or Center Weighted metering modes. All values are expressed as a percentage of the resolution size.	
Param.Exposure And Gain.Meter.ROI Pixels [Left Top Width Height]	Read, write, save
Returns the pixel locations of the actual rectangle of interest when using the Weighted ROI and Segmented metering methods.	
Param.Lens.Distortion.[k1 k2 k3 p1 p2]	Read, write, save
Lens distortion parameters for Zhang's method (in OpenCV).	
Param.Lens.Pinhole.[U0,V0,fx,fy]	Read, write, save
Lens pinhole parameters for the currently selected resolution. These parameters are used to relate the 3D scene into 2D sensor space.	
U0[x pixels], V0[y pixels], fx[mm], fy[mm]	
Param.Lens.6D.[q0 qx qy qz tx y z]	Read, write, save
Describes the location (in mm) and orientation (quaternion) of the video camera in measurement coordinate space.	

## **Bump Sensor User Parameters**

The following user parameters store information about the bumper sensor status. For details on the bump sensor, see the user guide that accompanied your system.

Table 4-15 Bump Sensor User Parameters

User Parameter	
Param.Bump Detector.Clear	Write
Set this user parameter to clear all bumps detected up to that point. This clears the	
"bump detected" bit in the Info.Status.Alerts user parameter, and sets the	
Info.Status.Bump Detected user parameter and the	
Param.Bump Detector.Bumped user parameter to "0".	
Values: "1" clears all detected bumps. The system will automatically reset this user parameter to "0".	
Param.Bump Detector.Bumped	Read
This user parameter indicates when the system has detected a bump.	
The system sets this user parameter to "1" upon detecting a bump. The system resets	
this user parameter to "0" once you have set the <b>Param.Bump Detector.Clear</b> user parameter to "1."	
Param.Bump Detector.Bump Detection	Read, write,
This user parameter enables the bump detector.	
Values: "1" bump detector enabled (default), "0" bump detector disabled.	

## 5 Command Details

Before sending any commands to the system, read the user guide that accompanied your system to ensure that you have a full understanding of the system functionality.

#### 3D

Returns the latest three-dimensional marker position of a single marker or multiple markers.

### Compatibility

Supported by the Position Sensor since G.001.

Deprecated.

#### **Operating Mode**

Diagnostic, Tracking

## **Prerequisite Command**

IRED (page 93), only for active markers in Diagnostic mode

### **Syntax**

3D<SPACE><Port Handle><Reply Option><CR>

Parameter	Desci	ription		
Port Handle	2 hexa	2 hexadecimal characters.		
		fies for which type of marker the system will report data (see "Usage Notes" on 49 for details). The specified port handle must be initialized (PINIT) and enabled A).		
Reply Option	Speci	pecifies which information will be returned.		
	The reply options cannot be OR'd.			
	Valid Values:			
	1	Single marker 3D data, with error value		
	2	Single marker 3D data, with error value and out-of-volume information		
	3	Single marker 3D data, with line separation value		
	4	Single marker 3D data, with line separation value and out-of-volume information		
	5	3D data for up to 50 markers, with line separation and out-of-volume information		

### **Replies**

#### **Upon Success:**

<Number of Visible Markers><LF>
<Reply Option n Data><CRC16><CR>>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
Number of	3 characters
Visible Markers	(a sign and 2 decimal digits)
	The number of markers detected by the system.
	For reply options 1 to 4, only one marker can be in view. If more than one marker is in view, the system will return 00 for the number of markers.
Reply Option n Data	The data specific to the requested reply option. See the reply option information below for details:
	Reply option 1 (3D data for a single marker, with error value)
	Reply option 2 (3D data for a single marker, with error value and out-of-volume information)
	Reply option 3 (3D data for a single marker, with line separation value)
	Reply option 4 (3D data for a single marker, with line separation value and out-of-volume information)
	Reply option 5 (3D data for up to 50 markers, with line separation and out-of-volume information)

## Reply Option 1 - 3D data for a single marker, with error value

<Reply Option 1 Data> = <Tx><Ty><Tz><Error Value>

Reply Component	Description			
Tx, Ty, Tz	9 characters each			
	(a sign, and 8 decimal digits with an implied decimal in the position XXXX . XXXX)			
	Position of the marker, in the coordinate system of the Position Sensor.			
Error Value	4 characters			
	(a sign, and 3 decimal digits with an implied decimal in the position X . XX)			
	The normalized error number associated with the calculation for this marker position.			
	Possible Values:			
	+000 (best case) to +100 (worst case)			

#### Reply Option 2 - 3D data for a single marker, with error value and out-of-volume information

<Reply Option 2 Data> = <Tx><Ty><Tz><Error Value><Out of Volume>

Reply Component	Description
Tx, Ty, Tz	9 characters each (a sign, and 8 decimal digits with an implied decimal in the position XXXX . XXXX)
	Position of the marker, in the coordinate system of the Position Sensor.

Reply Component	Description		
Error Value	4 characters		
	(a sign, and 3 decimal digits with an implied decimal in the position X . XX)		
	The normalized error number associated with the calculation for this marker position.		
	Possible Values:		
	+000 (best case) to +100 (worst case)		
Out of Volume	1 hexadecimal character		
	Indicates whether the marker is outside the characterized measurement volume.		
	Possible Values:		
	0 The marker is inside the characterized measurement volume.		
	1 The marker is out of volume.		

### Reply Option 3 - 3D data for a single marker, with line separation value

<Reply Option 3 Data> = <Tx><Ty><Tz><Line Separation>

Reply Component	Description
Tx, Ty, Tz	9 characters each (a sign, and 8 decimal digits with an implied decimal in the position XXXX . XXXX)
	Position of the marker, in the coordinate system of the Position Sensor.
Line Separation	4 characters (a sign, and 3 decimal digits with an implied decimal in the position X . XX)  The minimum distance (in mm) between the two lines of sight calculated from the marker image on the left and right sensor to the IR source.
	Possible Values: +000 (best case) to +999 (worst case)

# Reply Option 4 - 3D data for a single marker, with line separation value and out-of-volume information

<Reply Option 4 Data> =  $<T_x><T_y><T_z><Line Separation><Out of Volume>$ 

Reply Component	Description
Tx, Ty, Tz	9 characters each (a sign, and 8 decimal digits with an implied decimal in the position XXXX . XXXX)
	Position of the marker, in the coordinate system of the Position Sensor.

Reply Component	Description			
Line	4 characters			
Separation	(a sign, and 3 decimal digits with an implied decimal in the position $\boldsymbol{X}$ . $\boldsymbol{X}\boldsymbol{X}$ )			
	The minimum distance (in mm) between the two lines of sight calculated from the marker image on the left and right sensor to the IR source.			
	Possible Values:			
	+000 (best case) to +999 (worst case)			
Out of Volume	1 hexadecimal character			
	Indicates whether the marker is outside the characterized measurement volume.			
	Possible Values:			
	The marker is inside the characterized measurement volume.			
	1 The marker is out of volume.			

# Reply Option 5 - 3D data for up to 50 markers, with line separation value and out-of-volume information

```
<Reply Option 5 Data> = 
 <T_{\rm x1}><T_{\rm y1}><T_{\rm z1}>< Line Separation 1><Out of Volume 1><LF> 
 <T_{\rm x50}><T_{\rm y50}><T_{\rm z50}>< Line Separation 50><Out of Volume 50><LF>
```

Reply Component	Description			
Txn, Tyn, Tzn	9 characters each (a sign, and 8 decimal digits with an implied decimal in the position XXXX . XXXX)			
	Position of the n <sup>th</sup> marker, in the coordinate system of the Position Sensor. The system will report up to 50 3D positions, including phantom markers. If the system detects more than 50 IR sources, it will only report the first 50. The IR sources are not reported in any particular order.			
Line	4 characters			
Separation n	(a sign, and 3 decimal digits with an implied decimal in the position X . XX)			
	Line separation of the n <sup>th</sup> marker. The minimum distance (in mm) between the two lines of sight calculated from the marker image on the left and right sensor to the IR source.			
	Possible Values:			
	+000 (best case) to +999 (worst case)			
Out of Volume n	1 hexadecimal character			
	Indicates whether the n <sup>th</sup> marker is outside the characterized measurement volume.			
	Possible Values:			
	The marker is inside the characterized measurement volume.			
	1 The marker is out of volume.			

#### **Usage Notes**

- 1. The specified port handle must be enabled using PENA (page 98).
- 2. You may need to use the 3D command about ten times if it is sent immediately after using IRED (page 93). This allows time for the system to implement the activation signature and optimize the signal by adjusting the range control.
- 3. **Reply Options 1 to 4**: You cannot have more than one marker in view. Any other IR sources in view will prevent the system from returning marker data.
- 4. **Reply Option 5**: The system does not distinguish between real markers, phantom markers, or other IR sources. You must determine whether the reported marker positions are valid. See the user guide that accompanied the system for more information on phantom markers.
- 5. The 3D command returns data regardless of the bump status, temperature status, and other system status conditions. Before trusting the marker positions returned by the 3D command, you should check these conditions by reading the Info.Status.Alerts user parameter. (Use the GET (page 82) command to check the value of user parameters.) You can use the BX (page 53) or TX (page 150) command to request 3D data that is filtered when the bump status, temperature status, or other system conditions are not ideal.
- 6. **Reply Option 1** and **Reply Option 2**: The system will not calculate an error, and will return an error value of +000.

#### **Example**

#### Command:

3D 011

#### Reply:

+01-12345678+12345678-12345678+0954B7B

In this case, one marker is in view.

#### **APIREV**

Returns the API revision number that functions with your system.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

**Deprecated.** Use the parameter **Features.Firmware.API Revision** instead.

#### **Operating Mode**

All modes

#### **Syntax**

APIREV<SPACE><CR>

#### **Replies**

#### **Upon Success:**

<Family>.<Major revision number>.<Minor revision number><CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description		
Family	1 ASCII character. This character is always G. (Other types of NDI measurement systems use other characters.)		
Major revision number	3 ASCII characters The major revision number is incremented whenever there is an incompatible change in the API. (Whenever a command is deprecated or when its response is changed in a way that may break an application.)		
Minor revision number	3 ASCII characters The minor number is incremented whenever there is an addition to the API that is compatible with all existing applications and usage. (Compatible changes are additions to the API command or option set that will not affect any existing applications.)		

### **Example**

#### Command:

APIREV

#### Reply:

G.003.0016379

#### **BEEP**

Sounds the system beeper.

#### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

### **Operating Mode**

All modes

#### **Syntax**

BEEP<SPACE><Number of Beeps><CR>

Parameter	Description
Number of Beeps	Valid Values:
	1 to 9

#### **Replies**

#### **Upon Success:**

<Beep Status><CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Desc	cription
Beep Status	Possible Values:	
	0	The system is busy beeping.
	1	Beeping has started.

#### **Usage Notes**

- 1. The beep duration is shorter than the beep used for reset and fatal error conditions.
- 2. Disabling the system beeper (by setting the value of the user parameter **Param.System Beeper**) does not affect the BEEP command.
- 3. The system will never return a beep status of 0. If you send the BEEP command while the system is busy beeping, the system will return a beep status of 1, but will not initiate the second sequence of beeps.

## Example

### Command:

BEEP 1

## Reply:

1D4C1

#### BX

Returns the latest tool transformations, individual marker positions, and system status in binary format.

#### Compatibility

Supported by the Position Sensor since G.001.

BX2 is recommended for new application development.

### **Operating Mode**

Tracking

### **Syntax**

BX<SPACE><Reply Option><CR>

Parameter	Description			
Reply Option		nal. Specifies which information will be returned. If no reply is specified, the system returns information for reply option		
	ple reply in order Reply o simply o options. Reply o	option 1000 is reported after all handle-specific options but the <system status=""> and <crc16>.</crc16></system>		
	0001	Transformation data (default)		
	0002	Tool and marker information		
	0004	3D position of a single stray active marker		
	0008	3D positions of markers on tools		
	0800	Transformations not normally reported		
	1000	3D positions of stray passive markers		
	2000	Appends extended stray passive marker status		

#### **Replies**

#### **Upon Success:**

```
<Start Sequence><Reply Length><Header CRC><01(Number of Handles)>
<Handle 1><Handle 1 Status><Reply Opt 0001 Data>...<Reply Opt 0008 Data>
...
<Handle n><Handle n Status><Reply Opt 0001 Data>...<Reply Opt 0008 Data>
```

<Reply Option 1000 Data>
<System Status><CRC16>

#### Note The reply for the BX command is binary data.

Note If a handle status is "disabled," the system will not return any of <Reply Option 0001 Data>... <Reply Option 0008> for that port handle.

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description		
Start Sequence	2 bytes: A5C4		
	Indicates the start of the BX reply.		
Reply Length	2 bytes		
	Indicates the number of bytes in the reply body between the <header crc=""> and the <crc16>, exclusive.</crc16></header>		
Header CRC	2 bytes		
	CRC16 of <start sequence=""> and <reply length=""></reply></start>		
Number of Handles	1 byte		
nanares	The number of port handles for which information is returned.		
Handle n	1 byte		
	The port handle whose information follows.		
Handle Status	1 byte Possible Values:		
	01	Valid	
	02	Missing	
	04 Disabled		

Reply Component	Description								
Reply Option m Data	The data specific to the requested reply option. See the reply option information below for details:								
	Reply option 0001 (transformation data) (default)								
	Reply option	0002 (tool and marker information)							
	Reply option marker)	0004 (latest 3D position of single stray active							
	Reply option	0008 (3D position of markers on tools)							
	Reply option	0800 (reporting all transformations)							
	Reply option Reply option	1000 (3D position of stray passive markers) 2000 (							
System Status	2 bytes								
	The status of the system.								
	Bit field:								
	bit 0	System communication synchronization error							
	bits 1 and 2	Reserved							
	bit 3	Recoverable system processing exception.							
	bit 4-5	Reserved							
	bit 6	Some port handle has become occupied							
	bit 7	Some port handle has become unoccupied							
	bit 8	Diagnostic pending							
	bit 9 Temperature (system is not within operating temperature range)								
	bit 10	Hardware configuration changed (e.g. VCU or SCU has connected or disconnected)							
	bits 11 to 15	Reserved							

Note The "diagnostic pending" bit is set whenever an alert is detected or cleared. To view the alerts status and clear the diagnostic pending bit, use GET (page 82) to check the Info.Status.New Alerts user parameter for every hardware device in the system. See "Usage Notes" on page 62 for more details. (For API revision G.001.003 and earlier, the diagnostic pending bit did not indicate when an alert was cleared.)

## **Reply Option 0001 - Transformation Data**

```
<Reply Option 0001 Data> = <Q_0><Q_x><Q_y><Q_z><T_x><T_y><T_z><Error><Port Status> <Frame Number> or <Reply Option 0001 Data> = <Port Status><Frame Number>
```

Reply Component	Description
Q0, Qx, Qy, Qz	4 bytes each
	Rotational components of the transformation, quaternion, unitless, reported as IEEE 32-bit, single precision, floating point numbers. The value for Q0 is always non-negative.
Tx, Ty, Tz	4 bytes each
	Translational components of the transformation, in mm, reported as IEEE 32-bit, single precision, floating point numbers.
Error	4 bytes
	The error is an RMS value, given in mm. It is the result of the least squares minimization between the marker geometry in the tool definition file and the data from the tool's markers measured by the system. Reported as IEEE 32-bit, single precision, floating point number.

Reply Component	Description							
Port Status	4 bytes							
	Bit field:							
	bit 0	Occupied						
	bit 1	Switch 1 closed						
	bit 2	Switch 2 closed						
	bit 3	Switch 3 closed						
	bits 4	Initialized						
	bit 5	Enabled						
	bit 6	Out of volume						
	bit 7	Partially out of volume						
	bit 8	Algorithm limitation (processing requires more buffer than is available)						
	bit 9	IR interference (a large bright IR object)						
	bits 10 and 11	Reserved						
	bit 12	Processing exception (same as tool information bit 7 in reply option 0002)						
	bit 13	Reserved						
	bit 14	Fell behind while processing (same as tool information bit 3 in reply option 0002)						
	bit 15	Data buffer limitation (too much data; for example, too many markers)						
	bits 16 to 31 Reserved							
Frame Number	4 byte unsigned number							
	The frame number is an internal counter related to data acquisition, which is derived from the PTP time. The frame number corresponds to the frame in which the raw data, used to calculate the accompanying transformation, was collected.							

Note If the handle status is "missing," the system returns only the port status and the frame number.

- Tools are reported as missing if a transformation cannot be determined.
- In the event of a system error that prevents tracking, all tools are reported as missing.

## Reply Option 0002 - Tool and Marker Information

<Reply Option 0002 Data> = <Tool Information><Marker Information>

Reply Component	Description	on					
Tool Information	1 byte						
	Bit field:						
	bit 0	Bad transformation fit					
	bit 1	Not enough acceptable markers for transformation					
	bit 2	IR interference—environmental IR is interfering with the system (combination of port status bits 9 and 15 in reply option 0001)					
	bit 3	Fell behind while processing (same as port status bit 14 in reply option 0001)					
	bits 4 to 6	Tool face used					
	bit 7	Processing exception (same as port status bit 12 in reply option 0001)					
Marker	10 bytes (4	bits per marker)					
Information	See below	for an example.					
	Possible V	'alues:					
	0000	Not used because it was missing					
	0001	Not used because it exceeded the maximum marker angle					
	0010	Not used because it exceeded the maximum 3D error for the tool					
	0011	Used to calculate the transformation					
	0100	Used to calculate the transformation, but it is out of volume					
	0101	Not used because it was outside the characterized measurement and was not needed to calculate a transformation.					

**Example - Marker Information:** A tool with markers located at T, R, C, and A, where all four markers were used to determine the calculation, would have the following reply:

Marker	T	S	R	Q	•••	D	С	В	Α
Reply	0011	0000	0011	0000	•••	0000	0011	0000	0011

#### Reply Option 0004 - 3D Position of Single Stray Active Marker

```
<Reply Option 0004 Data> = \langle Status \rangle \langle T_x \rangle \langle T_y \rangle \langle T_z \rangle
or
<Reply Option 0004 Data> = <Status>
```

Reply Component	Descripti	Description						
Status	1 byte							
	active too	The status of the stray active marker. A stray marker on an active tool is not fixed with respect to the other markers that make up the tool.						
	Bit field:							
	bit 0	Valid stray active marker						
	bit 1 Marker is missing							
	bit 2	Reserved						
	bit 3	Marker is out of volume						
	bits 4 to	Reserved						
Tx, Ty, Tz	4 bytes ea	nch						
	Position of the marker in the coordinate system of the Position Sensor, reported as IEEE 32-bit, single precision, floating point numbers. The marker position is reported only if the marker status is "valid," or "out of volume" and reply option 0800 is used.							

Note If no stray active marker is defined (for example, for wireless port handles, or wired tools with no stray marker defined in the tool definition file), the status is 00, and no position information is returned. If the marker is missing, or if the marker is out of volume and reply option 0800 is not used, the system returns only the status.

#### Reply Option 0008 - 3D Position of Markers On Tools

<Reply Option 0008 Data> = <Number of Markers><Out of Volume>< $T_{xn}$ >< $T_{yn}$ >< $T_{zn}$ >

Reply Component	Description
Number of Markers	1 byte
	Number of markers used in tool transformations.
Out of Volume	1 byte/8 markers (1 bit per marker)
	The bit is set when the marker is outside the characterized measurement volume (see example below).
	Reply size = (number of markers)/8, rounded up to the nearest integer.
Txn, Tyn, and Tzn	4 bytes each
	Position of the n <sup>th</sup> marker, reported in the coordinate system of the Position Sensor, reported as IEEE 32-bit, single precision, floating point numbers. The system will report the positions of markers used in tool transformations, as well as markers that exceeded the maximum marker angle or maximum 3D error specified in the tool definition file.
	See "Usage Notes" on page 62 for more information.

**Example - Out of Volume** The information is returned in the format illustrated in the following example: one bit per marker, in little endian format. In this example there are nine markers, all of which are out of volume:

Marker Number								9	8	7	6	5	4	3	2	1
Bit Field	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	1
Reply	0				1				F				F			
Reply Byte		n									n ·	+ 1				

#### Reply Option 0800 - Reporting All Transformations

This option enables the reporting of transformations or translations in situations where translations or transformations are calculated, but by default are not reported by the system. Such situations include:

- The tool or marker is outside of the characterized measurement volume.
- The bump sensor has been tripped.
- The system is outside of the optimal operating temperature range.
- Other system conditions are not ideal; see "Alerts User Parameters" on page 22 for a full list of these conditions.

This reply option must be OR'd with reply option 0001 to obtain transformations for tools in the situations listed above. It must be OR'd with reply options 0004, 0008, or 1000 to obtain position information for markers in the situations listed above.



When using reply option 0800 with the BX command, you must take appropriate action to detect the events listed above, and determine whether they are detrimental to your application. If one or more of the events listed above occurs, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.

Appropriate action to detect the events listed above includes:

- reading the out-of-volume flag in reply options 0001 and 0002 when tracking tools
- reading the out-of-volume information in reply options 0004, 0008, and 1000 when tracking stray markers
- reading the temperature flag in the system status
- reading the diagnostic pending bit in the system status
- reading the Info.Status.New Alerts user parameter for every hardware device in the system when the diagnostic pending bit is set. See "Usage Notes" on page 62 for details.

#### Reply Option 1000 - 3D Position of Stray Passive Markers

<Reply Option 1000 Data> = <Number of Markers><Out of Volume>< $T_{xn}$ >< $T_{vn}$ >< $T_{zn}$ ><2000

Reply Component	Description
Number of	1 byte
Markers	
	Number of stray markers.
Out of Volume	1 byte/8 markers (1 bit per marker)
	The bit is set when the marker is outside the characterized measurement volume (see example below).
	Reply size = (number of markers)/8, rounded up to the nearest integer.
Txn, Tyn, Tzn	4 bytes each
	Position of the n <sup>th</sup> marker in the coordinate system of the Position Sensor, reported as IEEE 32-bit, single precision, floating point numbers.

reply option data if requested>

Note At least one passive port handle must be enabled, to activate the illuminators on the Position Sensor. If no passive port handles are enabled, <Number of Markers> will return 00 and no other data will be returned.

Stray passive markers are defined as markers which are not used to calculate any of the transformations for any enabled, passive tools. Stray active wireless tool markers are not reported.

**Example - Out of Volume** The information is returned in the format illustrated in the following example: one bit per marker, in little endian format. In this example there are nine markers, all of which are out of volume:

Marker Number										7	6	5	4	3	2	1
Bit Field	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	1
Reply	0				1				F				F			
Reply Byte		n								n -	+ 1					

#### Reply Option 2000 - Extended Stray Passive Marker Status

<Reply Option 2000 Data> = <extended marker information status>

Reply Component	Descripti	on
extended marker information status	4 bits / str Bit field:	ray marker
Status	bit 0=0	The marker does not share lines of site with any other marker and is therefore unlikely to be a phantom marker.
	bit 0=1	The marker shares lines of site with other markers and is therefore possibly a phantom marker.
	bits 1-3	Reserved

This reply option can be used in conjunction with reply option 1000 to help identify stray passive markers that could be phantom markers. See the user guide that accompanied your system for information about phantom markers.

#### **Usage Notes**

- 1. The BX reply format requires fewer characters than the text format; this allows transformations to be reported more quickly. For replies in text format, use TX (page 150).
- 2. Replies are returned in little endian format.
- 3. By default, transformations will not be reported if the tool is either partially or wholly out of the characterized measurement volume, if the bump sensor has been tripped, if the system is outside of the optimal operating temperature range, or if certain other alerts have occurred (see "Alerts User Parameters" on page 22 for details). To report these transformations, you must use reply option 0800 OR'd with the desired reply option(s). The accuracy of these transformations is unknown.
- **4. Reply Option 0001:**

- When the "diagnostic pending" bit is set in the system status, use GET (page 82) to read the Info.Status.New Alerts user parameter for every hardware device in the system. The act of reading these parameters clears the parameters and the "diagnostic pending" bit. For more information on alerts and their associated user parameters, see "Alerts User Parameters" on page 22.
- For wired tools, bits 1, 2, and 3 in the port status report switch status.
- 5. Reply Option 0008: Markers are returned in alphabetical order according to how they are labelled in the tool definition file. For example, for a tool with markers labelled A, G, M and S, the system will return the marker positions in the order A G M S. Reply option 0008 only returns data for markers that the system detects. To identify which marker is which, compare the reply option 0008 data to the data returned with reply option 0002. The marker order is the same for both replies; each marker that does not have a <marker information> status of 0000 ("missing") in reply option 0002 corresponds to a marker in reply option 0008.

#### 6. System Status:

- The external IR bit (bit 1) and system CRC error bit (bit 2) are not used by the system.
- In API revision G.001.004 and later, the diagnostic pending bit (bit 8) is set whenever an alert is detected or cleared. In API revision G.001.003 and earlier, the diagnostic pending bit is set only when an alert is detected.

#### 7. Reply Option 0002:

• Reply 0010 means that the marker was not used because it exceeded the maximum 3D error for the tool.

#### Example

#### Command:

BX 0801

#### Reply:

A5C4005723130201013F3AF3CABE5B7209BF1C07713E635592C39E831F43332973C500511 33DA5BD9F00000031000002CC02013EA1B5D03D137D21BD787C673F72394A4286B6CB4360 6EF4C50468C13ED4E74100000031000002CD000059C9

This is the hexadecimal representation of the binary data being returned. This example returns data for two tools.

#### BX2

Returns the latest tool transformations, individual marker positions, and system status in the General Binary Format.

The BX2 command provides a flexible way of providing measurement data at various levels of detail. The reply can contain a single or multiple frames. Each frame can contain various levels of measurement data details such as 6D, 3D or 2D data.

- It does not repeat already reported information.
- It works with the STREAM command to keep latency to a minimum and avoid missing or repeating information.
- Addresses the problem of providing system wide failures and warning in the multiconnection environment.

#### Compatibility

Supported by the Position Sensor since G.003.

#### **Operating Mode**

Tracking

#### **Syntax**

BX2<SPACE><Reply Options><CR>

Reply Option	Description
6d=tools none	specifies whether 6D information for tools are returned or not. Default is "tools"
3d=none tools strays all	specifies which 3D information is returned, none, tool 3D's, stray 3D's or all 3D's. The default is none. (If selected, 3D's will be returned for all frame types, not just passive frames.)
2d=none tools strays all	specifies which 2D (line of sight) information will be returned. The default is none.
sensor=none tools strays all	sensor specifies which scaled sensor UV information is returned. Scaled UV can be used to visualize the images on the sensors and also provide diagnostic information related to UV brightness. The default is none.
1d=buttons none	1d specifies whether buttons are reported or not. The default is buttons.

#### **Replies**

#### **Upon Success:**

<Start Sequence><2 byte Reply Length><Header CRC><GBF Version>
<Component Count><Frame Component 1>...<Frame Component N><Data CRC>

or

<Extended Binary Start Sequence><4 byte Reply Length><GBF Version><Component Count><Frame Component 1>...<Frame Component N>

#### On Error:

ERROR<error code>

See page 176 for error code definitions.

#### Frame Component: 0x0001

The Frame status field contains error status information related to the frame. In all cases, a value of zero indicates no errors or fault conditions.

All other measurement data details are included as part of the frame data payload. The payload itself follows the General Binary Format.

Frame Data Item		
Frame Type	1 byte	See below
Frame Sequence Index	1 byte	
Frame Status	2 bytes	See below
Frame Number	4 bytes	
Frame Timestamp*	8 bytes	struct timespec (bytes 0-3=seconds since start of epoch, bytes 4-7=nanoseconds)
Frame Data Payload	Variable	General Binary Format

<sup>\*</sup>The frame timestamp is reported in Coordinated Universal Time (UTC). The absolute accuracy of the timestamp depends on the quality of the PTP Master. In the absence of a Grandmaster or Boundary Clock, one of the PTP devices on the network will become PTP Master. The timebase of all PTP Slaves will be adjusted to that of the PTP Master. While this will ensure accurate synchronization between all PTP devices, it does not guarantee that the absolute timestamp will be correct.

#### Frame Types will be as follows:

0
0
1
2
3
4
5
6
7

Frame Status is as follows:

Bit 0-15 This field uses the same codes as the 6D Port/

Tool Status, but only the ones which are applicable to the frame as a whole.

## 6D Data Component: 0x0002

The payload consists of a variable number of 6D data items. Each item has a tool handle (2 bytes in the interest of data alignment) followed by a 2 byte bit-field of port/tool status. If the tool is not missing, this will be followed by a transformation in the same format as the BX command (q0, qx, qy, qz, tx, ty, tz, error)

6D Tool Data Item		
Tool Handle	2 bytes	
Status	2 bytes	See below
Q0, Qx, Qy, Qz, Tx, Ty, Tz, Error	4 bytes each	

## Port/Tool Status is as follows:

Bit 0-7	Error codes as described in Port/Tool Status Error Codes (page 66) and Port/Tool Status Error Codes (Tool Missing) (page 67)	
Bit 8	Transform missing	
Bit 9-12	Reserved	
Bit 13-15	Which face of a multi-face tool is being tracked	

**Table 5-1 Port/Tool Status Error Codes** 

Error Code	Description
0	Enabled
3	Tool is partially out of the characterized measurement volume
9	Tool is out of the characterized measurement volume

Note

The following error codes will only be reported if the tool is missing

Table 5-2 Port/Tool Status Error Codes (Tool Missing)

Error Code	Description
13	Too few markers detected
14	IR interference (a large bright IR object)
17	Bad transformation fit
18	Data buffer limitation (too much data; for example, too many markers)
19	Algorithm limitation (processing requires more buffer than is available)
20	Fell behind while processing
21	Position sensors out of synch
22	Processing exception
31	Tool is missing
32	Tracking is not enabled for this tool
33	Tool has been unplugged from the System Control Unit

### 3D Data Component: 0x0003

The 3D component payload consists of a variable number of 3D items. Each item has a 4 byte handle reference to the port handle of the tool to which the 3D's belong. If the 3D is "stray", the handle reference will be -1. Location information will be equivalent to the 3D information in the BX command. If the marker is missing its 3D item then information will not be present.

### Note

To provide additional diagnostic information for active and passive tools, all defined markers are reported with appropriate status and index (whether they are visible or not) for tools defined with up to 20 markers. For tools with more than 20 defined markers, only visible markers will be reported.

3D Tool Data Item		
Tool Handle Reference	2 bytes	0xffff for "stray" 3D
Number of 3Ds	2 bytes	
3D Data Item		
Status	1 byte	See below
-reserved-	1 byte	
Marker Index	2 bytes	index of marker on tool, sequential # for strays
X, Y, Z	4 bytes each	

For data alignment, the marker status field is 1 byte as follows:

0x00	OK
0x01	Missing (missing markers may not be reported in component
	at all)
0x02	Not used: exceeded max marker angle
0x03	Not used: exceeded max 3D error for tool
0x04	Not used: Out of Volume
0x05	Out of Volume – used in 6D
0x06	Possible phantom marker (in volume, applies to stray
	markers only)
0x07	Saturated (in or out of volume, not used in 6D)
0x08	Saturated and out of volume (not used in 6D)
0x09-0xFF	reserved

## 1D Button Component: 0x0004

The 1D button component consists of a variable number of button state items. Each item contains a port handle (tool) reference or, in the case of non-tool buttons, a dummy tool reference corresponding to the frame in which the button was sampled. Button states are 1 byte each. Use 0 for open and 1 for closed.

Note Currently the only supported states are CLOSED and OPEN. In future, button processing on the firmware may be enhanced to support additional states, such as PRESSED, RELEASED, CLICKED, DOUBLE-CLICKED, HOLD, etc.

1D Button Data Item		
Tool Handle Reference	2 bytes	0xffff for "stray" (non-tool) buttons
Number of buttons	2 bytes	
Button Data Item		
Button data	4 bytes	1 byte for each 4 buttons (little endian)

## 2D Data Component: 0x0005

The 2D data component is as follows:

Tool Line of Sight (LOS) Item		
Tool Handle Reference	2 bytes	0xffff for "stray" LOS
Number of Sensors	2 bytes	
LOS Sensor Item		
Sensor Reference	2 bytes	Index number of the sensor
Number of LOS Items	2 bytes	
LOS Item		
Status	4 bytes	See below
Base X,Y,Z	4 bytes each	vector from origin to sensor
LOS X,Y,Z	4 bytes each	LOS vector from sensor
Number Marker References	2 bytes	0-65535
(N)		

Marker References	2 bytes each	Index of 3D item reported for tool handle
LOS Item padding	((N+1)*2)%4	0 or 2 bytes of padding to ensure each item ends in
	bytes	a 4 byte boundary

The marker status field is 4 bytes as follows:

0x00	OK
0x07	Saturated (in volume, not used in 6D)

## Sensor UV Component: 0x0011

This component is returned if the –sensor option is used. It returns simplified uv data that can be used for diagnostics.

Component Item		
Tool Handle Reference	2 bytes	0xffff for "stray" LOS
Number of Sensors	2 bytes	
UV Sensor Item		
Sensor Reference	2 bytes	Index number of the sensor
Number of UV Items	2 bytes	
Scaled UV Item		
Scaled U, scaled V	1 byte each	0-255 upper left of view is 0,0
Width U, Height V	1 bytes each	
Energy	4 bytes	Sum intensity of all centroid pixels
Peak Intensity	2 bytes	0-65535
Number Marker References	2 bytes	
(N)		
Marker References	2 bytes each	Refers to 3D index for tool in 3D item
UV Item padding	((N+1)*2)%4	0 or 2 bytes of padding to ensure each item ends in
	bytes	a 4 byte boundary

### System Alert Component 0x0012

The System Alert Component returns all current system faults, alerts and events. The component header indicates the number of items. An item consists of a 2 byte type followed by a 2 byte code.

Faults are conditions that indicate the system is unable to function correctly. In general the unit must be returned to NDI for repair. Alerts are conditions that may impact measurement performance but can be resolved on their own or without physical repair. Events may also impact performance or system behaviour but they are a normal part of operations and do not indicate a system malfunction.

Component Item		
Condition Type	1 byte	0=fault, 1=alert 2=event
- reserved -	1 bytes	
Condition Code	2 bytes each	

### **Faults**

The following faults are returned as part of the BX2 component 0x0012:

Error Code	Description
1	Non-recoverable parameter fault
2	Sensor parameter fault
3	Main voltage fault
4	Sensor voltage fault
5	Illuminator voltage fault
6	Illuminator current fault
7	Sensor 0 temperature fault (left)
8	Sensor 1 temperature fault (right)
9	Main temperature fault
10	Sensor fault

### **Alerts**

The following alerts are returned as part of the BX2 component 0x0012:

Error Code	Description
1	Battery fault
2	Bump detected
3	Firmware incompatible
4	Non fatal parameter fault
5	Not used
6	Not used
7	Not used
8	Temperature high
9	Temperature low
10	System Control Unit disconnected
11	Not used
12	Not used
13	Not used
14	PTP synchronization fault
15	Video camera not functioning
17	Firmware running in Safe Mode

For detailed information on system faults and alerts, refer to "Position Sensor Alerts" on page 23.

### **Events**

The following events are returned as part of the BX2 component 0x0012:

<b>Event Code</b>	Description	How the event is cleared
1	Active tool connected	PHSR by the master connection
2	Active tool disconnected	PHSR by the master connection
5	Hardware configuration changed (e.g. VCU or System Control Unit has connected or disconnected)	PHSR by the master connection
6	The PTP Master has changed	Automatically cleared after being reported in a BX2 response

### **Usage Notes**

The <Reply> will be either Requested Data or ERROR<error code>. The BX2 command can be used alone to generate one reply for each BX2 request, or it can be used with the STREAM command to generate a continuous, non-repeating stream of tracking data.

Data returned by the BX2 command is reported in a new binary format, see "General Binary Format" on page 5. The content is wrapped in the same Binary Reply Format as the BX command. When streamed, the entire response will be preceded by the Streaming Reply Format header, see "Data Streaming" on page 7.



No options exist for filtering data returned from the BX2 (page 64) command on the basis of system or tool status or location in the volume. Complete system and tool status information is always included in the reply and it is the application's responsibility to interpret this data and ignore those measurements that fall outside of application requirements and constraints. Failure to do so may lead to inaccurate conclusions that may cause personal injury.

BX2 Binary Data structured in General Binary Format contains one or more tracking frames, similar to the BX command. It contains up to one full frame sequence of previously unreported data. Each frame will be contained in the Frame Data Component, see "General Binary Format" on page 5.

Frame data component will contain various level of tracking data according to the specified BX2 commands. Each type of the tracking data such as 6D, 3D or 2D will be reported again in the General Binary Data Format as separate components.

The content of the single frame of data contains various levels of tracking detail. Each lower level of information references the higher-level information, see Figure 5-1.




Figure 5-1 Frame Component Overview

### **Example**

### Command:

6D tools (2 passive tools loaded and tracking)

Command: BX2 --6d=tools --1d=none

### Reply:

## This string decodes as:

Start sequence Reply length	2 Bytes 2 Bytes	Unitless Bytes	0xA5C4 0x0064	100 Bytes
Header CRC	2 Bytes	Unitless	0xD307	-
GBF version	2 Bytes	Unitless	0x0001	Version 1
Component count	2 Bytes	Unitless	0x0001	1 Component
Component 1				
Component type	2 Bytes	Unitless	0x0001	Frame Component
Component size	4 Bytes	Bytes	0x00000060	96 Bytes
Item Format Option	2 Bytes	Unitless	0x0000	
Item count	4 Bytes	Count	0x0000001	1 Item to parse

Frame Item 1				
<del></del>	1 Byte 1 Byte	Туре	0x02 0x00	Passive
	2 Bytes		0x0000	OK
	4 Bytes	Count	0x382E05BF	942540223 decimal Jun 30 2016 15:36:43
Timestamp	8 Bytes	Seconds Nanoseconds	0x577574CB 0x2AD9A212	Jun 30 2016 13:36:43
GBF version	2 Bytes	Unitless	0x0001	Version 1
Component count	2 Bytes	Unitless	0x0002	2 Data Components
Data Component 1				
Component type	2 Bytes	Unitless	0x0012	System Alerts
Component size	4 Bytes	Count	0x000000C	12 Bytes
Item Format Option	-	Unitless	0x0000	
Item count	4 Bytes	Count	0x00000000	No System Alert Items
Data Component 2				
Component type	2 Bytes	Unitless	0x0002	6D Data Component
Component size	4 Bytes	Bytes	0x00000034	52 Bytes
Item Format Option	-	Unitless	0x0000	
Item count	4 Bytes	Count	0x0000002	Two 6D Data Items
6D Data Item 1				
Tool Handle	2 Bytes		0x0003	Handle 3
Handle status	2 Bytes		0x2000	OK, Face 1
				Transform not missing
Q0	4 Bytes	Unitless	0x3F7E3A79	+0.993079722
Qx	4 Bytes	Unitless	0xBD37F076	-0.044907056
QУ	4 Bytes	Unitless	0xBDDE39DE	-0.108508810
Qz	4 Bytes	Unitless	0xBAB23A83	-0.001359776
Tx	4 Bytes	mm	0x426A9510	58.645568848 mm
Ту	4 Bytes	mm	0xC2F605C0	-123.0112305 mm
Tz	4 Bytes	mm	0xC48CCABD	-1126.335571 mm
Error	4 Bytes	mm	0x3CCE7B6F	0.0252053421 mm RMS
6D Data Item 2				
Tool Handle	2 Bytes		0x0004	Handle 4
Handle status	2 Bytes		0x010D	Too Few Markers
				Transform missing

2 Bytes Unitless 0x7DF3

CRC16

## **COMM**

Sets the serial communication settings for the system.

## Compatibility

Supported by the Position Sensor since G.001. Used for serial communications only with Position Sensors equipped with a serial communications port (LEMO connector).

## **Operating Mode**

All modes

## **Syntax**

COMM<SPACE><Baud Rate><Data Bits><Parity><Stop Bits><Hardware Handshaking><CR>

Parameter	Desc	cription		
Baud Rate		data transmission rate between the system and the host com- r, in bits per second. The default baud rate is 9600 bps.		
	Valid Values:			
	0	9600 bps		
	1	14 400 bps		
	2	19 200 bps		
	3	38 400 bps		
	4	57 600 bps		
	5	115 200 bps		
	6	921 600 bps		
	7	1 228 739 bps		
Data Bits	that	The data bits must be set to 8 bits in order to use any command that returns binary data (BX, BX2, GETLOG, or VCAP). The default is 8 data bits.		
	Valid	Valid Values:		
	0	8 bits		
	1	7 bits		
Parity	The default is no parity.			
	Valid Values:			
	0	None		
	1	Odd		
	2	Even		

Parameter	Desc	ription	
Stop Bits	The o	default is one stop bit.	
	Valid	l Values:	
	0	1 bit	
	1	1 2 bits	
Hardware Handshakin	The	The default is no hardware handshaking.	
g	Valid Values:		
	0	0 Off	
	1 On		

### **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- 1. The system serial communication parameters have a default setting of 00000 (i.e. 9600 baud, 8 data bits, no parity, 1 stop bit, hardware handshaking off).
- 2. To use any command that returns binary data (BX, GETLOG, or VCAP), you must set the data bits to 0 (8 bits).
- 3. If you change the baud rate using the COMM command, you must also change your host computer baud rate; otherwise, a system reset or other unexpected communication behaviour will occur. The host application should wait approximately 100 ms after receiving the OKAY reply from the system before changing its own communication parameters.
- 4. NDI strongly recommends using hardware handshaking when using the higher baud rates.
- 5. Most Windows applications do not allow you to choose 1.2 Mbaud. To allow you to communicate at this speed, NDI has aliased 19 200 baud to 1.2 Mbaud when using a USB connection. Thus, to communicate at 1.2 MB:
  - a) Connect the system using a USB connection (this is the only option for passive systems).
  - b) Set the system to 1.2 Mbaud (<baud rate> parameter value 7).
  - c) Set the application on the host computer to 19 200 baud. The virtual COM driver maps the communications speed to 1.2 Mbaud, so the application will actually communicate with the system at 1.2 Mbaud.

Do not set the System to 19 200 baud when using a USB connection; if the system is set to 19 200 baud, it will be unable to communicate with the host computer, because setting the host application to 19 200 baud will result in the aliased rate of 1.2 Mbaud.

# Example

### Command:

COMM 30001

## Reply:

OKAYA896

This changes the serial communication parameters to 38400 baud, 8 data bits, no parity, 1 stop bit, hardware handshaking on.

## **DFLT**

Restores the user parameters to factory default values.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

## **Operating Mode**

All modes

### **Syntax**

DFLT<SPACE><User Parameter Name><CR>

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*)  Use <b>DFLT</b> * to restore all user parameters to default values.
	User parameter names are case-sensitive.

### **Replies**

## **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

- 1. The user parameter name may include a trailing wild card character (\*).
- 2. Use **DFLT** \* to return all user parameters to their default values.
- 3. The user parameter values set using the DFLT command persist until the system is reset or initialized. To save the user parameters at their factory default values, use SAVE (page 130) after using the DFLT command.
- 4. To view a list of user parameters and their current values, use **GET** \*.
- 5. User parameter names are case-sensitive.
- 6. For more information on user parameters, see "User Parameters" on page 19.

# Example

## Command:

DFLT \*

# Reply:

### **DSTART**

Starts Diagnostic mode.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

### **Prerequisite Command**

INIT (page 89)

### **Syntax**

DSTART<SPACE><Reply Option><CR>

Parameter	Description
Reply Option	80 (Optional)

## **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

The frame number is reported in reply option 0001 of the TX (page 150) and BX (page 53) commands. In the Polaris Vega System, the frame number is derived from the PTP time, and reply option 80 is ignored.

In order to facilitate active tool setup from a monitor connection, DSTART will return OKAY when in diagnostic mode.

### **Example**

### Command:

DSTART

## Reply:

## **DSTOP**

Stops Diagnostic mode.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Diagnostic

## **Prerequisite Command**

DSTART (page 79)

## **Syntax**

DSTOP<SPACE><CR>

## **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

If executed from setup mode, it will return OKAY.

## **Example**

### Command:

DSTOP

## Reply:

## **ECHO**

Returns exactly what is sent with the command.

## Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

### **Operating Mode**

All modes

## **Syntax**

ECHO<SPACE><Any ASCII characters><CR>

## **Replies**

### **Upon Success:**

Exactly what is sent with the command, with <CRC16><CR>.

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

The ECHO command can handle a maximum of  $\sim$ 50,000 characters. Exceeding this number will cause the system to return error 02.

## **Example**

### Command:

ECHO Testing!

### Reply:

Testing!A81C

### **GET**

Returns the user parameter values.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

### **Operating Mode**

All modes

## **Syntax**

GET<SPACE><User Parameter Name><CR>

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*).  Use GET * to return all user parameter values.
	User parameter names are case-sensitive.

## **Replies**

### **Upon Success:**

<User Parameter Name>=<value><LF> (repeated for each user parameter name, but no line feed after the last parameter) < CRC16 > < CR >

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
User Parameter Name	Variable size Full name of the user parameter
Value	Value of the user parameter

## **Usage Notes**

- 1. The user parameter name may include a trailing wild card character (\*).
- 2. Use **GET** \* to return the names and values of all user parameters.
- 3. Numeric user parameter values are returned as decimal strings.
- 4. User parameter names are case-sensitive.

5. For descriptive information about each user parameter, including type, attributes, and possible values, use the GETINFO command.

For more information on user parameters, see "User Parameters" on page 19.

## Example

### Command:

GET Info.Status.New Alerts

## Reply:

Info.Status.New Alerts=08B32

## **GETINFO**

Returns descriptive information about the user parameters.

## Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

## **Operating Mode**

All modes

## **Syntax**

GETINFO<SPACE><User Parameter Name><CR>

Parameter	Description
User Parameter Name	A string, identifying the name of the user parameter. May include a trailing wild card character (*).  Use <b>GETINFO</b> * to return information for all user parameters.
	User parameter names are case-sensitive.

## **Replies**

### **Upon Success:**

<User Parameter Name>=<Value>;<Type>;<Attribute>;<Minimum>;<Maximum>;
<Enumeration>;<Description><LF> (repeated for each user parameter, but no line feed after last parameter)
<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
User Parameter Name	Variable size Full name of the user parameter
Value	Variable size
	Value of the user parameter

Reply Component	Description	Description							
Туре		nal character							
	Describes the data type.								
	Possible Values:								
	0	Boolean							
	1	Integer							
	2	Float							
	3	String							
Attribute	1 to 4 hexad	lecimal characters							
	Describes the access rules.								
	Bit field:								
	bit 0	Read							
	bit 1	Write							
	bit 2	Save							
	bit 3	Volatile (may change frequently)							
	bit 4	Keyed (cannot be changed unless key is supplied) - Not used in Vega							
	bit 5	Enabled keyed parameter - Not used in Vega							
	bits 6 to 7	Reserved (may not all be set to 0)							
	bit 8	Table parameter							
	bit 9-15	Reserved (may not all be set to 0)							
Minimum	of character								
	If minimum = maximum = 0, no range check is performed.								
Maximum	Maximum allowed value of the user parameter. For a string, the maximum number of characters allowed.								
	= maximum = 0, no range check is performed.								
Enumeration	Comma-separated enumeration list. This is a list of possible values that the user parameter can take, and corresponds to the values in the <value> field (the first item in the list corresponds to value 0, the second item corresponds to value 1, etc.).</value>								
Description	Describes th	ne user parameter's function.							

# **Usage Notes**

- 1. The user parameter name may include a trailing wild card character (\*).
- 2. Use **GETINFO** \* to return information for all user parameters.
- 3. Numeric user parameter values are returned as decimal strings.
- 4. User parameter names are case-sensitive.
- 5. For a list of user parameters and values without descriptive information, use the GET command.

For more information on user parameters, see "User Parameters" on page 19.

# Example 1

### Command:

GETINFO Info.Status.Bump Detected

## Reply:

Info.Status.Bump Detected=0;1;800D;0;1;False,True;Indicates if the system has
detected a bump49CB

The system returns descriptive information for the specified parameter.

## **GETLOG**

Returns the contents of the device's event log.

## Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

## **Operating Mode**

All modes

## **Syntax**

GETLOG<SPACE><Offset><Length><Logname><CR>

Parameter	Description							
Offset	8 hexadecimal character string							
	Specifies the offset of the data requested within the file.							
Length	4 hexadecimal character string							
	Specifies the requested amount of data, in bytes. Up to 50 kilobytes can be requested at one time.							
Logname	String identifying the name of the log. Log names are case-sensitive.							
	API revision	Name of log file						
	API revision G.001.003 and earlier, and G.003.001 and later	sysinfo						
	API revision G.001.004 up to but not including G.003.001 \Cee "Device Names" on page 20 for device name details							

## **Replies**

### **Upon Success:**

<Header><Length><Header CRC><Data><Data CRC>

Note The reply for the GETLOG command is binary data.

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
Header	2 bytes: A5C4
	Indicates the start of the GETLOG reply.
Length	2 bytes
	The number of bytes of data being returned.
Header CRC	2 bytes
	CRC16 for header.
Data	Up to 50 kilobytes of binary data
Data CRC	2 hexadecimal characters
	CRC16 of the <data> section.</data>

## **Usage Notes**

- 1. To read the entire log file:
  - a) Start with an offset of 0, and request 50 kilobytes of data.
  - b) Increment the offset by 50 kilobytes, and request another 50 kilobytes of data.
  - c) Repeat step b) until the reply length of the data is less than the amount you requested. This indicates that you have reached the end of the log file.
- 2. Replies are returned in little endian format.
- 3. To write to a log, use SYSLOG (page 142).
- 4. The log name is **sysinfo**.

## **Example**

### Command:

GETLOG 000000000800sysinfo

### INIT

Initializes the system.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

### **Operating Mode**

All modes

### **Syntax**

INIT<SPACE><CR>

### Replies

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- During power up or system reset, the system configuration is determined. The configuration includes firmware revisions and the characterized measurement volumes for which the Position Sensor has been calibrated. The INIT command ensures that the system configuration was determined successfully.
- 2. The system will automatically return to Setup mode after using the INIT command.
- 3. The INIT command sets any modified user parameters back to the saved values. To prevent modified values from being reset, send the SAVE command before sending INIT.
- 4. If ERROR2E or ERROR15 is returned, there may be a system fault that is indicated by the alerts in the **Info.Status. New Alerts** or **Info.Status.Alerts** user parameter on one or more devices. Use GET to read these user parameters. See "Alerts User Parameters" on page 22 for details.
- 5. In the case where a Monitor mode connection issues the INIT command
  - a) if the system is already in the Setup mode with no tools loaded the system, the response is OKAY.
  - b) if the system is already initialized but is in Tracking or Diagnostics mode, or if there are tools loaded, in API version G.003.005 and later the response is WARNING06. In versions before G.003.005, the response is WARNING01.
  - c) if the system is not initialized, the response is ERROR39 (Permission denied).

## **Command Details**

Exam	pl	e

Command:

INIT

Reply:

## **IRATE**

Sets the illuminator rate.

## Compatibility

Supported by the Position Sensor since G.001.

**Deprecated.** To set the illuminator rate for Vega, use the command SET (page 131) to set the user parameter **Param.Tracking.Track Frequency**.

## **Operating Mode**

Setup

## **Prerequisite Command**

INIT (page 89)

## **Syntax**

IRATE<SPACE><Illuminator Rate><CR>

Parameter	Description				
Illuminator Rate	Sets the number of times per second that the illuminators emit IR.  Valid values:				
	0 1/3 of the frame frequency If the MR250 option is enabled, 0 = 250Hz.				
	1 1/2 of the frame frequency				
	1/1 of the frame frequency				

# **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Command Details**

# Example

## Command:

IRATE 0

# Reply:

## **IRED**

Turns the markers on a wired tool on or off.

## Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

Diagnostic

# **Prerequisite Command**

PENA (page 98)

## **Syntax**

IRED<SPACE><Port Handle><Marker Activation Signature><CR>

Parameter	Description						
Port Handle	2 hexadecimal characters						
Marker Activation Signature	8 hexadecimal characters (32 bits)						
	One bit for each marker. Set the bits corresponding to the markers you wish to activate. See example in Usage Notes.						
	Bit field:						
	bit 0	Marker A					
	bit 1	Marker B					
	bit 2	Marker C					
	bit 19 Marker T						
	bits 20 to Reserved 31						

# **Replies**

## **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

There are 20 marker positions, labelled "A" to "T." To specify that a marker should be turned on, set the bit corresponding to that marker to 1. For example, you will need to set the bit field as follows if you wanted to activate markers B, G, M and T:

Marker Location		Т	S	R	Q	Р	0	N	M	L	K	J	I	Н	G	F	Е	D	С	В	Α
Bit	31- 20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Bit Value	0	1	0	0	0	0	0	0	1	0	0	0	0	0	1	0	0	0	0	1	0
Activation Signature Parameter Value	000		8	3			]	1			(	)			4	4			2	2	

## **Example**

### Command:

IRED 0A00081042

## Reply:

# **LED**

Changes the state of visible LEDs on a wired tool.

# Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

All modes

# **Prerequisite Command**

INIT (page 89)

## **Syntax**

LED<SPACE><Port Handle><LED Number><State><CR>

Parameter	Descrip	Description						
Port Handle	2 hexad	hexadecimal characters						
LED Number	Specifie	ifies the LED.						
	Valid v	lid values:						
	1 to 3							
State	Sets the	Sets the state of the specified LED.						
	B Blank (not on)							
F Flash								
S Solid on								

## **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

## On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

The visible LEDs are only activated while the system is in Tracking and Diagnostic modes.

# Example

## Command:

LED OA1S

## Reply:

## **PDIS**

Disables the reporting of transformations for a particular port handle.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

# **Prerequisite Command**

PENA (page 98)

## **Syntax**

PDIS<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

## **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

## On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Example**

## Command:

PDIS 01

### Reply:

### **PENA**

Enables the reporting of transformations for a particular port handle.

### Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

### **Syntax**

PENA<SPACE><Port Handle><Tool Tracking Priority><CR>

Parameter	Description					
Port Handle	2 hexadecimal characters					
Tool Tracking Priority	Describes the type of tool.  Valid Values:					
	S Static: a static tool is considered to be relatively immobile, e.g. a reference tool.					
	D Dynamic: a dynamic tool is considered to be in motion, e.g. a probe.					
	B Button box: a button box can have and LEDs, but no markers. No transformations are returned for a button box tool, but switch status is returned.					

### **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

or

WARNING02<CRC16><CR> (Indicates that the tool you are trying to enable is a unique geometry tool that doesn't meet the unique geometry requirements.)

WARNING03<CRC16><CR> (Indicates that the tool you are trying to enable is a unique geometry tool that conflicts with another unique geometry tool already loaded and enabled.)

WARNING04<CRC16><CR> (Indicates that the tool you are trying to enable is a unique geometry tool that doesn't meet the unique geometry requirements, and conflicts with another unique geometry tool already loaded and enabled.)

WARNING05<CRC16><CR> (Returned when the system selects a default marker wavelength to track a tool if the tool's definition file did not specify a marker wavelength.)

## On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- 1. The system does not make use of the tool tracking priority. You must still specify a value, but it does not matter which tool tracking priority you choose.
- 2. When the PENA command is issued, the system compares the tool being enabled with currently enabled tools for conflicting unique geometry constraints. This process is almost instantaneous. If the tool doesn't meet the unique geometry constraints, or conflicts with a tool that is already enabled, the system will issue a WARNING02, WARNING03, or WARNING04.
- 3. The system will still enable the tool when the system returns WARNING02, WARNING03 or WARNING04; however, the tool may not track properly since the unique geometry is compromised.
- 4. For more information on unique geometry tools and unique geometry constraints, see the *Polaris Tool Design Guide*.

## **Example**

### Command:

PENA 01D

### Reply:

## **PFSEL**

Sets which tool faces to use to track a multi-faced tool.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

# **Prerequisite Command**

PINIT (page 114)

## **Syntax**

PFSEL<SPACE><Port Handle><Face Selection Mask><CR>

## Reply

OKAY<CRC16><CR>

Parameter	Description		
Port Handle	2 hexadecimal characters		
Face Selection 2 hexadecimal characters (8 bits)			
	Set the bits corresponding to the faces you wish to track.		

# Replies

### **Upon Success:**

OKAY<CRC16><CR>

## On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

- 1. When a tool is initialized, the face selection defaults to a value of 0xFF, so all faces are tracked by default.
- 2. To include a tool face to be tracked, set the corresponding bit. For example, if you wish to track faces 0 and 5, the face selection value is 0x21, as shown in the following table:

Tool Face Number	7	6	5	4	3	2	1	0
Bit Value	0	0	1	0	0	0	0	1
Face Selection Hexadecimal Value	2				1			

3. If the system returns error code 23, the face selection did not include any of the valid faces of the selected tool.

## Example

### Command:

PFSEL 0121

### Reply:

# **PHF**

Releases system resources from an unused port handle.

### Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

Setup

### **Prerequisite Command**

PHRQ (page 109)

### **Syntax**

PHF<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

### **Replies**

# **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- 1. The PHF command should be used whenever a tool is disconnected. This optimizes the use of system resources. If PHF is not used, the system will be unable to assign a port handle after the maximum number of port handles has been reached.
- 2. If a tool is disconnected then reconnected, it is a assigned a new port handle. The old port handle is no longer in use and should be freed using PHF.

### Example

### Command:

PHF 01

### Reply:

OKAYA896

This frees port handle 01, so it is no longer assigned.

# **PHINF**

Returns port handle status, information about the tool associated with the port handle, and the physical location of a port handle.

# Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

All modes

# **Prerequisite Command**

PHSR (page 111) or PHRQ (page 109)

# **Syntax**

PHINF<SPACE><Port Handle><Reply Option><CR>

Parameter	Description		
Port Handle	2 hexadecimal characters		
Reply Option	Optional. Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 0001.		
	the reply options are hexadecimal numbers that can be OR'd. If ultiple reply options are used, the replies are returned in order of creasing option value.		
	Valid Values:  0001 Tool information (default)		
	0002 Wired tool electrical information		
	0004 Tool part number		
	0008 Switch and visible LED information		
	0010 Tool marker type and wavelength		
	0020 Physical port location		

# **Replies**

# **Upon Success:**

If there is a tool assigned tool definition file to the port handle:

<Reply Option 0001 Data><Reply Option 0002 Data>...<Reply Option 0020
Data><CRC16><CR>

# Note

The physical location of a port handle is the only information available unless PHINF has been preceded by PINIT (page 114).

If no tool definition file is assigned to the port handle:

UNOCCUPIED<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Reply Option 0001 - Tool Information**

<Reply Option 0001 Data> = <Tool Type><Manufacturer's ID><Tool Revision><Serial
Number><Port Status>

Reply Component	Description		
Tool Type	<pre>8 characters  <tool type=""> = <main type=""><number of="" switches=""><number leds="" of="" visible=""><reserved><subtype></subtype></reserved></number></number></main></tool></pre>		
	Main Type	2 hexadec	imal characters
		Possible V	Values:
		01	Reference
		02	Probe
		03	Button box or foot switch
		04	Software-defined
		05	Microscope tracker
		06	Reserved
		07	Calibration device
		08	Tool Docking Station
		09	Isolation box
		0A	C-arm tracker
		0B	Catheter
		0D to FF	Reserved
	Number of Switches	1 character	
	Number of Visible LEDs	1 characte	r
	Reserved	2 characte	rs
	Subtype	2 characte	rs
Manufacturer's	12 characters	characters	
Tool Revision	3 characters		

Reply Component	Description		
Serial Number	8 hexadecimal characters (32 bits)  Bit field:		
	bits 0 to 9	Sequence number (one-based)	
	bits 10 to 18	Day of year (zero-based, e.g. Jan 1 is day 0 and Dec 31 is day 364)	
	bits 19 to 22	Month (zero-based)	
	bits 23 to 31	Year (year is <current year=""> - 1900, e.g. the year 2009 is 109)</current>	
Port Status	2 hexadecimal c	characters (8 bits)	
	Bit field:		
	bit 0	Tool-in-port	
	bit 1	Switch 1 closed	
	bit 2	Switch 2 closed	
	bit 3	Switch 3 closed	
	bit 4	Port initialized	
	bit 5	Port enabled	
	bit 6	Reserved	
	bit 7	Tool-in-port from current sensing	

# Reply Option 0002 - Wired Tool Electrical Information

Reply Component	Description		
Reply Option 0002 Data	8 hexadecima	ll characters	
	Wired tool electrical information. The electrical current is tested for two conditions: over and under. An "over" current condition indicates that there is a short circuit in either the cable or the marker. An "under" current condition indicates that there is either a break in the cable or the marker has burnt out.  Bit field:		
	bits 0 to 19 Marker failed. Bit 0 = marker A,, bit 19 = marker T		
	bits 20 to 29 Reserved		
	bit 30 Under		
	bit 31	Over	

You can test the electrical current of all the markers on a tool using TCTST (page 144).

# Reply Option 0004 - Tool Part Number

Reply Component	Description
Reply Option 0004 Data	20 characters
	The part number of the tool.

# Reply Option 0008 - Switch and Visible LED Information

Reply Component	Description		
Reply Option 0008 Data	2 hexad	decimal characters (8 bits)	
	This option reports the information found in the tool description. It is not information sensed by the hardware.		
	Bit fiel	d:	
	bit 0 Tool-in-port switch supported		
	bit 1 Switch 1 supported		
	bit 2 Switch 2 supported		
	bit 3 Switch 3 supported		
	bit 4 Tool tracking LED supported		
	bit 5 LED 1 line 1 supported		
	bit 6 LED 2 line 2 supported		
	bit 7	LED 3 line 3 supported	

# Reply Option 0010 - Tool Marker Type and Wavelength

Reply Component	Description		
Reply Option 0010 Data	2 hexadecimal characters (8 bits)		
	Bits 0 to 2 give	information on the marker wavelength:	
	000	9x0 nm	
	001	880 nm	
	010	930 nm	
	100	870 nm	
	111	850 nm	
	Bits 3 to 7 give information on the marker type:		
	00000	Reserved	
	00001	NDI active	
	00010	NDI ceramic	
	00011	Unknown active	
	00100	Unknown passive	
	00101	Passive sphere	
	00110	Passive disc	
	00111	NDI Radix	
	01000 to 11111	Reserved	

# **Reply Option 0020 - Physical Port Location**

<Reply Option 0020 Data> = <Hardware Device><System Type><Tool Type>
<Port Number><Reserved>

Reply Component	Description		
Hardware	8 characte	rts	
Device	For passiv	e or active wireless tools this is the Position Sensor serial number.	
	For Polari	s Vega active tools, this is STB-0.	
System Type	1 characte	r	
	Possible values:		
	Reserved		
Tool Type	1 character		
	Possible values:		
	0	Wired	
	1	Wireless	

Reply Component	Description		
Port Number	2 ASCII c	2 ASCII characters	
	Possible values:		
	01 to 03	01 to 03 Used for Polaris Vega wired tools	
	00	Used for Polaris Vega wireless tools	
Reserved	2 characters		

### **Usage Notes**

- 1. The physical location of a port handle is the only information available unless PHINF has been preceded by PINIT (page 114) or PENA (page 98).
- 2. Port handles for tools that have been disconnected will be reported as UNOCCUPIED and no additional information will be returned.
- 3. Reply option 0001: For wired tools, bits 1, 2, and 3 in the port status report status.
- 4. **Reply option 0008**: For wired tools, bits 1, 2, and 3 report status, and bits 5, 6, and 7 report LED status.
- 5. **Reply option 0010**: A value of 010 for marker wavelength can be returned only for tools characterized using NDI 6D Architect version 2.02 or later. Tools characterized with earlier versions of NDI 6D Architect will have a value of 000 for a marker wavelength of 930 nm.
- 6. Reply option 0040: This option is not supported by the hybrid Polaris Vega System.

# **Example**

### Command:

PHINF 040001

### Reply:



# **PHRQ**

Assigns a port handle to a tool.

# Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

# **Syntax**

PHRQ<SPACE><Hardware Device><System Type><Tool Type><Port Number><Dummy Tool><CR>

Parameter	Description	Description		
Hardware Device	8 characte	rs		
	0020, or u fying all w	The hardware device must match the one returned by PHINF (page 103) reply option 0020, or use wild card characters (*). For active tools connected to the system, specifying all wildcards will default to hardware device STB-0 (the tool ports on the System Control Unit).		
System Type	1 characte	r		
	Valid Valı	les:		
		l card character (*).		
Tool Type	1 characte	1 character		
	This must	This must be specified for wireless tools.		
	Valid Valu	Valid Values:		
	0 or *	0 or * Wired		
	1	Wireless (passive or active wireless)		
Port Number	2 characte	2 characters		
	The physical port number where a wired tool is plugged in. This must be specified for wired tools.			
	Valid Values:			
	01 to 03 Used for hybrid Polaris Vega wired tools			
	00 or **	00 or ** Used for wireless tools		

Parameter	Description	on		
Dummy Tool	2 character	2 characters		
	If specified marker tra-	d, will auto-generate a non-trackable dummy tool. Useful for 3D straycking.		
	In the case	In the case of Tool Type = Wired, either 01 or 02 adds an active wired dummy tool.		
	Otherwise	Otherwise, In case of Tool Type = Wireless:		
	<ul> <li>Valid Values:</li> <li>** Do not load a dummy tool. Requires tool definition to be loaded with sequent PVWR (page 127) commands.</li> </ul>			
	01	adds passive dummy tool		
	02	adds active wireless dummy tool		

### **Replies**

### **Upon Success:**

<Port Handle><CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- 1. Use PHRQ to assign a port handle to a wireless tool or to a wired tool that has neither a tool-in-port diode or a marker in position A of the tool wiring matrix. If a wired tool has a tool-in-port diode or a marker in position A of the tool wiring matrix, use PHSR (page 111) to detect the tool and assign it a port handle.
- 2. **Wireless tools**: You must specify the tool type. All other parameters may be left as wild card characters (\*).
- 3. **Wired tools**: You must specify the port number. All other parameters may be left as wild card characters (\*).
- 4. After using PHRQ, you must use PVWR (page 127) to assign a tool definition file to the tool. If you do not assign a tool definition file to the tool, the port handle will be reported as unoccupied when it is initialized with PINIT (page 114) or PENA (page 98).

# **Example**

### Command:

PHRQ \*\*\*\*\*\*\*1\*\*\*\*

### Reply:

04D715

This requests a port handle for a wireless tool.

# **PHSR**

Returns the number of assigned port handles and the port status for each one. Assigns a port handle to a wired tool.

# Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

All modes

# **Prerequisite Command**

INIT (page 89)

# **Syntax**

PHSR<SPACE><Reply Option><CR>

Parameter	Desc	ription	
Reply Option	Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 00.		
	The reply options cannot be OR'd.		
	Valid Values:		
	00 Reports all allocated port handles (default)		
	01 Reports port handles that need to be freed		
	02 Reports port handles that are occupied, but not initialized or enabled		
	03 Reports port handles that are occupied and initialized, but not enabled		
	04 Reports enabled port handles		

# **Replies**

### **Upon Success:**

```
<Number of Port Handles>
<1st Port Handle><1st Port Handle Status>
<2nd Port Handle><2nd Port Handle Status>
...
<nth Port Handle><nth Port Handle Status>
<CRC16><CR>
```

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions

Reply Component	Description	
Number of Port Handles	2 hexadecimal characters	
	option. If no 1	of allocated port handles of the type specified in the reply reply option is specified, the number returned is the total ocated port handles.
n <sup>th</sup> Port Handle	2 hexadecima	l characters
	Specifies the	port handle whose status follows.
n <sup>th</sup> Port Handle Status	3 hexadecimal characters (12 bits)	
	Bit field:	
	bit 0	Occupied
	bit 1	Switch 1 closed
	bit 2	Switch 2 closed
	bit 3	Switch 3 closed
	bit 4	Initialized
	bit 5	Enabled
	bit 6	Reserved
	bit 7	Tool detected from current sensing
	bit 8 to 11	Reserved

# **Usage Notes**

- 1. When you send the PHSR command, the system will detect and assign port handles to any wired tools that do not already have a port handle assigned (i.e. any wired tools that were plugged in after the last PHSR call). It will then return the requested port handle information.
- 2. The system will detect a wired tool if the tool has a tool-in-port diode, or a marker in position A of the tool wiring matrix. If you are using a wired tool that does not meet this criteria, you will need to request a port handle for the tool using PHRQ.
- 3. If you unplug a wired tool while the system is in tracking mode, the port handle will be reported as "disabled" in the replies to the BX and TX commands. If you reconnect the tool, it will need a new port handle.
- 4. If you connect a wired tool to the system while the system is in tracking mode, you will have to take the following steps before the system will report the tool:
  - a) Exit tracking mode (TSTOP).
  - b) Assign, initialize, and enable a port handle for the tool as outlined in Figure 3-1 on page 17.
  - c) Re-enter tracking mode (TSTART).

- 5. PHSR will report wireless tool ports as unoccupied if you have requested a port handle using PHRQ (page 109) but have not yet associated a tool definition file for the port handle (using PVWR (page 127)).
- 6. To obtain a port handle for a wireless tool, use PHRQ.
- 7. PHSR will only return the number of assigned port handles and their status when executed in tracking or diagnostic mode from a master connection, or when executed in any mode from a monitor connection.

### **Examples**

### Command:

PHSR

### Reply:

001414

In this case, there are no occupied port handles.

### Command:

PHSR

### Reply:

0101031F1AF

In this case, there is one occupied port handle, which is initialized and enabled.

### **PINIT**

Initializes a port handle.

### Compatibility

Supported by the Position Sensor since G.001.

Deprecated. PENA now initializes tools that have not been initialized by PINIT.

### **Operating Mode**

Setup

# **Prerequisite Command**

PVWR (page 127) or PHSR (page 111)

### **Syntax**

PINIT<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

### **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

or

WARNING01 (Indicates that a non-fatal tool error has been encountered, e.g. a burnt out marker.)

or

WARNING05 is returned when the system selects a default marker wavelength to track a tool (if the tool's tool definition file did not specify a marker wavelength).

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- 1. If the tool description is drawn from a tool definition file that has been loaded using PVWR (page 127), initialization involves unpacking and verifying the tool definition file. This process is almost instantaneous.
- 2. If the tool description is drawn from an SROM device, initialization involves reading, unpacking, and verifying the tool definition file contents, and testing electrical current through all the markers to detect burnt out markers. This process takes approximately two seconds if

successful, or several seconds longer if a problem is encountered and retries are attempted by the system.

- 3. The port handle will still initialize when the system returns WARNING01 or WARNING05.
- 4. The System Control Unit will load and parse active tool info when a tool is plugged in. PENA will load and parse passive tool info if not done so yet.

# **Example**

### Command:

PINIT 01

# Reply:

OKAYA896

This initializes port handle 01.

# **PPRD**

Reads data from the SROM device in a wired tool.

# Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

# **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

### **Syntax**

PPRD<SPACE><Port Handle><SROM Device Address><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
SROM Device Address	4 hexadecimal characters
	Valid Values:
	0x0000 to 0x07C0

# Replies

# **Upon Success:**

<SROM Device Data><CRC16><CR>

The SROM device data is 64 bytes (128 hexadecimal characters) of data.

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- 1. The SROM device is a 2-KB write-once device that must be read in 64-byte chunks. An SROM device is considered blank if its contents are all 0xFFs.
- 2. PPRD reads 64 bytes of data from the SROM device starting at a specified SROM device address.

# **Command Details**

# Example

### Command:

PPRD 010000

# Reply:

0123456789ABCDEF01256789ABCDEF0123456789ABCDEF01256789ABCDEF01256786789ABCDEF01256786789ABCDEF01256789ABCDEF01

### **PPWR**

Writes data to the SROM device in a wired tool.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

### **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

### **Syntax**

PPWR<SPACE><Port Handle><SROM Device Address><SROM Device Data><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
SROM Device Address	4 hexadecimal characters  Valid values:  0x0000 to 0x07C0
SROM Device Data	64 bytes (128 hexadecimal characters) of data

# Replies

### Command:

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- 1. PPWR writes 64 bytes of data to the SROM device starting at a specified SROM device address.
- 2. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character).
- 3. The tool description section of tool SROM device is a 1-Kbyte, write-once area that must be written in 64-byte chunks. If the information being written to the system is less than 64 bytes in size, then the remainder of the chunk must be padded out with ones to maintain the 64-byte size

before being written to the system. To write to the second 1-Kbyte section, use the PUWR command.

- 4. An SROM device is considered blank if its contents are all 0xFFs.
- 5. The recommended procedure to follow for updating an SROM device is:
  - a) Read the contents of the SROM device using PPRD (page 116).
  - b) Modify the data.
  - c) Write the modified data back to the SROM device using PPWR (page 118).

# **Example**

### Command:

### Reply:

OKAYA896

# **PSEL**

Selects an SROM device as the target for reading or writing with PPRD or PPWR.

# Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

# **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

# **Syntax**

PSEL<SPACE><Port Handle><SROM Device ID><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
Tool SROM Device ID	16 characters  Use PSRCH (page 121) to determine the SROM device ID.

# **Replies**

### Command:

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Example**

### Command:

PSEL 010B3876530000005B

# Reply:

OKAYA896

# **PSRCH**

Returns a list of valid SROM device IDs for a wired tool or GPIO device.

# Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

### **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

### **Syntax**

PSRCH<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

# **Replies**

### **Upon Success:**

<Number of SROM devices><SROM device 1 ID><SROM device 2 ID>...<SROM device 7 ID> <CRC16><CR>

Note For a single tool or GPIO device, only the first SROM device ID is reported and the remainder are blank. The remaining six positions are reserved for special functionality.

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
Number of SROM devices	1 character
SROM device n ID	16 characters

# **Usage Notes**

The SROM device has an embedded ID, which is a unique, 16 character, alphanumeric identifier. The SROM device ID is used to select an SROM device as a target with PSEL (page 120).

# Example

### Command:

PSRCH 01

# Reply:

10B3876530000005B

7FFF

There are 96 spaces between B and 7. The spaces are place holders for the SROM device ID numbers 2 to 7.

### **PURD**

Reads data from the user section of the SROM device in a wired tool.

# Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

### **Operating Mode**

All modes

### **Prerequisite Command**

INIT (page 89)

### **Syntax**

PURD<SPACE><Port Handle><User SROM Device Address><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
User SROM Device Address	4 hexadecimal characters
	Valid values: 0x0000 to 0x03C0

# Replies

### **Upon Success:**

<SROM Device Data><CRC16><CR>

The SROM device data is 64 bytes (128 hexadecimal characters) of data.

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- The SROM device is automatically selected as the reading target when this command is issued, so you do not need to find and specify the SROM device ID. The SROM device address has an implied offset in the command which places the user information at the correct SROM device address.
- 2. The PURD command returns 64 bytes of data at a time.

# **Command Details**

# Example

### Command:

PURD:010000

# Reply:

### **PUWR**

Writes data to the user section of the SROM device in a wired tool.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Used in hybrid Polaris Vega Systems only.

### **Operating Mode**

Setup

# **Prerequisite Command**

INIT (page 89)

### **Syntax**

PUWR<SPACE><Port Handle><User SROM device address><User SROM device Data><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
User SROM device address	4 hexadecimal characters
	Valid values:
	0x0000 to 0x03C0
User SROM device data	64 bytes of data to write (128 hexadecimal characters)

# **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- 1. The SROM device is automatically selected as the reading target when this command is issued, so you do not need to find and specify the SROM device ID. The SROM device address has an implied offset in the command which places the user information at the correct SROM device address.
- 2. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character).

- 3. The user section of SROM devices is a 1-Kbyte, write-once area that must be written in 64-byte chunks. If the information being written to the system is less than 64 bytes in size, then the remainder of the chunk must be padded out with ones to maintain the 64-byte size before being written to the system.
- 4. The recommended procedure to follow for updating an SROM device is outlined below:
  - a) Read the contents of the SROM device using PURD (page 123).
  - b) Modify the data read.
  - c) Write the modified data back to the SROM device using PUWR.

# **Example**

### Command:

### Reply:

OKAYA896

# **PVWR**

Assigns a tool definition file to a wireless tool, or overrides the SROM device in a wired tool.

### Compatibility

Supported by the Position Sensor since G.001.

# **Operating Mode**

Setup

# **Prerequisite Command**

PHRQ (page 109) or PHSR (page 111)

### **Syntax**

PVWR<SPACE><Port Handle><Start Address><Tool Definition File Data><CR>

Parameter	Description
Port Handle	2 hexadecimal characters
Start Address	4 hexadecimal characters
	Increment the start address by 64 bytes with each chunk of data sent for a particular port handle.
	Valid values:
	0x0000 to 0x3FC0
Tool Definition Data	64 bytes (128 hexadecimal characters) of data

### Replies

### **Upon Success:**

OKAY<CRC16><CR>

# On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

### 1. Use PVWR

- To assign a tool definition file to a wireless tool after using PHRQ.
- To assign a tool definition file to a wired tool, to override the SROM device in the tool.
- To assign a tool definition file to a wired tool, to test the tool definition file before permanently recording the tool definition file onto the SROM device.

- 2. The data must be formatted into unsigned ASCII characters. Each byte of binary data can be represented by two hexadecimal characters, which are then sent to the system in ASCII (4 bits per ASCII character.
- 3. Data is sent to the system in 64-byte chunks (128 hexadecimal characters). The last chunk must be padded out with zeroes to maintain the 64-byte size before being written to the system.
- 4. If a wireless tool port is the target of this command, the port becomes occupied when the first 64 bytes of information is written. Any previous initialization for the port is lost.
- 5. Use PVWR to assign a tool definition file to a wireless tool after using PHRQ (page 109).
- 6. After using PVWR, enable (PENA) the port handle in order to track the tool.
- 7. To permanently write a tool definition file to an SROM device, use PPWR (page 118).

# **Example**

### Command:

### Reply:

OKAYA896

# **RESET**

Resets the system.

# Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

# **Operating Mode**

All modes

# **Syntax**

RESET<SPACE><Reset Option><CR>

Parameter	Description	
Reset Option	Optional. Specifies the type of reset. If no reset option is specified, the system performs a RESET 0.	
	The reset options cannot be OR'd.	
	Valid Values:	
	0 Generates a soft reset. Does not power cycle the Position Sensor.	
	1 Performs a board-level reset of all hardware devices.	

# **Replies**

### **Upon Success:**

RESET<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Example**

### Command:

RESET 0

# Reply:

RESETBE6F

### **SAVE**

Saves all non-volatile user parameters that have been changed.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

### **Operating Mode**

All modes

### **Syntax**

SAVE<SPACE><CR>

### **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

# **Usage Notes**

- 1. To restore the user parameters to factory default values, use the DFLT (page 77) command. To save the user parameters at their factory default values, use the SAVE command after using the DFLT command.
- 2. On systems that have the Password Protect keyed feature enabled, user parameters can only be saved after the correct password is entered. To enter the password, use **SET Config.Password=** password>, where password> is the correct password. For more information on the Password Protect keyed feature, see the user guide that accompanied the system.
- 3. To set user parameter values, use the SET (page 131) command.
- 4. For more information on user parameters, see "User Parameters" on page 19.

### **Example**

### Command:

SAVE

### Reply:

OKAYA896

### **SET**

Sets user parameter values.

### Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

### **Operating Mode**

All modes

# **Syntax**

SET<SPACE><User Parameter Name>=<Value><CR>

Parameter	Description
User Parameter Name	A case-sensitive string, identifying the name of the user parameter.
Value	The value to set.  Numerical values are decimal unless preceded by 0x. For boolean values, 1 is true and 0 is false.

# **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

### **Usage Notes**

- 1. To view a list of user parameters and their current values, use **GET**\*. For a description of the user parameters, use **GETINFO**\*.
- 2. The user parameter values set using the SET command persist until the system is reset or initialized. To save the user parameter values, use SAVE (page 130). To reset user parameters to their default values, use DFLT (page 77).
- 3. User parameter names are case-sensitive.
- 4. For more information on user parameters, see "User Parameters" on page 19

# Example

# Command:

SET Param.Tracking.Sensitivity=1

# Reply:

OKAYA896

This sets the infrared light sensitivity level to level 1 on the first Position Sensor in the configuration.

# **SFLIST**

Returns information about the supported features of the system.

# Compatibility

Supported by the Position Sensor since G.001.

# Deprecated.

# **Operating Mode**

Setup, diagnostics or tracking

# **Syntax**

SFLIST<SPACE><Reply Option><CR>

Parameter	Description		
Reply Option	Specifies which information will be returned.		
	The reply options cannot be OR'd.		
	Valid values:		
	00 Summary of supported features		
	01 Number of active tool ports		
	02 Number of wireless tool ports		
	Number of measurement volumes and wavelengths; volume shapes and supported wavelengths		
	O4 The number of wired tool ports available which support tool-in-port detection from current sensing		
	05 Number of active wireless tools		

The reply options cannot be OR'd.

# **Replies**

# **Upon Success:**

<Reply Option n Data><CRC16><CR>

### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description		
Reply Option n Data	The data specific to the requested reply option. See the reply option information below for details:		
	Reply option 00 (Summary of supported features)		
	Reply option 01 (Number of active tool ports)		
	Reply option 02 (Number of wireless tool ports)		
	Reply option 03 (Number of characterized measurement volumes and wavelengths; volume shapes and supported wavelength)		
	Reply option 04 (The number of wired tool ports available which support		
	tool-in-port detection from current sensing)		
	Reply option 05 (Number of active wireless tools)		

# Reply Option 00 - Supported Features Summary

Reply Component	Description		
Reply Option 00 Data	8 hexadecimal characters (32 bits)		
	Bit field:		
	bit 0	Active tool ports available	
	bit 1	Passive tool ports available	
	bit 2	Multiple volume characterization parameters supported	
	bit 3	Tool-in-port from current sensing available	
	bit 4	Active wireless tool ports available	
	bit 5	Reserved	
	bits 7 to 31	Reserved	

# Reply Option 01 - Number of Active Tool Ports

Reply Component	Description
Reply Option 01 Data	1 hexadecimal character
	The number of wired tool ports.

# Reply Option 02 - Number of Wireless Tool Ports

Reply Component	Description
Reply Option 02 Data	1 hexadecimal character
	The number of wireless tool ports, up to a maximum of 15 (the highest number that can be represented in one hexadecimal digit).
	To find out the actual number of wireless tool ports, read the parameters <b>Features.Tools.Passive Ports</b> (for passive wireless)
	and Features. Tools. Wireless Ports (for active wireless).

# **Reply Option 03 - Volumes**

# Note Because SFLIST is deprecated, the Volume User Parameters on page 40 should be used instead.

```
<Reply Option 03 Data> =
<Number of Volumes>
<1st Shape Type><1st Shape Parameter><1st Number of Wavelengths Supported><1st
Supported Wavelengths><LF>
...
<nth Shape Type><nth Shape Parameter><nth Number of Wavelengths Supported><nth
Supported Wavelengths><LF>
```

Reply Component	Description	
Number of Volumes	1 hexade	cimal character
n <sup>th</sup> Shape Type	1 hexadecimal character	
	Possible	values:
	5	Extended Pyramid Shape
		The volumes are named "Pyramid", "Extended Pyramid"
	7	Arc Shape
		The volume name is "Vicra"
		Vega Position Sensors do not support this shape
n <sup>th</sup> Shape Parameter	10 parameters, 7 characters each (a sign, and six digits with an implied decimal in the position XXXX . XX)	
n <sup>th</sup> Number of Wavelengths Supported	1 hexadecimal character	
n <sup>th</sup> Supported Wavelengths	1 character per wavelength supported	
	Possible	values:
	0	930 nm (see "Usage Notes" on page 138)
	1	880 nm
	4	870 nm
	7	850 nm

# Reply Option 04 - Number of Active Tool Ports Supporting Tool-in-Port Detection From Current Sensing

Reply Component	Description
Reply Option 04 Data	1 hexadecimal character

# Reply Option 05 - Number of Active Wireless Ports

Reply Component	Description
Reply Option 05 Data	1 hexadecimal character


# **Polaris Vega System - Shape Parameters**

# Note

Because SFLIST is deprecated, the Volume User Parameters on page 40 should be used instead.

For the pyramid measurement volume, <Shape Parameter> in reply option 03 returns the following values (illustrated in Figure 5-2):

Shape Parameter	Value	Description
D1	-2400 mm	z-coordinate of back of volume
D2	-1532 mm	z-coordinate where sides of volume change slope
D3	-950 mm	z-coordinate of front of volume
D4	572 mm	Half width of volume at $z = D2$
D5	398 mm	Half height of volume $z = D2$
D6	0569.46	Slope of front part of volume sides in the yz-plane (scaled by 1000)
D7	0243.03	Slope of back part of volume sides in the yz-plane (scaled by 1000)
D8	0297.73	Slope of volume top and bottom in the <i>xz</i> -plane (scaled by 1000)
D9	9999.99 mm	Maximum half width of volume (unrestricted)
D10	9999.99 mm	Maximum half height of volume (unrestricted)







Figure 5-2 Pyramid Volume Parameters (Polaris Vega)

For the extended pyramid measurement volume, <Shape Parameter> in reply option 03 returns the following values (illustrated in Figure 5-2 and Figure 5-3):

Shape Parameter	Value	Description
D1	-3000 mm	z-coordinate of back of volume
D2	-1532 mm	z-coordinate where sides of volume change slope
D3	-950 mm	z-coordinate of front of volume
D4	572 mm	Half width of volume at $z = D2$
D5	398 mm	Half height of volume $z = D2$
D6	0569.46	Slope of front part of volume sides in the <i>yz</i> -plane (scaled by 1000)
D7	0243.03	Slope of back part of volume sides in the yz-plane (scaled by 1000)
D8	0297.73	Slope of volume top and bottom in the <i>xz</i> -plane (scaled by 1000)
D9	9999.99 mm	Maximum half width of volume (unrestricted)
D10	735 mm	Maximum half height of volume






Figure 5-3 Extended Pyramid Volume Parameters (Polaris Vega)

## **Usage Notes**

- 1. Use both the shape type and the shape parameters to represent the characterized measurement volume graphically. There may be multiple volumes with the same shape type. All volumes of the same shape type use the shape parameters the same way.
- 2. **Reply option 03**: A characterized measurement volume that supports wavelength value 0 (930 nm) supports the wavelength values of 000 (9x0 nm) and 010 (930 nm) returned with PHINF (page 103).

#### **Examples**

#### Command:

SFLIST


### Reply:

0000003FEEEC

#### Command:

SFLIST 03





## **STREAM**

Initiates a streaming response to a command.

#### Compatibility

Supported by the Position Sensor since G.003.

## **Operating Mode**

All modes

### **Syntax**

STREAM<SPACE><Parameter><CR>

Parameter	Description
[id= <id string="">]</id>	id= <id string=""> is an optional id string that will be returned in the stream response header. If it contains spaces it must be quoted. If it is omitted the command string will be used as the id. ids must be unique to the given connection.</id>
[interval= <frame count=""/> ]	interval= <frame count=""/> is an integer frame count interval that will be used to limit the response rate.
[diff=true]	diff=true when present indicates that only the differences between the current response and the last streamed response will be sent. At present this option is valid for ascii responses to commands such as GET and GETINFO.
[cmd=] <command stream="" to=""/>	<pre><command stream="" to=""/> is the command string exactly as it would be if issued separately. For consistency and flexibility it is also possible to spec- ify the command using optioncmd=<command stream="" to=""/></pre>

## **Replies**

**Upon Success:** 

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

#### Note

The response is binary and is similar to the BX binary response with a different header signature. In order to maintain compatibility with the serial protocol, all binary replies are in little endian format rather than network byte order. The header signature is a 2 byte little endian code. The first byte is 0xD4 the second byte is 0xB5.

**B5D4**<Stream ID Length(2 bytes)><Stream ID><Header CRC16><command reply>

<command reply> is the unmodified reply for the command that is being streamed exactly as it would
appear if the command were given separately without streaming.

## **Usage Notes**

For details on data streaming format see "Data Streaming" on page 7.

## Example

Command:

STREAM BX 0803

## Reply:

OKAYA896

The following would continue with updated data replies until USTREAM is issued

**B5D4**0700BX 08031234**A5C4**....

...

## **SYSLOG**

Writes data to the device's event log.

## Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

#### **Operating Mode**

All modes

## **Syntax**

SYSLOG<SPACE>\<Device Name>\<Category>=<Message><CR>

or

SYSLOG<SPACE><Category>=<Message><CR>

Parameter	Description
Device Name	Selects a hardware device to write to. See "Device Names" on page 20 for information on device names. The device name is ignored if it is specified.
Category	A string, up to 12 characters  Specifies the log entry category or source. If you enter more than 12 characters, the system will truncate the category to 12 characters.
Message	A string, up to 256 characters.  Contains the log message. If you enter more than 256 characters, the system will truncate the message to 256 characters.

### Replies

#### **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

- 1. The system log in each hardware device is intended to record events central to the life of the device. The system automatically records events such as updates, bump sensor events, and hardware faults in the log.
- 2. To read the log, use GETLOG (page 87).

## **Command Details**

# Example

## Command:

SYSLOG Test=This is a SYSLOG test!

# Reply:

OKAYA896

### **TCTST**

Returns diagnostics on the active markers of a wired tool.

#### Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

#### **Prerequisite Command**

PINIT (page 114)

### **Syntax**

TCTST<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

### **Replies**

#### Upon success:

<Marker A Current><Marker B Current>...<Marker T Current><CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description			
Marker n Current	2 hexadecimal characters			
	The electrical current of the markers.			

### **Usage Notes**

- 1. If the result is less than 0x0A either there is no marker, or there is a problem with the diode that has caused an open circuit.
- 2. If the result is greater than 0x0A the marker is either okay or it has short-circuited. The exact value cannot be predicted as it depends upon the System Control Unit and the tool design (cable length, number of markers, and marker configuration). This value should be determined on a historical basis for each particular tool design.
- 3. You cannot test a visible LED, since the System Control Unit cannot reliably test the low current of an LED because the LED current result may be corrupted from electrical noise.

# Example

# Command:

TCTST 01

## Reply:

9400000009401000000920000000940000000DF24

## **TSTART**

Starts Tracking mode.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

## **Prerequisite Command**

INIT (page 89)

### **Syntax**

TSTART<SPACE><Reply Option><CR>

Parameter	Description
Reply Option	80 (Optional)

## **Replies**

## **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

The frame number is reported in reply option 0001 of the TX (page 150) and BX (page 53) commands. In the Polaris Vega System, the frame number is derived from the PTP time, and reply option 80 is ignored.

In order to facilitate the retrieval of tracking data in a monitor connection, TSTART will return OKAY when in tracking mode.

### Example

#### Command:

TSTART

## Reply:

OKAYA896

## **TSTOP**

Stops tracking mode.

## Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Tracking

# **Prerequisite Command**

TSTART (page 146)

## **Syntax**

TSTOP<SPACE><CR>

## **Replies**

### **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

If executed from the Setup mode, it will return OKAY.

## **Example**

### Command:

TSTOP

## Reply:

OKAYA896

## **TTCFG**

Sets up a configuration for a wired tool, so that you can test the tool without using a tool definition file.

#### Compatibility

Supported by the Position Sensor since G.001.

## **Operating Mode**

Setup

## **Prerequisite Command**

INIT (page 89)

#### **Syntax**

TTCFG<SPACE><Port Handle><CR>

Parameter	Description
Port Handle	2 hexadecimal characters

## Replies

#### **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

- 1. TTCFG internally sets up a test configuration for a wired tool, so that it can be tested without having a tool definition file. This is useful for testing the wiring in the tool before characterizing the tool. For example, after sending TTCFG, you can:
  - use TCTST to test the current
  - in diagnostic mode, use IRED to individually activate the markers.
- 2. After sending the TTCFG command, you will need to enable (PENA) the port handle before using any other commands that list these as prerequisites.
- 3. With the test configuration, the tool cannot be tracked.

## **Command Details**

# Example

Command:

TTCFG 0A

Reply:

OKAYA896

## TX

Returns the latest tool transformations, individual marker positions, and system status in text format.

## Compatibility

Supported by the Position Sensor since G.001.

BX2 is recommended for new application development.

## **Operating Mode**

Tracking

## **Syntax**

TX<SPACE><Reply Option><CR>

Parameter	Description						
Reply Option	Optional. Specifies which information will be returned. If no reply option is specified, the system returns information for reply option 0001.						
	The reply options are hexadecimal numbers that can be OR'd. If multiple reply options are used, the replies are returned for each port handle in order of increasing option value, with the following exceptions:  Reply option 0800 is not reported separately from the other options; it simply enables the system to return certain information in the other options.  Reply option 1000 is reported after all handle-specific options but before the <system status=""> and <crc16>.  Valid Values:</crc16></system>						
	0001 Transformation data (default)						
	0002 Tool and marker information						
	0004 3D position of a single stray active marker						
	0008 3D positions of markers on tools						
	0800 Transformations not normally reported						
	1000 3D positions of stray passive markers						

## **Replies**

#### **Upon Success:**

```
<# of Handles><Handle 1><Reply Opt 0001 Data>...<Reply Opt 0008 Data><LF>
<Handle n><Reply Option 0001 Data>...<Reply Option 0008 Data><LF>
<Reply Option 1000 Data><System Status><CRC16><CR>
```

Note If the port handle is disabled, the system returns the string DISABLED instead of <Reply Option 0001 Data>...<Reply Option 0008 Data>.

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description						
Number of Handles	2 hexadecim	2 hexadecimal characters					
	The number	The number of port handles for which information is returned.					
Handle n	2 hexadecim	nal characters					
	The port har	ndle whose information follows.					
Reply Option m		ecific to the requested reply option. See the reply mation below for details:					
Data	Reply option	1 0001 (transformation data) (default)					
	Reply option	1 0002 (tool and marker information)					
	Reply option marker)	Reply option 0004 (latest 3D position of single, stray, active marker)					
	Reply option	Reply option 0008 (3D position of markers on tools)					
	Reply option	Reply option 0800 (reporting all transformations)					
	Reply option	1 1000 (3D position of stray passive markers)					
System Status		nal characters (16 bits)					
	The status of	f the system.					
	Bit field:						
	bit 0	System communication synchronization error					
	bits 1 and 2	Reserved					
	bit 3	Recoverable system processing exception.					
	bit 4-5	Reserved					
	bit 6	Some port handle has become occupied					
	bit 7	Some port handle has become unoccupied					
	bit 8	Diagnostic pending					
	bit 9	Temperature (system is not within operating temperature range)					
	bit 10	Hardware configuration changed (e.g. VCU or SCU has connected or disconnected)					
	bits 11 to 15	Reserved					

Note The "diagnostic pending" bit is set whenever an alert is detected or cleared. To view the alerts status and clear the diagnostic pending bit, use GET (page 82) to check the Info.Status.New Alerts user parameter for every

hardware device in the system. See "Usage Notes" on page 62 for more details. (Note: For API revision G.001.003 and earlier, the diagnostic pending bit did not indicate when an alert was cleared.)

## **Reply Option 0001 - Transformation Data**

```
<Reply Option 0001 Data> = <Q_0><Q_x><Q_y><Q_z><T_x><T_y><T_z><Error><Port Status> <Frame Number> or <Reply Option 0001 Data> = MISSING<Port Status><Frame Number>
```

Reply Component	Description				
Q0, Qx, Qy,	6 characters each				
Qz	(a sign, and 5 decimal digits with an implied decimal in the position X . XXXX)				
	Rotational component of the transformation, quaternion, unit- less. The value for Q0 is always non-negative.				
Tx, Ty, Tz	7 characters each				
	(a sign, and 6 decimal digits with an implied decimal in the position XXXX . XX)				
	Translational components of the transformation, in mm.				
Error	6 characters				
	(a sign, and 5 decimal digits with an implied decimal in the position X . XXXX)				
	The error is an RMS value, given in mm. It is the result of the least squares minimization between the marker geometry in the tool definition file and the data from the tool's markers measured by the system.				

Reply Component	Description								
Port Status	8 hexadecimal characters (32 bits)								
	Bit field:								
	bit 0 Occupied								
	bit 1	bit 1 Switch 1 closed							
	bit 2	bit 2 Switch 2 closed							
	bit 3	Switch 3 closed							
	bit 4	Initialized							
	bit 5	Enabled							
	bit 6	Out of volume							
	bit 7	Partially out of volume							
	bit 8 Algorithm limitation (processing requires more buffer than is available)								
	bit 9 IR interference (a large bright IR object)								
	bits 10 and 11	11							
	bit 12	bit 12 Processing exception (same as tool information bit 7 in reply option 0002)							
	bit 13 Reserved								
	bit 14	Fell behind while processing (same as tool information bit 3 in reply option 0002)							
	bit 15	Data buffer limitation (too much data; for example, too many markers)							
	bits 16 to 31 Reserved								
Frame Number	8 hexadecimal characters								
	The frame number is an internal counter related to data acquisition, which is derived from the PTP time. The frame number corresponds to the frame in which the raw data, used to calculate the accompanying transformation, was collected.								

Note The system returns the string MISSING, followed by the port status and frame number, in the following situation:

<sup>-</sup> Tools are reported as missing if a transformation cannot be determined.

## Reply Option 0002 - Tool and Marker Information

<Reply Option 0002 Data> = <Tool Information><Marker Information>

Reply Component	Description							
Tool Information	2 hexadecimal characters (8 bits)							
	Bit field:							
	bit 0	bit 0 Bad transformation fit						
	bit 1	Not enough acceptable markers for transformation						
	bit 2	IR interference—environmental IR is interfering with the system (combination of port status bits 9 and 15 in reply option 0001)						
	bit 3	Fell behind while processing (same as port status bit 14 in reply option 0001)						
	bits 4 to 6							
	bit 7	Processing exception (same as port status bit 12 in reply option 0001)						
Marker	20 hexade	ecimal characters (1 per marker)						
Information	See below for an example.							
	Possible '	Values:						
	0	Not used because it was missing						
	1	Not used because it exceeded the maximum marker angle						
	2	Not used because it exceeded the maximum 3D error for the tool						
	3	Used to calculate the transformation						
	4	Used to calculate the transformation, but it is out of volume						
	5	Not used because it was outside the characterized measurement volume and was not needed to calculate a transformation.						

**Example - Marker Information:** A tool with markers located at T, R, C, and A, where all four markers were used to determine the calculation, would have the reply 3030000000000000303, as illustrated:

Marker Letter	T	S	R	Q	 D	С	В	A
Reply Char (Hex)	3	0	3	0	 0	3	0	3

## Reply Option 0004 - 3D Position of Single Stray Active Marker

```
<Reply Option 0004 Data> = \langle Status \rangle \langle T_x \rangle \langle T_y \rangle \langle T_z \rangle
or
<Reply Option 0004 Data> = <Status>
```

Reply Component	Descripti	on							
Status	2 hexadeo	2 hexadecimal characters (8 bits)							
	active too	The status of the stray active marker. A stray marker on an active tool is not fixed with respect to the other markers tha make up the tool.							
	Bit field:								
	bit 0	Valid stray active marker							
	bit 1	Marker is missing							
	bit 2	Reserved							
	bit 3	Marker is out of volume							
	bits 4 to 7	Reserved							
Tx, Ty, Tz	7 characte	ers each							
		nd 6 decimal digits with an implied decimal in the XXXX . XX)							
	Position of the marker, reported in the coordinate system the Position Sensor. The marker position is reported only the marker status is "valid," or if the status is "out of volume" and reply option 0800 is used.								

Note If no stray active marker is defined (for example, for wireless port handles or wired tools with no stray marker defined in the tool definition file), the status is 00, and no position information is returned. If the marker is missing, or if the marker is out of volume and reply option 0800 is not used, the system returns only the status.

## Reply Option 0008 - 3D Position of Markers on Tools

<Reply Option 0008 Data> = <Number of Markers><Out of Volume>< $T_{xn}$ >< $T_{yn}$ >< $T_{zn}$ >

Reply Component	Description
Number of Markers	2 hexadecimal characters
	Number of markers used in tool transformations.
Out of Volume	1 hexadecimal character per 4 markers (1 bit per marker)
	The bit is set when the marker is outside the characterized measurement volume (see example below).
	Reply size = (number of markers)/4, rounded up to the nearest integer.
Txn, Tyn, and	7 characters each
Tzn	(a sign, and 6 decimal digits with an implied decimal in the position XXXX . XX)
	Position of the n <sup>th</sup> marker, reported in the coordinate system of the Position Sensor. The system will report the positions of markers used in tool transformations, as well as markers that exceeded the maximum marker angle or maximum 3D error specified in the tool definition file.
	See "Usage Notes" on page 159 for more information.
	Reply size:
	If reply option 0800 is not used, reply size = (21 characters) x (number of markers inside the characterized measurement volume).
	If reply option 0800 is used, reply size = (21 characters) x (total number of markers).

**Example - Out of Volume:** The information is returned in the format illustrated in the following example: one bit per marker, in little endian format. In this example there are nine markers, all of which are out of volume:

Marker Number				9	8	7	6	5	4	3	2	1
Bit Field	0	0	0	1	1	1	1	1	1	1	1	1
Reply	1				F				F			

## Reply Option 0800 - Reporting All Transformations

This option enables the reporting of transformations or translations in situations where translations or transformations are calculated, but by default are not reported by the system. Such situations include:

- The tool or marker is outside of the characterized measurement volume.
- The bump sensor has been tripped.
- The system is outside of the optimal operating temperature range.
- Other system conditions are not ideal; see "Alerts User Parameters" on page 22 for a full list of these conditions.

This reply option must be OR'd with reply option 0001 to obtain transformations for tools in the situations listed above. It must be OR'd with reply options 0004, 0008, or 1000 to obtain position information for markers in the situations listed above.



When using reply option 0800 with the TX command, you must take appropriate action to detect the events listed above, and determine whether they are detrimental to your application. If one or more of the events listed above occurs, reply option 0800 enables the system to return data that may lead to inaccurate conclusions and may cause personal injury.

Appropriate action to detect the events listed above includes:

- reading the out-of-volume flag in reply options 0001 and 0002 when tracking tools
- reading the out-of-volume information in reply options 0004, 0008, and 1000 when tracking stray markers
- reading the temperature flag in the system status
- reading the diagnostic pending bit in the system status
- reading the **Info.Status.New Alerts** user parameter for every hardware device in the system when the diagnostic pending bit is set. See "Usage Notes" on page 159 for details.

## Reply Option 1000 - 3D Position of up to 50 Stray Passive Markers

<Reply Option 1000 Data> = <Number of Markers><Out of Volume>< $T_{xn}$ >< $T_{yn}$ >< $T_{zn}$ >

Reply Component	Description
Number of Markers	2 hexadecimal characters
	Number of stray markers.
Out of Volume	1 hexadecimal character per 4 markers (1 bit per marker)
	The bit is set when the marker is outside the characterized measurement volume (see example below).
	Reply size = (number of markers)/4, rounded up to the nearest integer.
Txn, Tyn, Tzn	7 characters each
	(a sign, and 6 decimal digits with an implied decimal in the position XXXX . XX)
	Position of the n <sup>th</sup> marker, reported in the coordinate system of the Position Sensor.
	Reply size:
	If reply option 0800 is not used, reply size = (21 characters) x (number of markers inside the characterized measurement volume).
	If reply option 0800 is used, reply size = (21 characters) x (total number of markers).

Note At least one passive port handle must be enabled, to activate the illuminators on the Position Sensor. If no passive port handles are enabled, <Number of Markers> will return 00 and no other data will be returned.

Stray passive markers are defined as markers which are not used to calculate any of the transformations for any enabled, passive tools. Stray active wireless tool markers are not reported.

**Example - Out of Volume** The information is returned in the format illustrated in the following example: one bit per marker, in little endian format. In this example there are nine markers, all of which are out of volume:

Marker Number				9	8	7	6	5	4	3	2	1
Bit Field	0	0	0	1	1	1	1	1	1	1	1	1
Reply	1				F				F			

#### **Usage Notes**

- 1. The TX format is easier to parse than the binary format; it is useful when troubleshooting, or observing data as it is collected. For replies in binary format, use BX2 (page 64).
- 2. By default, transformations will not be reported if the tool is either partially or wholly out of the characterized measurement volume, if the bump sensor has been tripped, or if the system is outside of the optimal operating temperature range. To report these transformations, you must use reply option 0800 OR'd with the desired reply option(s). The accuracy of these transformations is unknown.

### 3. Reply Option 0001:

- When the "diagnostic pending" bit is set in the system status, use GET (page 82) to read the **Info.Status.New Alerts** user parameter for every hardware device in the system. The act of reading these parameters clears the parameters and the "diagnostic pending" bit. For more information on alerts and their associated user parameters, see "Alerts User Parameters" on page 22.
- For wired tools, bits 1, 2, and 3 in the port status report switch status.
- 4. Reply Option 0008: Markers are returned in alphabetical order according to how they are labelled in the tool definition file. For example, for a tool with markers labelled A, G, M and S, the system will return the marker positions in the order A G M S. Reply option 0008 only returns data for markers that the system detects. To identify which marker is which, compare the reply option 0008 data to the data returned with reply option 0002. The marker order is the same for both replies; each marker that does not have a <marker information> status of 0 ("missing") in reply option 0002 corresponds to a marker in reply option 0008
- 5. **Reply Option 1000**: At least one passive tool definition file must be initialized and enabled in order for the system to return stray passive marker data. If no passive tool definition files are enabled, this reply option will return 00.

#### 6. System Status:

• In API revision G.001.004 and later, the diagnostic pending bit (bit 8) is set whenever an alert is detected or cleared. In API revision G.001.003 and earlier, the diagnostic pending bit is set only when an alert is detected.

#### **7. Reply Option 0002:**


• Marker information value 2 means that the marker was not used because it exceeded the maximum 3D error for the tool.

#### Example 1

## Command:

TX 0001

Reply:




The system reports that there is one tool, which is missing. Notice the port status, which indicates that the tool is occupied, initialized, enabled, and out of volume.

## Example 2

## Command:

TX 0801

#### Reply:




With the 0800 reply option applied, the system reports the missing tool. Notice the port status, which indicates that the tool is occupied, initialized, enabled, and out of volume.

## Example 3

Command:

TX 0001

Reply:




The system reports that there is one tool, whose port handle is disabled. It also reports the system status.

## Example 4

Command:

TX 1001

#### Reply:



The system reports the transformation for one tool (first line of the reply), and the positions of three stray passive markers (second line of the reply).

## **USTREAM**

Terminates a streaming response to a command.

## Compatibility

Supported by the Position Sensor since G.003.

## **Operating Mode**

All modes

## **Syntax**

```
USTREAM --id=<id string><CR>
--id= is optional
```

## **Replies**

## **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Example**

#### Command:

USTREAM BX 0803

## Reply:

OKAYA896

The stream of "B5D40700BX 08031234A5C4...." messages stops.

## **VCAP**

Captures and returns IR image data from the IR sensors and/or the Vega Video Camera Unit.

## Compatibility

Supported by the Position Sensor since G.003. Includes enhanced functionality since G.003.004.

Supported by the Video Camera since V.001.

VGET and VSNAP are recommended when using serial communications due to the latency introduced in VCAP when retrieving an image.

## **Operating Mode**

Tracking

## **Syntax**

VCAP<SPACE><Parameters><CR>

Parameter	Description	Sensor
action=capture  return all	Specifies whether new images should be only captured (capture), only returned (return), or both captured and returned (all). When capture is specified, no image data is returned regardless of any other parameter setting. The default is all.	IR + Video
type=IR video all	Specifies whether the command action applies to the IR sensors (IR), the video sensor (video), or both the IR and video sensors simultaneously (all). When IR is specified video-specific options are ignored and when video is specified IR-specific options are ignored. The default is IR.	IR + Video
frame=passive active  activewireless  background illuminated al	Specifies what type of frame in the IR frame sequence to return. When VCAP is sent with no parameters, the next available frame type is returned. The Param.Tracking.Illuminated (Background) Frame parameters must be set to 1 before frames will be returned. When all is specified, all frame indexes of the specified frame type will be returned.	IR
frameindex= <frame index&gt; all</frame 	Specifies which frame in the IR frame sequence to return. This is useful when the system is configured with more than one frame of a particular type (e.g. two active frames) and only one of them needs to be returned. When VCAP is sent with no frame index, the next available frame type is returned. When all is specified, all frame indexes of the specified frame type will be returned.	IR
sensor= <sensor number&gt; all</sensor 	Specifies which IR sensor to capture an image from. By default, or if all is specified, both sensors are used. The left sensor (sensor 0) is returned first, followed by the right sensor (sensor 1).	IR
format=RAW TIFF PGM	Specifies the IR image format. By default, RAW is used.	IR
depth= <bits-per-pixel></bits-per-pixel>	Specifies the number of bits to use per pixel. Valid values are 1, 2, 4, 8 and 16. The default is 16.	IR

Parameter	Description	Sensor
stride= <number of="" pixels=""></number>	Specifies the pixel-read step size. For example, a stride of 4 means that every fourth pixel is returned. The default is 1 (i.e. return every pixel).	IR
sample=pixel  average peak	If stride is greater than 1, this specifies how to sample the intermediate pixels. The default is pixel (i.e. intermediate pixels are ignored).	IR
area= <x, height="" width,="" y,=""></x,>	Specifies the area of the image to be returned. The maximum size of the image is 1920 x 1200. The default is to return the whole image. If the stride parameter is defined, the area returned will be a subset of the area that is defined.	IR
vid_format=JPEG	Specifies the video image format. JPEG is the only option supported today. The default is JPEG.	Video
vid_exp_bracket_ adjust= <incremental positive and negative EV adjustment per additional video image pair&gt;</incremental 	Floating-point amount of EVs to adjust per incremental pair of underand over-exposed video images. One (1) EV is equal to one (1) exposure step (or stop), corresponding to a doubling or halving of exposure. For example, increasing the EV by one(+1) will result in halving the exposure time and decreasing the EV by one(-1) will double the exposure. Ignored if exposure bracketing depth is set to 0. The maximum amount of EVs that may be adjusted by the end of the exposure bracketing depth is 5.0. The default is 0.33.	Video
vid_exp_bracket_ depth= <number adjusted="" capture="" exposure="" images="" increasing="" incremental="" of="" pairs="" to="" video="" with=""></number>	If set to 1, three video images will be captured at the following indexes and exposures:   Index 0: normal EV( $t_0$ ) Index 1: normal EV + vid_exp_bracket_adjust * 1EV $ (t_1 = t_0 * 2^{-\text{vid}} \text{exp\_bracket\_adjust}) $ Index 2: normal EV - vid_exp_bracket_adjust * 1EV $ (t_2 = t_0 * 2^{\text{vid}} \text{exp\_bracket\_adjust}) $ The maximum is 1, the default is 0.	Video
vid_read_index= <index of<br="">first captured video image to return&gt;</index>	Index of captured video image at which to begin reading. The default is 0.	Video
vid_read_length= all  <number captured="" images="" of="" return="" to="" video=""></number>	Number of captured video images to return, starting at the specified read index. Maximum is (1 + 2 * vid_exp_bracket_depth). The default is all.	Video

## **Replies**

## **Upon Success:**

A5C8<4 byte Reply Length><command reply>or A5C4<2 byte Reply Length><2 byte Header CRC><command reply><2 byte Data CRC>

 $\textbf{Note} \quad \textbf{The} < \texttt{command reply} > \textbf{payload is in the General Binary Format, which is documented in the section}$ "General Binary Format" on page 5.

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Image Data Component: 0x000A

Image Component Header	,		
Item Type	1 byte	0=RAW, 1=PGM, 2=TIFF, 3=JPEG	IR+Video
Sensor	1 byte	Sensor number (0-127 IR, 128 Video)	IR+Video
Frame Type	1 byte	Frame type (see BX2)	IR
Frame Index	1 byte	Frame sequence/read index	IR+Video
Frame Number	4 bytes	Frame number	IR
Trigger Threshold	4 bytes	Trigger threshold, percentage of full scale (float)	IR
Background Threshold	4 bytes	Background threshold, percentage of full scale (float)	IR
Exposure	2 bytes	Exposure in microseconds	IR
Stride	1 byte	Pixel stride count	IR
Image Depth	1 byte	Bits per pixel	IR+Video
Image Area	8 bytes	X, Y, Width, Height (2 bytes each)	IR+Video
Meta data length (M)	4 bytes	Length of optional meta data. Must be multiple of 4	IR+Video
Meta data	M bytes	Optional meta data	IR+Video
Image Item		The image data	IR+Video

PGM format images have the following meta data embedded as comments:

```
# frame_type = <frame type>
# frame_number = <frame number>
# sensor = <sensor number>
# exposure = <exposure time>
# trigger_threshold = <% of full scale>
# background_threshold = <% of full scale>
# stride = <stride pixel count>
# depth = <bits per pixel>
# area = <x,y,width,height>
```

Optional meta data for IR images:

timestamp = <date time string>: Date and time when IR image was captured.

Optional meta data for video images:

timestamp = <date time string>: Date and time when video image was captured.

**bracket index=<integer>**: The index of the image in the exposure bracket sequence.

**exposure** = **<exposure** time us>: Exposure time of captured video image in microseconds. The value of the Exposure field in the Image Component Header is set to 0.

## **Examples**

#### Command:

VCAP

## Reply:

9.2 MB of data in GBF format, consisting of two image components (one for each sensor), each showing the entire image (1920 x 1200 pixels x 16 bits of gray scale) in RAW format.

#### Command:

```
vcap --sensor=0 --stride=2 --format=tiff --depth=8
```

## Reply:

576,326 bytes of data in GBF format, consisting of one image component (for the left sensor), showing 960 x 600 pixels (sampling every second pixel in every second row of the entire image), in 8-bit gray scale, in TIFF format.

## **VER**

Returns the firmware revision number of critical processors installed in the system.

## Compatibility

Supported by the Position Sensor and System Control Unit since G.001.

Supported by the Video Camera since V.001.

## **Operating Mode**

All modes

## **Syntax**

VER<SPACE><Reply Option><CR>

Parameter	Des	cription					
Reply Option	Spe	Specifies which information will be returned.					
	The	reply options cannot be OR'd.					
	Vali	d Values:					
	0	System Control Processor					
	1	Reserved					
	2	Reserved					
	3	System Control Unit Processor, only supported by hybrid systems					
	4	System Control Processor, with enhanced revision numbering.  The revision numbering is XXX.YYY, where XXX = major revision and YYY = minor revision. The major revision number is always the same as the revision number for parameter value 0.					
	5	Combined firmware revision number. The revision numbering format is XXX. Only the number is reported; there is no information about the type of system.					
	6	Reserved					

## Replies

## **Upon Success:**

## Reply Options 0, 3, 4:

```
<Type of Firmware><LF>
<NDI Serial Number><LF>
<Characterization Date><LF> (included only for Reply Option 0 and 4)
<Freeze Tag><LF>
<Freeze Date><LF>
```

```
<Copyright Information><LF> <CRC16><CR>
```

## **Reply Option 5:**

<Combined Firmware Revision><CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

#### **Usage Notes**

- 1. If you send the command VER 5 after the INIT command has replied with ERROR2E, the reply will be ???, because component versions are incompatible.
- 2. You can also obtain the combined firmware revision of the system by using the command GET (page 82) to read the value of the user parameter **Config.Combined Firmware Revision**. See "User Parameters" on page 19 for more information on user parameters.
- 3. Reply Option 3: Only supported by hybrid systems.

### **Examples**

#### Command:

VER 4

#### Reply:

```
Polaris Vega Control Firmware
NDI S/N: P9-B0058
Characterization Date: 06/09/16
Freeze Tag: Polaris Vega Beta 008.002
Freeze Date: June 20 2016
(c) Northern Digital Inc.
AEBC
```

#### Command:

VER 5

#### Reply:

001BDB5

## **VGET**

The VGET command retrieves data previously captured with VSNAP (page 174).

## Compatibility

Supported by the Position Sensor since G.001.

VGET and VSNAP are recommended when using serial communications due to the latency introduced in VCAP when retrieving an image.

## **Operating Mode**

All modes

## **Prerequisite Command**

VSNAP (page 174)

## **Syntax**

VGET<SPACE><Row><Sensor><Frame Index><Start Column><End Column><Stride><CR>

Parameter	Des	scription							
Row	4 h	exadecimal characters							
	Spe	Specifies the row of data to retrieve.							
	Val	id Values:							
	0 to	the value of the user parameter <b>Cmd.VGet.Sensor.Height</b> - 1.							
Sensor	2 h	exadecimal characters							
	Specifies which sensor's data to return.  Valid values:								
	0	0 Left sensor							
	1	Right sensor							
Frame Index	ex 2 hexadecimal characters								
	The index into the array of frames captured by the VSNAP (page 174) command. Specifies which frame's data to return. The frame index is zero-based.								
		e tool class for each frame is returned in the VSNAP reply; to retrieve information for articular tool class, use the frame index for that frame returned in the VSNAP reply.							

Parameter	Description
Start Column	4 hexadecimal characters
	Indicates the first column to retrieve. Optional (see "Usage Notes" on page 171).
	Valid Values:
	0 to the value of the user parameter <b>Cmd.VGet.Sensor.Width</b> - 1.
End Column	4 hexadecimal characters
	Indicates the last column to retrieve. Optional (see "Usage Notes" on page 171).
	Valid Values:
	0 to the value of the user parameter <b>Cmd.VGet.Sensor.Width</b> - 1.
Stride	2 hexadecimal characters
	Indicates the stride count to use from start to end column. A lower stride count results in a higher resolution. The stride options are described in "Usage Notes" on page 171. To specify which stride option to use, set the value of the user parameter Cmd.VGet.Sample Option. Optional (see "Usage Notes" on page 171).

# Replies

## **Upon Success:**

<Header><Length><HeaderCRC><Data><DataCRC>

Note The reply for the VGET command is binary data.

## On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
Header	2 bytes: A5C4
	Indicates the start of the VGET reply.
Length	2 bytes
	Indicates data length.
Header CRC	2 bytes
	CRC16 for header.
Data	Up to 2048 bytes of binary data. The data is a sequence of grey-scale pixel intensities. The intensity for each pixel is given by x bits of data, where x is the value of the user parameter <b>Cmd.VGet.Color Depth</b> (see "Usage Notes" on page 171). A pixel inten-
	sity of 0 is black, and an intensity of $2^x$ -1 is white.

Reply Component	Description
DataCRC	2 bytes
	CRC16 of the <data> section.</data>

### **Usage Notes**

- 1. The VGET command retrieves one row of data. To retrieve an entire image, use a sequence of VGET commands. For a lower resolution image, retrieve fewer rows.
- 2. To use the VGET command, the data bits must be set to 0 (8 bits) using COMM (page 74).
- 3. Replies are returned in little endian format.
- 4. The parameters <Start Column>, <End Column>, and <Stride> are optional. You can instead set the values of the user parameters Cmd.VGet.Start X, Cmd.VGet.End X, and Cmd.VGet.Stride for the start column, end column, and stride, respectively.
- 5. A lower stride count results in a higher resolution. To specify the stride option to use, set the value of the user parameter **Cmd.VGet.Sample Option**. Options are as follows:
  - Point (Cmd.VGet.Sample Option = 0): For a stride of n, returns every n<sup>th</sup> pixel.
  - Average (Cmd.VGet.Sample Option = 1): For a stride of n, returns the average of the n pixels.
  - Peak (Cmd.VGet.Sample Option = 2): For a stride of n, returns the maximum value of the n pixels.
- 6. To adjust the number of bits per pixel returned, set the value of the user parameter **Cmd.VGet.Color Depth**. A higher value results in higher picture quality and longer reply length.
- 7. For diagnostic purposes, it may be helpful to color-code the image data according to the internal thresholds used by the system. Since these thresholds are dynamic and vary with exposure time and other factors, they have to be retrieved individually for each frame. To determine the threshold values:
  - a) Set the value of the user parameter **Cmd.VGet.Threshold.Shutter Time** to the exposure time for the frame and sensor whose threshold you wish to determine. The exposure time is returned in the VSNAP response.
  - b) Read the value of the user parameter **Cmd.VGet.Threshold.Trigger**. This value is a function of the exposure time and the sensitivity level (described in the user guide). In order for a marker to be detected by the system, at least on pixel must exceed this threshold.
  - c) Read the value of the user parameter **Cmd.VGet.Threshold.Background**. Ideally only markers exceed this threshold.
- 8. To read user parameter values, use GET (page 82). To set user parameter values, use SET (page 131). For more information on user parameters, see "User Parameters" on page 30.

## **Command Details**

# Example

## Command:

VGET 000100010010002001

## **VSEL**

Selects a characterised measurement volume.

## Compatibility

Supported by the Position Sensor since G.001.

**Deprecated.** Use the command SET (page 131) to set the user parameter **Param.Tracking.Selected Volume** instead.

## **Operating Mode**

Setup

## **Prerequisite Command**

INIT (page 89)

## **Syntax**

VSEL<SPACE><Volume Number><CR>

Parameter	Description
Volume Number	1 hexadecimal character
	Possible Values: 1 to the maximum returned by SFLIST (page 133)

## **Replies**

#### **Upon Success:**

OKAY<CRC16><CR>

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

## **Usage Notes**

Use SFLIST (page 133) to determine which measurement volumes are available.

## **Example**

#### Command:

VSEL 1

## Reply:

OKAYA896

### **VSNAP**

Captures one complete sequence of video data from the sensors. (See the "Usage Notes" on page 175 for details.)

### Compatibility

Supported by the Position Sensor since G.001.

VGET and VSNAP are recommended when using serial communications due to the latency introduced in VCAP when retrieving an image.

### **Operating Mode**

Diagnostic, Tracking

### **Syntax**

VSNAP<SPACE><CR>

### Reply

#### **Upon Success:**

```
<Frame Number><Number of Frames><Number of Sensors>
<Frame 0 Type><Frame 0 Exposure Time 0><Frame 0 Exposure Time 1>...
<Frame 1 Type><Frame 1 Exposure Time 0><Frame 1 Exposure Time 1>...
<CRC16><CR>
```

#### On Error:

ERROR<Error Code><CRC16><CR>

See page 176 for error code definitions.

Reply Component	Description
Frame Number	8 hexadecimal characters
	The frame number of the first frame in the sequence
Number of Frames	2 hexadecimal characters
	The number of frames in the sequence
Number of Sensors	2 hexadecimal characters
	The number of sensors for each frame. This is always 2.
Frame n Type	2 hexadecimal characters
	The tool class of frame n. The list of possible values is reported as the enumeration list in user parameter <b>Cmd.VSnap.Frame Types</b> . (See GETINFO (page 84) for details on reading the enumeration list of a user parameter.) A value of 0F indicates a frame that is used only for timing purposes, and contains no useful data.

Reply Component	Description
Frame n Exposure Time m	4 hexadecimal characters
	The exposure time of the m <sup>th</sup> sensor in µsec. Sensor 0 is the left sensor and sensor 1 is the right sensor, from the point of view of the Position Sensor.

### **VSNAP Usage Notes**

#### **Usage Notes**

- 1. The VSNAP command captures one complete sequence of video data from the sensors. The captured data is stored in internal memory; to retrieve the data, use VGET (page 169). A complete sequence of data consists of the following frames:
  - A frame for each type of tool loaded (passive or active wireless). This allows you to see exactly what the Position Sensor detects while it is tracking.
  - An illuminated frame (illuminators are activated), if the user parameter
     Cmd.VSnap.Illuminated Frame is enabled (set to 1). This allows you to detect any infrared light sources caused by reflections.
  - A background frame (illuminators are off), if the user parameter
     Cmd.VSnap.Background Frame is enabled (set to 1). This allows you to detect any environmental infrared light.

Note The "Cmd.VSnap.Illuminated Frame" and "Cmd.VSnap.Background Frame" user parameters can only be set when the system is in Setup mode.

- The exposure time (the amount of time during which the sensors collect light) for the illuminated and background frames is the value of the user parameter Cmd.VSnap.Manual Shutter.
- 3. To read user parameter values, use GET (page 82). To set user parameter values, use SET (page 131). For more information on user parameters, see "User Parameters" on page 19.

#### **Example**

#### Command:

VSNAP

#### Reply:



# **6** Error and Warning Code Definitions

## 6.1 Error Code Definitions

If the system receives an invalid command, it responds to the host with the message ERROR<Error Code>. Table 6-1 identifies the error codes and their definitions.

Table 6-1 Error Code Definitions

Error Code	Definition	
01	Invalid command.	
02	Command too long.	
03	Command too short.	
04	Invalid CRC calculated for command; calculated CRC does not match the one sent.	
05	Time-out on command execution.	
06	Unable to set up new communication parameters. This occurs if one of the communication parameters is out of range.	
07	Incorrect number of parameters.	
08	Invalid port handle selected.	
09	Invalid mode selected. Either the tracking priority is out of range, or an incorrect priority was selected (e.g. the tool has markers defined and "button box" was selected).	
0A	Invalid LED selected. The LED selected is out of range.	
0B	Invalid LED state selected. The LED state selected is out of range.	
0C	Command is invalid while in the current mode.	
0D	No tool is assigned to the selected port handle.	
0E	Selected port handle not initialized. The port handle needs to be initialized before the command is sent.	
0F	Selected port handle not enabled. The port handle needs to be enabled before the command is sent.	
10	System not initialized. The system must be initialized before the command is sent.	
11	Unable to stop tracking. This occurs if there are hardware problems. Please contact NDI.	
12	Unable to start tracking. This occurs if there are hardware problems. Please contact NDI.	
13	Hardware error: unable to read the SROM device.	
14	Invalid Position Sensor characterization parameters.	
15	Unable to initialize the system. This occurs if:	
	the system could not return to Setup mode	
	<ul> <li>there are internal hardware problems. Please contact NDI.</li> <li>there are internal parameter errors. Use GET to read the Info.Status.Alerts parameter for more details.</li> </ul>	

Table 6-1 Error Code Definitions (Continued)

Error Code	Definition
16	Unable to start Diagnostic mode. This occurs if there are hardware problems. Please contact NDI.
17	Unable to stop Diagnostic mode. This occurs if there are hardware problems. Please contact NDI.
18	Reserved
19	Unable to read device's version information. This occurs if:  • the processor selected is out of range  • the system is unable to inquire firmware version information from a processor
1A	Internal system error. This occurs when the system is unable to recover after:  • too much IR  • a system processing exception
1B	Reserved
1C	Unable to set marker activation signature.
1D	Reserved
1E	<ul> <li>Unable to read SROM device data. This occurs if the system is:</li> <li>unable to auto-select the first SROM device on the given port handle as a target to read from</li> <li>unable to read a page of SROM device data successfully</li> </ul>
1F	Unable to write SROM device data. This can occur if:
	<ul> <li>the system is unable to auto-select the first SROM device on the given port handle as a target for writing to the SROM device</li> <li>the system is unable to write a page of SROM device data successfully</li> </ul>
20	Reserved
21	Unable to test electrical current on tool.
22	Enabled tools are not supported by selected volume parameters. For example, a Position Sensor cannot track a tool if the volume parameter set does not include the marker wavelength of an enabled tool.
23	Command parameter is out of range.
24	Unable to select measurement volume. This occurs if:  • the selected volume is not available • there are internal hardware errors. Please contact NDI.
25	Unable to determine the system's supported features list. This occurs if the system is unable to read all the hardware information.
26-27	Reserved
28	Too many tools are enabled, or the configuration of tools loaded requires too many frames.
29	Reserved
2A	No memory is available for dynamic allocation (heap is full).

Table 6-1 Error Code Definitions (Continued)

Error Code	Definition
2B	The requested port handle has not been allocated.
2C	The requested port handle has become unoccupied.
2D	All handles have been allocated.
2E	Incompatible firmware versions. This can occur if:  • a firmware update failed  • components with incompatible firmware are connected  To correct the problem, update the firmware. If the Multi Firmware feature is installed, select a valid combined firmware revision.
2F	Invalid port description.
30	Requested port is already assigned a port handle.
31	Reserved
32	Invalid operation for the device associated with the specified port handle.
33	Feature not available.
34	User parameter does not exist.
35	Invalid value type (e.g. string instead of integer).
36	User parameter value set is out of valid range.
37	User parameter array index is out of valid range.
38	User parameter size is incorrect.
39	Permission denied; file or user parameter is read-only, or a command which requires master mode is attempted from a monitor mode connection.
3A	Reserved
3B	File not found.
3C	Error writing to file.
3D	Error reading from file.
3E-3F	Reserved
40	Tool Definition File Error. This occurs if:  • the CRC failed • the file format is invalid
41	Tool characteristics not supported. This occurs when one of the following fields in the tool definition file is outside of the range supported by the system:  • number of markers • number of faces • number of groups • number of markers per face (unique geometry tools only)
42	Device not present. This occurs when the command is specific to a device that is not connected to the system.
43-FF	Reserved

## 6.2 Warning Code Definitions

**Table 6-2 Warning Code Definitions** 

Warning	Definition
WARNING01	A non-fatal tool error has been encountered, e.g. a burnt out marker.
WARNING02	The tool you are trying to enable is a unique geometry tool that doesn't meet the unique geometry requirements.
WARNING03	The tool you are trying to enable is a unique geometry tool that conflicts with another unique geometry tool already loaded and enabled.
WARNING04	The tool you are trying to enable is a unique geometry tool that doesn't meet the unique geometry requirements, and conflicts with another unique geometry tool already loaded and enabled.
WARNING05	The system has selected a default marker wavelength to track a tool (if the tool's tool definition file did not specify a marker wavelength).
WARNING06	A Monitor connection has issued the INIT command while the system is in either Tracking or Diagnostics mode or a tool has been loaded.

WARNING01 and WARNING05 are returned with the PINIT or the PENA command.

WARNING02, WARNING03 and WARNING04 are returned with the PENA command.

WARNING06 is returned with the INIT command.

## Appendix A Keyed Features

This section describes how to use the API commands and user parameters with the keyed features. For more information on keyed features, see the user guide that accompanied your system. For more information on user parameters, see "User Parameters" on page 19.

## A.1 Disabling and Enabling Keyed Features

Disabling a keyed feature makes that feature unavailable. Enabling a keyed feature makes the feature available. A keyed feature is enabled upon installation.

### To disable or enable a keyed feature:

1. Use the API command SET to set the value of the user parameter Features.Keys.Disabled Keys.

The value of this parameter is a comma-separated list. To disable a keyed feature, add its name to the comma-separated list. To re-enable a keyed feature, remove its name from the comma-separated list. For example:

"SET Features.Keys.Disabled Keys=Multi Firmware" will disable the Multi Firmware feature. "SET Features.Keys.Disabled Keys=" will re-enable all the installed features keys.

- 2. Use the API command SAVE to save the settings.
- 3. Reset the system (use the API command RESET). The changed settings take effect upon system reset.

#### **A.2 Multi Firmware Feature**

The multi firmware feature allows the system to contain more than one combined firmware revision. When the multi firmware feature is enabled, you can specify which combined firmware revision the system will use on its next reset or power up.

This feature is referred to as "MultiFirmware" in the ToolBox user interface and Polaris Vega API.

### **Changing the Combined Firmware Revision Currently in Use**

#### **Procedure**

## 1. (Optional) Determine which combined firmware revision is currently in use: use the API command GET to read the user parameter **Config.Combined Firmware Revision.**

### Example

Command: GET Config.Combined Firmware Revision

Reply: Config.Combined Firmware Revision=002<CRC16>

2. Determine which combined firmware revisions are available:

API revision G.001.004 and later: use the API command GET (page 82) to read the user parameter Config. Multi Firmware. Available **Combined Firmware Revisions.** 

The list of possible firmware revisions is given in the enumerated list. In this example, the firmware revisions are 002 and 003.

Command: GET Config.Multi Firmware. Available Combined Firmware Revisions

**Reply:** 002,003<CRC16>

API revision G.001.003 or earlier: use GETINFO (page 84) to read the user parameter Config.Multi Firmware.Load **Combined Firmware Revision.**)

The list of possible firmware revisions is given in the enumerated list returned by GETINFO. In this example, the firmware revisions are 002 and 003.

Select the desired combined firmware revision: use the API command SET to set the Combined Firmware Revision=1 value of the user parameter

Config.Multi Firmware.Load Combined Firmware Revision. The enumeration is zerobased. For example, to select the second item in the list (revision 003), set the value of the user parameter to 1. This parameter value is automatically saved when set. The selected combined firmware revision is loaded on the next reset.

Command: GETINFO Config.Multi Firmware.Load Combined Firmware Revision Reply: Config.Multi Firmware.Load Combined Firmware Revision=0;1;3;0;255;002,003; Combined firmware revision to load on next reset (selection automatically saves when set) < CRC16>

Command: SET Config.Multi Firmware.Load

Reply: OKAY<CRC16>

**Polaris Vega Application Program Interface Guide** 

## A.3 Positioning Laser

The positioning laser is located in the Polaris Vega System Position Sensor and indicates the centre of the characterized measurement volume. This feature allows you to properly position the Position Sensor, or position objects in the measurement volume. The positioning laser feature cannot be purchased after you obtain the system; the laser hardware must be installed when the system is manufactured. For full details on the positioning laser, see the user guide that accompanied your system.

It is possible to activate (turn on) the laser by using an external laser switch connected to a laser switch port. The optional laser switch is not supplied by NDI.

This feature is referred to as "Laser" in the ToolBox user interface and Polaris Vega API.

### A.4 Password Protect

The password protect feature provides security against changes to the system configuration. When the password feature is enabled, you must enter the correct password before you can:

- save user parameter values,
- update the firmware, or
- install, disable, or enable a keyed feature.

If the correct password is not entered, user parameter values can be changed but not saved (they will return to their previous values upon system reset or initialization).

To enter the password, use NDI ToolBox or use the API command SET to set the value of the user parameter **Config.Password** to the correct password. If the system is subsequently reset or initialized, you will have to re-enter the password before you can make changes to the system configuration.

This feature is referred to as "Password" in the ToolBox user interface and Polaris Vega API.

### A.5 MR250

The MR250 feature key changes the base frame rate of the Polaris Vega system to 250Hz. The MR250 feature cannot be purchased after you obtain the system; it must be installed when the system is manufactured. It can be disabled in order to use standard frame rates. For full details on 250 Hz tracking rate, see the user guide that accompanied your system.

This feature is referred to as "MR250" in the ToolBox user interface and Polaris Vega API.

### A.6 Serial Communications - LEMO Connector

This feature key is enabled at the factory for Vega ST Systems that have a LEMO connector to support serial communications. There is no need to disable this feature key if ethernet communications are preferred.

• If serial and ethernet connections are made to the Position Sensor at the same time, the serial connection will be granted Master role whenever needed, even if an ethernet connection was already Master.

• When this feature key is enabled, the Position Sensor is configured for a static IP address by default for ethernet communication.

From the application perspective, the Polaris Vega System is a serial device, which is listening for incoming commands. Upon receiving a command, the system performs some action and returns the status of this action. The system never initiates communication with the application except on power up or reset, when it returns RESET<CRC16><CR>. (If only an SCU is connected it will return SCUONLY<CRC16><CR>.)

Immediately after sending a command, the application can begin to poll the serial buffer for a reply. Most commands reply almost instantaneously. After reaching the end of the reply, the application can send another command.

Note

The application must read the complete response from the system before sending another command. Failure to do so may result in an error or in unpredictable system behaviour.

For full details on serial communications, see the user guide that accompanied your system.

This feature is referred to as "LEMO" in the ToolBox user interface and Polaris Vega API.

### A.7 Radiation Robustness

This feature key is enabled at the factory for Vega ST Systems that are hardened against neutron radiation. Radiation robustness is achieved through a shielded processor and modified memory management.

This feature is referred to as "RadiationRobust" in the ToolBox user interface and Polaris Vega API.

### A.8 Video Camera

This feature key is enabled at the factory for Vega VT Systems, which are equipped with a video camera. The video camera is integrated into the Position Sensor. The video camera provides a live, color video stream of the Vega measurement volume but is not used for tracking tools.

This feature is referred to as "VideoCamera" in the ToolBox user interface and Polaris Vega API.

## Appendix B Sample C Routines

The following sample C routines are included for reference. For more information and sample code, refer to the Combined API Sample (CAPI).

**Table 6-3 Sample C Routines** 

Routine	Description
CalcCRC16	Calculates a running CRC16 using the polynomial $X^16 + X^15 + X^2 + 1$ .
EulerAngleTrig	Determines the sine and cosine of the Euler angles.
DetermineR	Calculates the 3x3 rotation matrix which corresponds to the given Euler angles.
CvtQuatToRotationMatrix	Determines the rotation matrix that corresponds to the given quaternion values.
DetermineEuler	Calculates the Euler angles given the 3x3 rotation matrix.
CvtQuatToEulerRotation	Determines the rotation in Euler angles (degrees) that corresponds to the given quaternion rotation.

The following defines are used by the sample C routines:

```
* Conversion factors.
#define RAD TO DEGREES
                       (180 / 3.1415926)
* Defined data types.
typedef float
   RotationMatrix[3][3];
typedef struct Rotation
    float
       fRoll,
                  /* rotation about the object's z-axis (Euler angle) */
                  /* rotation about the object's y-axis (Euler angle) */
                   /* rotation about the object's x-axis (Euler angle) */
} Rotation;
typedef struct QuatRotation
    float
       fQ0,
       fQX,
       fQY,
       fQZ;
} QuatRotation;
```

## B.1 CalcCRC16

The following is a sample C routine, for calculating a running 16 bit CRC, as used in communications between the host computer and the Polaris System.

```
/**********************
          CalcCRC16
Name:
Input Values:
   int
                  :Data value to add to running CRC16.
       data
   unsigned int
       *puCRC16
               :Ptr. to running CRC16.
Output Values:
   None.
Returned Value:
   None.
Description:
   This routine calculates a running CRC16 using the polynomial
   X^16 + X^15 + X^2 + 1.
*************************
void CalcCRC16( int data, unsigned int *puCRC16 )
{
   static int
      oddparity[16] = { 0, 1, 1, 0, 1, 0, 0, 1, 1, 0, 0, 1, 0, 1, 1, 0 };
   data = (data ^ (*puCRC16 & 0xff)) & 0xff;
   *puCRC16 >>= 8;
   if (oddparity[data & 0x0f] ^ oddparity[data >> 4] )
      *puCRC16 ^=0xc001
   } /* if */
   data <<= 6;
   *puCRC16 ^= data;
   data <<= 1;
   *puCRC16 ^= data;
} /* CalcCRC16 */
```

## B.2 EulerAngleTrig

```
*****************
          EulerAngleTrig
Input Values:
   Rotation
       *pdtRotationAngle :Ptr to struct containing the roll, pitch, yaw
                        Euler angles which define the required rotation.
Output Values:
   Rotation
       *pdtSinAngle :Ptr to struct containing the sine of the roll, pitch,
                   yaw Euler angles.
       *pdtCosAngle :Ptr to struct containing the cosine of the roll, pitch,
                    yaw Euler angles.
Returned Value:
   None.
Description:
   This routine determines the sine and cosine of the Euler angles.
**************************
static void EulerAngleTrig( Rotation *pdtRotationAngle,
              Rotation *pdtSinAngle,
              Rotation *pdtCosAngle )
{
   pdtSinAngle->fRoll=
                        sin( pdtRotationAngle->fRoll );
   pdtSinAngle->fPitch=
                        sin( pdtRotationAngle->fPitch );
   pdtSinAngle->fYaw =
                        sin( pdtRotationAngle->fYaw );
   pdtCosAngle->fRoll=
                        cos( pdtRotationAngle->fRoll );
   pdtCosAngle->fPitch=
                        cos( pdtRotationAngle->fPitch );
   pdtCosAngle->fYaw=
                        cos( pdtRotationAngle->fYaw );
} /* EulerAngleTrig */
```

### B.3 DetermineR

```
/**********************
           DetermineR
Input Values:
   Rotation
       *pdtRotationAngle :Ptr to struct containing the roll, pitch, yaw
                          Euler angles which define the required rotation.
Output Values:
   RotationMatrix
       dtRotationMatrix: The 3x3 rotation matrix to be determined.
Returned Value:
   None.
Description:
   This routine calculates the 3x3 rotation matrix which corresponds to the
   given Euler angles.
*******************
void DetermineR( Rotation *pdtRotationAngle, RotationMatrix
        dtRotationMatrix )
{
   Rotation
       dtSinAngle, /* the sine of the roll, pitch, and yaw angles */
       dtCosAngle; /* the cosine of the roll, pitch, and yaw angles */
* Might as well determine the sine and cosine of the given Euler
*angles right from the start
EulerAngleTrig( pdtRotationAngle, &dtSinAngle, &dtCosAngle );
* Fill in the rotation matrix.
dtRotationMatrix[0][0] = dtCosAngle.fRoll * dtCosAngle.fPitch;
dtRotationMatrix[0][1] = dtCosAngle.fRoll * dtSinAngle.fPitch *
   dtSinAngle.fYaw - dtSinAngle.fRoll * dtCosAngle.fYaw;
dtRotationMatrix[0][2] = dtCosAngle.fRoll * dtSinAngle.fPitch *
   dtCosAngle.fYaw + dtSinAngle.fRoll * dtSinAngle.fYaw;
dtRotationMatrix[1][0] = dtSinAngle.fRoll * dtCosAngle.fPitch;
dtRotationMatrix[1][1] = dtSinAngle.fRoll * dtSinAngle.fPitch *
   dtSinAngle.fYaw + dtCosAngle.fRoll * dtCosAngle.fYaw;
dtRotationMatrix[1][2] = dtSinAngle.fRoll * dtSinAngle.fPitch *
   dtCosAngle.fYaw - dtCosAngle.fRoll * dtSinAngle.fYaw;
dtRotationMatrix[2][0] = - dtSinAngle.fPitch;
dtRotationMatrix[2][1] = dtCosAngle.fPitch * dtSinAngle.fYaw;
dtRotationMatrix[2][2] = dtCosAngle.fPitch * dtCosAngle.fYaw;
} /* DetermineR */
```

## B.4 CvtQuatToRotationMatrix

```
/**********************
Name:
           CvtQuatToRotationMatrix
Input Values:
   QuatRotation
       *pdtQuatRot :Ptr to the quaternion rotation.
Output Values:
   RotationMatrix
       dtRotationMatrix : The 3x3 determined rotation matrix.
Returned Value:
   None.
Description:
   This routine determines the rotation matrix that corresponds
   to the given quaternion.
   Let the quaternion be represented by:
       | Q0 |
   Q = | Qx |
       | Qy |
       | Qz |
   and the rotation matrix by:
       | M00 M01 M02 |
   M = | M10 M11 M12 |
       | M20 M21 M22 |
   then assuming the quaternion, Q, has been normalized to convert
   Q to M we use the following equations:
   M00 = (Q0 * Q0) + (Qx * Qx) - (Qy * Qy) - (Qz * Qz)
   M01 = 2 * ((Qx * Qy) - (Q0 * Qz))
   M02 = 2 * ((Qx * Qz) + (Q0 * Qy))
   M10 = 2 * ((Qx * Qy) + (Q0 * Qz))
   M11 = (Q0 * Q0) - (Qx * Qx) + (Qy * Qy) - (Qz * Qz)
   M12 = 2 * ((Qy * Qz) - (Q0 * Qx))
   M20 = 2 * ((Qx * Qz) - (Q0 * Qy))
   M21 = 2 * ((Qy * Qz) + (Q0 * Qx))
   M22 = (Q0 * Q0) - (Qx * Qx) - (Qy * Qy) + (Qz * Qz)
*****************************
void CvtQuatToRotationMatrix( QuatRotation *pdtQuatRot,
              RotationMatrix dtRotMatrix )
{
   float
       fQ0Q0,
       fQxQx,
       fQyQy,
       fQzQz,
       fQ0Qx,
```

```
fQ0Qy,
        fQ0Qz,
        fQxQy,
        fQxQz,
        fQyQz;
     * Determine some calculations done more than once.
        fQ0Q0 = pdtQuatRot->fQ0 * pdtQuatRot->fQ0;
        fQxQx = pdtQuatRot->fQX * pdtQuatRot->fQX;
        fQyQy = pdtQuatRot->fQY * pdtQuatRot->fQY;
        fQzQz = pdtQuatRot->fQZ * pdtQuatRot->fQZ;
        fQ0Qx = pdtQuatRot->fQ0 * pdtQuatRot->fQX;
        fQ0Qy = pdtQuatRot->fQ0 * pdtQuatRot->fQY;
        fQ0Qz = pdtQuatRot->fQ0 * pdtQuatRot->fQZ;
        fQxQy = pdtQuatRot->fQX * pdtQuatRot->fQY;
        fQxQz = pdtQuatRot->fQX * pdtQuatRot->fQZ;
        fQyQz = pdtQuatRot->fQY * pdtQuatRot->fQZ;
     * Determine the rotation matrix elements.
       dtRotMatrix[0][0] = fQ0Q0 + fQxQx - fQyQy - fQzQz;
       dtRotMatrix[0][1] = 2.0 * (-fQ0Qz + fQxQy);
       dtRotMatrix[0][2] = 2.0 * (fQ0Qy + fQxQz);
       dtRotMatrix[1][0] = 2.0 * (fQ0Qz + fQxQy);
       dtRotMatrix[1][1] = fQ0Q0 - fQxQx + fQyQy - fQzQz;
       dtRotMatrix[1][2] = 2.0 * (-fQ0Qx + fQyQz);
       dtRotMatrix[2][0] = 2.0 * (-fQ0Qy + fQxQz);
       dtRotMatrix[2][1] = 2.0 * (fQ0Qx + fQyQz);
       dtRotMatrix[2][2] = fQ0Q0 - fQxQx - fQyQy + fQzQz;
} /* CvtQuatToRotationMatrix */
```

## B.5 DetermineEuler

```
/*********************
           DetermineEuler
Input Values:
   RotationMatrix
       dtRotationMatrix : The 3x3 rotation matrix to convert.
Output Values:
   Rotation
       *pdtEulerRot :Rotation is Euler angle format.
           Roll, pitch, yaw Euler angles which define the required rotation.
Returned Value:
   None.
Description:
   This routine calculates the Euler angles given the 3x3 rotation matrix.
*************************
void DetermineEuler( RotationMatrix dtRotMatrix, Rotation *pdtEulerRot )
      float
       fRoll,
       fCosRoll,
       fSinRoll;
            = atan2( dtRotMatrix[1][0], dtRotMatrix[0][0] );
      fCosRoll = cos( fRoll );
      fSinRoll = sin(fRoll);
      pdtEulerRot->fRoll = fRoll;
     pdtEulerRot->fPitch = atan2( -dtRotMatrix[2][0],
                          (fCosRoll * dtRotMatrix[0][0]) + (fSinRoll *
      dtRotMatrix[1][0]) );
      pdtEulerRot->fYaw
                       = atan2(
                          (fSinRoll * dtRotMatrix[0][2]) -
                          (fCosRoll * dtRotMatrix[1][2]),
                          (-fSinRoll * dtRotMatrix[0][1]) +
                          (fCosRoll * dtRotMatrix[1][1]) );
      /* DetermineEuler */
```

## B.6 CvtQuatToEulerRotation

```
/*********************
          CvtQuatToEulerRotation
Input Values:
   QuatRotation
      *pdtQuatRot :Ptr to the quaternion rotation.
Output Values:
   Rotation
       *pdtEulerRot :Ptr to the determined rotation Euler angles.
Returned Value:
   None.
Description:
   This routine determines the rotation in Euler angles (degrees)that
   corresponds to the given quaternion rotation.
void CvtQuatToEulerRotation( QuatRotation *pdtQuatRot, Rotation *pdtEulerRot )
{
   RotationMatrix
      dtRotMatrix;
   CvtQuatToRotationMatrix( pdtQuatRot, dtRotMatrix );
   DetermineEuler( dtRotMatrix, pdtEulerRot );
   pdtEulerRot->fYaw *= RAD_TO_DEGREES;
   pdtEulerRot->fPitch *= RAD_TO_DEGREES;
   pdtEulerRot->fRoll *= RAD TO DEGREES;
} /* CvtQuatToEulerRotation */
```

## Appendix C Changes in Implementation between Spectra and Vega

This chapter describes the cumulative changes in commands between API version G.001, which was the version to support Polaris Spectra, and API version G.003, which supports the Polaris Vega platform.

This information may be useful when migrating from Spectra to Vega. For more detailed information on revisions to the Polaris Vega API, refer to the "Polaris Vega Firmware Revision History".

### C.1 New Commands

New commands in introduced between G.001 and G.003 are as follows:

New Command	Description
BX2 (page 64)	Returns various levels of data on the latest tool transformations, individual marker positions, and system status in binary format.
STREAM (page 140)	Initiates a streaming response to a specified command.
USTREAM (page 162)	Stops streaming of the specified command.
VCAP (page 163)	Captures IR image data from the sensors.(Replaces the VGET and VSNAP commands.)

#### BX2

The BX2 command provides a flexible way of providing measurement data at various levels of detail. The reply can contain a single or multiple frames. Each frame can contain various levels of measurement data detail such as 6D, 3D or 2D data.

- It does not repeat already reported information.
- It works with the STREAM command to keep latency to a minimum and avoid missing or repeating information.
- Addresses the problem of providing system wide failures and warnings in the multiconnection environment.

#### **STREAM**

STREAM initiates a streaming response to a command. For details on data streaming, see "Data Streaming" on page 7.

#### **USTREAM**

USTREAM terminates the streaming response to a command. For details on data streaming, see "Data Streaming" on page 7.

The VCAP command can be used instead of VSNAP and VGET. is recommended for Vega applications; VSNAP and VGET are supported for backwards compatibility with Spectra.

The command contains options to specify and control the image data returned. The reply contains the image data for a single frame from all sensors with embedded "meta-data" that includes sensor number, frame number, exposure and other relevant information about the frames. Readable parameters provide additional information that will assist in interpreting the image data, such as the makeup of the frame sequence and the number and names of the image sensors.

## **C.2** Deprecated Commands

The following commands are deprecated. Deprecated commands will no longer be enhanced to support new hardware devices or new API features. Support for deprecated commands may be discontinued in future releases.

Command	Replacement
3D	BX2 command
APIREV	User parameter Features.Firmware.API Revision.
IRATE	User parameter Param.Tracking.Track Frequency
PINIT	PENA command calls PINIT
SFLIST	User parameters: Features.Tools.Active Ports, Features.Tools.Passive Ports, Features.Volumes *, Features.Tools.Wireless Ports
VSEL	User parameter Param.Tracking.Selected Volume

### C.3 Deleted Commands

Deleted commands are as follows:

<b>Deleted Command</b>	Description
GETIO	Deleted
HCWDOG	Deleted
PSOUT	Deleted
SENSEL	Replaced by User Parameter Param. Tracking. Sensitivity (Table 4-6 on page 31)
SETIO	Deleted
SSTAT	Deleted

## 6.3 Changed Commands

The behaviour of some commands has changed since API version G.001. Refer to the "Polaris Vega Firmware Revision History" for details.

## 6.4 New Concepts

Several important concepts have been introduced in support of the Polaris Vega platform. Refer to "Important Concepts" on page 5 for information on these concepts.

## Appendix D Vega Video Camera Parameter Supplement

This chapter provides supplemental information about video camera parameters and characteristics. It includes the following sections:

- "Gamma Correction" on page 195
- "Exposure and Gain Control Meter Modes" on page 196

For a listing of all video camera parameters, refer to "Video Camera Parameters" on page 40.

#### **Gamma Correction D.1**

Gamma correction applies a non-linear gain to increase the gain in dark areas of an image while keeping the light areas relatively untouched.

The four supported gamma correction modes are

Off - no Gamma correction

Built-in – use built-in hardware gamma correction

User Defined – uses the Gamma Value to create a correction table

User-Defined Enhanced – uses the Gamma Value to create a correction table

A user specified value (Param. Effects. Gamma Value) is used to generate the correction for the User Defined and User-Defined Enhanced modes.

User Defined: output = input (1/gamma)

User-Defined Enhanced output = input (1/gamma) \* (1 - (3/(input+3)) + input\*0.01)

See Figure 6-1 for the User Defined gamma correction curves of 2.2.




Figure 6-1 User Defined and User-Defined Gamma Curve

Zooming in on the lower end of the graph, Figure 6-2, we see that the slope of the User-Defined Enhanced curve near the origin is less steep than the (more common) User Defined gamma curve. This reduces the "fogginess" in dark areas of the image when the gamma value is large.




Figure 6-2 Zoom in on User-Defined Enhanced Gamma Curve

## D.2 Exposure and Gain Control - Meter Modes

The Exposure and Gain Control algorithm optimizes the exposure time and/or the system gain to achieve a desired level of brightness in the image. A user-selected meter mode can be specified using the **Param.Exposure And Gain.Meter.Mode**. There are four meter modes to choose from:

- General scenes can usually use the **Center Weighted** mode.
- Backlit scenes should use the **Segmented** mode.
- Spotlighted scenes such as an operating room with a particularly bright area should use the **Spotlight** mode.
- The **Weighted ROI** mode uses a selected zone in the image area to adjust the brightness.

**Centre Weighted** This metering mode calculates a weighted average based on the regions shown in the diagram below.





Figure 6-3 Regions used for Centre Weighted Meter Mode

**Segmented** This metering mode is designed for scenes that have a principal object in a backlit condition. It prevents the background lighting from controlling the exposure.

The frame is divided into five regions. This algorithm assumes that the main object is in the center of the scene. The size of Region 4 is defined by the size of rectangle of interest (**Param.Exposure And Gain.Meter.ROI [Center X|Center Y|Width|Height]** and is centered in the sensor.

Figure 6-4 represents the Segmented metering system,. The main object is in Region 4. Region 0, Region 2, and Region 3 are considered the background.



Region 0

Figure 6-4 Segmented Metering Mode

**Spotlight** This metering mode is designed to prevent saturation of a spotlight area and may be ideal for surgical applications. The algorithm searches for the brightest center-weighted patch. The sensor is divided into several regions as shown in the figure below and each region is assigned a weight, with the highest weighting in the center of the image and decreasing towards the edges.





Figure 6-5 Regions used for Spotlight Meter Mode

**Weighted ROI** In the Weighted ROI metering mode, the current brightness value is calculated using a user selected region and a user defined weighting value. In Figure 6-6, Region 0 is the user-selected region and Region 1 is the background. The user-defined weighting value is the weighting between the average brightness of Region 0 and Region 1, expressed as a percentage.

Figure 6-6 ROI Metering Method



Param. Exposure And Gain. Meter. ROI Weighting sets the weighting value and Param. Exposure And Gain. Meter. ROI [Center X|Center Y|Width|Height] is used to specify the location and size of Region 1.

## Appendix E Vega Video Camera Alignment

This appendix describes how to align and synchronize the Vega video camera stream to the real-time tracking stream from the Polaris Vega Position Sensor.

The Vega video camera sensor has been characterized and aligned to the tracking system to describe the relationship between objects seen in the video images and objects tracked in the position sensor coordinate space. This feature may be used for augmented reality overlays, a simple example of which is shown in Figure E-1.




Figure E-1 Tracking Data Overlay on Video Stream

## E.1 Terminology

**6D Transformation** Mathematical operation that describes the transformation from one 3D coordinate system to another. A 6D transformation consists of a rotation in 3D, followed by a translation.

**6D/3D** 6D transformation of a tool and optional relative translation of tool markers.

**CCS** Camera Coordinate System, the coordinate system of the Position Sensor.

**KLV** Key-Length-Value is an optional type of data for an RTP packet defined by SMPTE336M, containing a 16-byte key for the value, a 1-byte length of the value, and the value.

**PSU** Position Sensor Unit

**Quaternion** Quaternions can be used to describe a 3D rotation. Alternatives include Euler Angles or Polar/Spherical notation.

**RTP** Real-time Transport Protocol is a network protocol for delivering audio and video over a network. The Vega video camera server implements this protocol. In the video camera implementation, individual RTP packets may contain portions of an encoded video image or metadata with a time stamp.

**RTSP** Real-Time Streaming Protocol is the network control protocol the Vega video camera server uses to set up the RTP video stream with a video client.

**TCS** Tool Coordinate System is the local coordinate system in the tool's frame of reference.

**VCS** Video Coordinate System is the coordinate system of the Vega video camera.

**VCU** Video Camera Unit, the Vega video camera.

## E.2 Spatial alignment

The video camera-to Vega tracking system alignment data is calculated for use with the OpenCV image processing library and its Calib3D (OpenCV, 2017) module, and describes four sets of parameters:

- Orientation and location of the video camera in Vega's measurement space, Figure E-2.
- Radial and tangential distortion coefficients of video camera lens for Zhang's method (Camera Resectioning, n.d.)
- Parameters describing the Pinhole Camera Model (Pinhole camera model, n.d.)
- Resolution-specific alignment parameters




Figure E-2 Video Alignment Pose

The video alignment pose (in blue, above) describes the video camera's pose with respect to the Vega tracking coordinate space (in red, above).

These sets of parameters are in the Vega video camera's parameter system and published through the Polaris Vega Application Program Interface, using the parameter names listed in Table E-1 when connected directly to the Video Camera Unit (port 8766). If connected through the PSU (port 8765), Video Camera Unit parameters are forwarded with the name prefix "VCU-0.".

Table E-1 VCU Parameters for Alignment and 3D Reconstruction with OpenCV

Parameter name	Description
Param.Lens.6D.q0	Quaternion rotation from Camera Coordinate System to Video Coordinate
Param.Lens.6D.qx	System
Param.Lens.6D.qy	
Param.Lens.6D.qz	
Param.Lens.6D.tx	Translation from Camera Coordinate System to Video Coordinate System
Param.Lens.6D.ty	[mm]
Param.Lens.6D.tz	
Param.Lens.Distortion.k1	Radial lens distortion coefficients for Zhang's method
Param.Lens.Distortion.k2	
Param.Lens.Distortion.k3	
Param.Lens.Distortion.p1	Tangential lens distortion coefficient for Zhang's method
Param.Lens.Distortion.p2	
Param.Lens.Pinhole.fu	Horizontal focal length in sensor space [pixels]
Param.Lens.Pinhole.fv	Vertical focal length in sensor space [pixels]
Param.Lens.Pinhole.u0	Horizontal position of pinhole in sensor space [pixels]
Param.Lens.Pinhole.v0	Vertical position of pinhole in sensor space [pixels]
Param.Left	Left coordinate of imaging window on the sensor [pixels]. Changes with selected resolution.
Param.Top	Top coordinate of imaging window on the sensor [pixels]. Changes with selected resolution.
Param.Binning X	Binning scale factor in horizontal direction. Changes with selected resolution.
Param.Binning Y	Binning scale factor in vertical direction. Changes with selected resolution.

## E.3 Calculating the Pinhole Model for each Resolution

Whenever the resolution of the video stream is changed, the binning scale factors and top-left window coordinates of the imaging window change. It is necessary to calculate resolution-specific pinhole model parameters for the selected resolution using the following transformations:

 $u_0 = ([Param.Lens.Pinhole.u0] - [Param.Left]) \div [Param.Binning X]$ 

 $v_0 = ([Param.Lens.Pinhole.v0] - [Param.Top]) \div [Param.Binning Y]$ 

 $f_u = [Param.Lens.Pinhole.fu] \div [Param.Binning X]$ 

 $f_v = [Param.Lens.Pinhole.fv] \div [Param.Binning Y]$ 

where

u<sub>0</sub>, v<sub>0</sub>: Resolution-specific coordinate of the optical axis in the imaging window

f<sub>u</sub>, f<sub>v</sub>: Resolution-specific horizontal and vertical focal length.

## E.4 Projecting Tracking Poses onto the Video Image

Given alignment, distortion, and pinhole model parameters, tracking data may be projected onto the video image. The parameters were designed to be used with the OpenCV library's Calib3d module (OpenCV, 2017). The following steps describe how coordinates given in a tools' coordinate frame (TCS) are projected onto the video image:

1. The 6D transformation of a tool as reported by the tracking system describes the transformation of the tool coordinate system (TCS) onto the camera's coordinate system (CCS):

The static 6D transformation described by the parameters in Param.Lens.6D.\* describe the transformation from the camera coordinate system (CCS) onto the video coordinate system (VCS):

Combining the two transformations results in a new 6D transformation that describes the transformation from the tool coordinate system onto the video coordinate system:

A 3D coordinate (x,y,z) expressed in the TCS can be transformed into the VCS by sequentially applying the two 6D transformations to it.

2. Project the 3D coordinate (x,y,z) in VCS onto the video image:

Pass the 3D position, the camera's resolution-specific pinhole model values and the camera's distortion coefficients to the OpenCV Calib3d::projectPoints method to find the tracking point's position relative to the top left corner of the video frame.

3. To highlight the marker positions of all markers on a tool, repeat these steps for each 3D coordinate in the tool definition file or using the 3D tracking option of the track tools command.

The resulting (x,y) coordinates are the location of the tool in image space, from the top-left corner.

To draw a set of axes to represent the tool's coordinate system:

1. Calculate the projection coordinates for each of the axes:

$$\begin{bmatrix} s \\ 0 \end{bmatrix}, \begin{bmatrix} 0 \\ s \end{bmatrix}, \begin{bmatrix} 0 \\ 0 \end{bmatrix}$$

where s is the desired length of the axis lines.

2. Draw lines from the tool's projected origin to each of the projected axis points.

## **E.5** Time Synchronization

The Vega Position Sensor provides a time stamp in every 6D/3D tracking frame using the BX2 command. The video camera unit's server provides two RTP (Real-time Transport Protocol) streams through the RTSP (Real-Time Streaming Protocol) server implementation. The first RTP stream is the H.264-encoded video frames, and the second RTP stream are packets with key-length-value objects, including the video stream time stamp.

To draw 6D/3D tracking-synchronized overlays onto the video stream in the application, two separate synchronization steps are required (Figure E-3). The first step is to line up the two

incoming RTP streams using RTP synchronization. A GStreamer implementation example is shown in Figure 4. The time-stamped video frames may be buffered while the incoming time-stamped 6D/3D data is also buffered, then matched up by RTP packet time stamps.

A second synchronizer is used to align the time-stamped video frames with time-stamped 6D/3D data. Because the two streams are arriving at different frequencies, there will not be a one-to-one match-up. The video camera's image stream is not synchronized to the tracking frames, although it uses the same clock.




Figure E-3 Time synchronization block diagram

The GStreamer audio- and video-streaming client supports the processing of RTP KLV packets. A GStreamer pipeline implementation is shown below (Figure E-4) that may be used to stream video and time stamp data from the Video Control Unit's video server.




Figure E-4 Example of a GStreamer video pipeline to decode video and time stamp RTP packets into raw video

Note

To ensure that the RTP GStreamer bin will order the incoming RTP packets from the two streams properly, the "buffer-mode" of the RTPBin is set to 0 (none).

## E.6 Decoding the KLV RTP stream

The RTP packets containing the time stamp follow the SMPTE336M format (SMPTE, 2017). The format of the 25-byte key-length-value time stamp object is described in Table E-1.

Table E-1 Description of Time Stamp KLV Object

Size (bytes)	Description
16	Time stamp key, Table E-2
1	Length of the time stamp in bytes = 8
8	Time stamp, nanoseconds since the epoch (big-endian)

The 16 bytes of the Key are shown in Table E-2:

Table E-2 KLV Time Stamp Key

0x06	0x0E	0x2B	0x34	0x01	0x01	0x01	0x03
0x07	0x02	0x01	0x01	0x01	0x05	0x00	0x00

For example, the time stamp bytes in Table E-3:

Table E-3 Example of KLV Time Stamp Bytes

0x15	0x71	0x81	0xb8	0x4c	0x44	0x68	0xa0

decode to the time stamp in Figure E-5:

Figure E-5 Time Stamp Decoded from the Bytes in Table E-3

2018-12-18 18:46:15, 718,308µs

Use the RTP packet times in the video frame stream and the KLV stream to match up the KLV meta data time stamp with each received video frame.

## E.7 References

- Camera Resectioning. (n.d.). Retrieved from Wikipedia: https://en.wikipedia.org/wiki/ Camera resectioning#Zhang's method
- OpenCV. (2017, October 24). *Camera Calibration and 3D Reconstruction*. Retrieved from OpenCV 3.3.1 Documentation: https://docs.opencv.org/3.3.1/d9/d0c/group\_\_calib3d.html
- Pinhole camera model. (n.d.). Retrieved from Wikipedia: https://en.wikipedia.org/wiki/ Pinhole camera model
- SMPTE. (2017, August 21). ST 336:2017 SMPTE Standard Data Encoding Protocol using Key-Length-Value. Retrieved from IEEE Xplore Digital Library: https://ieeexplore.ieee.org/ document/8019807

# **Abbreviations and Acronyms**

Abbreviation or Acronym	Definition
API	Application Program Interface
CRC	Cyclic Redundancy Check
IEEE	Institute of Electrical and Electronic Engineers
IRED	Infrared light Emitting Diode
LED	Light Emitting Diode
LOS	Line of Sight
OOV	Out of Volume
PSE	Power Sourcing Equipment
PSU	Position Sensor Unit
Rev xx	Combined firmware revision. For example, rev 24 refers to combined firmware revision 024.
RMS	Root Mean Square
SCU	System Control Unit
SROM	Serial Read Only Memory
TIP	Tool-In-Port
UV	Refers to the rows and columns on the Position Sensor. U is the column number and V is the row number
VCU	Video Camera Unit

## **Glossary**

#### characterized measurement volume

The characterized measurement volume is the volume within the field of view where accuracy is within specified limits. NDI cannot guarantee measurement accuracy performed outside this region.

#### faces

Tool faces are separate rigid bodies that make up a tool. Up to eight faces can be defined for one tool.

#### firmware

Firmware is a computer program stored in Polaris hardware and controls the Polaris System.

#### frame rate

The frame rate (or base frame rate) is the rate at which the system takes images of the measurement volume.

#### maximum 3D error

Maximum 3D error applies to individual markers. It is a parameter in the tool definition file, that specifies the maximum allowable difference between the actual and expected location of a marker on a tool.

#### maximum marker angle

Maximum marker angle is a parameter in the tool definition file, used to determine if the Position Sensor can view a specific marker and whether it should be included in the transformation calculated for the tool.

#### missing

If the system cannot detect a marker, that marker is considered missing. If the system cannot detect enough markers on a tool to determine a transformation, that tool is considered missing.

#### SCU

The System Control Unit (SCU) is a component of the hybrid Polaris Vega System.

#### stray marker

A stray marker is a marker that is not part of a tool.

#### **SROM** device

A tool definition file can be programmed into the SROM device so that the tool can carry its own information for automatic retrieval by an NDI measurement system.

#### switch

A switch, when activated, initiates certain actions in the associated software application. A tool may have switches incorporated into its design.

#### tool definition file

A tool definition file stores information about a tool. This includes information such as the placement of the tool's markers, the location of its origin, and its manufacturing data. A tool definition file is formatted as.rom.

### tracking rate

The tracking rate is the rate at which the system reports transformations for all the tools being tracked. The tracking rate cannot exceed the frame rate.

### VCU

The Video Camera Unit (VCU) is an optional component of the passive Polaris Vega System.

# Index

Numerics	С
250 Hz tracking feature, 182 3D command, 45 3D marker positions, 45 3D position markers on tools, 60, 156 single stray active marker, 59, 155 stray passive markers, 61, 62, 158  A  activation signature, 93 active tools activation signature, 93 electrical information, 105 number of ports available, 35, 134 active wireless tools number of ports available, 35, 134 alerts, 22, 34 simulated, 33 algorithm limitation, 57, 153 API commands SET, 182 API revision, 50 APIREV command, 50 assigning a port handle, 109, 111 a tool definition file, 127	C routine defines, 184 calibration device, 104 C-arm tracker, 104 catheter, 104 changes in implementation, 5, 192 characterized measurement volume Polaris Vega, 136 selecting, 173 shape types and parameters, 135 user parameters, 31 clock parameters, 40 combined firmware revision, 37, 167 COMM command, 74 commands complete list, 1 reply format, 12 syntax, 11 timeouts, 33 used with user parameters, 20 communication parameters, 74 with an NDI system, 10 Config.Password, 182 configuration of a tool, 148 contact information, iv CRC calculating using a C routine, 185 reply format, 12 current sensing, 105 current test, 144 customer number, 36
bad transformation fit, 58, 154 baud rate, 74 BEEP command, 51 beeper, 33 buffer limitation, 57, 153 bump sensor reporting data when triggered, 60, 157 user parameters, 32, 34, 43 button box, 98, 104 BX command, 53 BX2 command, 64	data bits, 74 data buffer limitation, 57, 153 default user parameter values, 77 defines, 184 device address, 38 information, 37 instance, 37 names, 20 port, 38 type, 37 DFTL command, 77

Diagnostic mode defined, 11 start, 79	F
stop, 80	feature keys
<del>-</del>	
diagnostic pending, 55, 151	250 Hz tracking, 182
disabled port handle, 16, 54, 150	enabling and disabling, 180
disabling	multi firmware, 181
keyed features, 180	password protect, 130, 182
port handles, 97	positioning laser, 182
DSTART command, 79	radiation robustness, 183
DSTOP command, 80	serial communications, 182
dynamic tool, 98	user parameters, 35
	video camera, 183
_	features of the system, 133
E	fell behind while processing, 57, 58, 153, 154
	firmware
	multiple versions, 181
ECHO command, 81	versions, 167
electrical current test, 144	foot switch, 104
electrical information, 105	
email NDI, iv	frame number, 57, 153
enabled tools, 35	freeing port handles, 102
enabling	
keyed features, 180	G
port handles, 98	•
enumeration list, 85	
error	GET command, 82
algorithm limitation, 57, 153	GETINFO command, 84
_	•
bad transformation fit, 58, 154	GETI OC
codes, 176	GETLOG command, 87
data buffer limitation, 57, 153	
fell behind while processing, 57, 58, 153, 154	Н
IR interference, 57, 58, 153, 154	"
not enough markers, 58, 154	
processing exception, 55, 57, 58, 151, 153,	handles
154	see port handles
RMS error, 56, 152	
synchronization, 55, 151	hard reset, 129
temperature out of range, 55, 151	hardware device
Euler angles	see device
converting from quaternion, 191	hardware handshaking, 75
converting to rotation matrix, 187	hardware model, 36
determining from rotation matrix, 190	
determining sine and cosine, 186	1
determining sine and cosme, 100	I
	:11:
	illuminator rate, 32
	image capture
	commands, 169, 174
	user parameters, 30
	information user parameters, 33
	INIT command, 89
	initializing
	port handles, 114
	the system, 89

input/output line	mode		
setting, 133	Diagnostic, 11		
status, 87	Setup, 11		
IR	Tracking, 11		
interference, 57, 58, 153, 154	user parameter, 33 model, 36 modes of operation, 11		
IRATE command, 91			
IRED command, 93			
IRED marker activation, 93	multi firmware feature, 37, 181		
isolation box, 104			
	M		
<b>V</b>	N		
K			
	NDL iv		
Irayyad faatumaa 25	NDI, iv		
keyed features, 35	not enough markers, 58, 154		
250 Hz tracking, 182			
enabling and disabling, 180	0		
multi firmware, 37, 181	•		
password protect, 182			
positioning laser, 182	operating modes, 11		
radiation robustness, 183	out of volume		
serial communications, 182	markers on tools, 60, 154, 156		
	reporting OOV data, 60, 157		
L	stray active marker, 59, 155		
_	stray passive markers, 61, 158		
	tools, 57, 153		
laser	output line		
keyed feature, 182	setting, 133		
status, 31	status, 87		
LED	,		
see also visible LEDs	_		
LED command, 95	Р		
line separation, 47, 48			
list of commands, 1			
log file	parameters		
retrieving, 87	see user parameters		
user parameter, 34	parity, 74		
writing to, 142	part number of tool, 106		
	partially out of volume, 57, 153		
	passive tools		
М	number of ports available, 35, 134		
	password protect feature, 130, 182		
C 4 2 ID 104	PDIS command, 97		
manufacturer's ID, 104	PENA command, 98		
markers	PFSEL command, 100		
3D positions, 45	phantom markers, 49		
activating, 93	PHF command, 102		
information, 58, 154	PHINF command, 103		
missing, 58, 154	PHRQ command, 109		
wavelength, 107	PHSR command, 111		
maximum marker angle, 58, 154	physical port location, 107		
microscope, 104	PINIT command, 114		
missing			
marker, 58, 154			
transformation, 57, 153			

port handles	S
about, 15	•
disabled, 150	
disabling, 97	SAVE command, 130
enabling, 98	sending commands, 11
freeing, 102	sensitivity level, 32
information, 111	serial communication parameters, 74
initializing, 114	serial communications feature, 182
physical location, 103	serial number
physical port location, 107	Position Sensor, 36
requesting, 109	tool, 105
status, 103, 111	video camera, 36
tool information, 103	SET command, 131, 182
unoccupied, 16	SETIO command, 133
port status, 57, 105, 153	settings user parameters, 31
positioning laser feature, 182	Setup mode, 11
PPRD command, 116	SFLIST command, 133
PPWR command, 118	simulated alerts, 33
probe, 104	soft reset, 129
processing exception, 55, 57, 58, 151, 153, 154	software-defined tool, 104
PURD command, 123	SROM device
PUWR command, 125	ID, 120
PVWR command, 127	reading, 116, 123
I V W K Command, 127	_
	writing to, 118, 125
Q	SROM Image file see tool definition file
	start
quaternion	Diagnostic mode, 79
converting to Euler angles, 191	Tracking mode, 146
converting to rotation matrix, 188	static tool, 98
E ,	status
_	port handles, 57, 103, 153
R	switches, 105, 153
	system, 55
	stop
radiation robustness feature, 183	Diagnostic mode, 80
reading the SROM device, 116, 123	Tracking mode, 147
receiving replies, 12	stop bits, 75
reference tool, 104	stray markers
releasing port handles, 102	3D position, 158
reply format, 12	active, 59
requesting a port handle, 109	passive, 61, 62
RESET command, 129	STREAM command, 140
resetting the system, 129	strober, 104
revision of API, 50	switches
RMS error, 56, 152	number of, 104
rotation matrix	status, 105, 153
converting from Euler, 187	supported, 106
converting from quaternion, 188	sync port
converting to Euler angles, 190	setting the value, 133
	status, 87
	synchronization error, 55, 151
	syntax, 11
	SYSLOG command, 142
	system alerts, 22, 34

system beeper, 33, 51 system configuration user parameters, 37	U
system control processor, 167	
system features, 133	unique geometry requirements, 98, 179
system log, 34, 142	unoccupied port handle, 16
system mode, 33	user parameters
system status, 55, 151	about, 19
	alerts parameters, 22
	bump sensor, 43
T	commands, 20
	Config.Password, 182
	device names, 20
TCTST command, 144	enumeration list, 85
temperature out of range	•
error, 55, 151	hardware device information, 37
reporting data, 157	image capture parameters, 30
test configuration, 148	information parameters, 33
testing electrical current, 144	restoring default values, 77
timeout	retrieving descriptive information, 84
commands, 33	retrieving values, 82
tool definition file, 127	saving values, 130
Tool Docking Station, 104	setting values, 131
tool-in-port, 105, 110, 112, 134	settings parameters, 31
tools	system configuration, 37
	video camera, 40
active wireless, 35	volume user parameters, 40
enabled, 35	USTREAM command, 162
information, 58, 154	
part number, 106	
passive, 35	V
physical location, 107	
revision, 104	
serial number, 105	VCAP command, 163
SROM device ID, 120	VER command, 167
test configuration, 148	version of API, 50
tracking LED, 106	versions of firmware, 167
tracking priority, 98	video camera
type, 104	user parameters, 34
tracking LED, 106	video capture, 174
Tracking mode	visible LEDs
about, 11	controlling, 95
start, 146	number of, 104
stop, 147	supported, 106
tracking priority, 98	tool tracking LED, 106
transformations	VSEL command, 173
bad fit, 58, 154	VSNAP command, 174
binary, 53	,
disabled, 16	
missing, 57, 153	W
text, 150	
TSTART command, 146	
TSTOP command, 147	warning codes, 98, 179
The state of the s	warning message, 115
TTCFG command, 148	warnings, iii
TX command, 150	wavelength of markers, 107
type of tool, 104	writing to the SROM device, 118, 125