OPL1000_WIFI_BLE_API_GUIDE v1.1.1.3

Generated by Doxygen 1.8.14

Contents

1	SDK	PREVI	EW	1
2	Mod	lule Inde	ex	3
	2.1	Module	es	3
3	Data	Struct	ure Index	5
	3.1	Data S	Structures	5
4	Mod	lule Dod	cumentation	9
	4.1	BLE A	LL APIs	9
		4.1.1	Detailed Description	9
		4.1.2	Function Documentation	9
			4.1.2.1 LeSmpGetBondIdFromAddr()	9
	4.2	BLE C	:M APIs	10
		4.2.1	Detailed Description	11
		4.2.2	Typedef Documentation	11
			4.2.2.1 LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T	11
			4.2.2.2 LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T	
			4.2.2.3 LE_CM_MSG_CANCEL_CONNECTION_CFM_T	
			4.2.2.4 LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T	
			4.2.2.5 LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T	
			4.2.2.6 LE_CM_MSG_CREATE_CONNECTION_CFM_T	12
			4.2.2.7 LE_CM_MSG_ENTER_ADVERTISING_CFM_T	12
			4.2.2.8 LE_CM_MSG_ENTER_SCANNING_CFM_T	12
			4.2.2.9 LE CM MSG EXIT ADVERTISING CFM T	12

ii CONTENTS

	4.2.2.10	LE_CM_MSG_EXIT_SCANNING_CFM_T	12
	4.2.2.11	LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T	13
	4.2.2.12	LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T	13
	4.2.2.13	LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T	13
	4.2.2.14	LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T	13
	4.2.2.15	LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T	13
	4.2.2.16	LE_CM_MSG_SET_CHANNEL_MAP_CFM_T	13
	4.2.2.17	LE_CM_MSG_SET_DEFAULT_PHY_CFM_T	13
	4.2.2.18	LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T	13
	4.2.2.19	LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T	14
	4.2.2.20	LE_CM_MSG_SET_SCAN_PARAMS_CFM_T	14
	4.2.2.21	LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T	14
4.2.3	Enumera	tion Type Documentation	14
	4.2.3.1	anonymous enum	14
4.2.4	Function	Documentation	15
	4.2.4.1	LeCmInit()	15
BLE G	AP APIs		17
4.3.1	Detailed	Description	19
4.3.2	Macro De	efinition Documentation	19
	4.3.2.1	GAP_ADTYPE_128BIT_COMPLETE	19
	4.3.2.2	GAP_ADTYPE_128BIT_MORE	19
	4.3.2.3	GAP_ADTYPE_16BIT_COMPLETE	20
	4.3.2.4	GAP_ADTYPE_16BIT_MORE	20
	4.3.2.5	GAP_ADTYPE_32BIT_COMPLETE	20
	4.3.2.6	GAP_ADTYPE_32BIT_MORE	20
	4.3.2.7	GAP_ADTYPE_3D_INFO_DATA	20
	4.3.2.8	GAP_ADTYPE_ADV_INTERVAL	20
	4.3.2.9	GAP_ADTYPE_APPEARANCE	20
	4.3.2.10	GAP_ADTYPE_FLAGS	20
	4.3.2.11	GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED	21
	4.2.4 BLE G 4.3.1	4.2.2.11 4.2.2.12 4.2.2.13 4.2.2.14 4.2.2.15 4.2.2.16 4.2.2.17 4.2.2.18 4.2.2.19 4.2.2.20 4.2.2.21 4.2.3 Enumera 4.2.3.1 4.2.4 Function 4.2.4.1 BLE GAP APIs 4.3.1 Detailed 4.3.2 Macro Date 4.3.2.1 4.3.2.2 4.3.2.3 4.3.2.4 4.3.2.5 4.3.2.5 4.3.2.6 4.3.2.7 4.3.2.8 4.3.2.9 4.3.2.10	4.2.11 LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T 4.2.12 LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T 4.2.13 LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T 4.2.14 LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T 4.2.15 LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T 4.2.16 LE_CM_MSG_SET_CHANNEL_MAP_CFM_T 4.2.17 LE_CM_MSG_SET_DEFAULT_PHY_CFM_T 4.2.18 LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T 4.2.210 LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T 4.2.221 LE_CM_MSG_SET_SCAN_PARAMS_CFM_T 4.2.221 LE_CM_MSG_SET_SCAN_PARAMS_CFM_T 4.2.23 Enumeration Type Documentation 4.2.3.1 anonymous enum 4.2.4.1 LeCM_INIT_DOCUMENTATION 4.2.4.1 LeCM_INIT_DOCUMENTATION 4.2.4.1 LeCM_INIT_DOCUMENTATION 4.2.4.1 LeCM_INIT_DOCUMENTATION 4.2.4.1 GAP_ADTYPE_128BIT_COMPLETE 4.3.2.1 GAP_ADTYPE_128BIT_MORE 4.3.2.1 GAP_ADTYPE_16BIT_COMPLETE 4.3.2.2 GAP_ADTYPE_16BIT_COMPLETE 4.3.2.3 GAP_ADTYPE_16BIT_MORE 4.3.2.4 GAP_ADTYPE_32BIT_MORE 4.3.2.5 GAP_ADTYPE_32BIT_MORE 4.3.2.6 GAP_ADTYPE_32BIT_MORE 4.3.2.7 GAP_ADTYPE_32BIT_MORE 4.3.2.8 GAP_ADTYPE_32BIT_MORE 4.3.2.9 GAP_ADTYPE_APPEARANCE 4.3.2.9 GAP_ADTYPE_APPEARANCE

4.3.2.12	GAP_ADTYPE_FLAGS_GENERAL	21
4.3.2.13	GAP_ADTYPE_FLAGS_LIMITED	21
4.3.2.14	GAP_ADTYPE_LE_BD_ADDR	21
4.3.2.15	GAP_ADTYPE_LE_ROLE	21
4.3.2.16	GAP_ADTYPE_LOCAL_NAME_COMPLETE	21
4.3.2.17	GAP_ADTYPE_LOCAL_NAME_SHORT	21
4.3.2.18	GAP_ADTYPE_MANUFACTURER_SPECIFIC	21
4.3.2.19	GAP_ADTYPE_OOB_CLASS_OF_DEVICE	22
4.3.2.20	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC	22
4.3.2.21	GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR	22
4.3.2.22	GAP_ADTYPE_POWER_LEVEL	22
4.3.2.23	GAP_ADTYPE_PUBLIC_TARGET_ADDR	22
4.3.2.24	GAP_ADTYPE_RANDOM_TARGET_ADDR	22
4.3.2.25	GAP_ADTYPE_SERVICE_DATA	22
4.3.2.26	GAP_ADTYPE_SERVICE_DATA_128BIT	22
4.3.2.27	GAP_ADTYPE_SERVICE_DATA_32BIT	23
4.3.2.28	GAP_ADTYPE_SERVICES_LIST_128BIT	23
4.3.2.29	GAP_ADTYPE_SERVICES_LIST_16BIT	23
4.3.2.30	GAP_ADTYPE_SIGNED_DATA	23
4.3.2.31	GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256	23
4.3.2.32	GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256	23
4.3.2.33	GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE	23
4.3.2.34	GAP_ADTYPE_SM_OOB_FLAG	23
4.3.2.35	GAP_ADTYPE_SM_TK	24
4.3.2.36	GAP_PUBLIC_ADDR	24
4.3.2.37	GAP_RAND_ADDR_NRPA	24
4.3.2.38	GAP_RAND_ADDR_RPA	24
4.3.2.39	GAP_RAND_ADDR_STATIC	24
4.3.2.40	GAP_SCAN_TYPE_ACTIVE	24
4.3.2.41	GAP_SCAN_TYPE_PASSIVE	24

iv CONTENTS

	4.3.2.42	GAP_TX_PWR_CURR_VAL	24
	4.3.2.43	GAP_TX_PWR_MAX_VAL	25
	4.3.2.44	GAPBOND_IO_CAP_DISPLAY_ONLY	25
	4.3.2.45	GAPBOND_IO_CAP_DISPLAY_YES_NO	25
	4.3.2.46	GAPBOND_IO_CAP_KEYBOARD_DISPLAY	25
	4.3.2.47	GAPBOND_IO_CAP_KEYBOARD_ONLY	25
	4.3.2.48	GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT	25
	4.3.2.49	GAPBOND_PAIRING_MODE_INITIATE	25
	4.3.2.50	GAPBOND_PAIRING_MODE_NO_PAIRING	25
	4.3.2.51	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ	26
	4.3.2.52	LE_GAP_ADV_MAX_SIZE	26
4.3.3	Function	Documentation	26
	4.3.3.1	LeGapAddToResolvingList()	26
	4.3.3.2	LeGapAddToWhiteList()	26
	4.3.3.3	LeGapAdvertisingEnable()	27
	4.3.3.4	LeGapCentralConnectReq()	27
	4.3.3.5	LeGapCentralSetDataChannel()	27
	4.3.3.6	LeGapClearResolvingList()	29
	4.3.3.7	LeGapClearWhiteList()	29
	4.3.3.8	LeGapConnectCancelReq()	29
	4.3.3.9	LeGapConnParaRequestRsp()	29
	4.3.3.10	LeGapConnUpdateRequest()	30
	4.3.3.11	LeGapConnUpdateResponse()	30
	4.3.3.12	LeGapDisconnectReq()	31
	4.3.3.13	LeGapGenRandAddr()	31
	4.3.3.14	LeGapGetBtAddr()	31
	4.3.3.15	LeGapReadAdvChannelTxPower()	32
	4.3.3.16	LeGapReadChannelMap()	32
	4.3.3.17	LeGapReadPhy()	32
	4.3.3.18	LeGapReadResolvingListSize()	32

		4.3.3.19	LeGapReadRssi()	32
		4.3.3.20	LeGapReadTxPower()	33
		4.3.3.21	LeGapReadWhiteListSize()	33
		4.3.3.22	LeGapRemoveFromWhiteList()	33
		4.3.3.23	LeGapScanningReq()	34
		4.3.3.24	LeGapSetAdvData()	34
		4.3.3.25	LeGapSetAdvParameter()	35
		4.3.3.26	LeGapSetConnParameter()	35
		4.3.3.27	LeGapSetDataChannelPduLen()	35
		4.3.3.28	LeGapSetDefaultPhy()	36
		4.3.3.29	LeGapSetPhy()	36
		4.3.3.30	LeGapSetRandAddr()	36
		4.3.3.31	LeGapSetRpaTimeout()	37
		4.3.3.32	LeGapSetStaticAddr()	37
		4.3.3.33	LeSetScanParameter()	37
		4.3.3.34	LeSetScanRspData()	38
4.4	BLE G	ATT APIs		39
	4.4.1	Detailed	Description	43
	4.4.2	Macro De	efinition Documentation	43
		4.4.2.1	CHAR_AGGREGATE_DESCRIPTOR	43
		4.4.2.2	CHAR_CLIENT_CONFIG_DESCRIPTOR	44
		4.4.2.3	CHAR_DECL_UUID16_ATTR_VAL	44
		4.4.2.4	CHAR_EXT_PROP_DESCRIPTOR	44
		4.4.2.5	CHAR_PRESENT_FORMAT_DESCRIPTOR	44
		4.4.2.6	CHAR_SERVER_CONFIG_DESCRIPTOR	44
		4.4.2.7	CHAR_USER_DESC_DESCRIPTOR	44
		4.4.2.8	CHARACTERISTIC_DECL_UUID128	45
		4.4.2.9	CHARACTERISTIC_DECL_UUID16	45
		4.4.2.10	CHARACTERISTIC_UUID128	45
		4.4.2.11	CHARACTERISTIC_UUID16	45

vi

4.4.2.12	GATT_CHAR_AGG_FORMAT_UUID	45
4.4.2.13	GATT_CHAR_EXT_PROPS_UUID	45
4.4.2.14	GATT_CHAR_FORMAT_UUID	46
4.4.2.15	GATT_CHAR_USER_DESC_UUID	46
4.4.2.16	GATT_CHARACTERISTIC_UUID	46
4.4.2.17	GATT_CLIENT_CHAR_CFG_UUID	46
4.4.2.18	GATT_EXT_REPORT_REF_UUID	46
4.4.2.19	GATT_INCLUDE_UUID	46
4.4.2.20	GATT_PRIMARY_SERVICE_UUID	46
4.4.2.21	GATT_REPORT_REF_UUID	46
4.4.2.22	GATT_SECONDARY_SERVICE_UUID	47
4.4.2.23	GATT_SERV_CHAR_CFG_UUID	47
4.4.2.24	GATT_VALID_RANGE_UUID	47
4.4.2.25	INCLUDE_DECL_UUID128	47
4.4.2.26	INCLUDE_DECL_UUID128_ATTR_VAL	47
4.4.2.27	INCLUDE_DECL_UUID16_ATTR_VAL	47
4.4.2.28	INCLUDE_DECL_UUINT16	47
4.4.2.29	LE_ATT_UUID_SIZE	48
4.4.2.30	LE_GATT_CHAR_PROP_AUTH	48
4.4.2.31	LE_GATT_CHAR_PROP_BCAST	48
4.4.2.32	LE_GATT_CHAR_PROP_EXT_PROP	48
4.4.2.33	LE_GATT_CHAR_PROP_IND	48
4.4.2.34	LE_GATT_CHAR_PROP_NTF	48
4.4.2.35	LE_GATT_CHAR_PROP_RD	48
4.4.2.36	LE_GATT_CHAR_PROP_WR	49
4.4.2.37	LE_GATT_CHAR_PROP_WR_NO_RESP	49
4.4.2.38	LE_GATT_CLIENT_CFG_INDICATION	49
4.4.2.39	LE_GATT_CLIENT_CFG_NOTIFICATION	49
4.4.2.40	LE_GATT_EXT_PROP_RELIABLE_WR	49
4.4.2.41	LE_GATT_EXT_PROP_WR_AUX	49

CONTENTS vii

4.4.2.42	LE_GATT_FLAG_PREPARE_WRITE	49
4.4.2.43	LE_GATT_FLAG_WRITE_CMD	49
4.4.2.44	LE_GATT_FLAG_WRITE_REQ	50
4.4.2.45	LE_GATT_PERM_AUTH_READABLE	50
4.4.2.46	LE_GATT_PERM_AUTH_WRITABLE	50
4.4.2.47	LE_GATT_PERM_NONE	50
4.4.2.48	LE_GATT_PERM_READ	50
4.4.2.49	LE_GATT_PERM_RELIABLE_WRITE	50
4.4.2.50	LE_GATT_PERM_WRITE_CMD	50
4.4.2.51	LE_GATT_PERM_WRITE_REQ	50
4.4.2.52	LE_GATT_PERMIT_AUTHEN_READ	51
4.4.2.53	LE_GATT_PERMIT_AUTHEN_WRITE	51
4.4.2.54	LE_GATT_PERMIT_AUTHOR_READ	51
4.4.2.55	LE_GATT_PERMIT_AUTHOR_WRITE	51
4.4.2.56	LE_GATT_PERMIT_ENCRYPT_READ	51
4.4.2.57	LE_GATT_PERMIT_ENCRYPT_WRITE	51
4.4.2.58	LE_GATT_PERMIT_READ	51
4.4.2.59	LE_GATT_PERMIT_READABLE	51
4.4.2.60	LE_GATT_PERMIT_SC_AUTHEN_READ	52
4.4.2.61	LE_GATT_PERMIT_SC_AUTHEN_WRITE	52
4.4.2.62	LE_GATT_PERMIT_WRITABLE	52
4.4.2.63	LE_GATT_PERMIT_WRITE	52
4.4.2.64	PRIMARY_SERVICE_DECL_UUID128	52
4.4.2.65	PRIMARY_SERVICE_DECL_UUID16	52
4.4.2.66	SECONDARY_SERVICE_DECL_UUID128	52
4.4.2.67	SECONDARY_SERVICE_DECL_UUID16	53
Enumera	tion Type Documentation	53
4.4.3.1	anonymous enum	53
Function	Documentation	54
4.4.4.1	LeGattAccessReadRsp()	54

4.4.3

4.4.4

viii CONTENTS

4.4.4.2	LeGattAccessWriteRsp()	54
4.4.4.3	LeGattChangeAttrVal()	55
4.4.4.4	LeGattCharValConfirmation()	55
4.4.4.5	LeGattCharValIndicate()	56
4.4.4.6	LeGattCharValNotify()	56
4.4.4.7	LeGattExchangeMtuReq()	57
4.4.4.8	LeGattExchangeMtuRsp()	57
4.4.4.9	LeGattExecuteWriteCharValReliable()	58
4.4.4.10	LeGattFindAllCharacteristic()	58
4.4.4.11	LeGattFindAllCharDescriptor()	58
4.4.4.12	LeGattFindAllPrimaryService()	59
4.4.4.13	LeGattFindCharacteristicByUuid()	59
4.4.4.14	LeGattFindIncludedService()	60
4.4.4.15	LeGattFindPrimaryServiceByUuid()	60
4.4.4.16	LeGattGetAttrHandle()	61
4.4.4.17	LeGattGetAttrVal()	61
4.4.4.18	LeGattGetAttrValLen()	61
4.4.4.19	LeGattGetAttrValMaxLen()	63
4.4.4.20	LeGattInit()	63
4.4.4.21	LeGattModifyAttrVal()	64
4.4.4.22	LeGattPrepareWriteCharValReliable()	64
4.4.4.23	LeGattReadCharValByUuid()	65
4.4.4.24	LeGattReadCharValue()	65
4.4.4.25	LeGattReadLongCharVal()	66
4.4.4.26	LeGattReadMultipleCharVal()	66
4.4.4.27	LeGattRegisterIncludeService()	66
4.4.4.28	LeGattRegisterService()	67
4.4.4.29	LeGattSignedWriteNoRsp()	67
4.4.4.30	LeGattStopCurrentProcedure()	68
4.4.4.31	LeGattWriteCharVal()	68

		4.4.4.32	LeGattWriteCharValReliable()	69
		4.4.4.33	LeGattWriteLongCharVal()	69
		4.4.4.34	LeGattWriteNoRsp()	70
	4.4.5	Variable l	Documentation	70
		4.4.5.1	gcCharacteristicUuid	70
		4.4.5.2	gcCharAggregateUuid	70
		4.4.5.3	gcCharExtPropUuid	71
		4.4.5.4	gcCharFormatUuid	71
		4.4.5.5	gcCharUserDescUuid	71
		4.4.5.6	gcClientCharConfigUuid	71
		4.4.5.7	gcExtReportRefUuid	71
		4.4.5.8	gcIncludeUuid	71
		4.4.5.9	gcPrimaryServiceUuid	71
		4.4.5.10	gcReportRefUuid	71
		4.4.5.11	gcSecondaryServiceUuid	72
		4.4.5.12	gcServerCharConfigUuid	72
		4.4.5.13	gcValidRangeUuid	72
4.5	BLE M	SG APIs		73
	4.5.1	Detailed	Description	74
	4.5.2	Macro De	efinition Documentation	74
		4.5.2.1	LE_ATT_MSG_BASE	74
		4.5.2.2	LE_CM_MSG_BASE	74
		4.5.2.3	LE_GATT_MSG_BASE	75
		4.5.2.4	LE_HCI_MSG_BASE	75
		4.5.2.5	LE_L2CAP_MSG_BASE	75
		4.5.2.6	LE_SMP_MSG_BASE	75
		4.5.2.7	LE_SYS_MSG_BASE	75
		4.5.2.8	MESSAGE_ALLOCATE	75
		4.5.2.9	MESSAGE_BULID	75
		4.5.2.10	MESSAGE_DATA_BULID	76

	4.5.2.11	MESSAGE_OFFSET	76
	4.5.2.12	T_HOUR	76
	4.5.2.13	T_MIN	76
	4.5.2.14	T_SEC	76
4.5.3	Typedef I	Documentation	76
	4.5.3.1	MESSAGE	76
	4.5.3.2	MESSAGEID	77
	4.5.3.3	MsgData	77
	4.5.3.4	MsgLock	77
	4.5.3.5	MSGLOCK	77
	4.5.3.6	MSGSUBID	77
	4.5.3.7	MSGTIMER	77
	4.5.3.8	Task	77
	4.5.3.9	TASK	77
	4.5.3.10	TASKHANDLER	78
	4.5.3.11	TASKPACK	78
4.5.4	Enumera	tion Type Documentation	78
	4.5.4.1	anonymous enum	78
4.5.5	Function	Documentation	78
	4.5.5.1	LeCancelAllMessage()	78
	4.5.5.2	LeCancelAllSubMessage()	79
	4.5.5.3	LeCancelFirstMessage()	79
	4.5.5.4	LeCancelFirstSubMessage()	80
	4.5.5.5	LeGetSubMsgld()	80
	4.5.5.6	LeHostCreateTask()	80
	4.5.5.7	LeHostMessageLoop()	81
	4.5.5.8	LeSendMessage()	81
	4.5.5.9	LeSendMessageAfter()	81
	4.5.5.10	LeSendMessageUnlock()	82
	4.5.5.11	LeSendSubMessage()	82

CONTENTS xi

		4.5.5.12	LeSendSubMessageAfter()	83
		4.5.5.13	LeSendSubMessageUnlock()	83
4.6	BLE SI	MP APIs		85
	4.6.1	Detailed	Description	86
	4.6.2	Macro De	efinition Documentation	86
		4.6.2.1	LE_MAX_BOND_COUNT	86
		4.6.2.2	LE_SM_IO_CAP_DISP_ONLY	86
		4.6.2.3	LE_SM_IO_CAP_DISP_YES_NO	86
		4.6.2.4	LE_SM_IO_CAP_KEYBOARD_DISP	87
		4.6.2.5	LE_SM_IO_CAP_KEYBOARD_ONLY	87
		4.6.2.6	LE_SM_IO_CAP_NO_IO	87
		4.6.2.7	LE_SM_PAIR_MITM_NO	87
		4.6.2.8	LE_SM_PAIR_MITM_YES	87
		4.6.2.9	LE_SM_PAIR_OOB_NO	87
		4.6.2.10	LE_SM_PAIR_OOB_YES	87
		4.6.2.11	LE_SM_PAIR_SC_NO	87
		4.6.2.12	LE_SM_PAIR_SC_YES	88
	4.6.3	Enumera	tion Type Documentation	88
		4.6.3.1	anonymous enum	88
		4.6.3.2	anonymous enum	88
	4.6.4	Function	Documentation	89
		4.6.4.1	LeSmpInit()	89
		4.6.4.2	LeSmpOobAuthDataRsp()	89
		4.6.4.3	LeSmpOobPresent()	89
		4.6.4.4	LeSmpPasskeyInput()	90
		4.6.4.5	LeSmpScOobComputeConfirmVal()	90
		4.6.4.6	LeSmpScOobDataRsp()	91
		4.6.4.7	LeSmpSecurityReq()	91
		4.6.4.8	LeSmpSecurityRsp()	91
		4.6.4.9	LeSmpSetDefaultConfig()	92

xii CONTENTS

		4.6.4.10	LeSmpUserConfirmRsp()	92
4.7	WIFI A	NPIs		93
	4.7.1	Detailed D	Description	94
	4.7.2	Macro De	finition Documentation	94
		4.7.2.1	WIFI_BEACON_INTERVAL_LENGTH	94
		4.7.2.2	WIFI_CAPABILITY_INFO_LENGTH	95
		4.7.2.3	WIFI_LENGTH_802_11	95
		4.7.2.4	WIFI_LENGTH_PASSPHRASE	95
		4.7.2.5	WIFI_MAC_ADDRESS_LENGTH	95
		4.7.2.6	WIFI_MAX_LENGTH_OF_SSID	95
		4.7.2.7	WIFI_MAX_SCAN_AP_NUM	95
		4.7.2.8	WIFI_MAX_SUPPORTED_RATES	96
	4.7.3	Typedef D	Oocumentation	96
		4.7.3.1	wifi_ap_record_t	96
		4.7.3.2	wifi_event_notify_cb_t	96
	4.7.4	Enumerat	ion Type Documentation	96
		4.7.4.1	wifi_auto_connet_mode_e	96
	4.7.5	Function [Documentation	96
		4.7.5.1	wifi_event_process_handler()	96
		4.7.5.2	wifi_install_default_event_handlers()	97
		4.7.5.3	wifi_register_event_handler()	97
4.8	WIFI C	Common AP	Pls	99
	4.8.1	Detailed [Description	99
	4.8.2	Typedef D	Occumentation	99
		4.8.2.1	wifi_event_cb_t	99
	4.8.3	Function I	Documentation	99
		4.8.3.1	wifi_event_loop_init()	99
		4.8.3.2	wifi_event_loop_send()	100
		4.8.3.3	wifi_event_loop_set_cb()	100
		4.8.3.4	wifi_event_process_handler()	101

CONTENTS xiii

4.9	WIFI S	TA APIs
	4.9.1	Detailed Description
	4.9.2	Macro Definition Documentation
		4.9.2.1 WIFI_READY_TIME
	4.9.3	Typedef Documentation
		4.9.3.1 wifi_auto_connect_clear_ap_info_fp_t
		4.9.3.2 wifi_auto_connect_get_ap_info_fp_t
		4.9.3.3 wifi_auto_connect_get_ap_num_fp_t
		4.9.3.4 wifi_auto_connect_get_mode_fp_t
		4.9.3.5 wifi_auto_connect_init_fp_t
		4.9.3.6 wifi_auto_connect_reset_fp_t
		4.9.3.7 wifi_auto_connect_set_ap_num_fp_t
		4.9.3.8 wifi_auto_connect_set_mode_fp_t
		4.9.3.9 wifi_auto_connect_start_fp_t
		4.9.3.10 wifi_config_get_bandwidth_fp_t
		4.9.3.11 wifi_config_get_bssid_fp_t
		4.9.3.12 wifi_config_get_channel_fp_t
		4.9.3.13 wifi_config_get_dtim_interval_fp_t
		4.9.3.14 wifi_config_get_listen_interval_fp_t
		4.9.3.15 wifi_config_get_mac_address_fp_t
		4.9.3.16 wifi_config_get_opmode_fp_t
		4.9.3.17 wifi_config_get_ssid_fp_t
		4.9.3.18 wifi_config_set_bandwidth_fp_t
		4.9.3.19 wifi_config_set_bssid_fp_t
		4.9.3.20 wifi_config_set_channel_fp_t
		4.9.3.21 wifi_config_set_dtim_interval_fp_t
		4.9.3.22 wifi_config_set_listen_interval_fp_t
		4.9.3.23 wifi_config_set_mac_address_fp_t
		4.9.3.24 wifi_config_set_opmode_fp_t
		4.9.3.25 wifi_config_set_ssid_fp_t

xiv CONTENTS

4.9.3.26	wifi_connection_connect_fp_t	109
4.9.3.27	wifi_connection_disconnect_ap_fp_t	109
4.9.3.28	wifi_connection_disconnect_sta_fp_t	110
4.9.3.29	wifi_connection_get_rssi_fp_t	110
4.9.3.30	wifi_connection_register_event_handler_fp_t	110
4.9.3.31	wifi_connection_scan_start_fp_t	110
4.9.3.32	wifi_connection_unregister_event_handler_fp_t	110
4.9.3.33	wifi_convert_auth_mode_fp_t	110
4.9.3.34	wifi_deinit_fp_t	110
4.9.3.35	wifi_event_handler_t	110
4.9.3.36	wifi_fast_connect_get_mode_fp_t	111
4.9.3.37	wifi_fast_connect_set_mode_fp_t	111
4.9.3.38	wifi_fast_connect_start_fp_t	111
4.9.3.39	wifi_get_config_fp_t	111
4.9.3.40	wifi_init_complete_cb_t	111
4.9.3.41	wifi_init_fp_t	112
4.9.3.42	wifi_result_t	112
4.9.3.43	wifi_scan_get_ap_list_fp_t	112
4.9.3.44	wifi_scan_get_ap_num_fp_t	112
4.9.3.45	wifi_scan_get_ap_records_fp_t	112
4.9.3.46	wifi_scan_start_fp_t	112
4.9.3.47	wifi_scan_stop_fp_t	113
4.9.3.48	wifi_set_config_fp_t	113
4.9.3.49	wifi_sta_get_ap_info_fp_t	113
4.9.3.50	wifi_start_fp_t	113
4.9.3.51	wifi_stop_fp_t	113
Function	Documentation	113
4.9.4.1	wifi_auto_connect_clear_ap_info()	113
4.9.4.2	wifi_auto_connect_get_ap_info()	114
4.9.4.3	wifi_auto_connect_get_ap_num()	114

4.9.4

CONTENTS xv

4.9.4.4	wifi_auto_connect_get_mode()
4.9.4.5	wifi_auto_connect_init()
4.9.4.6	wifi_auto_connect_reset()
4.9.4.7	wifi_auto_connect_set_ap_num()
4.9.4.8	wifi_auto_connect_set_mode() 110
4.9.4.9	wifi_auto_connect_start()
4.9.4.10	wifi_config_get_bandwidth()
4.9.4.11	wifi_config_get_bssid()
4.9.4.12	wifi_config_get_channel()
4.9.4.13	wifi_config_get_dtim_interval()
4.9.4.14	wifi_config_get_listen_interval()
4.9.4.15	wifi_config_get_mac_address()
4.9.4.16	wifi_config_get_opmode()
4.9.4.17	wifi_config_get_skip_dtim()
4.9.4.18	wifi_config_get_ssid()
4.9.4.19	wifi_config_set_bandwidth()
4.9.4.20	wifi_config_set_bssid()
4.9.4.21	wifi_config_set_channel()
4.9.4.22	wifi_config_set_dtim_interval()
4.9.4.23	wifi_config_set_listen_interval()
4.9.4.24	wifi_config_set_mac_address()
4.9.4.25	wifi_config_set_opmode()
4.9.4.26	wifi_config_set_skip_dtim()
4.9.4.27	wifi_config_set_ssid()
4.9.4.28	wifi_connection_connect()
4.9.4.29	wifi_connection_connect_from_ac_index()
4.9.4.30	wifi_connection_connect_from_ac_list()
4.9.4.31	wifi_connection_disconnect_ap()
4.9.4.32	wifi_connection_disconnect_sta()
4.9.4.33	wifi_connection_get_rssi()

xvi CONTENTS

	4.9.4.34	wifi_connection_register_event_handler()	127
	4.9.4.35	wifi_connection_scan_start()	127
	4.9.4.36	wifi_connection_unregister_event_handler()	128
	4.9.4.37	wifi_convert_auth_mode()	128
	4.9.4.38	wifi_deinit()	128
	4.9.4.39	wifi_fast_connect_get_mode()	128
	4.9.4.40	wifi_fast_connect_set_mode()	129
	4.9.4.41	wifi_fast_connect_start()	129
	4.9.4.42	wifi_get_config()	130
	4.9.4.43	wifi_init()	130
	4.9.4.44	wifi_scan_get_ap_list()	131
	4.9.4.45	wifi_scan_get_ap_num()	131
	4.9.4.46	wifi_scan_get_ap_records()	132
	4.9.4.47	wifi_scan_scan_stop()	132
	4.9.4.48	wifi_scan_start()	132
	4.9.4.49	wifi_set_config()	133
	4.9.4.50	wifi_sta_get_ap_info()	133
	4.9.4.51	wifi_start()	134
	4.9.4.52	wifi_stop()	134
4.9.5	Variable I	Documentation	134
	4.9.5.1	wifi_auto_connect_clear_ap_info_api	135
	4.9.5.2	wifi_auto_connect_get_ap_info_api	135
	4.9.5.3	wifi_auto_connect_get_ap_num_api	135
	4.9.5.4	wifi_auto_connect_get_mode_api	135
	4.9.5.5	wifi_auto_connect_init_api	135
	4.9.5.6	wifi_auto_connect_reset_api	135
	4.9.5.7	wifi_auto_connect_set_ap_num_api	135
	4.9.5.8	wifi_auto_connect_set_mode_api	135
	4.9.5.9	wifi_auto_connect_start_api	136
	4.9.5.10	wifi_config_get_bandwidth_api	136

CONTENTS xvii

4.9.5.11	wifi_config_get_bssid_api	136
4.9.5.12	wifi_config_get_channel_api	136
4.9.5.13	wifi_config_get_dtim_interval_api	136
4.9.5.14	wifi_config_get_listen_interval_api	136
4.9.5.15	wifi_config_get_mac_address_api	136
4.9.5.16	wifi_config_get_opmode_api	136
4.9.5.17	wifi_config_get_ssid_api	137
4.9.5.18	wifi_config_set_bandwidth_api	137
4.9.5.19	wifi_config_set_bssid_api	137
4.9.5.20	wifi_config_set_channel_api	137
4.9.5.21	wifi_config_set_dtim_interval_api	137
4.9.5.22	wifi_config_set_listen_interval_api	137
4.9.5.23	wifi_config_set_mac_address_api	137
4.9.5.24	wifi_config_set_opmode_api	137
4.9.5.25	wifi_config_set_ssid_api	138
4.9.5.26	wifi_connection_connect_api	138
4.9.5.27	wifi_connection_disconnect_ap_api	138
4.9.5.28	wifi_connection_disconnect_sta_api	138
4.9.5.29	wifi_connection_get_rssi_api	138
4.9.5.30	wifi_connection_register_event_handler_api	138
4.9.5.31	wifi_connection_scan_start_api	138
4.9.5.32	wifi_connection_unregister_event_handler_api	138
4.9.5.33	wifi_convert_auth_mode_api	139
4.9.5.34	wifi_deinit_api	139
4.9.5.35	wifi_fast_connect_get_mode_api	139
4.9.5.36	wifi_fast_connect_set_mode_api	139
4.9.5.37	wifi_fast_connect_start_api	139
4.9.5.38	wifi_get_config_api	139
4.9.5.39	wifi_init_api	139
4.9.5.40	wifi_scan_get_ap_list_api	139

xviii CONTENTS

	4.9.5.41	wifi_scan_get	_ap_num_a	api	 	 	 	 	 140
	4.9.5.42	wifi_scan_get	_ap_record	ls_api .	 	 	 	 	 140
	4.9.5.43	wifi_scan_sta	rt_api		 	 	 	 	 140
	4.9.5.44	wifi_scan_sto	o_api		 	 	 	 	 140
	4.9.5.45	wifi_set_confi	g_api		 	 	 	 	 140
	4.9.5.46	wifi_sta_get_a	ap_info_api		 	 	 	 	 140
	4.9.5.47	wifi_start_api			 	 	 	 	 140
	4.9.5.48	wifi_stop_api			 	 	 	 	 140
4.10 Enume	eration				 	 	 	 	 141
4.10.1	Detailed	Description .			 	 	 	 	 141
4.10.2	Enumera	ition Type Docu	mentation		 	 	 	 	 141
	4.10.2.1	wifi_auth_mod	de_t		 	 	 	 	 142
	4.10.2.2	wifi_bandwidt	n_t		 	 	 	 	 143
	4.10.2.3	wifi_cipher_ty	pe_t		 	 	 	 	 143
	4.10.2.4	wifi_event_t			 	 	 	 	 143
	4.10.2.5	wifi_mode_t			 	 	 	 	 144
	4.10.2.6	wifi_reason_c	ode_t		 	 	 	 	 144
	4.10.2.7	wifi_scan_me	thod_t		 	 	 	 	 145
	4.10.2.8	wifi_scan_typ	e_t		 	 	 	 	 146
	4.10.2.9	wifi_sort_metl	nod_t		 	 	 	 	 146

CONTENTS xix

5	Data	Structi	ure Docun	nentation	147
	5.1	_wpa_	ie_data Stı	ruct Reference	147
		5.1.1	Field Doo	cumentation	147
			5.1.1.1	capabilities	147
			5.1.1.2	group_cipher	147
			5.1.1.3	key_mgmt	148
			5.1.1.4	mgmt_group_cipher	148
			5.1.1.5	num_pmkid	148
			5.1.1.6	pairwise_cipher	148
			5.1.1.7	pmkid	148
			5.1.1.8	proto	148
	5.2	asso_c	lata Struct	Reference	148
		5.2.1	Field Doo	cumentation	149
			5.2.1.1	eap_workaround	149
			5.2.1.2	eapol_flags	149
			5.2.1.3	group_cipher	149
			5.2.1.4	key_mgmt	149
			5.2.1.5	leap	149
			5.2.1.6	mgmt_group_cipher	150
			5.2.1.7	non_leap	150
			5.2.1.8	pairwise_cipher	150
			5.2.1.9	passphrase	150
			5.2.1.10	proto	150
			5.2.1.11	psk	150
			5.2.1.12	psk_set	150
	5.3	auto_c	onn_info_t	Struct Reference	150
		5.3.1	Field Doo	cumentation	151
			5.3.1.1	ap_channel	151
			5.3.1.2	beacon_interval	151
			5.3.1.3	bssid	151

		5.3.1.4	capabilities	 151
		5.3.1.5	dtim_prod	 152
		5.3.1.6	fast_connect	 152
		5.3.1.7	free_ocpy	 152
		5.3.1.8	hid_ssid	 152
		5.3.1.9	hid_ssid_len	 152
		5.3.1.10	latest_beacon_rx_time	 152
		5.3.1.11	passphrase	 152
		5.3.1.12	psk	 152
		5.3.1.13	rsn_ie	 153
		5.3.1.14	rssi	 153
		5.3.1.15	ssid	 153
		5.3.1.16	ssid_len	 153
		5.3.1.17	supported_rates	 153
		5.3.1.18	wpa_data	 153
		5.3.1.19	wpa_ie	 153
5.4	auto_c	onnect_cfo	g_t Struct Reference	 153
	5.4.1	Field Doo	cumentation	 154
		5.4.1.1	flag	 154
		5.4.1.2	front	 154
		5.4.1.3	max_save_num	 154
		5.4.1.4	pFCInfo	 154
		5.4.1.5	rear	 154
		5.4.1.6	retryCount	 155
		5.4.1.7	targetldx	 155
		5.4.1.8	uFCApNum	 155
5.5	event_	msg_t Stru	uct Reference	 155
	5.5.1	Detailed	Description	 155
	5.5.2	Field Doo	cumentation	 155
		5.5.2.1	event	 155

CONTENTS xxi

		5.5.2.2	length	156
		5.5.2.3	param	156
5.6	hap_co	ontrol_t St	ruct Reference	156
	5.6.1	Field Do	cumentation	156
		5.6.1.1	hap_ap_info	156
		5.6.1.2	hap_bitvector	156
		5.6.1.3	hap_en	156
		5.6.1.4	hap_final_index	157
		5.6.1.5	hap_index	157
		5.6.1.6	hap_ssid	157
5.7	LE_BT	_ADDR_T	Struct Reference	157
	5.7.1	Field Do	cumentation	157
		5.7.1.1	addr	157
		5.7.1.2	type	157
5.8	LE_CN	/_CONNE	CTION_COMPLETE_IND_T Struct Reference	158
	5.8.1	Field Do	cumentation	158
		5.8.1.1	conn_hdl	158
		5.8.1.2	conn_interval	158
		5.8.1.3	conn_latency	158
		5.8.1.4	dev_id	158
		5.8.1.5	peer_addr	159
		5.8.1.6	peer_addr_type	159
		5.8.1.7	role	159
		5.8.1.8	status	159
		5.8.1.9	supervison_timeout	159
5.9	LE_CN	/I_MSG_A	DVERTISE_REPORT_IND_T Struct Reference	159
	5.9.1	Field Do	cumentation	160
		5.9.1.1	addr	160
		5.9.1.2	addr_type	160
		5.9.1.3	data	160

xxii CONTENTS

	5.9.1.4	event_type	160
	5.9.1.5	len	160
	5.9.1.6	rssi	160
5.10 LE_CM	M_MSG_C	ONN_PARA_REQ_T Struct Reference	160
5.10.1	Field Do	cumentation	161
	5.10.1.1	conn_hdl	161
	5.10.1.2	itv_max	161
	5.10.1.3	itv_min	161
	5.10.1.4	latency	161
	5.10.1.5	sv_tmo	161
5.11 LE_CN	M_MSG_C	ONN_UPDATE_COMPLETE_IND_T Struct Reference	161
5.11.1	Field Do	cumentation	162
	5.11.1.1	conn_hdl	162
	5.11.1.2	interval	162
	5.11.1.3	latency	162
	5.11.1.4	status	162
	5.11.1.5	supervision_timeout	162
5.12 LE_CM	M_MSG_D	ATA_LEN_CHANGE_IND_T Struct Reference	162
5.12.1	Field Doo	cumentation	163
	5.12.1.1	conn_hdl	163
	5.12.1.2	max_rx_octets	163
	5.12.1.3	max_rx_time	163
	5.12.1.4	max_tx_octets	163
	5.12.1.5	max_tx_time	163
5.13 LE_CN	/I_MSG_D	IRECT_ADV_REPORT_IND_T Struct Reference	163
5.13.1	Field Do	cumentation	164
	5.13.1.1	direct_addr	164
	5.13.1.2	direct_addr_type	164
		peer_addr	
		peer_addr_type	
		· — — — ··	

CONTENTS xxiii

5.13.1.5 rssi	164
5.14 LE_CM_MSG_DISCONNECT_COMPLETE_IND_T Struct Reference	164
5.14.1 Field Documentation	165
5.14.1.1 conn_hdl	165
5.14.1.2 reason	165
5.14.1.3 status	165
5.15 LE_CM_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference	165
5.15.1 Field Documentation	165
5.15.1.1 conn_hdl	166
5.15.1.2 devid	166
5.15.1.3 enabled	166
5.15.1.4 status	166
5.16 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference	166
5.16.1 Field Documentation	166
5.16.1.1 conn_hdl	166
5.16.1.2 devid	167
5.16.1.3 enabled	167
5.16.1.4 status	167
5.17 LE_CM_MSG_INIT_COMPLETE_CFM_T Struct Reference	167
5.17.1 Field Documentation	167
5.17.1.1 status	167
5.18 LE_CM_MSG_LTK_REQ_IND_T Struct Reference	167
5.18.1 Field Documentation	168
5.18.1.1 conn_hdl	168
5.18.1.2 devid	168
5.18.1.3 ediv	168
5.18.1.4 rand	168
5.19 LE_CM_MSG_READ_ADV_TX_POWER_CFM_T Struct Reference	168
5.19.1 Field Documentation	169
5.19.1.1 pwr_level	169

xxiv CONTENTS

5.19.1.2 status	169
5.20 LE_CM_MSG_READ_BD_ADDR_CFM_T Struct Reference	169
5.20.1 Field Documentation	169
5.20.1.1 bd_addr	169
5.20.1.2 status	169
5.21 LE_CM_MSG_READ_CHANNEL_MAP_CFM_T Struct Reference	170
5.21.1 Field Documentation	170
5.21.1.1 ch_map	170
5.21.1.2 conn_hdl	170
5.21.1.3 status	170
5.22 LE_CM_MSG_READ_PHY_CFM_T Struct Reference	170
5.22.1 Field Documentation	171
5.22.1.1 conn_hdl	171
5.22.1.2 rx_phy	171
5.22.1.3 status	171
5.22.1.4 tx_phy	171
5.23 LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM_T Struct Reference	171
5.23.1 Field Documentation	171
5.23.1.1 size	171
5.23.1.2 status	172
5.24 LE_CM_MSG_READ_RSSI_CFM_T Struct Reference	172
5.24.1 Field Documentation	172
5.24.1.1 conn_hdl	172
5.24.1.2 rssi	172
5.24.1.3 status	172
5.25 LE_CM_MSG_READ_TX_POWER_CFM_T Struct Reference	172
5.25.1 Field Documentation	173
5.25.1.1 conn_hdl	173
5.25.1.2 status	173
5.25.1.3 tx_power	173

CONTENTS xxv

5.26 LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T Struct Reference
5.26.1 Field Documentation
5.26.1.1 size
5.26.1.2 status
5.27 LE_CM_MSG_SET_DATA_LENGTH_CFM_T Struct Reference
5.27.1 Field Documentation
5.27.1.1 conn_hdl
5.27.1.2 status
5.28 LE_CM_MSG_SET_DISCONNECT_CFM_T Struct Reference
5.28.1 Field Documentation
5.28.1.1 handle
5.28.1.2 status
5.29 LE_CM_MSG_SET_PHY_CFM_T Struct Reference
5.29.1 Field Documentation
5.29.1.1 conn_hdl
5.29.1.2 status
5.30 LE_CM_MSG_SIGNAL_UPDATE_REQ_T Struct Reference
5.30.1 Field Documentation
5.30.1.1 conn_hdl
5.30.1.2 identifier
5.30.1.3 interval_max
5.30.1.4 interval_min
5.30.1.5 slave_latency
5.30.1.6 timeout_multiplier
5.31 LE_CM_REQ_STATUS_T Struct Reference
5.31.1 Field Documentation
5.31.1.1 status
5.32 LE_CONN_PARA_T Struct Reference
5.32.1 Field Documentation
5.32.1.1 itv_max

xxvi CONTENTS

	5.32.1.2	itv_min	 178
	5.32.1.3	latency	 178
	5.32.1.4	sv_timeout	 178
5.33 LE_GA	AP_ADVEF	RTISING_PARAM_T Struct Reference	 178
5.33.1	Field Doo	cumentation	 178
	5.33.1.1	channel_map	 178
	5.33.1.2	filter_policy	 179
	5.33.1.3	interval_max	 179
	5.33.1.4	interval_min	 179
	5.33.1.5	own_addr_type	 179
	5.33.1.6	peer_addr	 179
	5.33.1.7	peer_addr_type	 179
	5.33.1.8	type	 179
5.34 LE_GA	AP_CONN_	_PARAM_T Struct Reference	 179
5.34.1	Field Doo	cumentation	 180
	5.34.1.1	interval_max	 180
	5.34.1.2	interval_min	 180
	5.34.1.3	latency	 180
	5.34.1.4	supervision_timeout	 180
5.35 LE_GA	AP_SCAN_	PARAM_T Struct Reference	 180
5.35.1	Field Doo	cumentation	 181
	5.35.1.1	filter_policy	 181
	5.35.1.2	interval	 181
	5.35.1.3	own_addr_type	 181
	5.35.1.4	type	 181
	5.35.1.5	window	 181
5.36 LE_GA	ATT_ATTR	_T Struct Reference	 181
5.36.1	Field Doo	cumentation	 182
	5.36.1.1	format	 182
	5.36.1.2	handle	 182

CONTENTS xxvii

	5.36.1.3	len	. 182
	5.36.1.4	maxLen	. 182
	5.36.1.5	permit	. 182
	5.36.1.6	pUuid	. 182
	5.36.1.7	pVal	. 182
5.37 LE_G/	ATT_MSG_	ACCESS_READ_IND_T Struct Reference	. 183
5.37.1	Field Doc	umentation	. 183
	5.37.1.1	conn_hdl	. 183
	5.37.1.2	devid	. 183
	5.37.1.3	handle	. 183
	5.37.1.4	offset	. 183
5.38 LE_G/	ATT_MSG_	ACCESS_WRITE_IND_T Struct Reference	. 183
5.38.1	Field Doc	umentation	. 184
	5.38.1.1	conn_hdl	. 184
	5.38.1.2	devid	. 184
	5.38.1.3	flag	. 184
	5.38.1.4	handle	. 184
	5.38.1.5	len	. 184
	5.38.1.6	offset	. 185
	5.38.1.7	pVal	. 185
5.39 LE_G/	ATT_MSG_	CHAR_DESCRIPTOR_INFO_IND_T Struct Reference	. 185
5.39.1	Field Doc	umentation	. 185
	5.39.1.1	conn_hdl	. 185
	5.39.1.2	devid	. 185
	5.39.1.3	format	. 185
	5.39.1.4	handle	. 186
	5.39.1.5	uuid	. 186
5.40 LE_G/	ATT_MSG_	CHARACTERISTIC_DECL_INFO_IND_T Struct Reference	. 186
5.40.1	Field Doc	umentation	. 186
	5.40.1.1	conn_hdl	. 186

xxviii CONTENTS

	5.40.1.2	devid	186
	5.40.1.3	format	187
	5.40.1.4	handle	187
	5.40.1.5	property	187
	5.40.1.6	uuid	187
	5.40.1.7	val_hdl	187
5.41 LE_GA	ATT_MSG_	_CHARACTERISTIC_VAL_IND_T Struct Reference	187
5.41.1	Field Doo	cumentation	188
	5.41.1.1	att_err	188
	5.41.1.2	conn_hdl	188
	5.41.1.3	devid	188
	5.41.1.4	handle	188
	5.41.1.5	len	188
	5.41.1.6	offset	188
	5.41.1.7	val	188
5.42 LE_GA	ATT_MSG_	_CONFIRMATION_CFM_T Struct Reference	189
		_CONFIRMATION_CFM_T Struct Reference	
	Field Doo		189
	Field Doo	cumentation	189
	Field Doc 5.42.1.1 5.42.1.2	cumentation	189 189
5.42.1	Field Doo 5.42.1.1 5.42.1.2 5.42.1.3	cumentation	189 189 189
5.42.1 5.43 LE_GA	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_	cumentation	189 189 189 189
5.42.1 5.43 LE_GA	5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc	conn_hdl	189 189 189 189 189
5.42.1 5.43 LE_GA	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1	cumentation	189 189 189 189 189 190
5.42.1 5.43 LE_GA	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1 5.43.1.2	conn_hdl	189 189 189 189 190 190
5.42.1 5.43 LE_GA 5.43.1	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1 5.43.1.2 5.43.1.3	conn_hdl	189 189 189 189 190 190
5.42.1 5.43 LE_GA 5.43.1	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1 5.43.1.2 5.43.1.3 ATT_MSG_	conn_hdl	189 189 189 189 190 190 190
5.42.1 5.43 LE_GA 5.43.1	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1 5.43.1.2 5.43.1.3 ATT_MSG_	conn_hdl devid handle EXCHANGE_MTU_CFM_T Struct Reference cumentation conn_hdl current_rx_mtu devid EXCHANGE_MTU_IND_T Struct Reference	189 189 189 189 189 190 190 190
5.42.1 5.43 LE_GA 5.43.1	Field Doc 5.42.1.1 5.42.1.2 5.42.1.3 ATT_MSG_ Field Doc 5.43.1.1 5.43.1.2 5.43.1.3 ATT_MSG_ Field Doc 5.44.1.1	conn_hdl devid handle EXCHANGE_MTU_CFM_T Struct Reference cumentation conn_hdl current_rx_mtu devid EXCHANGE_MTU_IND_T Struct Reference	189 189 189 189 189 190 190 190 190

CONTENTS xxix

5.45 LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CFM_T Struct Reference	191
5.45.1 Field Documentation	191
5.45.1.1 att_err	191
5.45.1.2 conn_hdl	191
5.45.1.3 devid	191
5.45.1.4 err_hdl	192
5.45.1.5 status	192
5.46 LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T Struct Reference	192
5.46.1 Field Documentation	192
5.46.1.1 att_err	192
5.46.1.2 conn_hdl	192
5.46.1.3 devid	192
5.46.1.4 handle	193
5.46.1.5 status	193
5.47 LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T Struct Reference	193
5.47.1 Field Documentation	193
5.47.1.1 att_err	193
5.47.1.2 conn_hdl	193
5.47.1.3 devid	193
5.47.1.4 handle	194
5.47.1.5 status	194
5.48 LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T Struct Reference	194
5.48.1 Field Documentation	194
5.48.1.1 att_err	194
5.48.1.2 conn_hdl	194
5.48.1.3 devid	194
5.48.1.4 handle	195
5.48.1.5 status	195
5.49 LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T Struct Reference	195
5.49.1 Field Documentation	195

5.49.1.1 att_err	195
5.49.1.2 conn_hdl	195
5.49.1.3 devid	195
5.49.1.4 handle	196
5.49.1.5 status	196
5.50 LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T Struct Reference	196
5.50.1 Field Documentation	196
5.50.1.1 att_err	196
5.50.1.2 conn_hdl	196
5.50.1.3 devid	196
5.50.1.4 handle	197
5.50.1.5 status	197
5.51 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T Struct Reference	197
5.51.1 Field Documentation	197
5.51.1.1 conn_hdl	197
5.51.1.2 devid	197
5.51.1.3 end_hdl	198
5.51.1.4 format	198
5.51.1.5 handle	198
5.51.1.6 start_hdl	198
5.51.1.7 uuid	198
5.52 LE_GATT_MSG_INDICATE_IND_T Struct Reference	198
5.52.1 Field Documentation	198
5.52.1.1 conn_hdl	199
5.52.1.2 devid	199
5.52.1.3 handle	199
5.52.1.4 len	199
5.52.1.5 val	199
5.53 LE_GATT_MSG_NOTIFY_CFM_T Struct Reference	199
5.53.1 Field Documentation	199

CONTENTS xxxi

	5.53.1.1	conn_hdl	200
	5.53.1.2	devid	200
	5.53.1.3	handle	200
	5.53.1.4	status	200
5.54 LE_GA	ATT_MSG_	_NOTIFY_IND_T Struct Reference	200
5.54.1	Field Doo	cumentation	200
	5.54.1.1	conn_hdl	200
	5.54.1.2	devid	201
	5.54.1.3	handle	201
	5.54.1.4	len	201
	5.54.1.5	val	201
5.55 LE_GA	ATT_MSG_	_OPERATION_TIMEOUT_T Struct Reference	201
5.55.1	Field Doo	cumentation	201
	5.55.1.1	att_op	201
	5.55.1.2	conn_hdl	202
	5.55.1.3	devid	202
5.56 LE_GA	ATT_MSG	PREPARE_WRITE_RELIABLE_CFM_T Struct Reference	202
5.56.1	Field Doo	cumentation	202
	5.56.1.1	att_err	202
	5.56.1.2	conn_hdl	202
	5.56.1.3	devid	202
	5.56.1.4	handle	203
	5.56.1.5	status	203
5.57 LE_GA	ATT_MSG_	READ_CHAR_VAL_BY_UUID_CFM_T Struct Reference	203
5.57.1	Field Doo	cumentation	203
	5.57.1.1	att_err	203
	5.57.1.2	conn_hdl	203
	5.57.1.3	devid	203
	5.57.1.4	handle	204
	5.57.1.5	status	204

xxxii CONTENTS

5.58 LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T Struct Reference	 204
5.58.1 Field Documentation	 204
5.58.1.1 att_err	 204
5.58.1.2 conn_hdl	 204
5.58.1.3 devid	 204
5.58.1.4 handle	 205
5.58.1.5 status	 205
5.59 LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T Struct Reference	 205
5.59.1 Field Documentation	 205
5.59.1.1 att_err	 205
5.59.1.2 conn_hdl	 205
5.59.1.3 devid	 205
5.59.1.4 handle	 206
5.59.1.5 status	 206
5.60 LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T Struct Reference	 206
5.60.1 Field Documentation	 206
5.60.1.1 att_err	 206
5.60.1.2 conn_hdl	 206
5.60.1.3 devid	 207
5.60.1.4 err_hdl	 207
5.60.1.5 len	 207
5.60.1.6 status	 207
5.60.1.7 val	 207
5.61 LE_GATT_MSG_SERVICE_INFO_IND_T Struct Reference	 207
5.61.1 Field Documentation	 208
5.61.1.1 conn_hdl	 208
5.61.1.2 devid	 208
5.61.1.3 end_hdl	 208
5.61.1.4 format	 208
5.61.1.5 start_hdl	 208

CONTENTS xxxiii

5.61.1.6 uuid
5.62 LE_GATT_MSG_SIGNED_WRITE_CFM_T Struct Reference
5.62.1 Field Documentation
5.62.1.1 conn_hdl
5.62.1.2 devid
5.62.1.3 handle
5.62.1.4 status
5.63 LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T Struct Reference
5.63.1 Field Documentation
5.63.1.1 att_err
5.63.1.2 conn_hdl
5.63.1.3 devid
5.63.1.4 handle
5.63.1.5 status
5.64 LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T Struct Reference
5.64.1 Field Documentation
5.64.1.1 att_err
5.64.1.2 conn_hdl
5.64.1.3 devid
5.64.1.4 handle
5.64.1.5 status
5.65 LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T Struct Reference
5.65.1 Field Documentation
5.65.1.1 att_err
5.65.1.2 conn_hdl
5.65.1.3 devid
5.65.1.4 handle
5.65.1.5 status
5.66 LE_GATT_MSG_WRITE_NO_RSP_CFM_T Struct Reference
5.66.1 Field Documentation

5.66.1.1 conn_hdl	 213
5.66.1.2 devid	 213
5.66.1.3 handle	 213
5.66.1.4 status	 213
5.67 LE_GATT_SERVICE_T Struct Reference	 213
5.67.1 Field Documentation	 213
5.67.1.1 endHdl	 214
5.67.1.2 pAttr	 214
5.67.1.3 startHdl	 214
5.67.1.4 svc_id	 214
5.68 LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference	 214
5.68.1 Field Documentation	 214
5.68.1.1 conn_hdl	 214
5.68.1.2 enable	 215
5.69 LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference	 215
5.69.1 Field Documentation	 215
5.69.1.1 conn_hdl	 215
5.69.1.2 status	 215
5.70 LE_SMP_MSG_OOB_DATA_REQUEST_IND_T Struct Reference	 215
5.70.1 Field Documentation	 215
5.70.1.1 conn_hdl	 216
5.71 LE_SMP_MSG_PAIRING_ACTION_IND_T Struct Reference	 216
5.71.1 Field Documentation	 216
5.71.1.1 action	 216
5.71.1.2 conn_hdl	 216
5.71.1.3 lost_bond	 216
5.71.1.4 sc	 216
5.72 LE_SMP_MSG_PAIRING_COMPLETE_IND_T Struct Reference	 217
5.72.1 Field Documentation	 217
5.72.1.1 authenticated	 217

CONTENTS XXXV

5.7	72.1.2 bonded	217
5.7	72.1.3 conn_hdl	217
5.7	72.1.4 peer_id_addr	217
5.7	72.1.5 sc	217
5.7	72.1.6 status	218
5.73 LE_SMP_	MSG_PASSKEY_DISPLAY_IND_T Struct Reference	218
5.73.1 Fie	eld Documentation	218
5.7	73.1.1 conn_hdl	218
5.7	73.1.2 passkey	218
5.74 LE_SMP_	MSG_PASSKEY_INPUT_IND_T Struct Reference	218
5.74.1 Fie	eld Documentation	218
5.7	74.1.1 conn_hdl	219
5.75 LE_SMP_	MSG_SC_OOB_DATA_REQUEST_IND_T Struct Reference	219
5.75.1 Fie	eld Documentation	219
5.7	75.1.1 conn_hdl	219
5.76 LE_SMP_	MSG_SLAVE_SECURITY_REQUEST_IND_T Struct Reference	219
5.76.1 Fie	eld Documentation	219
5.7	76.1.1 bondable	220
5.7	76.1.2 conn_hdl	220
5.7	76.1.3 keypress	220
5.7	76.1.4 mitm	220
5.7	76.1.5 sc	220
5.77 LE_SMP_	MSG_USER_CONFIRM_IND_T Struct Reference	220
5.77.1 Fie	eld Documentation	220
5.7	77.1.1 confirm_num	221
5.7	77.1.2 conn_hdl	221
5.78 LE_SMP_	SC_OOB_DATA_T Struct Reference	221
5.78.1 Fie	eld Documentation	221
5.7	78.1.1 confirm	221
5.7	78.1.2 rand	221

xxxvi CONTENTS

5.79 LE_SYS_MSG_BUF_OVERFLOW_T Struct Reference	221
5.79.1 Field Documentation	222
5.79.1.1 conn_hdl	222
5.80 mw_blewifi_cbs_store_t Struct Reference	222
5.80.1 Field Documentation	222
5.80.1.1 manufacture_name	222
5.81 mw_wifi_auto_connect_ap_info_t Struct Reference	222
5.81.1 Field Documentation	223
5.81.1.1 ap_channel	223
5.81.1.2 beacon_interval	223
5.81.1.3 bssid	223
5.81.1.4 capabilities	223
5.81.1.5 dtim_prod	224
5.81.1.6 fast_connect	224
5.81.1.7 free_ocpy	224
5.81.1.8 hid_ssid	224
5.81.1.9 hid_ssid_len	224
5.81.1.10 latest_beacon_rx_time	224
5.81.1.11 passphrase	224
5.81.1.12 psk	224
5.81.1.13 rsn_ie	225
5.81.1.14 rssi	225
5.81.1.15 ssid	225
5.81.1.16 ssid_len	225
5.81.1.17 supported_rates	225
5.81.1.18 wpa_data	225
5.81.1.19 wpa_ie	225
5.82 mw_wifi_sta_info_t Struct Reference	225
5.82.1 Field Documentation	226
5.82.1.1 au8Dot11MACAddress	226

CONTENTS xxxvii

5.82.	2 u8SkipDtimPeriods	6
5.83 MwFimAutoC	nnectCFG_t Struct Reference	6
5.83.1 Field	Occumentation	6
5.83.	1 flag	6
5.83.	2 front	7
5.83.	3 max_save_num	7
5.83.	4 rear	7
5.83.	5 targetldx	7
5.84 rx_eapol_data	Struct Reference	7
5.84.1 Field	Occumentation	7
5.84.	1 frame_buffer	7
5.84.	2 frame_length	8
5.85 S_WIFI_MLM	SCAN_CFG Struct Reference	8
5.85.1 Detai	ed Description	8
5.85.2 Field	Occumentation	8
5.85.	1 ptScanReport	8
5.85.	2 tScanType	8
5.85.	3 u32ActiveScanDur	8
5.85.	4 u32PassiveScanDur	9
5.85.	5 u8aBssid	9
5.85.	6 u8aSsid	9
5.85.	7 u8Channel	9
5.85.	8 u8MaxScanApNum	9
5.85.	9 u8ResendCnt	9
5.86 scan_info_t S	ruct Reference	9
5.86.1 Field	Oocumentation	0
5.86.	1 ap_channel	0
5.86.	2 beacon_interval	0
5.86.	3 bssid	0
5.86.	4 capabilities	0

xxxviii CONTENTS

	5.86.1.5 dtim_prod	231
	5.86.1.6 free_ocpy	231
	5.86.1.7 latest_beacon_rx_time	231
	5.86.1.8 rsn_ie	231
	5.86.1.9 rssi	231
	5.86.1.10 ssid	231
	5.86.1.11 ssid_len	231
	5.86.1.12 supported_rates	231
	5.86.1.13 wpa_data	232
	5.86.1.14 wpa_ie	232
5.87 scan_i	port_t Struct Reference	232
5.87.1	Field Documentation	232
	5.87.1.1 pScanInfo	232
	5.87.1.2 uScanApNum	232
5.88 T_RfC	d Struct Reference	232
5.88.1	Field Documentation	233
	5.88.1.1 iArgc	233
	5.88.1.2 saArgv	233
	5.88.1.3 u32Type	233
5.89 T_RfE	Struct Reference	233
5.89.1	Field Documentation	233
	5.89.1.1 pParam	234
	5.89.1.2 u16RfMode	234
	5.89.1.3 u16RxCnt	234
	5.89.1.4 u16RxCrcOkCnt	234
	5.89.1.5 u32Freq	234
	5.89.1.6 u32Mode	
	5.89.1.7 u32RfChannel	
	5.89.1.8 u32Type	
	5.89.1.9 u8Freq	
		_55

CONTENTS xxxix

	5.89.1.10 u8lpcEnable	35
	5.89.1.11 u8Len	35
	5.89.1.12 u8Pkt	35
	5.89.1.13 u8Reserved	35
	5.89.1.14 u8Status	35
	5.89.1.15 u8Unicast	35
5.90 wifi_ac	ctive_scan_time_t Struct Reference	35
5.90.1	Detailed Description	36
5.90.2	Field Documentation	36
	5.90.2.1 max	36
	5.90.2.2 min	36
5.91 wifi_ap	o_config_t Struct Reference	36
5.91.1	Detailed Description	37
5.91.2	Field Documentation	37
	5.91.2.1 auth_mode	37
	5.91.2.2 beacon_interval	37
	5.91.2.3 channel	37
	5.91.2.4 encrypt_type	37
	5.91.2.5 max_connection	37
	5.91.2.6 password	37
	5.91.2.7 password_length	38
	5.91.2.8 ssid	38
	5.91.2.9 ssid_hidden	38
	5.91.2.10 ssid_length	38
5.92 wifi_au	uto_connect_info_t Struct Reference	38
5.92.1	Detailed Description	38
5.92.2	Field Documentation	39
	5.92.2.1 ap_channel	39
	5.92.2.2 beacon_interval	39
	5.92.2.3 bssid	39

xI CONTENTS

		5.92.2.4	capabilities				 	 	 	 	 	239
		5.92.2.5	dtim_prod				 	 	 	 	 	239
		5.92.2.6	fast_connec	t			 	 	 	 	 	239
		5.92.2.7	hid_ssid .				 	 	 	 	 	239
		5.92.2.8	rssi				 	 	 	 	 	240
		5.92.2.9	ssid				 	 	 	 	 	240
		5.92.2.10	supported_i	rates .			 	 	 	 	 	240
5.93	wifi_cm	nd_t Struct I	Reference				 	 	 	 	 	240
	5.93.1	Field Docu	umentation				 	 	 	 	 	240
		5.93.1.1	arg1				 	 	 	 	 	240
		5.93.1.2	cmd_type .				 	 	 	 	 	240
		5.93.1.3	prvData .				 	 	 	 	 	241
		5.93.1.4	reserved .				 	 	 	 	 	241
5.94	wifi_co	nfig_t Unior	n Reference				 	 	 	 	 	241
	5.94.1	Detailed D	escription				 	 	 	 	 	241
	5.94.2	Field Docu	umentation				 	 	 	 	 	241
		5.94.2.1	ap_config .				 	 	 	 	 	241
		5.94.2.2	sta_config				 	 	 	 	 	241
5.95	wifi_ev	ent_info_t L	Jnion Refere	ence .			 	 	 	 	 	242
	5.95.1	Detailed D	escription				 	 	 	 	 	242
	5.95.2	Field Docu	umentation				 	 	 	 	 	242
		5.95.2.1	connected				 	 	 	 	 	242
		5.95.2.2	disconnecte	ed			 	 	 	 	 	242
		5.95.2.3	got_ip				 	 	 	 	 	242
		5.95.2.4	scan_done				 	 	 	 	 	242
5.96	wifi_ev	ent_sta_cor	nnected_t S	truct Re	eferend	ce .	 	 	 	 	 	243
	5.96.1	Detailed D	escription				 	 	 	 	 	243
	5.96.2	Field Docu	umentation				 	 	 	 	 	243
		5.96.2.1	authmode				 	 	 	 	 	243
		5.96.2.2	bssid				 	 	 	 	 	243

CONTENTS xli

5.96.2.3 channel	243
5.96.2.4 ssid	243
5.96.2.5 ssid_len	244
5.97 wifi_event_sta_disconnected_t Struct Reference	244
5.97.1 Detailed Description	244
5.97.2 Field Documentation	244
5.97.2.1 bssid	244
5.97.2.2 reason	244
5.97.2.3 ssid	244
5.97.2.4 ssid_len	245
5.98 wifi_event_sta_got_ip_t Struct Reference	245
5.98.1 Field Documentation	245
5.98.1.1 ip_changed	245
5.99 wifi_event_sta_scan_done_t Struct Reference	245
5.99.1 Detailed Description	245
5.99.2 Field Documentation	245
5.99.2.1 number	246
5.99.2.2 scan_id	246
5.99.2.3 status	246
5.100 wifi_evt_t Struct Reference	246
5.100.1 Field Documentation	246
5.100.1.1 evt_type	246
5.100.1.2 prvData	246
5.101 wifi_fast_scan_threshold_t Struct Reference	247
5.101.1 Detailed Description	247
5.101.2 Field Documentation	247
5.101.2.1 authmode	247
5.101.2.2 rssi	247
5.102wifi_init_config_t Struct Reference	247
5.102.1 Detailed Description	248

xlii CONTENTS

5.102.2 Field Documentation	248
5.102.2.1 event_handler	<u>2</u> 48
5.102.2.2 magic	248
5.103wifi_scan_config_t Struct Reference	248
5.103.1 Detailed Description	<u>2</u> 48
5.103.2 Field Documentation	<u>2</u> 48
5.103.2.1 bssid	<u>2</u> 49
5.103.2.2 channel	<u>2</u> 49
5.103.2.3 scan_time	249
5.103.2.4 scan_type	249
5.103.2.5 show_hidden	249
5.103.2.6 ssid	249
5.104wifi_scan_info_t Struct Reference	249
5.104.1 Detailed Description	<u>2</u> 50
5.104.2 Field Documentation	250
5.104.2.1 auth_mode	<u>2</u> 50
5.104.2.2 beacon_interval	250
5.104.2.3 bssid	250
5.104.2.4 capability_info	250
5.104.2.5 channel	251
5.104.2.6 dtim_period	251
5.104.2.7 group_cipher	251
5.104.2.8 pairwise_cipher	251
5.104.2.9 rssi	251
5.104.2.10ssid	251
5.104.2.11ssid_length	251
5.105wifi_scan_list_t Struct Reference	252
5.105.1 Detailed Description	252
5.105.2 Field Documentation	252
5.105.2.1 ap_record	252

CONTENTS xliii

	5.105.2.2 num	. 252
5.106wifi_sca	an_time_t Union Reference	. 252
5.106.1	Detailed Description	. 253
5.106.2	Field Documentation	. 253
	5.106.2.1 active	. 253
	5.106.2.2 passive	. 253
5.107wifi_sta	_config_t Struct Reference	. 253
5.107.1	Detailed Description	. 253
5.107.2	Field Documentation	. 254
	5.107.2.1 bssid	. 254
	5.107.2.2 bssid_present	. 254
	5.107.2.3 password	. 254
	5.107.2.4 password_length	. 254
	5.107.2.5 scan_method	. 254
	5.107.2.6 sort_method	. 254
	5.107.2.7 ssid	. 254
	5.107.2.8 ssid_length	. 255
	5.107.2.9 threshold	. 255
5.108wifi_wp	a_ie_data_t Struct Reference	. 255
5.108.1	Detailed Description	. 255
5.108.2	Field Documentation	. 255
	5.108.2.1 capabilities	. 255
	5.108.2.2 group_cipher	. 256
	5.108.2.3 key_mgmt	. 256
	5.108.2.4 mgmt_group_cipher	. 256
	5.108.2.5 num_pmkid	. 256
	5.108.2.6 pairwise_cipher	. 256
	5.108.2.7 pmkid	. 256
	5.108.2.8 proto	. 256
Index		257

Chapter 1

SDK PREVIEW

• BLE APIs :

GAP APIs: ble GAP APIs
GATT APIs: ble GATT APIs
CM APIs: ble CM APIs
MSG APIs: ble MSG APIs
SMP APIs: ble SMP APIs

· WiFi APIs:

Station APIs : station APIsCommon APIs : common APIsEnumerations : enumerations

2 SDK PREVIEW

Chapter 2

Module Index

2.1 Modules

Here is a list of all modules:

E ALL APIs
BLE CM APIs
BLE GAP APIs
BLE GATT APIs
BLE MSG APIs
BLE SMP APIs
FI APIs
WIFI Common APIs
WIFI STA APIs
Enumeration

4 Module Index

Chapter 3

Data Structure Index

3.1 Data Structures

Here are the data structures with brief descriptions:

_wpa_ie_data	147
asso_data	148
auto_conn_info_t	150
auto_connect_cfg_t	153
event_msg_t	
,	155
	156
 	157
	158
	159
	160
	161
	162
	163
	164
	165
	166
	167
	167
	168
	169
	170
	170
	171
	172
	172
	173
	174
	174
	175
	176
	177
	177
	178
LE GAP CONN PARAM T	179

6 Data Structure Index

LE_GAP_SCAN_PARAM_T 180
LE_GATT_ATTR_T
LE_GATT_MSG_ACCESS_READ_IND_T
LE_GATT_MSG_ACCESS_WRITE_IND_T
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T
LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_IND_T
LE_GATT_MSG_CONFIRMATION_CFM_T
LE_GATT_MSG_EXCHANGE_MTU_CFM_T
LE GATT MSG EXCHANGE MTU IND T
LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CFM_T
LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T
LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T
LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T
LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T
LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T
LE_GATT_MSG_INDICATE_IND_T 198
LE_GATT_MSG_NOTIFY_CFM_T 199
LE_GATT_MSG_NOTIFY_IND_T 200
LE_GATT_MSG_OPERATION_TIMEOUT_T
LE_GATT_MSG_PREPARE_WRITE_RELIABLE_CFM_T
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T 203
LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T 204
LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T
LE_GATT_MSG_SERVICE_INFO_IND_T
LE_GATT_MSG_SIGNED_WRITE_CFM_T
LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T
LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T
LE GATT SERVICE T
LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T
LE SMP MSG ENCRYPTION REFRESH IND T
LE SMP MSG OOB DATA REQUEST IND T
LE SMP MSG PAIRING ACTION IND T
LE SMP MSG PAIRING COMPLETE IND T
LE SMP MSG PASSKEY DISPLAY IND T
LE SMP MSG PASSKEY INPUT IND T
LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T
LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T
LE_SMP_MSG_USER_CONFIRM_IND_T
LE_SMP_SC_OOB_DATA_T 22
LE_SYS_MSG_BUF_OVERFLOW_T 22
mw_blewifi_cbs_store_t
mw_wifi_auto_connect_ap_info_t 222
mw_wifi_sta_info_t
MwFimAutoConnectCFG_t
rx_eapol_data
S_WIFI_MLME_SCAN_CFG
scan_info_t
scan_report_t
T_RfCmd
T_RfEvt
wifi_active_scan_time_t Range of active scan times per channel
Hange of active scar times per charmer

3.1 Data Structures 7

wifi_ap_config_t	
This structure is the Wi-Fi configuration for initialization for Soft-AP mode	. 236
wifi_auto_connect_info_t	
This structure is the Wi-Fi auto connect for save in the flash (FIM)	. 238
wifi_cmd_t	. 240
wifi_config_t	
Wi-Fi configuration for initialization	. 241
wifi_event_info_t	
Wifi_event_info_t	. 242
wifi_event_sta_connected_t	
Wifi_event_sta_connected_t	. 243
wifi_event_sta_disconnected_t	
Wifi_event_sta_disconnected_t	. 244
wifi_event_sta_got_ip_t	. 245
wifi_event_sta_scan_done_t	
Wifi_event_sta_scan_done_t	. 245
wifi_evt_t	. 246
wifi_fast_scan_threshold_t	
Structure describing parameters for a Wi-Fi fast scan	. 247
wifi_init_config_t	
WiFi stack configuration parameters	. 247
wifi_scan_config_t	
Parameters for an SSID scan	. 248
wifi_scan_info_t	
This structure defines the inforamtion of scanned APs	. 249
wifi_scan_list_t	
This structure defines the list of scanned APs with their corresponding information	. 252
wifi_scan_time_t	
Aggregate of active & passive scan time per channel	. 252
wifi_sta_config_t	
This structure is the Wi-Fi configuration for initialization for STA mode	. 253
wifi_wpa_ie_data_t	
This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM)	. 255

8 Data Structure Index

Chapter 4

Module Documentation

4.1 BLE ALL APIs

BLE ALL APIs.

Modules

- BLE CM APIs
- BLE GAP APIs
- BLE GATT APIs
- BLE MSG APIs
- BLE SMP APIs

Functions

• UINT8 LeSmpGetBondIdFromAddr (LE_BT_ADDR_T *peer_addr)

4.1.1 Detailed Description

BLE ALL APIs.

4.1.2 Function Documentation

4.1.2.1 LeSmpGetBondldFromAddr()

```
UINT8 LeSmpGetBondIdFromAddr ( \label{eq:less_def} \texttt{LE\_BT\_ADDR\_T} \ * \ peer\_addr \ )
```

4.2 BLE CM APIS

Data Structures

- struct LE CM CONNECTION COMPLETE IND T
- struct LE_CM_MSG_ADVERTISE_REPORT_IND_T
- struct LE_CM_MSG_CONN_PARA_REQ_T
- struct LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T
- struct LE CM MSG DATA LEN CHANGE IND T
- struct LE_CM_MSG_DIRECT_ADV_REPORT_IND_T
- struct LE CM MSG DISCONNECT COMPLETE IND T
- struct LE CM MSG ENCRYPTION CHANGE IND T
- struct LE_CM_MSG_ENCRYPTION_REFRESH_IND_T
- struct LE_CM_MSG_INIT_COMPLETE_CFM_T
- struct LE CM MSG LTK REQ IND T
- struct LE_CM_MSG_READ_ADV_TX_POWER_CFM_T
- struct LE_CM_MSG_READ_BD_ADDR_CFM_T
- struct LE_CM_MSG_READ_CHANNEL_MAP_CFM_T
- struct LE_CM_MSG_READ_PHY_CFM_T
- struct LE CM MSG READ RESOLVING LIST SIZE CFM T
- struct LE_CM_MSG_READ_RSSI_CFM_T
- struct LE_CM_MSG_READ_TX_POWER_CFM_T
- struct LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T
- struct LE_CM_MSG_SET_DATA_LENGTH_CFM_T
- struct LE CM MSG SET DISCONNECT CFM T
- struct LE_CM_MSG_SET_PHY_CFM_T
- struct LE_CM_MSG_SIGNAL_UPDATE_REQ_T
- struct LE_CM_REQ_STATUS_T

Typedefs

- typedef LE CM REQ STATUS T LE CM MSG ADD TO RESOLVING LIST CFM T
- typedef LE CM REQ STATUS T LE CM MSG ADD TO WHITE LIST CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CANCEL_CONNECTION_CFM_T
- typedef LE CM REQ STATUS T LE CM MSG CLEAR RESOLVING LIST CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CREATE_CONNECTION_CFM_T
- typedef LE CM REQ STATUS TLE CM MSG ENTER ADVERTISING CFM T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_SCANNING_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_ADVERTISING_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_SCANNING_CFM_T
- typedef LE_CM_MSG_READ_PHY_CFM_T LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_CHANNEL_MAP_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_PARAMS_CFM_T
- typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

4.2 BLE CM APIs 11

Enumerations

- enum {
 - LE_CM_MSG_INIT_COMPLETE_CFM = LE_CM_MSG_BASE, LE_CM_MSG_SET_DISCONNECT_CFM,
 - LE_CM_MSG_DISCONNECT_COMPLETE_IND, LE_CM_MSG_SET_ADVERTISING_DATA_CFM,
 - LE CM MSG SET SCAN RSP DATA CFM, LE CM MSG SET ADVERTISING PARAMS CFM,
 - LE_CM_MSG_ENTER_ADVERTISING_CFM, LE_CM_MSG_EXIT_ADVERTISING_CFM,
 - LE_CM_MSG_SET_SCAN_PARAMS_CFM, LE_CM_MSG_ENTER_SCANNING_CFM, LE_CM_MSG_EXIT_SCANNING_CF
 - LE CM MSG CREATE CONNECTION CFM,
 - LE_CM_MSG_CANCEL_CONNECTION_CFM, LE_CM_MSG_READ_TX_POWER_CFM, LE_CM_MSG_READ_BD_ADDR_
- LE_CM_MSG_READ_RSSI_CFM,
- LE_CM_MSG_SET_RANDOM_ADDRESS_CFM, LE_CM_MSG_READ_ADV_TX_POWER_CFM, LE_CM_MSG_READ_WH
- LE CM MSG CLEAR WHITE LIST CFM,
- LE CM MSG ADD TO WHITE LIST CFM, LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM,
- LE_CM_MSG_SET_CHANNEL_MAP_CFM, LE_CM_MSG_READ_CHANNEL_MAP_CFM,
- LE_CM_MSG_SET_DATA_LENGTH_CFM, LE_CM_MSG_DATA_LEN_CHANGE_IND, LE_CM_MSG_ADD_TO_RESOLVIN
- LE CM MSG REMOVE FROM RESOLVING LIST CFM.
- LE CM MSG CLEAR RESOLVING LIST CFM, LE CM MSG READ RESOLVING LIST SIZE CFM,
- LE CM MSG SET RPA TIMEOUT CFM, LE CM MSG SIGNAL UPDATE REQ,
- LE_CM_MSG_CONN_UPDATE_COMPLETE_IND, LE_CM_MSG_CONN_PARA_REQ, LE_CM_MSG_ENCRYPTION_CHAN
- LE CM MSG ENCRYPTION REFRESH IND,
- LE_CM_MSG_LTK_REQ_IND, LE_CM_MSG_ADVERTISE_REPORT_IND, LE_CM_MSG_DIRECT_ADV_REPORT_IND,
- LE_CM_CONNECTION_COMPLETE_IND,
- LE_CM_MSG_READ_LOCAL_RPA_CFM, LE_CM_MSG_READ_PHY_CFM, LE_CM_MSG_SET_DEFAULT_PHY_CFM,
- LE CM MSG SET PHY CFM,
- LE_CM_MSG_PHY_UPDATE_COMPLETE_IND, LE_CM_MSG_TOP }

BLE connection management message id.

Functions

void LeCmInit (TASK appTask)

BLE Connection Management Module Init.

- 4.2.1 **Detailed Description**
- 4.2.2 Typedef Documentation

4.2.2.1 LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T

4.2.2.2 LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T

```
4.2.2.3 LE_CM_MSG_CANCEL_CONNECTION_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CANCEL_CONNECTION_CFM_T
4.2.2.4 LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T
4.2.2.5 LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T
4.2.2.6 LE_CM_MSG_CREATE_CONNECTION_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_CREATE_CONNECTION_CFM_T
4.2.2.7 LE_CM_MSG_ENTER_ADVERTISING_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_ADVERTISING_CFM_T
4.2.2.8 LE CM MSG ENTER SCANNING CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_ENTER_SCANNING_CFM_T
4.2.2.9 LE_CM_MSG_EXIT_ADVERTISING_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_ADVERTISING_CFM_T
4.2.2.10 LE_CM_MSG_EXIT_SCANNING_CFM_T
```

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_EXIT_SCANNING_CFM_T

4.2 BLE CM APIs 13

```
4.2.2.11 LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
typedef LE_CM_MSG_READ_PHY_CFM_T LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
4.2.2.12 LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM_T
4.2.2.13 LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM_T
4.2.2.14 LE CM MSG SET ADVERTISING DATA CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T
4.2.2.15 LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM_T
4.2.2.16 LE CM MSG SET CHANNEL MAP CFM T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_CHANNEL_MAP_CFM_T
4.2.2.17 LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_DEFAULT_PHY_CFM_T
4.2.2.18 LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T
typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T
```

4.2.2.19 LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T

4.2.2.20 LE_CM_MSG_SET_SCAN_PARAMS_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_PARAMS_CFM_T

4.2.2.21 LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

typedef LE_CM_REQ_STATUS_T LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T

4.2.3 Enumeration Type Documentation

4.2.3.1 anonymous enum

anonymous enum

BLE connection management message id.

Enumerator

LE_CM_MSG_INIT_COMPLETE_CFM	initialize complete
LE_CM_MSG_SET_DISCONNECT_CFM	set disconnect confirm
LE_CM_MSG_DISCONNECT_COMPLETE_IND	disconnect complete indication
LE_CM_MSG_SET_ADVERTISING_DATA_CFM	set advertising data confirm
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM	set scan response data confirm
LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM	set advertising parameters confirm
LE_CM_MSG_ENTER_ADVERTISING_CFM	enter advertising confirm
LE_CM_MSG_EXIT_ADVERTISING_CFM	exit advertising confirm
LE_CM_MSG_SET_SCAN_PARAMS_CFM	set scan parameters confirm
LE_CM_MSG_ENTER_SCANNING_CFM	enter scanning confirm
LE_CM_MSG_EXIT_SCANNING_CFM	exit scanning confirm
LE_CM_MSG_CREATE_CONNECTION_CFM	create connection confirm
LE_CM_MSG_CANCEL_CONNECTION_CFM	cancel connection confirm
LE_CM_MSG_READ_TX_POWER_CFM	read tx power confirm
LE_CM_MSG_READ_BD_ADDR_CFM	read device address confirm
LE_CM_MSG_READ_RSSI_CFM	read RSSI confirm
LE_CM_MSG_SET_RANDOM_ADDRESS_CFM	set random address confirm
LE_CM_MSG_READ_ADV_TX_POWER_CFM	read advertising tx power confirm
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM	read whitelist size confirm

4.2 BLE CM APIs 15

Enumerator

LE_CM_MSG_CLEAR_WHITE_LIST_CFM	clear whitelist confirm
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM	add to whitelist confirm
LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM	remove from whitelist confirm
LE_CM_MSG_SET_CHANNEL_MAP_CFM	set channel map confirm
LE_CM_MSG_READ_CHANNEL_MAP_CFM	read channel map confirm
LE_CM_MSG_SET_DATA_LENGTH_CFM	set data length confirm
LE_CM_MSG_DATA_LEN_CHANGE_IND	data length change indication
LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM	add to resolving list confirm
LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST_CFM	remove from resolving list confirm
LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM	clear resolving list confirm
LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM	read resolving list size confirm
LE_CM_MSG_SET_RPA_TIMEOUT_CFM	set resolving private address timeout confirm
LE_CM_MSG_SIGNAL_UPDATE_REQ	signal update request
LE_CM_MSG_CONN_UPDATE_COMPLETE_IND	connection update complete indication
LE_CM_MSG_CONN_PARA_REQ	connection parameters request
LE_CM_MSG_ENCRYPTION_CHANGE_IND	encryption change indication
LE_CM_MSG_ENCRYPTION_REFRESH_IND	encryption refresh indication
LE_CM_MSG_LTK_REQ_IND	long term key indication
LE_CM_MSG_ADVERTISE_REPORT_IND	advertising report indication
LE_CM_MSG_DIRECT_ADV_REPORT_IND	direct advertising report indication
LE_CM_CONNECTION_COMPLETE_IND	connection complete indication
LE_CM_MSG_READ_LOCAL_RPA_CFM	read local resolving private address confirm
LE_CM_MSG_READ_PHY_CFM	
LE_CM_MSG_SET_DEFAULT_PHY_CFM	
LE_CM_MSG_SET_PHY_CFM	
LE_CM_MSG_PHY_UPDATE_COMPLETE_IND	
LE_CM_MSG_TOP	top of CM message id

4.2.4 Function Documentation

4.2.4.1 LeCmInit()

BLE Connection Management Module Init.

Parameters

the reference of BLE task.

Returns

None.

4.3 BLE GAP APIs

4.3 BLE GAP APIS

Data Structures

- struct LE GAP ADVERTISING PARAM T
- struct LE GAP CONN PARAM T
- struct LE_GAP_SCAN_PARAM_T

Macros

- #define GAP_ADTYPE_128BIT_COMPLETE 0x07
- #define GAP_ADTYPE_128BIT_MORE 0x06
- #define GAP ADTYPE 16BIT COMPLETE 0x03
- #define GAP ADTYPE 16BIT MORE 0x02
- #define GAP ADTYPE 32BIT COMPLETE 0x05
- #define GAP_ADTYPE_32BIT_MORE 0x04
- #define GAP ADTYPE 3D INFO DATA 0x3D
- #define GAP_ADTYPE_ADV_INTERVAL 0x1A
- #define GAP_ADTYPE_APPEARANCE 0x19
- #define GAP_ADTYPE_FLAGS 0x01
- #define GAP ADTYPE FLAGS BREDR NOT SUPPORTED 0x04
- #define GAP ADTYPE FLAGS GENERAL 0x02
- #define GAP_ADTYPE_FLAGS_LIMITED 0x01
- #define GAP ADTYPE LE BD ADDR 0x1B
- #define GAP_ADTYPE_LE_ROLE 0x1C
- #define GAP_ADTYPE_LOCAL_NAME_COMPLETE 0x09
- #define GAP_ADTYPE_LOCAL_NAME_SHORT 0x08
- #define GAP_ADTYPE_MANUFACTURER_SPECIFIC 0xFF
- #define GAP_ADTYPE_OOB_CLASS_OF_DEVICE 0x0D
- #define GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC 0x0E
- #define GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR 0x0F
- #define GAP ADTYPE POWER LEVEL 0x0A
- #define GAP_ADTYPE_PUBLIC_TARGET_ADDR 0x17
- #define GAP ADTYPE RANDOM TARGET ADDR 0x18
- #define GAP_ADTYPE_SERVICE_DATA 0x16
- #define GAP ADTYPE SERVICE DATA 128BIT 0x21
- #define GAP_ADTYPE_SERVICE_DATA_32BIT 0x20
- #define GAP_ADTYPE_SERVICES_LIST_128BIT 0x15
- #define GAP ADTYPE SERVICES LIST 16BIT 0x14
- #define GAP_ADTYPE_SIGNED_DATA 0x13
- #define GAP ADTYPE SIMPLE PAIRING HASHC 256 0x1D
- #define GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256 0x1E
- #define GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE 0x12
- #define GAP ADTYPE SM OOB FLAG 0x11
- #define GAP ADTYPE SM TK 0x10
- #define GAP PUBLIC ADDR 0
- #define GAP_RAND_ADDR_NRPA 2
- #define GAP_RAND_ADDR_RPA 3
- #define GAP_RAND_ADDR_STATIC 1
- #define GAP SCAN TYPE ACTIVE 1
- #define GAP_SCAN_TYPE_PASSIVE 0
- #define GAP TX PWR CURR VAL 0
- #define GAP_TX_PWR_MAX_VAL 1

- #define GAPBOND_IO_CAP_DISPLAY_ONLY 0x00
- #define GAPBOND_IO_CAP_DISPLAY_YES_NO 0x01
- #define GAPBOND_IO_CAP_KEYBOARD_DISPLAY 0x04
- #define GAPBOND IO CAP KEYBOARD ONLY 0x02
- #define GAPBOND IO CAP NO INPUT NO OUTPUT 0x03
- #define GAPBOND_PAIRING_MODE_INITIATE 0x02
- #define GAPBOND PAIRING MODE NO PAIRING 0x00
- #define GAPBOND PAIRING MODE WAIT FOR REQ 0x01
- #define LE_GAP_ADV_MAX_SIZE 31

Functions

LE ERR STATE LeGapAddToResolvingList (LE BT ADDR T *bt addr, UINT8 *irk)

Add device to resolving-list.

• LE ERR STATE LeGapAddToWhiteList (LE BT ADDR T *bt addr)

Add device to whitelist.

LE_ERR_STATE LeGapAdvertisingEnable (BOOL start)

Enable or disable advertising function.

• LE_ERR_STATE LeGapCentralConnectReq (LE_BT_ADDR_T *taddr, UINT8 own_addr_type)

Central connect request.

• LE_ERR_STATE LeGapCentralSetDataChannel (UINT8 *ch)

Central set data channel.

LE ERR STATE LeGapClearResolvingList (void)

Clear the resolving-list in the controller.

LE ERR STATE LeGapClearWhiteList (void)

Clear whitelist in the controller.

LE_ERR_STATE LeGapConnectCancelReq (void)

Cancel connect request.

void LeGapConnParaRequestRsp (UINT16 conn_hdl, BOOL accept)

Connection parameters request response.

• LE_ERR_STATE LeGapConnUpdateRequest (UINT16 conn_hdl, LE_CONN_PARA_T *para)

Connection parameters update request.

• void LeGapConnUpdateResponse (UINT16 conn_hdl, UINT8 identifier, BOOL accept)

Connection parameters update response.

LE_ERR_STATE LeGapDisconnectReq (UINT16 conn_hdl)

Disconnect the physical connection.

LE_ERR_STATE LeGapGenRandAddr (UINT8 type, BD_ADDR addr)

Called to generation random address.

void LeGapGetBtAddr (void)

Get owner device address.

void LeGapReadAdvChannelTxPower (void)

Read ADV channel txpower.

• LE_ERR_STATE LeGapReadChannelMap (UINT16 conn_hdl)

Read channel map.

- LE_ERR_STATE LeGapReadPhy (UINT16 conn_hdl)
- void LeGapReadResolvingListSize (void)

Read the resolving-list size in the controller.

LE_ERR_STATE LeGapReadRssi (UINT16 conn_hdl)

Read RSSI value from controller.

• LE_ERR_STATE LeGapReadTxPower (UINT16 conn_hdl, UINT8 type)

Read tx power value for the specified connection.

4.3 BLE GAP APIs

void LeGapReadWhiteListSize (void)

Read whitelist size in the controller.

• LE_ERR_STATE LeGapRemoveFromWhiteList (LE_BT_ADDR_T *bt_addr)

Remove device from whitelist.

• LE_ERR_STATE LeGapScanningReq (BOOL start, BOOL filter)

Request scanning start.

• LE_ERR_STATE LeGapSetAdvData (UINT8 len, UINT8 *data)

Called to set ADV data.

• LE_ERR_STATE LeGapSetAdvParameter (LE_GAP_ADVERTISING_PARAM_T *params)

Called to set ADV parameters.

LE_ERR_STATE LeGapSetConnParameter (UINT16 interval_min, UINT16 interval_max, UINT16 slave_
 — latency, UINT16 supervision_timeout)

Called to set connection parameters.

- LE_ERR_STATE LeGapSetDataChannelPduLen (UINT16 conn_hdl, UINT16 tx_octets, UINT16 tx_time) Set data channel PDU length.
- LE ERR STATE LeGapSetDefaultPhy (UINT8 tx, UINT8 rx)
- LE ERR STATE LeGapSetPhy (UINT16 conn hdl, UINT8 tx, UINT8 rx, UINT16 option)
- LE ERR STATE LeGapSetRandAddr (BD ADDR addr)

Called to set random address.

LE ERR STATE LeGapSetRpaTimeout (UINT16 timeout)

Set resolvable private address timeout.

LE_ERR_STATE LeGapSetStaticAddr (BD_ADDR addr)

Called to set static address.

• LE ERR STATE LeSetScanParameter (LE GAP SCAN PARAM T *params)

Called to set scan parameters.

• LE ERR STATE LeSetScanRspData (UINT8 len, UINT8 *data)

Called to set scan response data.

- 4.3.1 Detailed Description
- 4.3.2 Macro Definition Documentation

4.3.2.1 GAP_ADTYPE_128BIT_COMPLETE

#define GAP_ADTYPE_128BIT_COMPLETE 0x07

4.3.2.2 GAP_ADTYPE_128BIT_MORE

#define GAP_ADTYPE_128BIT_MORE 0x06

4.3.2.3 GAP_ADTYPE_16BIT_COMPLETE

#define GAP_ADTYPE_16BIT_COMPLETE 0x03

4.3.2.4 GAP_ADTYPE_16BIT_MORE

#define GAP_ADTYPE_16BIT_MORE 0x02

4.3.2.5 GAP_ADTYPE_32BIT_COMPLETE

#define GAP_ADTYPE_32BIT_COMPLETE 0x05

4.3.2.6 GAP_ADTYPE_32BIT_MORE

#define GAP_ADTYPE_32BIT_MORE 0x04

4.3.2.7 GAP_ADTYPE_3D_INFO_DATA

#define GAP_ADTYPE_3D_INFO_DATA 0x3D

4.3.2.8 GAP_ADTYPE_ADV_INTERVAL

#define GAP_ADTYPE_ADV_INTERVAL 0x1A

4.3.2.9 GAP_ADTYPE_APPEARANCE

#define GAP_ADTYPE_APPEARANCE 0x19

4.3.2.10 GAP_ADTYPE_FLAGS

#define GAP_ADTYPE_FLAGS 0x01

4.3 BLE GAP APIs 21

4.3.2.11 GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED

#define GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED 0x04

4.3.2.12 GAP_ADTYPE_FLAGS_GENERAL

#define GAP_ADTYPE_FLAGS_GENERAL 0x02

4.3.2.13 GAP_ADTYPE_FLAGS_LIMITED

#define GAP_ADTYPE_FLAGS_LIMITED 0x01

4.3.2.14 GAP_ADTYPE_LE_BD_ADDR

#define GAP_ADTYPE_LE_BD_ADDR 0x1B

4.3.2.15 GAP_ADTYPE_LE_ROLE

#define GAP_ADTYPE_LE_ROLE 0x1C

4.3.2.16 GAP_ADTYPE_LOCAL_NAME_COMPLETE

#define GAP_ADTYPE_LOCAL_NAME_COMPLETE 0x09

4.3.2.17 GAP_ADTYPE_LOCAL_NAME_SHORT

#define GAP_ADTYPE_LOCAL_NAME_SHORT 0x08

4.3.2.18 GAP_ADTYPE_MANUFACTURER_SPECIFIC

#define GAP_ADTYPE_MANUFACTURER_SPECIFIC 0xFF

4.3.2.19 GAP_ADTYPE_OOB_CLASS_OF_DEVICE

#define GAP_ADTYPE_OOB_CLASS_OF_DEVICE 0x0D

4.3.2.20 GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC

#define GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC 0x0E

4.3.2.21 GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR

#define GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR 0x0F

4.3.2.22 GAP_ADTYPE_POWER_LEVEL

#define GAP_ADTYPE_POWER_LEVEL 0x0A

4.3.2.23 GAP_ADTYPE_PUBLIC_TARGET_ADDR

#define GAP_ADTYPE_PUBLIC_TARGET_ADDR 0x17

4.3.2.24 GAP_ADTYPE_RANDOM_TARGET_ADDR

#define GAP_ADTYPE_RANDOM_TARGET_ADDR 0x18

4.3.2.25 GAP_ADTYPE_SERVICE_DATA

#define GAP_ADTYPE_SERVICE_DATA 0x16

4.3.2.26 GAP_ADTYPE_SERVICE_DATA_128BIT

#define GAP_ADTYPE_SERVICE_DATA_128BIT 0x21

4.3 BLE GAP APIs 23

4.3.2.27 GAP_ADTYPE_SERVICE_DATA_32BIT

#define GAP_ADTYPE_SERVICE_DATA_32BIT 0x20

4.3.2.28 GAP_ADTYPE_SERVICES_LIST_128BIT

#define GAP_ADTYPE_SERVICES_LIST_128BIT 0x15

4.3.2.29 GAP_ADTYPE_SERVICES_LIST_16BIT

#define GAP_ADTYPE_SERVICES_LIST_16BIT 0x14

4.3.2.30 GAP_ADTYPE_SIGNED_DATA

#define GAP_ADTYPE_SIGNED_DATA 0x13

4.3.2.31 GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256

#define GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256 0x1D

4.3.2.32 GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256

#define GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256 0x1E

4.3.2.33 GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE

#define GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE 0x12

4.3.2.34 GAP_ADTYPE_SM_OOB_FLAG

#define GAP_ADTYPE_SM_OOB_FLAG 0x11

4.3.2.35 GAP_ADTYPE_SM_TK

#define GAP_ADTYPE_SM_TK 0x10

4.3.2.36 GAP_PUBLIC_ADDR

#define GAP_PUBLIC_ADDR 0

4.3.2.37 GAP_RAND_ADDR_NRPA

#define GAP_RAND_ADDR_NRPA 2

4.3.2.38 GAP_RAND_ADDR_RPA

#define GAP_RAND_ADDR_RPA 3

4.3.2.39 GAP_RAND_ADDR_STATIC

#define GAP_RAND_ADDR_STATIC 1

4.3.2.40 GAP_SCAN_TYPE_ACTIVE

#define GAP_SCAN_TYPE_ACTIVE 1

4.3.2.41 GAP_SCAN_TYPE_PASSIVE

#define GAP_SCAN_TYPE_PASSIVE 0

4.3.2.42 GAP_TX_PWR_CURR_VAL

#define GAP_TX_PWR_CURR_VAL 0

4.3 BLE GAP APIs 25

4.3.2.43 GAP_TX_PWR_MAX_VAL

#define GAP_TX_PWR_MAX_VAL 1

4.3.2.44 GAPBOND_IO_CAP_DISPLAY_ONLY

#define GAPBOND_IO_CAP_DISPLAY_ONLY 0x00

4.3.2.45 GAPBOND_IO_CAP_DISPLAY_YES_NO

#define GAPBOND_IO_CAP_DISPLAY_YES_NO 0x01

4.3.2.46 GAPBOND_IO_CAP_KEYBOARD_DISPLAY

#define GAPBOND_IO_CAP_KEYBOARD_DISPLAY 0x04

4.3.2.47 GAPBOND_IO_CAP_KEYBOARD_ONLY

#define GAPBOND_IO_CAP_KEYBOARD_ONLY 0x02

4.3.2.48 GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT

#define GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT 0x03

4.3.2.49 GAPBOND_PAIRING_MODE_INITIATE

#define GAPBOND_PAIRING_MODE_INITIATE 0x02

4.3.2.50 GAPBOND_PAIRING_MODE_NO_PAIRING

#define GAPBOND_PAIRING_MODE_NO_PAIRING 0×00

4.3.2.51 GAPBOND_PAIRING_MODE_WAIT_FOR_REQ

```
#define GAPBOND_PAIRING_MODE_WAIT_FOR_REQ 0x01
```

4.3.2.52 LE_GAP_ADV_MAX_SIZE

```
#define LE_GAP_ADV_MAX_SIZE 31
```

4.3.3 Function Documentation

4.3.3.1 LeGapAddToResolvingList()

Add device to resolving-list.

Parameters

bt_addr	BT device address.
irk	IRK, Identity Resolving Key

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.2 LeGapAddToWhiteList()

```
LE_ERR_STATE LeGapAddToWhiteList ( \label{legapAddToWhiteList} \mbox{LE\_BT\_ADDR\_T} \ * \ bt\_addr \ )
```

Add device to whitelist.

Parameters

bt addr	BT device address.

4.3 BLE GAP APIs 27

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.3 LeGapAdvertisingEnable()

```
LE_ERR_STATE LeGapAdvertisingEnable ( {\tt BOOL}\ start\ )
```

Enable or disable advertising function.

Parameters

```
start TRUE is enable, FALSE is disable.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.4 LeGapCentralConnectReq()

Central connect request.

Parameters

taddr	advertisers device address.
own_addr_type	owner address type.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.5 LeGapCentralSetDataChannel()

```
LE_ERR_STATE LeGapCentralSetDataChannel ( {\tt UINT8~*~ch~})
```

Central set data channel.

4.3 BLE GAP APIs

Parameters

```
ch data channel.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.6 LeGapClearResolvingList()

```
\label{legap} \begin{array}{lll} \mbox{LE\_ERR\_STATE LeGapClearResolvingList (} \\ & \mbox{void )} \end{array}
```

Clear the resolving-list in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.7 LeGapClearWhiteList()

Clear whitelist in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.8 LeGapConnectCancelReq()

Cancel connect request.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.9 LeGapConnParaRequestRsp()

Connection parameters request response.

Parameters

conn_hdl	connection handle.
accept	TRUE is accept, FALSE is not.

Returns

None.

4.3.3.10 LeGapConnUpdateRequest()

```
LE_ERR_STATE LeGapConnUpdateRequest (  \label{legapConn_hdl}  \mbox{UINT16 } conn\_hdl, \\ \mbox{LE_CONN_PARA_T * para )}
```

Connection parameters update request.

Parameters

conn_hdl	connection handle.
para	update connection parameters.

Returns

None.

4.3.3.11 LeGapConnUpdateResponse()

Connection parameters update response.

Parameters

conn_hdl	connection handle.
identifier	TBD
accept	accept request, or not.

Returns

None.

4.3 BLE GAP APIs 31

4.3.3.12 LeGapDisconnectReq()

Disconnect the physical connection.

Parameters

```
conn_hdl connection handle.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.13 LeGapGenRandAddr()

```
LE_ERR_STATE LeGapGenRandAddr (  \mbox{UINT8 } type, \\ \mbox{BD\_ADDR } addr \mbox{ )}
```

Called to generation random address.

Parameters

type	address type.
addr	address.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.14 LeGapGetBtAddr()

```
void LeGapGetBtAddr (
     void )
```

Get owner device address.

4.3.3.15 LeGapReadAdvChannelTxPower()

```
\begin{tabular}{ll} \beg
```

Read ADV channel txpower.

4.3.3.16 LeGapReadChannelMap()

Read channel map.

Parameters

```
conn_hdl connection handle.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.17 LeGapReadPhy()

```
LE_ERR_STATE LeGapReadPhy ( UINT16 conn_hdl )
```

4.3.3.18 LeGapReadResolvingListSize()

Read the resolving-list size in the controller.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.19 LeGapReadRssi()

Read RSSI value from controller.

4.3 BLE GAP APIs 33

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.20 LeGapReadTxPower()

Read tx power value for the specified connection.

Parameters

conn_hdl	connection handle.
type	current tx power, or maxinum tx power. Don't support.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.21 LeGapReadWhiteListSize()

Read whitelist size in the controller.

4.3.3.22 LeGapRemoveFromWhiteList()

```
LE_ERR_STATE LeGapRemoveFromWhiteList (  \label{legapRemoveFromWhiteList}  \mbox{LE\_BT\_ADDR\_T} * bt\_addr )
```

Remove device from whitelist.

Remove device from resolving-list.

Parameters

```
bt_addr BT device address.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.23 LeGapScanningReq()

```
LE_ERR_STATE LeGapScanningReq (
BOOL start,
BOOL filter )
```

Request scanning start.

Parameters

start	TRUE is start, FALSE is not.
filter	scan policy, refer to LE_HCI_SCAN_FILT_* in ble_hci_if.h

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.24 LeGapSetAdvData()

Called to set ADV data.

Parameters

len	ADV data length.
data	ADV data.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3 BLE GAP APIs 35

4.3.3.25 LeGapSetAdvParameter()

Called to set ADV parameters.

Parameters

params	advertising params.
--------	---------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.26 LeGapSetConnParameter()

Called to set connection parameters.

Parameters

interval_min	mininum connection interval.
interval_max	maxinum connection interval.
slave_letency	slave letency.
supervision_timeout	supervison timeout.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.27 LeGapSetDataChannelPduLen()

```
LE_ERR_STATE LeGapSetDataChannelPduLen ( UINT16 conn_hdl,
```

```
UINT16 tx_octets,
UINT16 tx_time )
```

Set data channel PDU length.

Parameters

tx_octets	the maximum number of octets in the Payload field that the local device will send to the remote
	device.
tx_time	the maximum number of microseconds that the local device will take to transmit a PDU to the
	remote device.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.28 LeGapSetDefaultPhy()

4.3.3.29 LeGapSetPhy()

4.3.3.30 LeGapSetRandAddr()

```
LE_ERR_STATE LeGapSetRandAddr ( {\tt BD\_ADDR} \  \, addr \  \, )
```

Called to set random address.

Parameters

addr	the random address which should be set.

4.3 BLE GAP APIs 37

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.31 LeGapSetRpaTimeout()

Set resolvable private address timeout.

Parameters

timeout RPA_Timeout, measured in seconds.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.32 LeGapSetStaticAddr()

```
LE_ERR_STATE LeGapSetStaticAddr ( {\tt BD\_ADDR} \  \, addr \ )
```

Called to set static address.

Parameters

addr the static address which should be set.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.33 LeSetScanParameter()

Called to set scan parameters.

Parameters

```
params scan parameters.
```

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.3.3.34 LeSetScanRspData()

Called to set scan response data.

Parameters

len	scan response data length.
data	scan response data.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4 BLE GATT APIS 39

4.4 BLE GATT APIS

Data Structures

- struct LE_GATT_ATTR_T
- struct LE GATT MSG ACCESS READ IND T
- struct LE_GATT_MSG_ACCESS_WRITE_IND_T
- struct LE GATT MSG CHAR DESCRIPTOR INFO IND T
- struct LE GATT MSG CHARACTERISTIC DECL INFO IND T
- struct LE GATT MSG CHARACTERISTIC VAL IND T
- struct LE GATT MSG CONFIRMATION CFM T
- struct LE_GATT_MSG_EXCHANGE_MTU_CFM_T
- struct LE_GATT_MSG_EXCHANGE_MTU_IND_T
- struct LE GATT MSG EXECUTE WRITE RELIABLE CFM T
- struct LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T
- struct LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T
- struct LE GATT MSG FIND CHARACTERISTIC CFM T
- struct LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T
- struct LE GATT MSG FIND PRIMARY SERVICE BY UUID CFM T
- struct LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T
- struct LE_GATT_MSG_INDICATE_IND_T
- struct LE_GATT_MSG_NOTIFY_CFM_T
- struct LE_GATT_MSG_NOTIFY_IND_T
- struct LE_GATT_MSG_OPERATION_TIMEOUT_T
- struct LE GATT MSG PREPARE WRITE RELIABLE CFM T
- struct LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T
- struct LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T
- struct LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T
- struct LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T
- struct LE_GATT_MSG_SERVICE_INFO_IND_T
- struct LE_GATT_MSG_SIGNED_WRITE_CFM_T
- struct LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T
- struct LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T
- struct LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T
- struct LE_GATT_MSG_WRITE_NO_RSP_CFM_T
- struct LE_GATT_SERVICE_T

Macros

- #define CHAR_AGGREGATE_DESCRIPTOR(len, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharAggregateUuid, LE_GATT_PERMIT_READ, 0, len, (UINT8 *)(pVal)}
- #define CHAR_CLIENT_CONFIG_DESCRIPTOR(permit, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcClientCharConfigUuid, LE_GATT_PERMIT_READ | permit, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_DECL_UUID16_ATTR_VAL(prop, type) {(prop), 0, 0, UINT16_LO(type), UINT16_HI(type)}
- #define CHAR_EXT_PROP_DESCRIPTOR(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharExtPropUuid, LE_GATT_PERMIT_READ, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_PRESENT_FORMAT_DESCRIPTOR(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharFormatUuid, LE_GATT_PERMIT_READ, 0, 7, (UINT8 *)(pVal)}
- #define CHAR_SERVER_CONFIG_DESCRIPTOR(permit, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcServerCharConfigUuid, LE_GATT_PERMIT_READ | permit, 0, 2, (UINT8 *)(pVal)}
- #define CHAR_USER_DESC_DESCRIPTOR(permit, maxLen, len, pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharUserDescUuid, permit, maxLen, len, (UINT8 *)(pVal)}

• #define CHARACTERISTIC_DECL_UUID128(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharacteristicUuid, LE_GATT_PERMIT_READ, 0, 19, (UINT8 *)(pVal)}

- #define CHARACTERISTIC_DECL_UUID16(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcCharacteristicUuid, LE_GATT_PERMIT_READ, 0, 5, (UINT8 *)(pVal)}
- #define CHARACTERISTIC_UUID128(pUuid, permit, maxLen, len, pVal) {0, LE_GATT_UUID128, (UINT16 *)pUuid, permit, maxLen, len, (UINT8 *)(pVal)}
- #define CHARACTERISTIC_UUID16(pUuid, permit, maxLen, len, pVal) {0, LE_GATT_UUID16, (UINT16 *)pUuid, permit, maxLen, len, (UINT8 *)(pVal)}
- #define GATT CHAR AGG FORMAT UUID 0x2905
- #define GATT CHAR EXT PROPS UUID 0x2900
- #define GATT CHAR FORMAT UUID 0x2904
- #define GATT_CHAR_USER_DESC_UUID 0x2901
- #define GATT CHARACTERISTIC UUID 0x2803
- #define GATT CLIENT CHAR CFG UUID 0x2902
- #define GATT_EXT_REPORT_REF_UUID 0x2907
- #define GATT INCLUDE UUID 0x2802
- #define GATT_PRIMARY_SERVICE_UUID 0x2800
- #define GATT REPORT REF UUID 0x2908
- #define GATT SECONDARY SERVICE UUID 0x2801
- #define GATT_SERV_CHAR_CFG_UUID 0x2903
- #define GATT VALID RANGE UUID 0x2906
- #define INCLUDE_DECL_UUID128(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcIncludeUuid, LE_GATT_PERMIT_READ, 0, 4, (UINT8 *)(pVal)}
- #define INCLUDE_DECL_UUID128_ATTR_VAL() {0, 0, 0, 0}
- #define INCLUDE DECL UUID16 ATTR VAL(uuid) {0, 0, 0, 0, UINT16 LO(uuid), UINT16 HI(uuid)}
- #define INCLUDE_DECL_UUINT16(pVal) {0, LE_GATT_UUID16, (UINT16 *)&gcIncludeUuid, LE_GATT_PERMIT_READ, 0, 6, (UINT8 *)(pVal)}
- #define LE_ATT_UUID_SIZE 2
- #define LE GATT CHAR PROP AUTH 0x40
- #define LE GATT CHAR PROP BCAST 0x01

Characteristic Properties Bit.

- #define LE_GATT_CHAR_PROP_EXT_PROP 0x80
- #define LE_GATT_CHAR_PROP_IND 0x20
- #define LE GATT CHAR PROP NTF 0x10
- #define LE GATT CHAR PROP RD 0x02
- #define LE GATT CHAR PROP WR 0x08
- #define LE_GATT_CHAR_PROP_WR_NO_RESP 0x04
- #define LE_GATT_CLIENT_CFG_INDICATION 0x02
- #define LE_GATT_CLIENT_CFG_NOTIFICATION 0x01
- #define LE_GATT_EXT_PROP_RELIABLE_WR 0x0001
- #define LE_GATT_EXT_PROP_WR_AUX 0x0002
- #define LE_GATT_FLAG_PREPARE_WRITE 0x02
- #define LE_GATT_FLAG_WRITE_CMD 0x01
- #define LE_GATT_FLAG_WRITE_REQ 0x00
- #define LE_GATT_PERM_AUTH_READABLE (0x1<<4)
- #define LE GATT PERM AUTH WRITABLE (0x1<<6)
- #define LE GATT PERM NONE (0x00)
- #define LE GATT PERM READ (0x1<<1)
- #define LE GATT PERM RELIABLE WRITE (0x1<<5)
- #define LE_GATT_PERM_WRITE_CMD (0x1<<2)
- #define LE_GATT_PERM_WRITE_REQ (0x1<<3)
- #define LE_GATT_PERMIT_AUTHEN_READ (0x0040)
- #define LE_GATT_PERMIT_AUTHEN_WRITE (0x0080)
- #define LE_GATT_PERMIT_AUTHOR_READ (0x0004)
- #define LE_GATT_PERMIT_AUTHOR_WRITE (0x0008)

4.4 BLE GATT APIS 41

- #define LE_GATT_PERMIT_ENCRYPT_READ (0x0010)
- #define LE_GATT_PERMIT_ENCRYPT_WRITE (0x0020)
- #define LE_GATT_PERMIT_READ (0x0001)
- #define LE_GATT_PERMIT_READABLE (LE_GATT_PERMIT_READ | LE_GATT_PERMIT_AUTHEN_READ | LE_GATT_PERMIT_AUTHOR_READ | LE_GATT_PERMIT_ENCRYPT_READ | LE_GATT_PERMIT_SC_AUTHEN_READ)
- #define LE_GATT_PERMIT_SC_AUTHEN_READ (0x0100)
- #define LE GATT PERMIT SC AUTHEN WRITE (0x0200)
- #define LE_GATT_PERMIT_WRITABLE (LE_GATT_PERMIT_WRITE | LE_GATT_PERMIT_AUTHEN_WRITE | LE_GATT_PERMIT_AUTHOR_WRITE | LE_GATT_PERMIT_ENCRYPT_WRITE | LE_GATT_PERMIT_SC_AUTHEN_WRITE | LE_GA
- #define LE_GATT_PERMIT_WRITE (0x0002)
- #define PRIMARY_SERVICE_DECL_UUID128(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcPrimaryServiceUuid, LE GATT PERMIT READ, 0, 16, (UINT8 *)(pUuid)}
- #define PRIMARY_SERVICE_DECL_UUID16(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcPrimaryServiceUuid, LE GATT PERMIT READ, 0, 2, (UINT8 *)(pUuid)}
- #define SECONDARY_SERVICE_DECL_UUID128(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcSecondaryServiceUuid, LE_GATT_PERMIT_READ, 0, 16, (UINT8 *)(pUuid)}
- #define SECONDARY_SERVICE_DECL_UUID16(pUuid) {0, LE_GATT_UUID16, (UINT16 *)&gcSecondaryServiceUuid, LE_GATT_PERMIT_READ, 0, 2, (UINT8 *)(pUuid)}

Enumerations

```
enum {
 LE_GATT_MSG_INIT_CFM = LE_GATT_MSG_BASE, LE_GATT_MSG_EXCHANGE_MTU_IND, LE_GATT_MSG_EXCHANG
 LE GATT MSG ACCESS READ IND,
 LE_GATT_MSG_ACCESS_WRITE_IND, LE_GATT_MSG_SERVICE_INFO_IND, LE_GATT_MSG_FIND_ALL_PRIMARY_SE
 LE GATT MSG FIND PRIMARY SERVICE BY UUID CFM,
 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND, LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM,
 LE GATT MSG CHARACTERISTIC DECL INFO IND, LE GATT MSG FIND CHARACTERISTIC CFM,
                                          LE GATT MSG FIND ALL CHAR DESC CFM,
 LE GATT MSG CHAR DESCRIPTOR INFO IND,
 LE_GATT_MSG_CHARACTERISTIC_VAL_IND, LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM,
 LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM, LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM,
 LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM, LE_GATT_MSG_WRITE_CHAR_VALUE_CFM,
 LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM, LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM,
 LE GATT MSG PREPARE WRITE RELIABLE CFM, LE GATT MSG EXECUTE WRITE RELIABLE CFM,
 LE GATT MSG WRITE NO RSP CFM, LE GATT MSG SIGNED WRITE CFM, LE GATT MSG NOTIFY IND,
 LE GATT MSG NOTIFY CFM,
 LE GATT MSG INDICATE IND, LE GATT MSG CONFIRMATION CFM, LE GATT MSG OPERATION TIMEOUT,
 LE_GATT_MSG_SIGN_RESOLUTION_FAIL,
 LE_GATT_MSG_TOP }
```

Functions

BLE GATT message id.

- LE_ERR_STATE LeGattAccessReadRsp (UINT16 conn_hdl, UINT16 handle, UINT8 att_err)
 Gatt access read response.
- LE_ERR_STATE LeGattAccessWriteRsp (UINT16 conn_hdl, UINT8 method, UINT16 handle, UINT8 att_err)

 Gatt access write response.
- LE_ERR_STATE LeGattChangeAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 len, void *val) Change attribute value.
- LE_ERR_STATE LeGattCharValConfirmation (UINT16 conn_hdl)

Prepare write characteristic value response.

• LE_ERR_STATE LeGattCharValIndicate (UINT16 conn_hdl, UINT16 hdl, UINT16 len, UINT8 *pval) Gatt characteristic value indication.

• LE_ERR_STATE LeGattCharValNotify (UINT16 conn_hdl, UINT16 hdl, UINT16 len, UINT8 *pval)

Gatt characteristic value notification.

• LE_ERR_STATE LeGattExchangeMtuReq (UINT16 conn_hdl, UINT16 mtu)

Exchange MTU request.

LE_ERR_STATE LeGattExchangeMtuRsp (UINT16 conn_hdl, UINT16 mtu)

Exchange MTU response.

• LE ERR STATE LeGattExecuteWriteCharValReliable (UINT16 conn hdl, BOOL yesno)

Execute write characteristic value request.

LE_ERR_STATE LeGattFindAllCharacteristic (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl)
 Find all characteristic.

• LE_ERR_STATE LeGattFindAllCharDescriptor (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl) Find all characteristic description.

• LE_ERR_STATE LeGattFindAllPrimaryService (UINT16 conn_hdl)

Find all primary service.

• LE_ERR_STATE LeGattFindCharacteristicByUuid (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl, UINT8 format, UINT16 *uuid)

Find characteristic by UUID.

LE_ERR_STATE LeGattFindIncludedService (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl)
 Find include service.

• LE_ERR_STATE LeGattFindPrimaryServiceByUuid (UINT16 conn_hdl, UINT8 format, UINT16 *uuid) Find primary service by UUID.

• UINT16 LeGattGetAttrHandle (LE_GATT_SERVICE_T *svc, UINT16 attrld)

Get attribute handle.

• LE_ERR_STATE LeGattGetAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 *len, void *val)

Get attribute value.

UINT16 LeGattGetAttrValLen (LE GATT SERVICE T *svc, UINT16 attrld)

Get the length of attribute value.

• UINT16 LeGattGetAttrValMaxLen (LE_GATT_SERVICE_T *svc, UINT16 attrld)

Get the max length of attribute value.

void LeGattInit (TASK appTask)

BLE Gatt module init.

• LE_ERR_STATE LeGattModifyAttrVal (LE_GATT_SERVICE_T *svc, UINT16 attrld, UINT16 offset, UINT16 len, void *val)

Modify attribute value.

• LE_ERR_STATE LeGattPrepareWriteCharValReliable (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Prepare write characteristic value request.

• LE_ERR_STATE LeGattReadCharValByUuid (UINT16 conn_hdl, UINT16 start_hdl, UINT16 end_hdl, UINT8 format, UINT16 *uuid)

Read a characteristic value by UUID.

• LE_ERR_STATE LeGattReadCharValue (UINT16 conn_hdl, UINT16 handle)

Read a characteristic value.

• LE ERR STATE LeGattReadLongCharVal (UINT16 conn hdl, UINT16 handle, UINT16 offset)

Read a long characteristic value.

 $\bullet \ \ \mathsf{LE}_\mathsf{ERR}_\mathsf{STATE} \ \mathsf{LeGattReadMultipleCharVal} \ (\mathsf{UINT16} \ \mathsf{conn_hdl}, \ \mathsf{UINT16} \ \mathsf{count}, \ \mathsf{UINT16} \ \mathsf{*handle})$

Read Multiple characteristic values.

LE_ERR_STATE LeGattRegisterIncludeService (UINT16 inc_hdl, UINT16 start_hdl, UINT16 end_hdl, UI
 NT16 uuid)

Called to register an include service.

LE GATT SERVICE T * LeGattRegisterService (LE GATT ATTR T *attrTable, UINT16 numAttr)

Called to register a service.

4.4 BLE GATT APIS 43

• LE_ERR_STATE LeGattSignedWriteNoRsp (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val) Signed write without response.

void LeGattStopCurrentProcedure (UINT16 conn_hdl)

Stop current procedure.

- LE_ERR_STATE LeGattWriteCharVal (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val)

 Write characteristic value.
- LE_ERR_STATE LeGattWriteCharValReliable (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Write characteristic value reliable.

• LE_ERR_STATE LeGattWriteLongCharVal (UINT16 conn_hdl, UINT16 handle, UINT16 offset, UINT16 len, UINT8 *val)

Write long characteristic value.

• LE_ERR_STATE LeGattWriteNoRsp (UINT16 conn_hdl, UINT16 handle, UINT16 len, UINT8 *val) Write without response.

Variables

- · const UINT16 gcCharacteristicUuid
- · const UINT16 gcCharAggregateUuid
- · const UINT16 gcCharExtPropUuid
- const UINT16 gcCharFormatUuid
- const UINT16 gcCharUserDescUuid
- const UINT16 gcClientCharConfigUuid
- · const UINT16 gcExtReportRefUuid
- · const UINT16 gcIncludeUuid
- const UINT16 gcPrimaryServiceUuid
- · const UINT16 gcReportRefUuid
- · const UINT16 gcSecondaryServiceUuid
- const UINT16 gcServerCharConfigUuid
- · const UINT16 gcValidRangeUuid

4.4.1 Detailed Description

4.4.2 Macro Definition Documentation

4.4.2.1 CHAR AGGREGATE DESCRIPTOR

4.4.2.2 CHAR_CLIENT_CONFIG_DESCRIPTOR

4.4.2.3 CHAR_DECL_UUID16_ATTR_VAL

4.4.2.4 CHAR_EXT_PROP_DESCRIPTOR

4.4.2.5 CHAR_PRESENT_FORMAT_DESCRIPTOR

4.4.2.6 CHAR_SERVER_CONFIG_DESCRIPTOR

4.4.2.7 CHAR_USER_DESC_DESCRIPTOR

4.4 BLE GATT APIS 45

4.4.2.8 CHARACTERISTIC_DECL_UUID128

4.4.2.9 CHARACTERISTIC DECL_UUID16

4.4.2.10 CHARACTERISTIC_UUID128

4.4.2.11 CHARACTERISTIC UUID16

4.4.2.12 GATT_CHAR_AGG_FORMAT_UUID

```
#define GATT_CHAR_AGG_FORMAT_UUID 0x2905
```

4.4.2.13 GATT_CHAR_EXT_PROPS_UUID

```
#define GATT_CHAR_EXT_PROPS_UUID 0x2900
```

4.4.2.14 GATT_CHAR_FORMAT_UUID

#define GATT_CHAR_FORMAT_UUID 0x2904

4.4.2.15 GATT_CHAR_USER_DESC_UUID

#define GATT_CHAR_USER_DESC_UUID 0x2901

4.4.2.16 GATT_CHARACTERISTIC_UUID

#define GATT_CHARACTERISTIC_UUID 0x2803

4.4.2.17 GATT_CLIENT_CHAR_CFG_UUID

#define GATT_CLIENT_CHAR_CFG_UUID 0x2902

4.4.2.18 GATT_EXT_REPORT_REF_UUID

#define GATT_EXT_REPORT_REF_UUID 0x2907

4.4.2.19 GATT_INCLUDE_UUID

#define GATT_INCLUDE_UUID 0x2802

4.4.2.20 GATT_PRIMARY_SERVICE_UUID

#define GATT_PRIMARY_SERVICE_UUID 0x2800

4.4.2.21 GATT_REPORT_REF_UUID

#define GATT_REPORT_REF_UUID 0x2908

4.4 BLE GATT APIs 47

4.4.2.22 GATT_SECONDARY_SERVICE_UUID

```
#define GATT_SECONDARY_SERVICE_UUID 0x2801
```

4.4.2.23 GATT_SERV_CHAR_CFG_UUID

```
#define GATT_SERV_CHAR_CFG_UUID 0x2903
```

4.4.2.24 GATT_VALID_RANGE_UUID

```
#define GATT_VALID_RANGE_UUID 0x2906
```

4.4.2.25 INCLUDE DECL_UUID128

4.4.2.26 INCLUDE_DECL_UUID128_ATTR_VAL

```
#define INCLUDE_DECL_UUID128_ATTR_VAL() {0, 0, 0, 0}
```

4.4.2.27 INCLUDE_DECL_UUID16_ATTR_VAL

4.4.2.28 INCLUDE_DECL_UUINT16

4.4.2.29 LE_ATT_UUID_SIZE

#define LE_ATT_UUID_SIZE 2

4.4.2.30 LE_GATT_CHAR_PROP_AUTH

#define LE_GATT_CHAR_PROP_AUTH 0x40

4.4.2.31 LE_GATT_CHAR_PROP_BCAST

#define LE_GATT_CHAR_PROP_BCAST 0x01

Characteristic Properties Bit.

4.4.2.32 LE_GATT_CHAR_PROP_EXT_PROP

#define LE_GATT_CHAR_PROP_EXT_PROP 0x80

4.4.2.33 LE_GATT_CHAR_PROP_IND

 $\verb|#define LE_GATT_CHAR_PROP_IND 0x20|\\$

4.4.2.34 LE_GATT_CHAR_PROP_NTF

#define LE_GATT_CHAR_PROP_NTF 0x10

4.4.2.35 LE_GATT_CHAR_PROP_RD

#define LE_GATT_CHAR_PROP_RD 0x02

4.4 BLE GATT APIs 49

4.4.2.36 LE_GATT_CHAR_PROP_WR

#define LE_GATT_CHAR_PROP_WR 0x08

4.4.2.37 LE_GATT_CHAR_PROP_WR_NO_RESP

#define LE_GATT_CHAR_PROP_WR_NO_RESP 0x04

4.4.2.38 LE_GATT_CLIENT_CFG_INDICATION

#define LE_GATT_CLIENT_CFG_INDICATION 0x02

4.4.2.39 LE_GATT_CLIENT_CFG_NOTIFICATION

#define LE_GATT_CLIENT_CFG_NOTIFICATION 0x01

4.4.2.40 LE_GATT_EXT_PROP_RELIABLE_WR

 $\verb|#define LE_GATT_EXT_PROP_RELIABLE_WR 0x0001|\\$

4.4.2.41 LE_GATT_EXT_PROP_WR_AUX

#define LE_GATT_EXT_PROP_WR_AUX 0x0002

4.4.2.42 LE_GATT_FLAG_PREPARE_WRITE

#define LE_GATT_FLAG_PREPARE_WRITE 0x02

4.4.2.43 LE_GATT_FLAG_WRITE_CMD

 $\#define LE_GATT_FLAG_WRITE_CMD 0x01$

4.4.2.44 LE_GATT_FLAG_WRITE_REQ

#define LE_GATT_FLAG_WRITE_REQ 0x00

4.4.2.45 LE_GATT_PERM_AUTH_READABLE

#define LE_GATT_PERM_AUTH_READABLE (0x1 << 4)

4.4.2.46 LE_GATT_PERM_AUTH_WRITABLE

#define LE_GATT_PERM_AUTH_WRITABLE (0x1<<6)</pre>

4.4.2.47 LE_GATT_PERM_NONE

#define LE_GATT_PERM_NONE (0x00)

4.4.2.48 LE_GATT_PERM_READ

#define LE_GATT_PERM_READ (0x1<<1)</pre>

4.4.2.49 LE_GATT_PERM_RELIABLE_WRITE

#define LE_GATT_PERM_RELIABLE_WRITE (0x1 << 5)

4.4.2.50 LE_GATT_PERM_WRITE_CMD

#define LE_GATT_PERM_WRITE_CMD (0x1 << 2)

4.4.2.51 LE_GATT_PERM_WRITE_REQ

 $\texttt{\#define LE_GATT_PERM_WRITE_REQ (0x1}{<<3})$

4.4 BLE GATT APIs 51

4.4.2.52 LE_GATT_PERMIT_AUTHEN_READ

#define LE_GATT_PERMIT_AUTHEN_READ (0x0040)

4.4.2.53 LE_GATT_PERMIT_AUTHEN_WRITE

#define LE_GATT_PERMIT_AUTHEN_WRITE (0x0080)

4.4.2.54 LE_GATT_PERMIT_AUTHOR_READ

#define LE_GATT_PERMIT_AUTHOR_READ (0x0004)

4.4.2.55 LE_GATT_PERMIT_AUTHOR_WRITE

#define LE_GATT_PERMIT_AUTHOR_WRITE (0x0008)

4.4.2.56 LE_GATT_PERMIT_ENCRYPT_READ

#define LE_GATT_PERMIT_ENCRYPT_READ (0x0010)

4.4.2.57 LE_GATT_PERMIT_ENCRYPT_WRITE

#define LE_GATT_PERMIT_ENCRYPT_WRITE (0x0020)

4.4.2.58 LE_GATT_PERMIT_READ

#define LE_GATT_PERMIT_READ (0x0001)

4.4.2.59 LE_GATT_PERMIT_READABLE

#define LE_GATT_PERMIT_READABLE (LE_GATT_PERMIT_READ | LE_GATT_PERMIT_AUTHEN_READ | LE_GATT_PERMIT_AUTHOR_READ | LE_GATT_PERMIT_ENCRYPT_READ | LE_GATT_PERMIT_SC_AUTHEN_READ)

4.4.2.60 LE_GATT_PERMIT_SC_AUTHEN_READ

```
#define LE_GATT_PERMIT_SC_AUTHEN_READ (0x0100)
```

4.4.2.61 LE_GATT_PERMIT_SC_AUTHEN_WRITE

```
#define LE_GATT_PERMIT_SC_AUTHEN_WRITE (0x0200)
```

4.4.2.62 LE_GATT_PERMIT_WRITABLE

```
#define LE_GATT_PERMIT_WRITABLE (LE_GATT_PERMIT_WRITE | LE_GATT_PERMIT_AUTHEN_WRITE | LE_GATT_PERMIT_AUTHOR_WRITE | LE_GATT_PERMIT_ENCRYPT_WRITE | LE_GATT_PERMIT_SC_AUTHEN_WRITE)
```

4.4.2.63 LE_GATT_PERMIT_WRITE

```
#define LE_GATT_PERMIT_WRITE (0x0002)
```

4.4.2.64 PRIMARY_SERVICE_DECL_UUID128

4.4.2.65 PRIMARY_SERVICE_DECL_UUID16

4.4.2.66 SECONDARY_SERVICE_DECL_UUID128

4.4 BLE GATT APIs 53

4.4.2.67 SECONDARY_SERVICE_DECL_UUID16

4.4.3 Enumeration Type Documentation

4.4.3.1 anonymous enum

anonymous enum

BLE GATT message id.

Enumerator

LE_GATT_MSG_INIT_CFM	initialize confirm message
LE_GATT_MSG_EXCHANGE_MTU_IND	exchange MTU indication
LE_GATT_MSG_EXCHANGE_MTU_CFM	exchange MTU confirm
LE_GATT_MSG_ACCESS_READ_IND	access read indication
LE_GATT_MSG_ACCESS_WRITE_IND	access write indication
LE_GATT_MSG_SERVICE_INFO_IND	service infomation indication
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE←	find all primary service confirm
_CFM	
LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY←	find primary service by UUID fonfirm
_UUID_CFM	
LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND	include service infomation
LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM	find include service confirm
LE_GATT_MSG_CHARACTERISTIC_DECL_INF	characteristic declaration info indication
O_IND	
LE_GATT_MSG_FIND_CHARACTERISTIC_CFM	find characteristic confirm
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND	characteristic descriptor info indication
LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM	find all characteristic descriptors confirm
LE_GATT_MSG_CHARACTERISTIC_VAL_IND	characteristic value, indication message
LE_GATT_MSG_READ_CHARACTERISTIC_VAL	read characteristic value, confirm message
UE_CFM	
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_C	read characteristic value by UUID confirm message
FM LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM	read long characteristic value confirm mesage
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_ CFM	read multiple characteristic value confirm
LE GATT MSG WRITE CHAR VALUE CFM	write characteristic value confirm
LE GATT MSG WRITE LONG CHAR VALUE ↔	write long characteristic value confirm
CFM	
LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE↔	write characteristic value reliable confirm
LE_GATT_MSG_PREPARE_WRITE_RELIABLE_←	prepare write reliable confirm
CFM	

Enumerator

LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_	execute write reliable confirm
CFM	
LE_GATT_MSG_WRITE_NO_RSP_CFM	write no response confirm
LE_GATT_MSG_SIGNED_WRITE_CFM	signed write confirm
LE_GATT_MSG_NOTIFY_IND	notify indication
LE_GATT_MSG_NOTIFY_CFM	notify confirm
LE_GATT_MSG_INDICATE_IND	indicate indication
LE_GATT_MSG_CONFIRMATION_CFM	confirmation confirm
LE_GATT_MSG_OPERATION_TIMEOUT	operation timeout
LE_GATT_MSG_SIGN_RESOLUTION_FAIL	sign resolution fail
LE_GATT_MSG_TOP	top of GATT message id

4.4.4 Function Documentation

4.4.4.1 LeGattAccessReadRsp()

Gatt access read response.

Parameters

conn_hdl	connection handle.
handle	attribute handle.
att err	0 is OK, others refer to LE ATT ERR * in ble att if.h.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.2 LeGattAccessWriteRsp()

Gatt access write response.

4.4 BLE GATT APIs 55

Parameters

conn_hdl	connection handle.
method	refer to LE_GATT_FLAG_* in ble_gatt_if.h
handle	attribute handle.
att_err	0 is OK, others refer to LE_ATT_ERR_* in ble_att_if.h.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.3 LeGattChangeAttrVal()

```
LE_ERR_STATE LeGattChangeAttrVal (

LE_GATT_SERVICE_T * svc,

UINT16 attrId,

UINT16 len,

void * val )
```

Change attribute value.

Parameters

	svc	service.
	attr⇔	attribute index of service.
	ld	
in	len	attribute value length.
in	val	attribute value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.4 LeGattCharValConfirmation()

```
LE_ERR_STATE LeGattCharValConfirmation ( {\tt UINT16} \ \ conn\_hdl \ )
```

Prepare write characteristic value response.

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.5 LeGattCharValIndicate()

Gatt characteristic value indication.

Parameters

conn_hdl	connection handle.
hdl	characteristic value handle.
len	value length.
pval	value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.6 LeGattCharValNotify()

Gatt characteristic value notification.

Parameters

conn_hdl	connection handle.
hdl	characteristic value handle.
len	value length.
pval	value.

4.4 BLE GATT APIs 57

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.7 LeGattExchangeMtuReq()

Exchange MTU request.

Parameters

conn_hdl	connection handle.
mtu	MTU.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.8 LeGattExchangeMtuRsp()

Exchange MTU response.

Parameters

conn_hdl	connection handle.
mtu	MTU.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.9 LeGattExecuteWriteCharValReliable()

Execute write characteristic value request.

Parameters

conn_hdl	connection handle.
yesno	execute write or not.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.10 LeGattFindAllCharacteristic()

Find all characteristic.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.11 LeGattFindAllCharDescriptor()

Find all characteristic description.

4.4 BLE GATT APIS 59

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.12 LeGattFindAllPrimaryService()

```
LE_ERR_STATE LeGattFindAllPrimaryService ( {\tt UINT16} \ \ conn\_hdl \ )
```

Find all primary service.

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.13 LeGattFindCharacteristicByUuid()

Find characteristic by UUID.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.14 LeGattFindIncludedService()

Find include service.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.15 LeGattFindPrimaryServiceByUuid()

Find primary service by UUID.

Parameters

conn_hdl	connection handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4 BLE GATT APIs 61

4.4.4.16 LeGattGetAttrHandle()

Get attribute handle.

Parameters

svc	service.
attr⇔	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.17 LeGattGetAttrVal()

```
LE_ERR_STATE LeGattGetAttrVal (

LE_GATT_SERVICE_T * svc,

UINT16 attrId,

UINT16 * len,

void * val )
```

Get attribute value.

Parameters

	SVC	service.
	attr⇔ Id	attribute index of service.
out	len	attribute value length.
out	val	attribute value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.18 LeGattGetAttrValLen()

Get the length of attribute value.

4.4 BLE GATT APIs 63

Parameters

SVC	service.
attr⊷	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.19 LeGattGetAttrValMaxLen()

Get the max length of attribute value.

Parameters

SVC	service.
attr⇔	attribute index of service.
ld	

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.20 LeGattInit()

BLE Gatt module init.

Parameters

appTask the reference of BLE task

Returns

None.

4.4.4.21 LeGattModifyAttrVal()

Modify attribute value.

Parameters

SVC	servie.
attrld	attribute index of service.
offset	modify offset.
len	modify length.
val	modify value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.22 LeGattPrepareWriteCharValReliable()

Prepare write characteristic value request.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	offset written.
len	length written.
val	value.

4.4 BLE GATT APIS 65

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.23 LeGattReadCharValByUuid()

Read a characteristic value by UUID.

Parameters

conn_hdl	connection handle.
start_hdl	start handle.
end_hdl	end handle.
format	UUID type.
uuid	UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.24 LeGattReadCharValue()

Read a characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.25 LeGattReadLongCharVal()

Read a long characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	characteristic value offset.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.26 LeGattReadMultipleCharVal()

Read Multiple characteristic values.

Parameters

conn_hdl	connection handle.
count	handle count.
handle	handle table.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.27 LeGattRegisterIncludeService()

```
LE_ERR_STATE LeGattRegisterIncludeService ( UINT16 inc_hdl,
```

4.4 BLE GATT APIS 67

```
UINT16 start_hdl,
UINT16 end_hdl,
UINT16 uuid )
```

Called to register an include service.

Parameters

inc_hdl	include service handle.
start_hdl	start handle.
end_hdl	end handle.
uuid	include service UUID.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.28 LeGattRegisterService()

Called to register a service.

Parameters

attrTable	service attribute table.
numAttr	the attribute number of service.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.29 LeGattSignedWriteNoRsp()

Signed write without response.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.30 LeGattStopCurrentProcedure()

Stop current procedure.

Parameters

conn_hdl	connection handle.
----------	--------------------

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.31 LeGattWriteCharVal()

Write characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

4.4 BLE GATT APIS 69

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.32 LeGattWriteCharValReliable()

Write characteristic value reliable.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	offset written.
len	length written.
val	value.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.33 LeGattWriteLongCharVal()

Write long characteristic value.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
offset	value position offset.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.4.34 LeGattWriteNoRsp()

Write without response.

Parameters

conn_hdl	connection handle.
handle	characteristic value handle.
len	length of the data to be written.
val	the value to be written.

Returns

- SYS_ERR_SUCCESS: success.
- others: refer to error code in ble_err.h.

4.4.5 Variable Documentation

4.4.5.1 gcCharacteristicUuid

```
const UINT16 gcCharacteristicUuid
```

4.4.5.2 gcCharAggregateUuid

const UINT16 gcCharAggregateUuid

4.4 BLE GATT APIs 71

4.4.5.3 gcCharExtPropUuid

const UINT16 gcCharExtPropUuid

4.4.5.4 gcCharFormatUuid

const UINT16 gcCharFormatUuid

4.4.5.5 gcCharUserDescUuid

const UINT16 gcCharUserDescUuid

4.4.5.6 gcClientCharConfigUuid

const UINT16 gcClientCharConfigUuid

4.4.5.7 gcExtReportRefUuid

const UINT16 gcExtReportRefUuid

4.4.5.8 gclncludeUuid

const UINT16 gcIncludeUuid

4.4.5.9 gcPrimaryServiceUuid

const UINT16 gcPrimaryServiceUuid

4.4.5.10 gcReportRefUuid

const UINT16 gcReportRefUuid

4.4.5.11 gcSecondaryServiceUuid

const UINT16 gcSecondaryServiceUuid

4.4.5.12 gcServerCharConfigUuid

const UINT16 gcServerCharConfigUuid

4.4.5.13 gcValidRangeUuid

const UINT16 gcValidRangeUuid

4.5 BLE MSG APIs 73

4.5 BLE MSG APIs

Data Structures

struct LE_SYS_MSG_BUF_OVERFLOW_T

Macros

- #define LE ATT MSG BASE 0x1400
- #define LE_CM_MSG_BASE 0x1100
- #define LE_GATT_MSG_BASE 0x1500
- #define LE_HCI_MSG_BASE 0x1000
- #define LE_L2CAP_MSG_BASE 0x1200
- #define LE_SMP_MSG_BASE 0x1300
- #define LE_SYS_MSG_BASE 0x8000
- #define MESSAGE_ALLOCATE(M, S) PanicUnlessMalloc(sizeof(M##_T) + S)
- #define MESSAGE BULID(M) M## T *msg = PanicUnlessMalloc(sizeof(M## T))
- #define MESSAGE_DATA_BULID(M, S) M##_T *msg = PanicUnlessMalloc(sizeof(M##_T) + S)
- #define MESSAGE_OFFSET(M) ((UINT8 *)msg + sizeof(M##_T))
- #define T_HOUR(h) ((UINT32)((h) * (UINT32)1000 * (UINT32)60) * (UINT32)60)
- #define T_MIN(m) ((UINT32)((m) * (UINT32)1000 * (UINT32)60))
- #define T SEC(s) ((UINT32)((s) * (UINT32)1000))

Typedefs

- typedef MsgData MESSAGE
- typedef UINT16 MESSAGEID
- typedef void const * MsgData
- typedef const UINT8 * MsgLock
- typedef MsgLock MSGLOCK
- typedef UINT16 MSGSUBID
- typedef UINT32 MSGTIMER
- typedef TASKPACK * Task
- · typedef Task TASK
- typedef void(* TASKHANDLER) (Task, UINT16, MsgData)
- typedef void ** TASKPACK

Enumerations

enum { LE_SYS_MSG_BUF_OVERFLOW = (LE_SYS_MSG_BASE + 1), LE_SYS_MSG_TOP }
 BLE system message id.

Functions

• UINT16 LeCancelAllMessage (TASK task, MESSAGEID id)

Cancel all message in queue.

• UINT16 LeCancelAllSubMessage (TASK task, MESSAGEID id, MSGSUBID subId)

Cancel all sub message in queue.

BOOL LeCancelFirstMessage (TASK task, MESSAGEID id)

Cancel the first message in queue.

BOOL LeCancelFirstSubMessage (TASK task, MESSAGEID id, MSGSUBID subId)

Cancel the first sub message in queue.

UINT16 LeGetSubMsgld (UINT16 *s)

Get sub message id.

• BOOL LeHostCreateTask (TASK task, TASKHANDLER hdl)

Create BLE task.

void LeHostMessageLoop (void)

message loop run.

void LeSendMessage (TASK task, MESSAGEID msgld, MESSAGE msg)

Send message to BLE task.

• void LeSendMessageAfter (TASK task, MESSAGEID msgld, MESSAGE msg, UINT32 delay)

Delay, then send message to BLE task.

void LeSendMessageUnlock (TASK task, MESSAGEID id, MESSAGE msg, MSGLOCK lock)

Send message until lock is 0.

• void LeSendSubMessage (TASK task, MESSAGEID msgld, MSGSUBID subId, MESSAGE msg)

Send sub message.

void LeSendSubMessageAfter (TASK task, MESSAGEID msgld, MSGSUBID subId, MESSAGE msg, UIN

T32 delay)

Delay, then send sub message.

 void LeSendSubMessageUnlock (TASK task, MESSAGEID id, MSGSUBID subId, MESSAGE msg, MSGLOCK lock)

Send sub message until lock is 0.

4.5.1 Detailed Description

4.5.2 Macro Definition Documentation

4.5.2.1 LE_ATT_MSG_BASE

#define LE_ATT_MSG_BASE 0x1400

4.5.2.2 LE_CM_MSG_BASE

#define LE_CM_MSG_BASE 0x1100

4.5 BLE MSG APIs 75

4.5.2.3 LE_GATT_MSG_BASE

```
#define LE_GATT_MSG_BASE 0x1500
```

4.5.2.4 LE_HCI_MSG_BASE

```
#define LE_HCI_MSG_BASE 0x1000
```

4.5.2.5 LE_L2CAP_MSG_BASE

```
#define LE_L2CAP_MSG_BASE 0x1200
```

4.5.2.6 LE_SMP_MSG_BASE

```
#define LE_SMP_MSG_BASE 0x1300
```

4.5.2.7 LE_SYS_MSG_BASE

```
#define LE_SYS_MSG_BASE 0x8000
```

4.5.2.8 MESSAGE_ALLOCATE

4.5.2.9 MESSAGE_BULID

4.5.2.10 MESSAGE_DATA_BULID

4.5.2.11 MESSAGE_OFFSET

4.5.2.12 T_HOUR

4.5.2.13 T_MIN

```
#define T_MIN(  m \ ) \ ((UINT32) \ ((m) \ * \ (UINT32) \ 1000 \ * \ (UINT32) \ 60))
```

4.5.2.14 T_SEC

4.5.3 Typedef Documentation

4.5.3.1 MESSAGE

typedef MsgData MESSAGE

4.5 BLE MSG APIs 77

4.5.3.2 MESSAGEID

typedef UINT16 MESSAGEID

4.5.3.3 MsgData

typedef void const* MsgData

4.5.3.4 MsgLock

typedef const UINT8* MsgLock

4.5.3.5 MSGLOCK

typedef MsgLock MSGLOCK

4.5.3.6 MSGSUBID

typedef UINT16 MSGSUBID

4.5.3.7 MSGTIMER

typedef UINT32 MSGTIMER

4.5.3.8 Task

typedef TASKPACK* Task

4.5.3.9 TASK

typedef Task TASK

4.5.3.10 TASKHANDLER

```
typedef void(* TASKHANDLER) (Task, UINT16, MsgData)
```

4.5.3.11 TASKPACK

```
typedef void** TASKPACK
```

4.5.4 Enumeration Type Documentation

4.5.4.1 anonymous enum

anonymous enum

BLE system message id.

Enumerator

LE_SYS_MSG_BUF_OVERFLOW	message buffer overflow
LE_SYS_MSG_TOP	top of system message id

4.5.5 Function Documentation

4.5.5.1 LeCancelAllMessage()

```
UINT16 LeCancelAllMessage ( {\it TASK}~task, \\ {\it MESSAGEID}~id~)
```

Cancel all message in queue.

Parameters

task	task.
id	message id.

4.5 BLE MSG APIs 79

Returns

0 is ok, others is error.

4.5.5.2 LeCancelAllSubMessage()

Cancel all sub message in queue.

Parameters

task	the task of recvice message.
id	message id.
sub⊷	sub message id.
ld	

Returns

0 is ok, others is error.

4.5.5.3 LeCancelFirstMessage()

```
BOOL LeCancelFirstMessage ( {\tt TASK}\ task, {\tt MESSAGEID}\ id\ )
```

Cancel the first message in queue.

Parameters

task	task.
id	message id.

Returns

True is ok, false is error.

4.5.5.4 LeCancelFirstSubMessage()

Cancel the first sub message in queue.

Parameters

task	the task of recvice message.
id	message id.
sub⇔	sub message id.
ld	

Returns

True is ok, false is error.

4.5.5.5 LeGetSubMsgld()

Get sub message id.

Parameters

sub	message id.
sub	message id.

Returns

0 is ok, others is error.

4.5.5.6 LeHostCreateTask()

```
BOOL LeHostCreateTask (
TASK task,
TASKHANDLER hdl )
```

Create BLE task.

4.5 BLE MSG APIs 81

Parameters

task	the reference of BLE task.
hdl	callback handle of BLE task.

Returns

TRUE is success, FALSE is failed.

4.5.5.7 LeHostMessageLoop()

message loop run.

Returns

None.

4.5.5.8 LeSendMessage()

Send message to BLE task.

Parameters

task	reference of BLE task.
msg←	message ID.
ld	
msg	message.

Returns

None.

4.5.5.9 LeSendMessageAfter()

```
void LeSendMessageAfter ( {\tt TASK}\ task,
```

```
MESSAGEID msgId,
MESSAGE msg,
UINT32 delay)
```

Delay, then send message to BLE task.

Parameters

task	reference of BLE task.
msg⇔	message ID.
ld	
msg	message.
delay	delay time, ms.

Returns

None.

4.5.5.10 LeSendMessageUnlock()

Send message until lock is 0.

Parameters

task	the task of recvice message.
id	message id.
msg	message.
lock	lock number.

Returns

None.

4.5.5.11 LeSendSubMessage()

Send sub message.

4.5 BLE MSG APIs 83

Parameters

task	the task of recvice message.
msg← Id	message id.
subId	sub message id.
msg	message.

Returns

None.

4.5.5.12 LeSendSubMessageAfter()

Delay, then send sub message.

Parameters

task	the task of recvice message.
msg⊷	message id.
ld	
subId	sub message id.
msg	message.
delay	delay time.

Returns

None.

4.5.5.13 LeSendSubMessageUnlock()

```
void LeSendSubMessageUnlock (
    TASK task,
    MESSAGEID id,
    MSGSUBID subId,
    MESSAGE msg,
    MSGLOCK lock )
```

Send sub message until lock is 0.

Parameters

task	the task of recvice message.
id	message id.
sub⊷ Id	sub message id.
msg	message.
lock	lock number.

Returns

None.

4.6 BLE SMP APIs 85

4.6 BLE SMP APIS

Data Structures

- struct LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T
- struct LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T
- struct LE SMP MSG OOB DATA REQUEST IND T
- struct LE_SMP_MSG_PAIRING_ACTION_IND_T
- struct LE_SMP_MSG_PAIRING_COMPLETE_IND_T
- struct LE SMP MSG PASSKEY DISPLAY IND T
- struct LE_SMP_MSG_PASSKEY_INPUT_IND_T
- struct LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T
- struct LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T
- struct LE_SMP_MSG_USER_CONFIRM_IND_T
- struct LE_SMP_SC_OOB_DATA_T

Macros

- #define LE MAX BOND COUNT 8
- #define LE_SM_IO_CAP_DISP_ONLY 0x00
- #define LE_SM_IO_CAP_DISP_YES_NO 0x01
- #define LE_SM_IO_CAP_KEYBOARD_DISP 0x04
- #define LE_SM_IO_CAP_KEYBOARD_ONLY 0x02
- #define LE SM IO CAP NO IO 0x03
- #define LE_SM_PAIR_MITM_NO 0x00
- #define LE_SM_PAIR_MITM_YES 0x01
- #define LE SM PAIR OOB NO 0x00
- #define LE_SM_PAIR_OOB_YES 0x01
- #define LE SM PAIR SC NO 0x00
- #define LE_SM_PAIR_SC_YES 0x01

Enumerations

```
    enum {
        LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND = LE_SMP_MSG_BASE, LE_SMP_MSG_PAIRING_ACTION_IND,
        LE_SMP_MSG_PASSKEY_DISPLAY_IND, LE_SMP_MSG_PASSKEY_INPUT_IND,
        LE_SMP_MSG_OOB_DATA_REQUEST_IND, LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND, LE_SMP_MSG_USER_CC_LE_SMP_MSG_ENCRYPTION_CHANGE_IND,
        LE_SMP_MSG_ENCRYPTION_REFRESH_IND, LE_SMP_MSG_PAIRING_COMPLETE_IND, LE_SMP_LONG_TERM_KEY_LE_SMP_KEYS_IND,
        LE_SMP_MSG_TOP }
```

BLE SMP message id.

enum {
 LE_SMP_PAIR_JUST_WORK, LE_SMP_PAIR_OOB, LE_SMP_PAIR_PASSKEY_INPUT, LE_SMP_PAIR_DISPLAY,
 LE_SMP_PAIR_NUM_COMPARE }

Functions

void LeSmpInit (TASK appTask)

BLE SMP Module Init.

• void LeSmpOobAuthDataRsp (UINT16 conn_hdl, UINT8 *data, UINT16 len)

SMP OOB authenticate data response.

• UINT16 LeSmpOobPresent (UINT16 conn_hdl, BOOL oob_present)

SMP OOB present.

void LeSmpPasskeyInput (UINT16 conn_hdl, UINT32 passkey)

Input passkey.

• UINT16 LeSmpScOobComputeConfirmVal (UINT8 *rand, UINT8 *confirm)

SMP secure connection OOB compute confirm value.

- void LeSmpScOobDataRsp (UINT16 conn_hdl, UINT8 *our_rand, LE_SMP_SC_OOB_DATA_T *peer)

 OOB data response.
- UINT16 LeSmpSecurityReq (UINT16 conn_hdl)

BLE SMP security request.

UINT16 LeSmpSecurityRsp (UINT16 conn_hdl, BOOL accept)

BLE SMP security request.

• UINT16 LeSmpSetDefaultConfig (UINT8 iocap, BOOL mitm, BOOL sc, BOOL bond)

Set default configure for pairing.

• UINT16 LeSmpUserConfirmRsp (UINT16 conn_hdl, BOOL accept)

User confirm response.

4.6.1 Detailed Description

4.6.2 Macro Definition Documentation

```
4.6.2.1 LE_MAX_BOND_COUNT
```

#define LE_MAX_BOND_COUNT 8

4.6.2.2 LE_SM_IO_CAP_DISP_ONLY

 $\texttt{\#define LE_SM_IO_CAP_DISP_ONLY 0x00}$

display only

4.6.2.3 LE_SM_IO_CAP_DISP_YES_NO

#define LE_SM_IO_CAP_DISP_YES_NO 0x01

display + yes or no

4.6 BLE SMP APIs 87

4.6.2.4 LE_SM_IO_CAP_KEYBOARD_DISP

#define LE_SM_IO_CAP_KEYBOARD_DISP 0x04

display + keyboard

4.6.2.5 LE_SM_IO_CAP_KEYBOARD_ONLY

#define LE_SM_IO_CAP_KEYBOARD_ONLY 0x02

keyboard only

4.6.2.6 LE_SM_IO_CAP_NO_IO

#define LE_SM_IO_CAP_NO_IO 0x03

no input and output

4.6.2.7 LE_SM_PAIR_MITM_NO

#define LE_SM_PAIR_MITM_NO 0x00

4.6.2.8 LE_SM_PAIR_MITM_YES

#define LE_SM_PAIR_MITM_YES 0x01

4.6.2.9 LE_SM_PAIR_OOB_NO

#define LE_SM_PAIR_OOB_NO 0x00

4.6.2.10 LE_SM_PAIR_OOB_YES

#define LE_SM_PAIR_OOB_YES 0x01

4.6.2.11 LE_SM_PAIR_SC_NO

#define LE_SM_PAIR_SC_NO 0x00

4.6.2.12 LE_SM_PAIR_SC_YES

#define LE_SM_PAIR_SC_YES 0x01

4.6.3 Enumeration Type Documentation

4.6.3.1 anonymous enum

anonymous enum

BLE SMP message id.

Enumerator

LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND	slave security request
LE_SMP_MSG_PAIRING_ACTION_IND	pairing action indication
LE_SMP_MSG_PASSKEY_DISPLAY_IND	passkey display indication
LE_SMP_MSG_PASSKEY_INPUT_IND	passkey input indication
LE_SMP_MSG_OOB_DATA_REQUEST_IND	OOB date request indication
LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND	SC OOB data request indication
LE_SMP_MSG_USER_CONFIRM_IND	user confirm indication
LE_SMP_MSG_ENCRYPTION_CHANGE_IND	encryption change indication
LE_SMP_MSG_ENCRYPTION_REFRESH_IND	encryption refresh indication
LE_SMP_MSG_PAIRING_COMPLETE_IND	pairing complete indication
LE_SMP_LONG_TERM_KEY_REQ	long term key request
LE_SMP_KEYS_IND	keys indication
LE_SMP_MSG_TOP	top of SMP message id

4.6.3.2 anonymous enum

anonymous enum

Enumerator

LE_SMP_PAIR_JUST_WORK	just work
LE_SMP_PAIR_OOB	out of band
LE_SMP_PAIR_PASSKEY_INPUT	passkey entry
LE_SMP_PAIR_DISPLAY display	
LE_SMP_PAIR_NUM_COMPARE	number compare

4.6 BLE SMP APIs 89

4.6.4 Function Documentation

4.6.4.1 LeSmpInit()

BLE SMP Module Init.

Parameters

appTask	the reference of BLE task.
---------	----------------------------

Returns

None.

4.6.4.2 LeSmpOobAuthDataRsp()

SMP OOB authenticate data response.

Parameters

conn_hdl	connection handle.
data	response data.
len	data length.

Returns

None.

4.6.4.3 LeSmpOobPresent()

SMP OOB present.

Parameters

conn_hdl	connection handle.
oob_present	present or not.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.6.4.4 LeSmpPasskeyInput()

Input passkey.

Parameters

conn_hdl	connection handle.
passkey	passkey.

Returns

None.

4.6.4.5 LeSmpScOobComputeConfirmVal()

SMP secure connection OOB compute confirm value.

Parameters

rand	random data.
confirm	confirm data.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.6 BLE SMP APIs 91

4.6.4.6 LeSmpScOobDataRsp()

OOB data response.

Parameters

conn_hdl	connection handld.
our_rand	our random data.
peer	peer OOB data.

Returns

None.

4.6.4.7 LeSmpSecurityReq()

BLE SMP security request.

Parameters

```
conn_hdl connection handle.
```

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.6.4.8 LeSmpSecurityRsp()

BLE SMP security request.

Parameters

conn_hdl	connection handle.
accept	TRUE is accept, FALSE is not.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.6.4.9 LeSmpSetDefaultConfig()

Set default configure for pairing.

Parameters

iocap	IO capability.	
mitm	TRUE is MITM protected, FALSE is not.	
sc	TRUE is request BLE secure connection pairing, FALSE is not.	
bond	TRUE: bonding, FALSE: no bonding.	

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.6.4.10 LeSmpUserConfirmRsp()

User confirm response.

Parameters

conn_hdl	connection handle.
accept	yes or no.

Returns

0 is Ok, others refer to SMP_ERR_* in ble_err.h.

4.7 WIFI APIS 93

4.7 WIFI APIs

WIFI APIs.

Modules

- · WIFI Common APIs
- WIFI STA APIs
- Enumeration

Data Structures

· struct wifi_active_scan_time_t

Range of active scan times per channel.

· struct wifi_ap_config_t

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

· struct wifi_auto_connect_info_t

This structure is the Wi-Fi auto connect for save in the flash (FIM).

· union wifi_config_t

Wi-Fi configuration for initialization.

· struct wifi_fast_scan_threshold_t

Structure describing parameters for a Wi-Fi fast scan.

· struct wifi_init_config_t

WiFi stack configuration parameters.

struct wifi_scan_config_t

Parameters for an SSID scan.

· struct wifi_scan_info_t

This structure defines the inforamtion of scanned APs.

struct wifi_scan_list_t

This structure defines the list of scanned APs with their corresponding information.

· union wifi scan time t

Aggregate of active & passive scan time per channel.

struct wifi_sta_config_t

This structure is the Wi-Fi configuration for initialization for STA mode.

· struct wifi_wpa_ie_data_t

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

Macros

#define WIFI_BEACON_INTERVAL_LENGTH (2)

Beacon interval length in a frame header.

• #define WIFI CAPABILITY INFO LENGTH (2)

Length of capability information in a frame header.

• #define WIFI LENGTH 802 11 (24)

Length of 802.11 MAC header.

#define WIFI LENGTH PASSPHRASE (64)

The maximum length of passphrase used in WPA-PSK and WPA2-PSK encryption types.

#define WIFI_MAC_ADDRESS_LENGTH (6)

MAC address length.

#define WIFI_MAX_LENGTH_OF_SSID (32+1)

The maximum length of SSID.

• #define WIFI_MAX_SCAN_AP_NUM (16)

maximum number of ap list items which can stored

• #define WIFI MAX SUPPORTED RATES (8)

maximum number of supported data rate

Typedefs

- · typedef wifi scan info t wifi ap record t
- typedef int(* wifi_event_notify_cb_t) (void *data)

Enumerations

• enum wifi_auto_connet_mode_e { WIFI_AUTO_CONNECT_ENABLE, WIFI_AUTO_CONNECT_DISABLE } WiFi auto connect mode parameters.

Functions

- int wifi_event_process_handler (wifi_event_t event, uint8_t *payload, uint32_t length)
 - Default event handler for system events.

void wifi_install_default_event_handlers (void)

instaall default event handler for wifi event (internal use)

int wifi_register_event_handler (wifi_event_t idx, wifi_event_handler_t handler)
 register wifi event handlert (internal use)

4.7.1 Detailed Description

WIFI APIs.

4.7.2 Macro Definition Documentation

4.7.2.1 WIFI_BEACON_INTERVAL_LENGTH

#define WIFI_BEACON_INTERVAL_LENGTH (2)

Beacon interval length in a frame header.

4.7 WIFI APIS 95

4.7.2.2 WIFI_CAPABILITY_INFO_LENGTH

```
#define WIFI_CAPABILITY_INFO_LENGTH (2)
```

Length of capability information in a frame header.

4.7.2.3 WIFI_LENGTH_802_11

```
#define WIFI_LENGTH_802_11 (24)
```

Length of 802.11 MAC header.

4.7.2.4 WIFI_LENGTH_PASSPHRASE

```
#define WIFI_LENGTH_PASSPHRASE (64)
```

The maximum length of passphrase used in WPA-PSK and WPA2-PSK encryption types.

4.7.2.5 WIFI_MAC_ADDRESS_LENGTH

```
#define WIFI_MAC_ADDRESS_LENGTH (6)
```

MAC address length.

4.7.2.6 WIFI_MAX_LENGTH_OF_SSID

```
#define WIFI_MAX_LENGTH_OF_SSID (32+1)
```

The maximum length of SSID.

4.7.2.7 WIFI_MAX_SCAN_AP_NUM

```
#define WIFI_MAX_SCAN_AP_NUM (16)
```

maximum number of ap list items which can stored

4.7.2.8 WIFI_MAX_SUPPORTED_RATES

```
#define WIFI_MAX_SUPPORTED_RATES (8)
```

maximum number of supported data rate

4.7.3 Typedef Documentation

```
4.7.3.1 wifi_ap_record_t
```

```
typedef wifi_scan_info_t wifi_ap_record_t
```

4.7.3.2 wifi_event_notify_cb_t

```
typedef int(* wifi_event_notify_cb_t) (void *data)
```

4.7.4 Enumeration Type Documentation

4.7.4.1 wifi_auto_connet_mode_e

```
enum wifi_auto_connet_mode_e
```

WiFi auto connect mode parameters.

Enumerator

```
WIFI_AUTO_CONNECT_ENABLE
WIFI_AUTO_CONNECT_DISABLE
```

4.7.5 Function Documentation

4.7.5.1 wifi_event_process_handler()

4.7 WIFI APIs 97

```
uint8_t * payload,
uint32_t length )
```

Default event handler for system events.

This function performs default handling of system events. When using event_loop APIs, it is called automatically before invoking the user-provided callback function.

Applications which implement a custom event loop must call this function as part of event processing.

Parameters

in	event	event type Set the event type,Options are
		WIFI_EVENT_INIT_COMPLETE
		WIFI_EVENT_SCAN_COMPLETE
		WIFI_EVENT_STA_START
		WIFI_EVENT_STA_STOP
		WIFI_EVENT_STA_CONNECTED
		WIFI_EVENT_STA_DISCONNECTED
		WIFI_EVENT_STA_CONNECTION_FAILED
		WIFI_EVENT_STA_GOT_IP
in	payload	Data block that transmitted to event
in	length	The length of data block

Returns

0 : success other : failed

4.7.5.2 wifi_install_default_event_handlers()

instaall default event handler for wifi event (internal use)

4.7.5.3 wifi_register_event_handler()

register wifi event handelrt (internal use)

Parameters

in	idx	one of the enums of
		bt_scan_mode_t
in	handler	the Wi-Fi event handler

Returns

0 : success other : failed

4.8 WIFI Common APIs 99

4.8 WIFI Common APIs

Data Structures

```
    struct event_msg_t
        Send information to event by event_msg_t.
    union wifi_event_info_t
        wifi_event_info_t
    struct wifi_event_sta_connected_t
        wifi_event_sta_connected_t
    struct wifi_event_sta_disconnected_t
        wifi_event_sta_disconnected_t
    struct wifi_event_sta_got_ip_t
    struct wifi_event_sta_scan_done_t
```

wifi_event_sta_scan_done_t

Typedefs

typedef int(* wifi_event_cb_t) (wifi_event_id_t event, void *data, uint16_t length)
 Application specified event callback function.

Functions

• int wifi_event_loop_init (wifi_event_cb_t cb)

Event Loop Initialization Create the event handler and call back funtion.

int wifi_event_loop_send (event_msg_t *msg)

Send an event to event task.

void wifi_event_loop_set_cb (wifi_event_cb_t cb, void *ctx)

Set application specified event callback function.

• int wifi_event_process_handler (wifi_event_t event, uint8_t *payload, uint32_t length)

Default event handler for system events.

4.8.1 Detailed Description

4.8.2 Typedef Documentation

```
4.8.2.1 wifi_event_cb_t

typedef int(* wifi_event_cb_t) (wifi_event_id_t event, void *data, uint16_t length)
Application specified event callback function.
```

4.8.3 Function Documentation

Event Loop Initialization Create the event handler and call back funtion.

Parameters

cb : application specified event callback

Returns

0 : success other : failed

4.8.3.2 wifi_event_loop_send()

Send an event to event task.

Attention

1. Other task/modules, such as the TCPIP module, can call this API to send an event to event task

Parameters

```
event_msg_t | * msg: Send information to event by msg
```

Returns

0 : success other : failed

4.8.3.3 wifi_event_loop_set_cb()

Set application specified event callback function.

Attention

1. If cb is NULL, means application does not need to handle If cb is not NULL, it will be called when an event is received and after the default event callback is completed

4.8 WIFI Common APIs 101

Parameters

wifi_event_←	cb : callback
cb_t	
void	*ctx : reserved for user

4.8.3.4 wifi_event_process_handler()

Default event handler for system events.

This function performs default handling of system events.

Applications which implement a custom event loop must call this function as part of event processing.

Parameters

in	event	event type Set the event type,Options are	
		WIFI_EVENT_INIT_COMPLETE	
		WIFI_EVENT_SCAN_COMPLETE	
		WIFI_EVENT_STA_START	
	WIFI_EVENT_STA_STOP		
		WIFI_EVENT_STA_CONNECTED	
		WIFI_EVENT_STA_DISCONNECTED	
		WIFI_EVENT_STA_CONNECTION_FAILED	
		WIFI_EVENT_STA_GOT_IP	
		Data blank to a constitue data account	
in	payload	Data block transmitted to event	
in	length	The length of the data block	

Returns

0 : success other : failed

4.9 WIFI STA APIS

Macros

• #define WIFI READY TIME 2000

Typedefs

- typedef int(* wifi auto connect clear ap info fp t) (uint8 t index)
- typedef int(* wifi_auto_connect_get_ap_info_fp_t) (uint8_t index, wifi_auto_connect_info_t *info)
- typedef int(* wifi_auto_connect_get_ap_num_fp_t) (uint8_t *num)
- typedef int(* wifi_auto_connect_get_mode_fp_t) (uint8_t *mode)
- typedef int(* wifi_auto_connect_init_fp_t) (void)
- typedef int(* wifi_auto_connect_reset_fp_t) (void)
- typedef int(* wifi_auto_connect_set_ap_num_fp_t) (uint8_t num)
- typedef int(* wifi_auto_connect_set_mode_fp_t) (uint8_t mode)
- typedef int(* wifi auto connect start fp t) (void)
- typedef int(* wifi config get bandwidth fp t) (wifi mode t interface, wifi bandwidth t *bandwidth)
- typedef int(* wifi_config_get_bssid_fp_t) (uint8_t *bssid)
- typedef int(* wifi_config_get_channel_fp_t) (wifi_mode_t interface, uint8_t *channel)
- typedef int(* wifi_config_get_dtim_interval_fp_t) (uint8_t *interval)
- typedef int(* wifi_config_get_listen_interval_fp_t) (uint8_t *interval)
- typedef int(* wifi config get mac address fp t) (wifi mode t interface, uint8 t *address)
- typedef int(* wifi_config_get_opmode_fp_t) (uint8_t *mode)
- typedef int(* wifi_config_get_ssid_fp_t) (uint8_t *ssid, uint8_t *ssid_length)
- typedef int(* wifi_config_set_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t bandwidth)
- typedef int(* wifi_config_set_bssid_fp_t) (uint8_t *bssid)
- typedef int(* wifi config set channel fp t) (wifi mode t interface, uint8 t channel)
- typedef int(* wifi_config_set_dtim_interval_fp_t) (uint8_t interval)
- typedef int(* wifi config set listen interval fp t) (uint8 t interval)
- typedef int(* wifi_config_set_mac_address_fp_t) (wifi_mode_t interface, uint8_t *address)
- typedef int(* wifi_config_set_opmode_fp_t) (uint8_t mode)
- typedef int(* wifi config set ssid fp t) (wifi mode t interface, uint8 t *ssid, uint8 t ssid length)
- typedef int(* wifi_connection_connect_fp_t) (wifi_config_t *config)
- typedef int(* wifi_connection_disconnect_ap_fp_t) (void)
- typedef int(* wifi_connection_disconnect_sta_fp_t) (uint8_t *address)
- typedef int(* wifi_connection_get_rssi_fp_t) (int8_t *rssi)
- typedef int(* wifi_connection_register_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler)
- typedef int(* wifi_connection_scan_start_fp_t) (uint8_t *ssid, uint8_t ssid_length, uint8_t *bssid, uint8_←
 t scan mode, uint8 t scan option)
- typedef int(* wifi_connection_unregister_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler)
- typedef int(* wifi_convert_auth_mode_fp_t) (int wpa_pro, int privacy)
- typedef int(* wifi deinit fp t) (void)
- typedef int32_t(* wifi_event_handler_t) (wifi_event_t event, uint8_t *payload, uint32_t length)

This defines the Wi-Fi event handler. Call wifi_connection_register_event_handler() to register a handler, then the Wi-Fi driver generates an event and sends it to the handler.

- typedef int(* wifi_fast_connect_get_mode_fp_t) (uint8_t ap_index, uint8_t *mode)
- typedef int(* wifi_fast_connect_set_mode_fp_t) (uint8_t ap_index, uint8_t mode)
- typedef int(* wifi_fast_connect_start_fp_t) (uint8_t ap_index)
- typedef int(* wifi_get_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)
- typedef void(* wifi_init_complete_cb_t) (void *ctx)

Initialization of complete callback function.

```
typedef int(* wifi_init_fp_t) (const wifi_init_config_t *config, wifi_init_complete_cb_t init_cb)
typedef int32_t wifi_result_t
typedef int(* wifi_scan_get_ap_list_fp_t) (wifi_scan_list_t *scan_list)
typedef int(* wifi_scan_get_ap_num_fp_t) (uint16_t *number)
typedef int(* wifi_scan_get_ap_records_fp_t) (uint16_t *number, wifi_scan_info_t *ap_records)
```

- typedef int(* wifi_scan_start_fp_t) (const wifi_scan_config_t *config, bool block)
- typedef int(* wifi_scan_stop_fp_t) (void)
- typedef int(* wifi_set_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)
- typedef int(* wifi_sta_get_ap_info_fp_t) (wifi_ap_record_t *ap_info)
- typedef int(* wifi start fp t) (void)
- typedef int(* wifi_stop_fp_t) (void)

Functions

int wifi_auto_connect_clear_ap_info (uint8_t index)

Clear the AP information which index in the.

int wifi_auto_connect_get_ap_info (uint8_t index, wifi_auto_connect_info_t *info)

Get the AP information.

int wifi_auto_connect_get_ap_num (uint8_t *num)

Get the number of AP information.

int wifi auto connect get mode (uint8 t *mode)

Get the auto connect mode.

· int wifi auto connect init (void)

Initialize function of auto connect.

int wifi_auto_connect_reset (void)

Reset all of auto/fast connect configuration.

int wifi_auto_connect_set_ap_num (uint8_t num)

Set the number of AP information.

int wifi_auto_connect_set_mode (uint8_t mode)

Set the auto connect mode.

int wifi_auto_connect_start (void)

Start auto connect mechanism.

int wifi_config_get_bandwidth (wifi_mode_t interface, wifi_bandwidth_t *bandwidth)

Get the bandwidth of OPL1000 specified interface.

• int wifi_config_get_bssid (uint8_t *bssid)

get bssid after scan

int wifi_config_get_channel (wifi_mode_t interface, uint8_t *channel)

Get the primary/secondary channel of OPL1000.

- int wifi config get dtim interval (uint8 t *interval)
- int wifi_config_get_listen_interval (uint8_t *interval)
- int wifi_config_get_mac_address (wifi_mode_t interface, uint8_t *address)

Get mac of specified interface.

- int wifi_config_get_opmode (uint8_t *mode)
- int wifi_config_get_skip_dtim (uint8_t *value)

Get the Skip DTIM value in current wifi setting of OPL1000.

int wifi_config_get_ssid (uint8_t *ssid, uint8_t *ssid_length)

Get ssid value of AP.

int wifi config set bandwidth (wifi mode t interface, wifi bandwidth t bandwidth)

Set the bandwidth of OPL1000 specified interface.

• int wifi config set bssid (uint8 t *bssid)

config OPL1000 Wi-Fi bssid.

```
• int wifi_config_set_channel (wifi_mode_t interface, uint8_t channel)
      Set primary/secondary channel of OPL1000.

    int wifi config set dtim interval (uint8 t interval)

• int wifi config set listen interval (uint8 t interval)

    int wifi config set mac address (wifi mode t interface, uint8 t *address)

      Set MAC address of OPL1000 Wi-Fi station or the soft-AP interface.
• int wifi config set opmode (uint8 t mode)
int wifi_config_set_skip_dtim (uint8_t value)
      Set the Skip DTIM value of OPL1000.

    int wifi_config_set_ssid (wifi_mode_t interface, uint8_t *ssid, uint8_t ssid_length)

      Set the ssid value of the current device.

    int wifi_connection_connect (wifi_config_t *config)

      Connect OPL1000 Wi-Fi station to certain AP.
• int wifi_connection_connect_from_ac_index (uint8_t index)
      Connect OPL1000 Wi-Fi station to certain AP by auto connect index.

    int wifi_connection_connect_from_ac_list (wifi_config_t *config)

      Connect OPL1000 Wi-Fi station to certain AP in auto connect list.

    int wifi_connection_disconnect_ap (void)

      Disconnect the link between OPL1000 and connected AP.

    int wifi connection disconnect sta (uint8 t *address)

      Disconnect the link between the current device and the station.

    int wifi connection get rssi (int8 t *rssi)

      get signal strength of AP
· int wifi connection register event handler (wifi event t event, wifi event handler t handler)
      register wifi call back handler

    int wifi connection scan start (uint8 t *ssid, uint8 t ssid length, uint8 t *bssid, uint8 t scan mode, uint8 ←

  t scan option)
• int wifi_connection_unregister_event_handler (wifi_event_t event, wifi_event_handler_t handler)
     unregister wifi call back handler

    int wifi_convert_auth_mode (int wpa_pro, int privacy)

• int wifi deinit (void)
      De-init Wi-Fi Initialization and Configuration functions.

    int wifi_fast_connect_get_mode (uint8_t ap_index, uint8_t *mode)

      Get the fast connect mode.
• int wifi fast connect set mode (uint8 t ap index, uint8 t mode)
      Set the fast connect mode.

    int wifi_fast_connect_start (uint8_t ap_index)

      Start fast connect mechanism.

    int wifi get config (wifi mode t interface, wifi config t *conf)

      Get configuration of specified interface.
• int wifi init (const wifi init config t *config, wifi init complete cb t init cb)
      Init Wi-Fi Initializes the wifi according to the specified parameters in the config.

    int wifi scan get ap list (wifi scan list t *scan list)

      Get list of APs that found in last scan operation.

    int wifi scan get ap num (uint16 t *number)

      Get the number of scanned APs.

    int wifi_scan_get_ap_records (uint16_t *number, wifi_scan_info_t *ap_records)

      Get AP list found in last scan operation.
· int wifi scan scan stop (void)
      Stop scanning process.

    int wifi_scan_start (const wifi_scan_config_t *config, bool block)
```

Scan all available APs. After invoke the wifi_set_config() and wifi_start(), then call wifi_scan_start() to scan APs.

int wifi_set_config (wifi_mode_t interface, wifi_config_t *conf)

Set configuration of OPL1000 STA.

int wifi_sta_get_ap_info (wifi_ap_record_t *ap_info)

Get information of AP which OPL1000 station is associated with.

· int wifi start (void)

Start Wi-Fi working.

• int wifi_stop (void)

Stop wifi working.

Variables

- wifi_auto_connect_clear_ap_info_fp_t wifi_auto_connect_clear_ap_info_api
- · wifi auto connect get ap info fp t wifi auto connect get ap info api
- wifi_auto_connect_get_ap_num_fp_t wifi_auto_connect_get_ap_num_api
- wifi_auto_connect_get_mode_fp_t wifi_auto_connect_get_mode_api
- · wifi_auto_connect_init_fp_t wifi_auto_connect_init_api
- wifi_auto_connect_reset_fp_t wifi_auto_connect_reset_api
- · wifi auto connect set ap num fp t wifi auto connect set ap num api
- wifi_auto_connect_set_mode_fp_t wifi_auto_connect_set_mode_api
- · wifi auto connect start fp t wifi auto connect start api
- wifi_config_get_bandwidth_fp_t wifi_config_get_bandwidth_api
- · wifi config get bssid fp t wifi config get bssid api
- wifi_config_get_channel_fp_t wifi_config_get_channel_api
- wifi_config_get_dtim_interval_fp_t wifi_config_get_dtim_interval_api
- wifi_config_get_listen_interval_fp_t wifi_config_get_listen_interval_api
- wifi_config_get_mac_address_fp_t wifi_config_get_mac_address_api
- wifi_config_get_opmode_fp_t wifi_config_get_opmode_api
- wifi_config_get_ssid_fp_t wifi_config_get_ssid_api
- wifi_config_set_bandwidth_fp_t wifi_config_set_bandwidth_api
- wifi_config_set_bssid_fp_t wifi_config_set_bssid_api
- · wifi config set channel fp t wifi config set channel api
- · wifi config set dtim interval fp t wifi config set dtim interval api
- wifi_config_set_listen_interval_fp_t wifi_config_set_listen_interval_api
- wifi_config_set_mac_address_fp_t wifi_config_set_mac_address_api
- wifi_config_set_opmode_fp_t wifi_config_set_opmode_api
- wifi_config_set_ssid_fp_t wifi_config_set_ssid_api
- wifi_connection_connect_fp_t wifi_connection_connect_api
- wifi_connection_disconnect_ap_fp_t wifi_connection_disconnect_ap_api
- wifi_connection_disconnect_sta_fp_t wifi_connection_disconnect_sta_api
- wifi_connection_get_rssi_fp_t wifi_connection_get_rssi_api
- wifi_connection_register_event_handler_fp_t wifi_connection_register_event_handler_api
- wifi_connection_scan_start_fp_t wifi_connection_scan_start_api
- wifi_connection_unregister_event_handler_fp_t wifi_connection_unregister_event_handler_api
- · wifi convert auth mode fp t wifi convert auth mode api
- · wifi deinit fp t wifi deinit api
- wifi_fast_connect_get_mode_fp_t wifi_fast_connect_get_mode_api
- wifi_fast_connect_set_mode_fp_t wifi_fast_connect_set_mode_api
- wifi_fast_connect_start_fp_t wifi_fast_connect_start_api
- wifi_get_config_fp_t wifi_get_config_api
- wifi_init_fp_t wifi_init_api
- wifi_scan_get_ap_list_fp_t wifi_scan_get_ap_list_api
- wifi_scan_get_ap_num_fp_t wifi_scan_get_ap_num_api

```
• wifi_scan_get_ap_records_fp_t wifi_scan_get_ap_records_api
```

- wifi_scan_start_fp_t wifi_scan_start_api
- wifi_scan_stop_fp_t wifi_scan_stop_api
- wifi_set_config_fp_t wifi_set_config_api
- wifi_sta_get_ap_info_fp_t wifi_sta_get_ap_info_api
- wifi_start_fp_t wifi_start_api
- wifi_stop_fp_t wifi_stop_api

4.9.1 Detailed Description

4.9.2 Macro Definition Documentation

4.9.2.1 WIFI_READY_TIME

```
#define WIFI_READY_TIME 2000
```

4.9.3 Typedef Documentation

4.9.3.1 wifi_auto_connect_clear_ap_info_fp_t

```
typedef int(* wifi_auto_connect_clear_ap_info_fp_t) (uint8_t index)
```

4.9.3.2 wifi_auto_connect_get_ap_info_fp_t

```
typedef int(* wifi_auto_connect_get_ap_info_fp_t) (uint8_t index, wifi_auto_connect_info_t
*info)
```

4.9.3.3 wifi_auto_connect_get_ap_num_fp_t

```
typedef int(* wifi_auto_connect_get_ap_num_fp_t) (uint8_t *num)
```

4.9.3.4 wifi_auto_connect_get_mode_fp_t

```
typedef int(* wifi_auto_connect_get_mode_fp_t) (uint8_t *mode)
```

```
4.9.3.5 wifi_auto_connect_init_fp_t
typedef int(* wifi_auto_connect_init_fp_t) (void)
4.9.3.6 wifi_auto_connect_reset_fp_t
typedef int(* wifi_auto_connect_reset_fp_t) (void)
4.9.3.7 wifi_auto_connect_set_ap_num_fp_t
typedef int(* wifi_auto_connect_set_ap_num_fp_t) (uint8_t num)
4.9.3.8 wifi_auto_connect_set_mode_fp_t
typedef int(* wifi_auto_connect_set_mode_fp_t) (uint8_t mode)
4.9.3.9 wifi_auto_connect_start_fp_t
typedef int(* wifi_auto_connect_start_fp_t) (void)
4.9.3.10 wifi_config_get_bandwidth_fp_t
typedef int(* wifi_config_get_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t *bandwidth)
4.9.3.11 wifi_config_get_bssid_fp_t
typedef int(* wifi_config_get_bssid_fp_t) (uint8_t *bssid)
4.9.3.12 wifi_config_get_channel_fp_t
typedef int(* wifi_config_get_channel_fp_t) (wifi_mode_t interface, uint8_t *channel)
```

```
4.9.3.13 wifi_config_get_dtim_interval_fp_t
typedef int(* wifi_config_get_dtim_interval_fp_t) (uint8_t *interval)
4.9.3.14 wifi_config_get_listen_interval_fp_t
typedef int(* wifi_config_get_listen_interval_fp_t) (uint8_t *interval)
4.9.3.15 wifi_config_get_mac_address_fp_t
{\tt typedef\ int} \ (*\ wifi\_config\_get\_mac\_address\_fp\_t) \ \ (wifi\_mode\_t\ interface,\ uint8\_t\ *address)
4.9.3.16 wifi_config_get_opmode_fp_t
typedef int(* wifi_config_get_opmode_fp_t) (uint8_t *mode)
4.9.3.17 wifi_config_get_ssid_fp_t
typedef int(* wifi_config_get_ssid_fp_t) (uint8_t *ssid, uint8_t *ssid_length)
4.9.3.18 wifi config set bandwidth fp t
typedef int(* wifi_config_set_bandwidth_fp_t) (wifi_mode_t interface, wifi_bandwidth_t bandwidth)
4.9.3.19 wifi_config_set_bssid_fp_t
typedef int(* wifi_config_set_bssid_fp_t) (uint8_t *bssid)
4.9.3.20 wifi_config_set_channel_fp_t
typedef int(* wifi_config_set_channel_fp_t) (wifi_mode_t interface, uint8_t channel)
```

```
4.9.3.21 wifi_config_set_dtim_interval_fp_t
typedef int(* wifi_config_set_dtim_interval_fp_t) (uint8_t interval)
4.9.3.22 wifi_config_set_listen_interval_fp_t
typedef int(* wifi_config_set_listen_interval_fp_t) (uint8_t interval)
4.9.3.23 wifi_config_set_mac_address_fp_t
typedef int(* wifi_config_set_mac_address_fp_t) (wifi_mode_t interface, uint8_t *address)
4.9.3.24 wifi_config_set_opmode_fp_t
typedef int(* wifi_config_set_opmode_fp_t) (uint8_t mode)
4.9.3.25 wifi_config_set_ssid_fp_t
\texttt{typedef int} (* \ \texttt{wifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{wifi\_mode\_t interface}, \ \texttt{uint8\_t} \ *\texttt{ssid}, \ \texttt{uint8\_t} \ \texttt{ssid\_} \longleftrightarrow \texttt{typedef int} (* \ \texttt{wifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{uint8\_t} \ *\texttt{ssid}, \ \texttt{uint8\_t} \ \texttt{ssid\_} \longleftrightarrow \texttt{typedef int} (* \ \texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{uint8\_t} \ *\texttt{ssid}, \ \texttt{uint8\_t} \ \texttt{ssid\_} \longleftrightarrow \texttt{typedef int} (* \ \texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{uint8\_t} \ *\texttt{ssid}, \ \texttt{uint8\_t} \ \texttt{ssid\_} \longleftrightarrow \texttt{typedef int} (* \ \texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{uint8\_t} \ *\texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_mode\_t interface}, \ \texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_config\_set\_ssid\_fp\_t}) \ (\texttt{vifi\_config\_set
length)
4.9.3.26 wifi_connection_connect_fp_t
typedef int(* wifi_connection_connect_fp_t) (wifi_config_t *config)
4.9.3.27 wifi_connection_disconnect_ap_fp_t
typedef int(* wifi_connection_disconnect_ap_fp_t) (void)
```

4.9.3.28 wifi_connection_disconnect_sta_fp_t typedef int(* wifi_connection_disconnect_sta_fp_t) (uint8_t *address) 4.9.3.29 wifi_connection_get_rssi_fp_t typedef int(* wifi_connection_get_rssi_fp_t) (int8_t *rssi) 4.9.3.30 wifi_connection_register_event_handler_fp_t typedef int(* wifi_connection_register_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler) 4.9.3.31 wifi_connection_scan_start_fp_t typedef int(* wifi_connection_scan_start_fp_t) (uint8_t *ssid, uint8_t ssid_length, uint8_↔ t *bssid, uint8_t scan_mode, uint8_t scan_option) 4.9.3.32 wifi_connection_unregister_event_handler_fp_t typedef int (* wifi_connection_unregister_event_handler_fp_t) (wifi_event_t event, wifi_event_handler_t handler) 4.9.3.33 wifi_convert_auth_mode_fp_t typedef int(* wifi_convert_auth_mode_fp_t) (int wpa_pro, int privacy) 4.9.3.34 wifi_deinit_fp_t typedef int(* wifi_deinit_fp_t) (void) 4.9.3.35 wifi event handler t typedef int32_t(* wifi_event_handler_t) (wifi_event_t event, uint8_t *payload, uint32_t length) This defines the Wi-Fi event handler. Call wifi_connection_register_event_handler() to register a handler, then the

Wi-Fi driver generates an event and sends it to the handler.

Parameters

in	event	is an optional event to register. For more details, please refer to wifi_event_t.
in	payload	is the payload for the event. When the event is WIFI_EVENT_IOT_CONNECTED in AP mode, payload is the connected STA's MAC address. When the event is WIFI_EVENT_IOT_CONNECTED in STA mode, payload is the connected AP's BSSID.
in	length	is the length of a packet.

Returns

The return value is reserved and it is ignored.

4.9.3.36 wifi_fast_connect_get_mode_fp_t

```
typedef int(* wifi_fast_connect_get_mode_fp_t) (uint8_t ap_index, uint8_t *mode)
```

4.9.3.37 wifi_fast_connect_set_mode_fp_t

```
typedef int(* wifi_fast_connect_set_mode_fp_t) (uint8_t ap_index, uint8_t mode)
```

4.9.3.38 wifi_fast_connect_start_fp_t

```
typedef int(* wifi_fast_connect_start_fp_t) (uint8_t ap_index)
```

4.9.3.39 wifi_get_config_fp_t

```
typedef int(* wifi_get_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)
```

4.9.3.40 wifi_init_complete_cb_t

```
typedef void(* wifi_init_complete_cb_t) (void *ctx)
```

Initialization of complete callback function.

Invoked when Wi-Fi initialization is complete.

Parameters

ctx is context pointer that provided to wifi_init(). It will be passed back to the callback.

```
4.9.3.41 wifi_init_fp_t
typedef int(* wifi_init_fp_t) (const wifi_init_config_t *config, wifi_init_complete_cb_t init↔
_cb)
4.9.3.42 wifi_result_t
typedef int32_t wifi_result_t
4.9.3.43 wifi_scan_get_ap_list_fp_t
typedef int(* wifi_scan_get_ap_list_fp_t) (wifi_scan_list_t *scan_list)
4.9.3.44 wifi_scan_get_ap_num_fp_t
typedef int(* wifi_scan_get_ap_num_fp_t) (uint16_t *number)
4.9.3.45 wifi_scan_get_ap_records_fp_t
typedef int(* wifi_scan_get_ap_records_fp_t) (uint16_t *number, wifi_scan_info_t *ap_records)
4.9.3.46 wifi_scan_start_fp_t
typedef int(* wifi_scan_start_fp_t) (const wifi_scan_config_t *config, bool block)
```

```
4.9.3.47 wifi_scan_stop_fp_t
typedef int(* wifi_scan_stop_fp_t) (void)
4.9.3.48 wifi_set_config_fp_t
typedef int(* wifi_set_config_fp_t) (wifi_mode_t interface, wifi_config_t *conf)
4.9.3.49 wifi_sta_get_ap_info_fp_t
typedef int(* wifi_sta_get_ap_info_fp_t) (wifi_ap_record_t *ap_info)
4.9.3.50 wifi_start_fp_t
typedef int(* wifi_start_fp_t) (void)
4.9.3.51 wifi_stop_fp_t
typedef int(* wifi_stop_fp_t) (void)
4.9.4 Function Documentation
4.9.4.1 wifi_auto_connect_clear_ap_info()
int wifi_auto_connect_clear_ap_info (
             uint8_t index )
Clear the AP information which index in the.
```

Attention

1. API returns false if try to clear AP information which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2

Returns

0 : success other : failed

4.9.4.2 wifi_auto_connect_get_ap_info()

Get the AP information.

Attention

1. API returns false if try to get AP information which something error

Parameters

in	index The index of AP position	
		• Range is 0 to 2
out	mode	Get the AP information

Returns

0 : success other : failed

4.9.4.3 wifi_auto_connect_get_ap_num()

Get the number of AP information.

Attention

1. API returns false if try to get auto connect numbers which something error

Parameters

out mode Get the number of AP information

Returns

0 : success other : failed

4.9.4.4 wifi_auto_connect_get_mode()

```
int wifi_auto_connect_get_mode ( \label{eq:connect_get_mode} uint8\_t \, * \, mode \, )
```

Get the auto connect mode.

Attention

1. API returns false if try to get auto connect mode which something error

Parameters

out	mode	Get the auto connect mode
-----	------	---------------------------

Returns

0 : success other : failed

4.9.4.5 wifi_auto_connect_init()

Initialize function of auto connect.

Attention

1. API returns false if try to initial auto connect which something error

Returns

0 : success other : failed

4.9.4.6 wifi_auto_connect_reset()

Reset all of auto/fast connect configuration.

Attention

1. API returns false if try to reset auto connect configuration which something error

Returns

0 : success other : failed

4.9.4.7 wifi_auto_connect_set_ap_num()

Set the number of AP information.

Attention

1. API returns false if try to set auto connect numbers which something error

Parameters

in	num	The number of AP information will be saved in flash.	
		• Range is 1 to 3	

Returns

0 : success other : failed

4.9.4.8 wifi_auto_connect_set_mode()

Set the auto connect mode.

Attention

1. API returns false if try to set auto connect mode which something error

Parameters

in	mode	Configure the current wifi working mode, The options are
		WIFI_AUTO_CONNECT_ENABLE
		WIFI_AUTO_CONNECT_DISABLE

Returns

0 : success other : failed

4.9.4.9 wifi_auto_connect_start()

Start auto connect mechanism.

Attention

1. API returns false if try to start auto connect function which something error

Returns

0 : success other : failed

4.9.4.10 wifi_config_get_bandwidth()

Get the bandwidth of OPL1000 specified interface.

Attention

1. API returns false if try to get an interface which is not enable

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
out	bandwidth	Get the bandwidth value of the current wifi module working through the pointer

Returns

0 : success other : failed

4.9.4.11 wifi_config_get_bssid()

get bssid after scan

Parameters

out bs	sid the	string of bssid
---------------	---------	-----------------

Returns

0 : success other : failed

4.9.4.12 wifi_config_get_channel()

Get the primary/secondary channel of OPL1000.

Attention

1. API returns false if try to get an interface which is not enabled

Parameters

in	interface	Configure the current wifi working mode, The options are	
		WIFI_MODE_STA	
		WIFI_MODE_AP (currently not support)	
out	channel	Get Current module wifi work channel number	

Returns

0 : success other : failed

4.9.4.13 wifi_config_get_dtim_interval()

4.9.4.14 wifi_config_get_listen_interval()

4.9.4.15 wifi_config_get_mac_address()

Get mac of specified interface.

Parameters

in	interface	Configure the current wifi working mode, The options are	
		WIFI_MODE_STA	
		WIFI_MODE_AP (currently not support)	
out	address	Get the MAC address of the device through this interface, The address is similar to this	
		structure: xx:xx:xx:xx:xx	

Returns

0 : success other : failed

4.9.4.16 wifi_config_get_opmode()

4.9.4.17 wifi_config_get_skip_dtim()

Get the Skip DTIM value in current wifi setting of OPL1000.

Parameters

out	value	Get the Skip DTIM value in current wifi setting
-----	-------	---

Returns

0 : success other : failed

4.9.4.18 wifi_config_get_ssid()

Get ssid value of AP.

Parameters

out	ssid	Get ssid by pointer
out	ssid_length	Get the length of the ssid character

Returns

0 : success other : failed

4.9.4.19 wifi_config_set_bandwidth()

Set the bandwidth of OPL1000 specified interface.

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	bandwidth	Set the working bandwidth of wifi

Returns

0 : success other : failed

4.9.4.20 wifi_config_set_bssid()

```
int wifi_config_set_bssid ( \mbox{uint8\_t} \ * \ bssid \ )
```

config OPL1000 Wi-Fi bssid.

Parameters

in bssid the string of bssid

Returns

0 : success other : failed

4.9.4.21 wifi_config_set_channel()

Set primary/secondary channel of OPL1000.

Attention

- 1. This is a special API for sniffer
- 2. This API should be called after wifi_start()

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	channel	Set current Wi-Fi work channel number

Returns

0 : success other : failed

4.9.4.22 wifi_config_set_dtim_interval()

4.9.4.23 wifi_config_set_listen_interval()

4.9.4.24 wifi_config_set_mac_address()

Set MAC address of OPL1000 Wi-Fi station or the soft-AP interface.

Attention

- 1. This API can only be called when the interface is disabled
- 2. OPL1000 soft-AP and station have different MAC addresses, do not set them to be the same.

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	address	set MAC address

Returns

0 : success other : failed

4.9.4.25 wifi_config_set_opmode()

4.9.4.26 wifi_config_set_skip_dtim()

Set the Skip DTIM value of OPL1000.

Parameters

in	value	Set the Skip DTIM value
----	-------	-------------------------

Attention

- 1. This API will set the skip DTIM value to share memory and stored in flash, please use wifi_config_get_skip_dtim() to check it.
- 2. The setting will be effect after next connect. We recommend re-connect AP after setting to make sure the value is correct with negotiate between AP.

Returns

0 : success other : failed

4.9.4.27 wifi_config_set_ssid()

Set the ssid value of the current device.

Parameters

in	interface	Configure the current wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	ssid	Set the value of ssid
in	ssid_length	The length of ssid parameter

Returns

0 : success other : failed

4.9.4.28 wifi_connection_connect()

Connect OPL1000 Wi-Fi station to certain AP.

Attention

- 1. This API only impact WIFI_MODE_STA or WIFI_MODE_AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.

Parameters

in	config	Establish connection parameters
	009	parameter

Returns

0 : success other : failed

4.9.4.29 wifi_connection_connect_from_ac_index()

Connect OPL1000 Wi-Fi station to certain AP by auto connect index.

Attention

- 1. This API only impact WIFI_MODE_STA or WIFI_MODE_AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.
- 3. Then index should be 0 to begin.

Parameters

in index The index of AP in a	auto connect list
-------------------------------	-------------------

Returns

0 : success

1: The index of AP is null

other: failed

4.9.4.30 wifi_connection_connect_from_ac_list()

Connect OPL1000 Wi-Fi station to certain AP in auto connect list.

Attention

- 1. This API only impact WIFI MODE STA or WIFI MODE AP mode
- 2. If OPL1000 is connected to an AP, call wifi_disconnect to disconnect.

Parameters

in	config	Establish connection parameters
----	--------	---------------------------------

Returns

0: success

1 : Not found in list other : failed

4.9.4.31 wifi_connection_disconnect_ap()

Disconnect the link between OPL1000 and connected AP.

Returns

0 : success other : failed

4.9.4.32 wifi_connection_disconnect_sta()

Disconnect the link between the current device and the station.

Parameters

in	address	station address
----	---------	-----------------

Returns

0 : success other : failed

4.9.4.33 wifi_connection_get_rssi()

get signal strength of AP

Attention

1. If the scan is successful, this API returns signal strength value, otherwise it will get wrong result

Parameters

out	rssi	rssi value

Returns

0 : success other : failed

4.9.4.34 wifi_connection_register_event_handler()

register wifi call back handler

Parameters

in	event	The type of the registered event. Options are
		WIFI_EVENT_INIT_COMPLETE
		WIFI_EVENT_SCAN_COMPLETE
		WIFI_EVENT_STA_START
		WIFI_EVENT_STA_STOP
		WIFI_EVENT_STA_CONNECTED
		WIFI_EVENT_STA_DISCONNECTED
		WIFI_EVENT_STA_CONNECTION_FAILED
		WIFI_EVENT_STA_GOT_IP
in	handler	registered event handler

Returns

0 : success other : failed

4.9.4.35 wifi_connection_scan_start()

4.9.4.36 wifi_connection_unregister_event_handler()

unregister wifi call back handler

Parameters

in	event	The type of the unregistered event. Options please refer to wifi_connection_register_event_handler()	
in	handler	unregistered event handler	

Returns

0 : success other : failed

4.9.4.37 wifi_convert_auth_mode()

4.9.4.38 wifi_deinit()

```
int wifi_deinit (
     void )
```

De-init Wi-Fi Initialization and Configuration functions.

Attention

1. This API should be called if want to remove Wi-Fi driver from the system

Returns

0 : success other : failed

4.9.4.39 wifi_fast_connect_get_mode()

Get the fast connect mode.

Attention

1. API returns false if try to get fast connect mode which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2
out	mode	Get the fast connect mode

Returns

0 : success other : failed

4.9.4.40 wifi_fast_connect_set_mode()

Set the fast connect mode.

Attention

1. API returns false if try to set fast connect mode which something error

Parameters

	in	index	The index of AP position
			• Range is 0 to 2
İ	in	mode	The fast connect mode

Returns

0 : success other : failed

4.9.4.41 wifi_fast_connect_start()

Start fast connect mechanism.

Attention

1. API returns false if try to start fast connect function which something error

Parameters

in	index	The index of AP position
		• Range is 0 to 2

Returns

0 : success other : failed

4.9.4.42 wifi_get_config()

Get configuration of specified interface.

Parameters

in	interface	Configure wifi working mode, The options are
		WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
out	conf	return wifi's current operating parameters

Returns

0 : success other : failed

4.9.4.43 wifi_init()

Init Wi-Fi Initializes the wifi according to the specified parameters in the config.

Attention

1. This API must be called before other Wi-Fi APIs are invoked

Parameters

in	config	pointer to Wi-Fi init configuration structure; can point to a temporary variable.
in	init_cb	pointer to Wi-Fi init complete configuration structure; can point to a temporary variable.

Returns

0 : success other : failed

4.9.4.44 wifi_scan_get_ap_list()

Get list of APs that found in last scan operation.

Attention

This API only be called when scan is completed, otherwise it may get wrong value.

Parameters

out	scan_list	store APs' informaton that found in last scan operation
-----	-----------	---

Returns

0 : success other : failed

4.9.4.45 wifi_scan_get_ap_num()

Get the number of scanned APs.

Parameters

out	number	store number of APs found in last scan operation
-----	--------	--

Attention

This API only be called when scan is completed, otherwise it may get wrong value.

Returns

the scan result of AP number

```
4.9.4.46 wifi_scan_get_ap_records()
```

Get AP list found in last scan operation.

Parameters

out	number	As input param, it stores max AP number that ap_records can hold. As output param, it
		receives the actual AP number that this API returns.
out	ap_records	wifi_scan_info_t array stores the found APs

Returns

0 : success other : failed

4.9.4.47 wifi_scan_scan_stop()

Stop scanning process.

Attention

This API shall be called after wifi_scan_start()

Returns

0 : success other : failed

4.9.4.48 wifi_scan_start()

Scan all available APs. After invoke the wifi_set_config() and wifi_start(), then call wifi_scan_start() to scan APs.

Parameters

in	config	Configure parameters for scan operation	
in	block	if block is true, this API blocks the caller until scan operation is done, otherwise it returns	
		immediately	

Returns

0 : success other : failed

4.9.4.49 wifi_set_config()

Set configuration of OPL1000 STA.

Attention

- 1. This API is called only when specified interface is enabled, otherwise API calling will be failed
- 2. For station configuration, bssid_set shall be set to 0; set to 1 menas user want to check MAC address of certain AP.
- 3. OPL1000 is limited to working on one channel.

Parameters

in	interface	Configure wifi working mode, The options are
		• WIFI_MODE_STA
		WIFI_MODE_AP (currently not support)
in	conf	structure of configuration paremeters

Returns

0 : success other : failed

4.9.4.50 wifi_sta_get_ap_info()

Get information of AP which OPL1000 station is associated with.

Parameters

```
out ap_info get AP information from list
```

Returns

0 : success other : failed

4.9.4.51 wifi_start()

```
int wifi_start (
     void )
```

Start Wi-Fi working.

• If mode is WIFI_MODE_STA, it creates station control block and starts station

Returns

0 : success other : failed

4.9.4.52 wifi_stop()

```
int wifi_stop (
     void )
```

Stop wifi working.

• If mode is WIFI_MODE_STA, it stops station and releases station control block

Returns

0 : success other : failed

4.9.5 Variable Documentation

4.9 WIFI STA APIS

```
4.9.5.1 wifi_auto_connect_clear_ap_info_api
wifi_auto_connect_clear_ap_info_fp_t wifi_auto_connect_clear_ap_info_api
4.9.5.2 wifi_auto_connect_get_ap_info_api
wifi\_auto\_connect\_get\_ap\_info\_fp\_t \ wifi\_auto\_connect\_get\_ap\_info\_api
4.9.5.3 wifi_auto_connect_get_ap_num_api
wifi\_auto\_connect\_get\_ap\_num\_fp\_t \ wifi\_auto\_connect\_get\_ap\_num\_api
4.9.5.4 wifi_auto_connect_get_mode_api
wifi_auto_connect_get_mode_fp_t wifi_auto_connect_get_mode_api
4.9.5.5 wifi_auto_connect_init_api
wifi_auto_connect_init_fp_t wifi_auto_connect_init_api
4.9.5.6 wifi_auto_connect_reset_api
wifi_auto_connect_reset_fp_t wifi_auto_connect_reset_api
4.9.5.7 wifi_auto_connect_set_ap_num_api
wifi\_auto\_connect\_set\_ap\_num\_fp\_t \ wifi\_auto\_connect\_set\_ap\_num\_api
4.9.5.8 wifi_auto_connect_set_mode_api
wifi_auto_connect_set_mode_fp_t wifi_auto_connect_set_mode_api
```

136 Module Documentation

```
4.9.5.9 wifi_auto_connect_start_api
wifi_auto_connect_start_fp_t wifi_auto_connect_start_api
4.9.5.10 wifi_config_get_bandwidth_api
wifi\_config\_get\_bandwidth\_fp\_t \ wifi\_config\_get\_bandwidth\_api
4.9.5.11 wifi_config_get_bssid_api
wifi\_config\_get\_bssid\_fp\_t\ wifi\_config\_get\_bssid\_api
4.9.5.12 wifi_config_get_channel_api
wifi_config_get_channel_fp_t wifi_config_get_channel_api
4.9.5.13 wifi_config_get_dtim_interval_api
wifi\_config\_get\_dtim\_interval\_fp\_t \ wifi\_config\_get\_dtim\_interval\_api
4.9.5.14 wifi config get_listen_interval_api
wifi_config_get_listen_interval_fp_t wifi_config_get_listen_interval_api
4.9.5.15 wifi_config_get_mac_address_api
wifi\_config\_get\_mac\_address\_fp\_t \ wifi\_config\_get\_mac\_address\_api
4.9.5.16 wifi_config_get_opmode_api
wifi_config_get_opmode_fp_t wifi_config_get_opmode_api
```

4.9 WIFI STA APIS

```
4.9.5.17 wifi_config_get_ssid_api
wifi_config_get_ssid_fp_t wifi_config_get_ssid_api
4.9.5.18 wifi_config_set_bandwidth_api
wifi\_config\_set\_bandwidth\_fp\_t \ wifi\_config\_set\_bandwidth\_api
4.9.5.19 wifi_config_set_bssid_api
wifi\_config\_set\_bssid\_fp\_t\ wifi\_config\_set\_bssid\_api
4.9.5.20 wifi_config_set_channel_api
wifi_config_set_channel_fp_t wifi_config_set_channel_api
4.9.5.21 wifi_config_set_dtim_interval_api
wifi\_config\_set\_dtim\_interval\_fp\_t \ wifi\_config\_set\_dtim\_interval\_api
4.9.5.22 wifi_config_set_listen_interval_api
wifi_config_set_listen_interval_fp_t wifi_config_set_listen_interval_api
4.9.5.23 wifi_config_set_mac_address_api
wifi\_config\_set\_mac\_address\_fp\_t \ wifi\_config\_set\_mac\_address\_api
4.9.5.24 wifi_config_set_opmode_api
wifi_config_set_opmode_fp_t wifi_config_set_opmode_api
```

138 Module Documentation

```
4.9.5.25 wifi_config_set_ssid_api
wifi_config_set_ssid_fp_t wifi_config_set_ssid_api
4.9.5.26 wifi_connection_connect_api
{\tt wifi\_connect\_fp\_t\ wifi\_connect\_api}
4.9.5.27 wifi_connection_disconnect_ap_api
wifi\_connection\_disconnect\_ap\_fp\_t \ wifi\_connection\_disconnect\_ap\_api
4.9.5.28 wifi_connection_disconnect_sta_api
wifi_connection_disconnect_sta_fp_t wifi_connection_disconnect_sta_api
4.9.5.29 wifi_connection_get_rssi_api
wifi_connection_get_rssi_fp_t wifi_connection_get_rssi_api
4.9.5.30 wifi_connection_register_event_handler_api
wifi_connection_register_event_handler_fp_t wifi_connection_register_event_handler_api
4.9.5.31 wifi_connection_scan_start_api
wifi_connection_scan_start_fp_t wifi_connection_scan_start_api
4.9.5.32 wifi_connection_unregister_event_handler_api
wifi_connection_unregister_event_handler_fp_t wifi_connection_unregister_event_handler_api
```

4.9 WIFI STA APIS

```
4.9.5.33 wifi_convert_auth_mode_api
wifi_convert_auth_mode_fp_t wifi_convert_auth_mode_api
4.9.5.34 wifi_deinit_api
wifi_deinit_fp_t wifi_deinit_api
4.9.5.35 wifi_fast_connect_get_mode_api
wifi\_fast\_connect\_get\_mode\_fp\_t \ wifi\_fast\_connect\_get\_mode\_api
4.9.5.36 wifi_fast_connect_set_mode_api
wifi_fast_connect_set_mode_fp_t wifi_fast_connect_set_mode_api
4.9.5.37 wifi_fast_connect_start_api
wifi_fast_connect_start_fp_t wifi_fast_connect_start_api
4.9.5.38 wifi get config api
wifi_get_config_fp_t wifi_get_config_api
4.9.5.39 wifi_init_api
wifi_init_fp_t wifi_init_api
4.9.5.40 wifi_scan_get_ap_list_api
wifi_scan_get_ap_list_fp_t wifi_scan_get_ap_list_api
```

140 Module Documentation

```
4.9.5.41 wifi_scan_get_ap_num_api
wifi_scan_get_ap_num_fp_t wifi_scan_get_ap_num_api
4.9.5.42 wifi_scan_get_ap_records_api
{\tt wifi\_scan\_get\_ap\_records\_fp\_t\ wifi\_scan\_get\_ap\_records\_api}
4.9.5.43 wifi_scan_start_api
wifi_scan_start_fp_t wifi_scan_start_api
4.9.5.44 wifi_scan_stop_api
wifi_scan_stop_fp_t wifi_scan_stop_api
4.9.5.45 wifi_set_config_api
wifi_set_config_fp_t wifi_set_config_api
4.9.5.46 wifi_sta_get_ap_info_api
wifi_sta_get_ap_info_fp_t wifi_sta_get_ap_info_api
4.9.5.47 wifi_start_api
wifi_start_fp_t wifi_start_api
4.9.5.48 wifi_stop_api
wifi_stop_fp_t wifi_stop_api
```

4.10 Enumeration 141

4.10 Enumeration

Enumerations

```
enum wifi auth mode t {
  WIFI AUTH OPEN = 0, WIFI AUTH WEP, WIFI AUTH WPA PSK, WIFI AUTH WPA2 PSK,
  WIFI AUTH WPA WPA2 PSK, WIFI AUTH WPA2 ENTERPRISE }
        This enumeration defines the wireless authentication mode to indicate the Wi-Fi device authentication attribute.
enum wifi_bandwidth_t { WIFI_BW_HT20 = 1, WIFI_BW_HT40 }
enum wifi_cipher_type_t {
  WIFI_CIPHER_TYPE_NONE = 0, WIFI_CIPHER_TYPE_WEP40, WIFI_CIPHER_TYPE_WEP104,
  WIFI_CIPHER_TYPE_TKIP,
  WIFI CIPHER TYPE CCMP, WIFI CIPHER TYPE TKIP CCMP, WIFI CIPHER TYPE UNKNOWN }
        This enumeration defines wireless security cipher suits.
enum wifi_event_t {
  WIFI EVENT NONE = -1, WIFI EVENT INIT COMPLETE = 0, WIFI EVENT SCAN COMPLETE,
  WIFI EVENT STA START,
  WIFI EVENT STA STOP, WIFI EVENT STA CONNECTED, WIFI EVENT STA DISCONNECTED,
  WIFI EVENT STA CONNECTION FAILED,
  WIFI_EVENT_STA_GOT_IP, WIFI_EVENT_STA_AUTO_CONNECT_FAILED, WIFI_EVENT_MAX }
        This enumeration defines the supported events generated by the Wi-Fi driver. The event will be sent to the upper
       layer handler registered in wifi_register_event_handler().
enum wifi_mode_t { WIFI_MODE_NULL = 0, WIFI_MODE_STA, WIFI_MODE_AP, WIFI_MODE_MAX }
• enum wifi reason code t {
  WIFI REASON CODE SUCCESS, WIFI REASON CODE FIND AP FAIL, WIFI REASON CODE PREV AUTH INVALID
  WIFI REASON CODE DEAUTH LEAVING BSS,
  WIFI REASON CODE DISASSOC INACTIVITY, WIFI REASON CODE DISASSOC AP OVERLOAD,
  WIFI REASON CODE CLASS 2 ERR, WIFI REASON CODE CLASS 3 ERR,
  WIFI REASON CODE DISASSOC LEAVING BSS, WIFI REASON CODE ASSOC BEFORE AUTH,
  WIFI_REASON_CODE_DISASSOC_PWR_CAP_UNACCEPTABLE, WIFI_REASON_CODE_DISASSOC_SUP_CHS_UNACCEPTABLE, WIFI_REASON_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CHS_UNACCEPTABLE, WIFI_REASON_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_DISASSOC_SUP_CODE_D
  WIFI REASON CODE INVALID INFO ELEM = 13, WIFI REASON CODE MIC FAILURE, WIFI REASON CODE 4 WAY
  WIFI REASON CODE GROUP KEY UPDATE TIMEOUT,
  WIFI REASON CODE DIFFERENT INFO ELEM, WIFI REASON CODE GROUP CIPHER INVALID VALID,
  WIFI REASON CODE PAIRWISE CIPHER INVALID, WIFI REASON CODE AKMP INVALID,
  WIFI_REASON_CODE_UNSUPPORTED_RSNE_VERSION, WIFI_REASON_CODE_INVALID_RSNE_CAPABILITIES,
  WIFI REASON CODE IEEE 802 1X AUTH FAILED, WIFI REASON CODE CIPHER REJECTED,
  WIFI REASON CODE AUTO CONNECT FAILED = 200, WIFI REASON CODE CONNECT NOT FOUND,
  WIFI_REASON_CODE_CONNECT_TIMEOUT }
        This enumeration defines the reason code of the WIFI_EVENT_STA_CONNECTION_FAILED event in wifi_event_t.
        Find the details for the reason code below.

    enum wifi scan method t { WIFI FAST SCAN = 0, WIFI ALL CHANNEL SCAN }

    enum wifi scan type t{WIFI SCAN TYPE ACTIVE = 0, WIFI SCAN TYPE PASSIVE, WIFI SCAN TYPE MIX

        This enumeration defines the wireless STA scan type.
```

enum wifi_sort_method_t { WIFI_CONNECT_AP_BY_SIGNAL = 0, WIFI_CONNECT_AP_BY_SECURITY }

4.10.1 Detailed Description

4.10.2 Enumeration Type Documentation

142 Module Documentation

4.10.2.1 wifi_auth_mode_t

enum wifi_auth_mode_t

This enumeration defines the wireless authentication mode to indicate the Wi-Fi device authentication attribute.

4.10 Enumeration 143

Enumerator

WIFI_AUTH_OPEN	authenticate mode : open
WIFI_AUTH_WEP	authenticate mode : WEP
WIFI_AUTH_WPA_PSK	authenticate mode : WPA_PSK
WIFI_AUTH_WPA2_PSK	authenticate mode : WPA2_PSK
WIFI_AUTH_WPA_WPA2_PSK	authenticate mode : WPA_WPA2_PSK
WIFI_AUTH_WPA2_ENTERPRISE	authenticate mode : WPA2_ENTERPRISE

4.10.2.2 wifi_bandwidth_t

enum wifi_bandwidth_t

Enumerator

WIFI_BW_HT20	Bandwidth is HT20
WIFI_BW_HT40	Bandwidth is HT40

4.10.2.3 wifi_cipher_type_t

enum wifi_cipher_type_t

This enumeration defines wireless security cipher suits.

Enumerator

WIFI_CIPHER_TYPE_NONE	0, the cipher type is none
WIFI_CIPHER_TYPE_WEP40	1, the cipher type is WEP40
WIFI_CIPHER_TYPE_WEP104	2, the cipher type is WEP104
WIFI_CIPHER_TYPE_TKIP	3, the cipher type is TKIP
WIFI_CIPHER_TYPE_CCMP	4, the cipher type is CCMP
WIFI_CIPHER_TYPE_TKIP_CCMP	5, the cipher type is TKIP and CCMP
WIFI_CIPHER_TYPE_UNKNOWN	6, the cipher type is unknown

4.10.2.4 wifi_event_t

enum wifi_event_t

This enumeration defines the supported events generated by the Wi-Fi driver. The event will be sent to the upper layer handler registered in wifi_register_event_handler().

144 Module Documentation

Enumerator

WIFI_EVENT_NONE	Reserved
WIFI_EVENT_INIT_COMPLETE	Wi-Fi initialization complete event.
WIFI_EVENT_SCAN_COMPLETE	Scan completed event
WIFI_EVENT_STA_START	station start
WIFI_EVENT_STA_STOP	station stop
WIFI_EVENT_STA_CONNECTED	station connected to AP event
WIFI_EVENT_STA_DISCONNECTED	station disconnected from AP
WIFI_EVENT_STA_CONNECTION_FAILED	Connection has failed. For the reason code, please refer to
	wifi_reason_code_t.
WIFI_EVENT_STA_GOT_IP	station got IP from connected AP
WIFI_EVENT_STA_AUTO_CONNECT_FAILED	station auto connect failed indication
WIFI_EVENT_MAX	

4.10.2.5 wifi_mode_t

enum wifi_mode_t

Enumerator

WIFI_MODE_NULL	null mode
WIFI_MODE_STA	Wi-Fi station mode
WIFI_MODE_AP	Wi-Fi soft-AP mode
WIFI_MODE_MAX	

4.10.2.6 wifi_reason_code_t

enum wifi_reason_code_t

This enumeration defines the reason code of the WIFI_EVENT_STA_CONNECTION_FAILED event in wifi_event_t. Find the details for the reason code below.

Enumerator

WIFI_REASON_CODE_SUCCESS	0 Reserved.
WIFI_REASON_CODE_FIND_AP_FAIL	1 (Internal) No AP found.
WIFI_REASON_CODE_PREV_AUTH_INVALID	2 Previous authentication is no longer valid.
WIFI_REASON_CODE_DEAUTH_LEAVING_BSS	3 Deauthenticated because sending STA is leaving (or has left) IBSS or ES.
WIFI_REASON_CODE_DISASSOC_INACTIVITY	4 Disassociated due to inactivity.
WIFI_REASON_CODE_DISASSOC_AP_OVERL↔ OAD	5 Disassociated because AP is unable to handle all currently associated STAs.
WIFI_REASON_CODE_CLASS_2_ERR	6 Class 2 frame received from nonauthenticated STA.
WIFI_REASON_CODE_CLASS_3_ERR	7 Class 3 frame received from nonauthenticated STA.

4.10 Enumeration 145

Enumerator

WIFI_REASON_CODE_DISASSOC_LEAVING_BSS	8 Disassociated because sending STA is leaving (or has left) BSS.
WIFI_REASON_CODE_ASSOC_BEFORE_AUTH	9 STA requesting (re)association is not authenticated with responding STA.
WIFI_REASON_CODE_DISASSOC_PWR_CAP_← UNACCEPTABLE	10 Disassociated because the information in the Power Capability element is unacceptable.
WIFI_REASON_CODE_DISASSOC_SUP_CHS_U↔ NACCEPTABLE	11 Disassociated because the information in the Supported Channels element is unacceptable.
WIFI_REASON_CODE_INVALID_INFO_ELEM	13 Invalid information element.
WIFI_REASON_CODE_MIC_FAILURE	14 Message integrity code (MIC) failure.
WIFI_REASON_CODE_4_WAY_HANDSHAKE_TI↔ MEOUT	15 4-Way Handshake time out.
WIFI_REASON_CODE_GROUP_KEY_UPDATE_← TIMEOUT	16 Group Key Handshake time out.
WIFI_REASON_CODE_DIFFERENT_INFO_ELEM	17 Information element in 4-Way Handshake different from (Re)Association Request/Probe Response/Beacon frame.
WIFI_REASON_CODE_GROUP_CIPHER_INVALI↔ D_VALID	18 Invalid group cipher.
WIFI_REASON_CODE_PAIRWISE_CIPHER_INV↔ ALID	19 Invalid pairwise cipher.
WIFI_REASON_CODE_AKMP_INVALID	20 Invalid AKMP.
WIFI_REASON_CODE_UNSUPPORTED_RSNE_← VERSION	21 Unsupported RSN information element version.
WIFI_REASON_CODE_INVALID_RSNE_CAPABI↔ LITIES	22 Invalid RSN information element capabilities.
WIFI_REASON_CODE_IEEE_802_1X_AUTH_FAI↔ LED	23 IEEE 802.1X authentication failed.
WIFI_REASON_CODE_CIPHER_REJECTED	24 Cipher suite rejected because of the security policy.
WIFI_REASON_CODE_AUTO_CONNECT_FAILED	200 Auto connect failed.
WIFI_REASON_CODE_CONNECT_NOT_FOUND	201 The target AP is not found.
WIFI_REASON_CODE_CONNECT_TIMEOUT	202 Connect to AP timeout.

4.10.2.7 wifi_scan_method_t

enum wifi_scan_method_t

Enumerator

WIFI_FAST_SCAN	Do fast scan, scan will end after find SSID match AP
WIFI_ALL_CHANNEL_SCAN	All channel scan, scan will end after scan all the channel

146 Module Documentation

4.10.2.8 wifi_scan_type_t

```
enum wifi_scan_type_t
```

This enumeration defines the wireless STA scan type.

Enumerator

	WIFI_SCAN_TYPE_ACTIVE	Actively scan a network by sending 802.11 probe(s)
Ī	WIFI_SCAN_TYPE_PASSIVE	Passively scan a network by listening for beacons from APs
Ī	WIFI_SCAN_TYPE_MIX	Active + Passive scan

4.10.2.9 wifi_sort_method_t

enum wifi_sort_method_t

Enumerator

WIFI_CONNECT_AP_BY_SIGNAL	Sort match AP in scan list by RSSI
WIFI_CONNECT_AP_BY_SECURITY	Sort match AP in scan list by security mode

Chapter 5

Data Structure Documentation

5.1 _wpa_ie_data Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

- · int capabilities
- int group_cipher
- int key_mgmt
- int mgmt_group_cipher
- size_t num_pmkid
- int pairwise_cipher
- const u8 * pmkid
- int proto

5.1.1 Field Documentation

5.1.1.1 capabilities

int capabilities

5.1.1.2 group_cipher

int group_cipher

5.1.1.3 key_mgmt int key_mgmt 5.1.1.4 mgmt_group_cipher int mgmt_group_cipher 5.1.1.5 num_pmkid size_t num_pmkid 5.1.1.6 pairwise_cipher int pairwise_cipher 5.1.1.7 pmkid const u8* pmkid 5.1.1.8 proto int proto

5.2 asso_data Struct Reference

#include <controller_wifi_com.h>

- unsigned int eap_workaround
- int eapol_flags
- int group_cipher
- int key_mgmt
- int leap
- int mgmt_group_cipher
- int non_leap
- int pairwise_cipher
- char * passphrase
- int proto
- u8 psk [32]
- int psk_set

5.2.1 Field Documentation

5.2.1.1 eap_workaround

unsigned int eap_workaround

5.2.1.2 eapol_flags

int eapol_flags

5.2.1.3 group_cipher

int group_cipher

5.2.1.4 key_mgmt

int key_mgmt

5.2.1.5 leap

int leap

5.2.1.6 mgmt_group_cipher int mgmt_group_cipher 5.2.1.7 non_leap int non_leap 5.2.1.8 pairwise_cipher int pairwise_cipher 5.2.1.9 passphrase char* passphrase 5.2.1.10 proto int proto 5.2.1.11 psk u8 psk[32] 5.2.1.12 psk_set

5.3 auto_conn_info_t Struct Reference

int psk_set

#include <controller_wifi_com.h>

- u8 ap_channel
- u16 beacon_interval
- u8 bssid [MAC_ADDR_LEN]
- u16 capabilities
- u8 dtim_prod
- u8 fast_connect
- bool free_ocpy
- s8 hid_ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 hid_ssid_len
- u64 latest_beacon_rx_time
- s8 passphrase [MAX_LEN_OF_PASSPHRASE]
- u8 psk [32]
- u8 rsn_ie [256]
- s8 rssi
- s8 ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 ssid_len
- u8 supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

5.3.1 Field Documentation

5.3.1.1 ap_channel

u8 ap_channel

5.3.1.2 beacon_interval

ul6 beacon_interval

5.3.1.3 bssid

u8 bssid[MAC_ADDR_LEN]

5.3.1.4 capabilities

u16 capabilities

5.3.1.5 dtim_prod

u8 dtim_prod

5.3.1.6 fast_connect

u8 fast_connect

5.3.1.7 free_ocpy

bool free_ocpy

5.3.1.8 hid_ssid

s8 hid_ssid[IEEE80211_MAX_SSID_LEN+1]

5.3.1.9 hid_ssid_len

u8 hid_ssid_len

5.3.1.10 latest_beacon_rx_time

u64 latest_beacon_rx_time

5.3.1.11 passphrase

s8 passphrase[MAX_LEN_OF_PASSPHRASE]

5.3.1.12 psk

u8 psk[32]

```
5.3.1.13 rsn_ie
u8 rsn_ie[256]
5.3.1.14 rssi
s8 rssi
5.3.1.15 ssid
s8 ssid[IEEE80211_MAX_SSID_LEN+1]
5.3.1.16 ssid_len
u8 ssid_len
5.3.1.17 supported_rates
u8 supported_rates[IEEE80211_MAX_SUPPORTED_RATES]
5.3.1.18 wpa_data
wpa_ie_data_t wpa_data
5.3.1.19 wpa_ie
u8 wpa_ie[257]
```

5.4 auto_connect_cfg_t Struct Reference

#include <controller_wifi_com.h>

- bool flag
- s8 front
- u8 max_save_num
- auto_conn_info_t * pFCInfo
- s8 rear
- u8 retryCount
- u8 targetldx
- u32 uFCApNum

5.4.1 Field Documentation

5.4.1.1 flag

bool flag

5.4.1.2 front

s8 front

5.4.1.3 max_save_num

u8 max_save_num

5.4.1.4 pFCInfo

auto_conn_info_t* pFCInfo

5.4.1.5 rear

s8 rear

5.4.1.6 retryCount

u8 retryCount

5.4.1.7 targetIdx

u8 targetIdx

5.4.1.8 uFCApNum

u32 uFCApNum

5.5 event_msg_t Struct Reference

Send information to event by event_msg_t.

```
#include <event_loop.h>
```

Data Fields

- uint32_t event
- uint32_t length
- uint8_t * param

5.5.1 Detailed Description

Send information to event by event_msg_t.

5.5.2 Field Documentation

5.5.2.1 event

uint32_t event

event type

5.5.2.2 length

uint32_t length

Packet length

5.5.2.3 param

uint8_t* param

event parament

5.6 hap_control_t Struct Reference

```
#include <controller_wifi_com_patch.h>
```

Data Fields

- auto_conn_info_t * hap_ap_info
- u16 hap_bitvector
- u8 hap_en
- u8 hap_final_index
- u8 hap_index
- char hap_ssid [IEEE80211_MAX_SSID_LEN+1]

5.6.1 Field Documentation

5.6.1.1 hap_ap_info

auto_conn_info_t* hap_ap_info

5.6.1.2 hap_bitvector

u16 hap_bitvector

5.6.1.3 hap_en

u8 hap_en

5.6.1.4 hap_final_index

u8 hap_final_index

5.6.1.5 hap_index

u8 hap_index

5.6.1.6 hap_ssid

char hap_ssid[IEEE80211_MAX_SSID_LEN+1]

5.7 LE_BT_ADDR_T Struct Reference

#include <ble.h>

Data Fields

- BD_ADDR addr
- UINT8 type

5.7.1 Field Documentation

5.7.1.1 addr

BD_ADDR addr

address

5.7.1.2 type

UINT8 type

address type

Generated by Doxygen

5.8 LE_CM_CONNECTION_COMPLETE_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 conn_interval
- UINT16 conn_latency
- UINT16 dev_id
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- UINT8 role
- UINT16 status
- UINT16 supervison_timeout

5.8.1 Field Documentation

5.8.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.8.1.2 conn_interval

UINT16 conn_interval

connection interval

5.8.1.3 conn_latency

UINT16 conn_latency

connection latency

5.8.1.4 dev_id

UINT16 dev_id

device ID

```
5.8.1.5 peer_addr
BD_ADDR peer_addr
perr address
5.8.1.6 peer_addr_type
UINT8 peer_addr_type
peer address type
5.8.1.7 role
UINT8 role
master or slave
5.8.1.8 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
5.8.1.9 supervison_timeout
UINT16 supervison_timeout
supervision timeout
```

5.9 LE_CM_MSG_ADVERTISE_REPORT_IND_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- BD_ADDR addr
- UINT8 addr_type
- UINT8 data [1]
- UINT8 event_type
- UINT8 len
- INT8 rssi

5.9.1 Field Documentation

5.9.1.1 addr BD_ADDR addr address 5.9.1.2 addr_type UINT8 addr_type address type 5.9.1.3 data UINT8 data[1] 5.9.1.4 event_type UINT8 event_type 5.9.1.5 len UINT8 len 5.9.1.6 rssi INT8 rssi **RSSI**

5.10 LE_CM_MSG_CONN_PARA_REQ_T Struct Reference

- UINT16 conn_hdl
- UINT16 itv_max
- UINT16 itv_min
- UINT16 latency
- UINT32 sv_tmo

5.10.1 Field Documentation

5.10.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.10.1.2 itv_max

UINT16 itv_max

maxinum connection interval

5.10.1.3 itv_min

UINT16 itv_min

mininum connection interval

5.10.1.4 latency

UINT16 latency

slave latency

5.10.1.5 sv_tmo

UINT32 sv_tmo

supervision timeout

5.11 LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT16 interval
- UINT16 latency
- UINT16 status
- UINT32 supervision_timeout

5.11.1 Field Documentation

```
5.11.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.11.1.2 interval

UINT16 interval

connection interval
```

UINT16 latency

slave letency

5.11.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.11.1.5 supervision_timeout

UINT32 supervision_timeout

supervision timeout

5.12 LE_CM_MSG_DATA_LEN_CHANGE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT16 max_rx_octets
- UINT16 max_rx_time
- UINT16 max tx octets
- UINT16 max_tx_time

5.12.1 Field Documentation

5.12.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.12.1.2 max_rx_octets

UINT16 max_rx_octets

connMaxRxOctets

5.12.1.3 max_rx_time

UINT16 max_rx_time

connMaxRxTime

5.12.1.4 max_tx_octets

UINT16 max_tx_octets

connMaxTxOctets

5.12.1.5 max_tx_time

UINT16 max_tx_time

connMaxTxTime

5.13 LE_CM_MSG_DIRECT_ADV_REPORT_IND_T Struct Reference

- BD_ADDR direct_addr
- UINT8 direct_addr_type
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- INT8 rssi

5.13.1 Field Documentation

```
5.13.1.1 direct_addr

BD_ADDR direct_addr

direct address

5.13.1.2 direct_addr_type

UINT8 direct_addr_type

direct address type

5.13.1.3 peer_addr

BD_ADDR peer_addr

peer address
```

5.13.1.4 peer_addr_type

UINT8 peer_addr_type

peer address type

5.13.1.5 rssi

INT8 rssi

RSSI

5.14 LE_CM_MSG_DISCONNECT_COMPLETE_IND_T Struct Reference

- UINT16 conn_hdl
- UINT8 reason
- UINT16 status

5.14.1 Field Documentation

5.14.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.14.1.2 reason

UINT8 reason

disconnect reason

5.14.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.15 LE_CM_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT8 enabled
- UINT16 status

5.15.1 Field Documentation

5.15.1.1 conn_hdl
UINT16 conn_hdl
connection handle
5.15.1.2 devid
UINT16 devid
device ID
5.15.1.3 enabled
UINT8 enabled
5.15.1.4 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
5.16 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference

5.16 LE_CM_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- BOOL enabled
- UINT16 status

5.16.1 Field Documentation

5.16.1.1 conn_hdl

UINT16 conn_hdl

connection handle

<u> </u>
5.16.1.2 devid
UINT16 devid
device ID
5.16.1.3 enabled
BOOL enabled
enable or disable
5.16.1.4 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
<pre>5.17 LE_CM_MSG_INIT_COMPLETE_CFM_T Struct Reference #include <ble_cm_if.h></ble_cm_if.h></pre>
Data Fields
• UINT16 status
5.17.1 Field Documentation
5.17.1.1 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
5.18 LE_CM_MSG_LTK_REQ_IND_T Struct Reference

Generated by Doxygen

- UINT16 conn_hdl
- UINT16 devid
- UINT16 ediv
- UINT8 rand [8]

5.18.1 Field Documentation

5.18.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.18.1.2 devid

UINT16 devid

device ID

5.18.1.3 ediv

UINT16 ediv

5.18.1.4 rand

UINT8 rand[8]

5.19 LE_CM_MSG_READ_ADV_TX_POWER_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- INT8 pwr_level
- UINT16 status

5.19.1 Field Documentation

5.19.1.1 pwr_level

INT8 pwr_level

power level

5.19.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.20 LE_CM_MSG_READ_BD_ADDR_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- BD_ADDR bd_addr
- UINT16 status

5.20.1 Field Documentation

5.20.1.1 bd_addr

BD_ADDR bd_addr

5.20.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.21 LE_CM_MSG_READ_CHANNEL_MAP_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT8 ch map [5]
- UINT16 conn_hdl
- UINT16 status

5.21.1 Field Documentation

```
5.21.1.1 ch_map
```

UINT8 ch_map[5]

channel map

5.21.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.21.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.22 LE_CM_MSG_READ_PHY_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT16 conn hdl
- UINT8 rx_phy
- UINT16 status
- UINT8 tx_phy

5.22.1 Field Documentation

5.22.1.1 conn_hdl

UINT16 conn_hdl

5.22.1.2 rx_phy

UINT8 rx_phy

5.22.1.3 status

UINT16 status

5.22.1.4 tx_phy

UINT8 tx_phy

5.23 LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT8 size
- UINT16 status

5.23.1 Field Documentation

5.23.1.1 size

UINT8 size

resolving list size

5.23.1.2 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.24 LE_CM_MSG_READ_RSSI_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT16 conn_hdl
- INT8 rssi
- UINT16 status

5.24.1 Field Documentation

```
5.24.1.1 conn_hdl
```

UINT16 conn_hdl

connection handle

5.24.1.2 rssi

INT8 rssi

RSSI

5.24.1.3 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.25 LE_CM_MSG_READ_TX_POWER_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 status
- INT8 tx_power

5.25.1 Field Documentation

5.25.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.25.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.25.1.3 tx_power

INT8 tx_power

tx power

5.26 LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT8 size
- UINT16 status

5.26.1 Field Documentation

```
5.26.1.1 size

UINT8 size

white list size

5.26.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h
```

5.27 LE_CM_MSG_SET_DATA_LENGTH_CFM_T Struct Reference

```
#include <ble_cm_if.h>
```

Data Fields

- UINT16 conn_hdl
- UINT16 status

5.27.1 Field Documentation

```
UINT16 conn_hdl
connection handle
```

5.27.1.1 conn_hdl

5.27.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.28 LE_CM_MSG_SET_DISCONNECT_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 handle
- UINT16 status

5.28.1 Field Documentation

5.28.1.1 handle

UINT16 handle

connection handle

5.28.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.29 LE_CM_MSG_SET_PHY_CFM_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 status

5.29.1 Field Documentation

5.29.1.1 conn_hdl

UINT16 conn_hdl

5.29.1.2 status

UINT16 status

5.30 LE_CM_MSG_SIGNAL_UPDATE_REQ_T Struct Reference

#include <ble_cm_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 identifier
- UINT16 interval_max
- UINT16 interval_min
- UINT16 slave_latency
- UINT32 timeout_multiplier

5.30.1 Field Documentation

5.30.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.30.1.2 identifier

UINT16 identifier

5.30.1.3 interval_max

UINT16 interval_max

maxinum connection interval

5.30.1.4 interval_min

UINT16 interval_min

mininum connection interval

5.30.1.5 slave_latency

UINT16 slave_latency

slave latency

5.30.1.6 timeout_multiplier

UINT32 timeout_multiplier

5.31 LE_CM_REQ_STATUS_T Struct Reference

#include <ble_cm_if.h>

Data Fields

• UINT16 status

5.31.1 Field Documentation

5.31.1.1 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.32 LE_CONN_PARA_T Struct Reference

#include <ble.h>

Data Fields

- UINT16 itv_max
- UINT16 itv_min
- UINT16 latency
- UINT16 sv_timeout

5.32.1 Field Documentation

5.32.1.1 itv_max

UINT16 itv_max

maxinum connection interval

5.32.1.2 itv_min

UINT16 itv_min

mininum connection interval

5.32.1.3 latency

UINT16 latency

slave latency

5.32.1.4 sv_timeout

UINT16 sv_timeout

supervision timeout

5.33 LE_GAP_ADVERTISING_PARAM_T Struct Reference

#include <ble_gap_if.h>

Data Fields

- UINT8 channel_map
- UINT8 filter_policy
- UINT16 interval_max
- UINT16 interval_min
- UINT8 own_addr_type
- BD_ADDR peer_addr
- UINT8 peer_addr_type
- UINT8 type

5.33.1 Field Documentation

5.33.1.1 channel_map

UINT8 channel_map

advertising channel map

```
5.33.1.2 filter_policy
UINT8 filter_policy
advertising filter policy
5.33.1.3 interval_max
UINT16 interval_max
maxinum advertising interval
5.33.1.4 interval_min
UINT16 interval_min
mininum advertising interval
5.33.1.5 own_addr_type
UINT8 own_addr_type
owner address type
5.33.1.6 peer_addr
BD_ADDR peer_addr
peer address
5.33.1.7 peer_addr_type
UINT8 peer_addr_type
peer address type
5.33.1.8 type
UINT8 type
advertising type
```

5.34 LE_GAP_CONN_PARAM_T Struct Reference

#include <ble_gap_if.h>

Data Fields

- UINT16 interval_max
- UINT16 interval_min
- UINT16 latency
- UINT16 supervision_timeout

5.34.1 Field Documentation

```
5.34.1.1 interval_max
```

UINT16 interval_max

maxinum connection interval

5.34.1.2 interval_min

UINT16 interval_min

mininum connection interval

5.34.1.3 latency

UINT16 latency

slave latency

5.34.1.4 supervision_timeout

UINT16 supervision_timeout

supervision timeout for the LE Link

5.35 LE_GAP_SCAN_PARAM_T Struct Reference

#include <ble_gap_if.h>

Data Fields

- UINT8 filter_policy
- UINT16 interval
- UINT8 own_addr_type
- UINT8 type
- UINT16 window

5.35.1 Field Documentation

5.35.1.1 filter_policy

UINT8 filter_policy

scan filter policy

5.35.1.2 interval

UINT16 interval

scan interval

5.35.1.3 own_addr_type

UINT8 own_addr_type

owner address type

5.35.1.4 type

UINT8 type

scan type

5.35.1.5 window

UINT16 window

scan window

5.36 LE_GATT_ATTR_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 format
- UINT16 handle
- UINT16 len
- UINT16 maxLen
- UINT16 permit
- UINT16 *const pUuid
- UINT8 *const pVal

5.36.1 Field Documentation

5.36.1.1 format UINT8 format **UUID** type 5.36.1.2 handle UINT16 handle handle 5.36.1.3 len UINT16 len value length 5.36.1.4 maxLen UINT16 maxLen maxinum value length 5.36.1.5 permit UINT16 permit permit 5.36.1.6 pUuid UINT16* const pUuid UUID 5.36.1.7 pVal UINT8* const pVal value

5.37 LE_GATT_MSG_ACCESS_READ_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 offset

5.37.1 Field Documentation

5.37.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.37.1.2 devid

UINT16 devid

device index

5.37.1.3 handle

UINT16 handle

attribute handle

5.37.1.4 offset

UINT16 offset

attribute handle value

5.38 LE_GATT_MSG_ACCESS_WRITE_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT8 flag
- UINT16 handle
- UINT16 len
- UINT16 offset
- UINT8 * pVal

5.38.1 Field Documentation

```
5.38.1.1 conn_hdl
```

UINT16 conn_hdl

connection handle

5.38.1.2 devid

UINT16 devid

device ID

5.38.1.3 flag

UINT8 flag

refer to LE_GATT_FLAG_* in ble_gatt_if.h

5.38.1.4 handle

UINT16 handle

attribute handle

5.38.1.5 len

UINT16 len

length written

5.38.1.6 offset
UINT16 offset
attribute handle value
5.38.1.7 pVal
UINT8* pVal
value written
5.39 LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T Struct Reference
<pre>#include <ble_gatt_if.h></ble_gatt_if.h></pre>
Data Fields
UINT16 conn_hdlUINT16 devid
 UINT8 format UINT16 handle
• UINT16 uuid [8]
5.39.1 Field Documentation
5.39.1.1 conn_hdl
UINT16 conn_hdl
connection handle
5.39.1.2 devid
UINT16 devid
device ID
5.39.1.3 format
UINT8 format
UUID type

connection handle

5.40.1.2 devid

UINT16 devid

5.39.1.4 handle
UINT16 handle
characteristic descriptor handle
5.39.1.5 uuid
UINT16 uuid[8]
UUID
5.40 LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_IND_T Struct Reference
<pre>#include <ble_gatt_if.h></ble_gatt_if.h></pre>
Data Fields
• UINT16 conn_hdl
UINT16 conn_hdlUINT16 devidUINT8 format
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property UINT16 uuid [8]
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property UINT16 uuid [8] UINT16 val_hdl
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property UINT16 uuid [8]
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property UINT16 uuid [8] UINT16 val_hdl
 UINT16 conn_hdl UINT16 devid UINT8 format UINT16 handle UINT8 property UINT16 uuid [8] UINT16 val_hdl

5.40.1.3 format UINT8 format **UUID** type 5.40.1.4 handle UINT16 handle characteristic declaration handle 5.40.1.5 property UINT8 property property 5.40.1.6 uuid UINT16 uuid[8] UUID 5.40.1.7 val_hdl UINT16 val_hdl characteristic value handle 5.41 LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att_err
- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT16 offset
- UINT8 * val

value

5.41.1 Field Documentation

```
5.41.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
5.41.1.2 conn_hdl
UINT16 conn_hdl
connection handle
5.41.1.3 devid
UINT16 devid
device ID
5.41.1.4 handle
UINT16 handle
characteristic value handle
5.41.1.5 len
UINT16 len
value length
5.41.1.6 offset
UINT16 offset
value position offset
5.41.1.7 val
UINT8* val
```

5.42 LE_GATT_MSG_CONFIRMATION_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle

5.42.1 Field Documentation

5.42.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.42.1.2 devid

UINT16 devid

device ID

5.42.1.3 handle

UINT16 handle

attribute handle

5.43 LE_GATT_MSG_EXCHANGE_MTU_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 current_rx_mtu
- UINT16 devid

5.43.1 Field Documentation

5.43.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.43.1.2 current_rx_mtu

UINT16 current_rx_mtu

current receive MTU

5.43.1.3 devid

UINT16 devid

device ID

5.44 LE_GATT_MSG_EXCHANGE_MTU_IND_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT16 client_rx_mtu
- UINT16 conn_hdl
- UINT16 devid

5.44.1 Field Documentation

5.44.1.1 client_rx_mtu

UINT16 client_rx_mtu

client receive MTU

5.44.1.2 conn_hdl UINT16 conn_hdl connection handle 5.44.1.3 devid UINT16 devid device ID LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CFM_T Struct Reference 5.45 #include <ble_gatt_if.h> **Data Fields** • UINT8 att err • UINT16 conn hdl UINT16 devid UINT16 err_hdl • UINT16 status 5.45.1 Field Documentation 5.45.1.1 att_err UINT8 att_err 0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h 5.45.1.2 conn_hdl UINT16 conn_hdl connection handle 5.45.1.3 devid UINT16 devid

```
5.45.1.4 err_hdl

UINT16 err_hdl

TBD

5.45.1.5 status

UINT16 status
```

5.46 LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.46.1 Field Documentation

```
5.46.1.1 att_err

UINT8 att_err

O is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.46.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.46.1.3 devid
```

5.46.1.4 handle UINT16 handle characteristic descriptor handle 5.46.1.5 status UINT16 status

5.47 LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.47.1 Field Documentation

```
5.47.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.47.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.47.1.3 devid
```

5.47.1.4 handle

UINT16 handle

5.47.1.5 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.48 LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.48.1 Field Documentation

5.48.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.48.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.48.1.3 devid

UINT16 devid

5.48.1.4 handle UINT16 handle characteristic descriptor handle 5.48.1.5 status UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.49 LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.49.1 Field Documentation

```
5.49.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.49.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.49.1.3 devid
```

5.49.1.4 handle UINT16 handle include service start handle 5.49.1.5 status UINT16 status

5.50 LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_UUID_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

UINT16 devid

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.50.1 Field Documentation

```
5.50.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.50.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.50.1.3 devid
```

5.50.1.4 handle

UINT16 handle

service start handle

5.50.1.5 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.51 LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 end_hdl
- UINT8 format
- UINT16 handle
- UINT16 start_hdl
- UINT16 uuid [8]

5.51.1 Field Documentation

5.51.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.51.1.2 devid

UINT16 devid

5.51.1.3 end_hdl

UINT16 end_hdl

end handle

5.51.1.4 format

UINT8 format

UUID type

5.51.1.5 handle

UINT16 handle

include servie handle

5.51.1.6 start_hdl

UINT16 start_hdl

start handle

5.51.1.7 uuid

UINT16 uuid[8]

UUID

5.52 LE_GATT_MSG_INDICATE_IND_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT8 * val

5.52.1 Field Documentation

5.52.1.1 conn_hdl
UINT16 conn_hdl
connection handle
5.52.1.2 devid
UINT16 devid
device ID
5.52.1.3 handle
UINT16 handle
attribute handle
5.52.1.4 len
UINT16 len
value length
5.52.1.5 val
UINT8* val
value
5.53 LE_GATT_MSG_NOTIFY_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.53.1 Field Documentation

5.53.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.53.1.2 devid

UINT16 devid

device ID

5.53.1.3 handle

UINT16 handle

attribute handle

5.53.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.54 LE_GATT_MSG_NOTIFY_IND_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 len
- UINT8 * val

5.54.1 Field Documentation

5.54.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.54.1.2 devid UINT16 devid device ID 5.54.1.3 handle UINT16 handle attribute handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8+ val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT16 conn_hdl UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>		
device ID 5.54.1.3 handle UINT16 handle attribute handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8+ val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT16 conn.hdl UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	5.54.1.2 devid	
UINT16 handle attribute handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT16 conn hd UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	UINT16 devid	
UINT16 handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT8 att_op UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	device ID	
UINT16 handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT8 att_op UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>		
attribute handle 5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields • UINT8 att_op • UINT16 conn_hdl • UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	5.54.1.3 handle	
5.54.1.4 len UINT16 len value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT8 att_op UINT16 conn_hdl UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	UINT16 handle	
value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h>	attribute handle	
value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h>	5.54.1.4. Jon	
value length 5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h>	5.54.1.4 len	
5.54.1.5 val UINT8* val value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields UINT8 att_op UINT16 conn_hdl UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	UINT16 len	
value 5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields . UINT8 att_op . UINT16 conn_hdl . UINT16 devid 5.55.1 Field Documentation</ble_gatt_if.h>	value length	
5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h>	5.54.1.5 val	
5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h>		
<pre>5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference #include <ble_gatt_if.h> Data Fields</ble_gatt_if.h></pre>		
<pre>#include <ble_gatt_if.h> Data Fields</ble_gatt_if.h></pre>	value	
Data Fields • UINT8 att_op • UINT16 conn_hdl • UINT16 devid 5.55.1 Field Documentation	5.55 LE_GATT_MSG_OPERATION_TIMEOUT_T Struct Reference	
 UINT16 conn_hdl UINT16 devid 5.55.1 Field Documentation 5.55.1.1 att_op	<pre>#include <ble_gatt_if.h></ble_gatt_if.h></pre>	
 UINT16 conn_hdl UINT16 devid 5.55.1 Field Documentation 5.55.1.1 att_op	Data Fields	
• UINT16 devid 5.55.1 Field Documentation 5.55.1.1 att_op		
5.55.1.1 att_op		
5.55.1.1 att_op		
	5.55.1 Field Documentation	
	5.55.1.1 att_op	
UINT8 att_op	UINT8 att_op	
refer to LE_ATT_OP_* in ble_att_if.h	refer to LE_ATT_OP_* in ble_att_if.h	

5.55.1.2 conn_hdl UINT16 conn_hdl connection handle 5.55.1.3 devid UINT16 devid

5.56 LE_GATT_MSG_PREPARE_WRITE_RELIABLE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

device ID

device ID

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.56.1 Field Documentation

```
5.56.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.56.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.56.1.3 devid
```

5.56.1.4 handle UINT16 handle attribute handle 5.56.1.5 status UINT16 status refer to LE_ERR_STATE in ble_err.h

5.57 LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.57.1 Field Documentation

```
5.57.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.57.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.57.1.3 devid
```

5.57.1.4 handle

UINT16 handle

characteristic value handle

5.57.1.5 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.58 LE_GATT_MSG_READ_CHARACTERISTIC_VALUE_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.58.1 Field Documentation

```
5.58.1.1 att_err
```

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.58.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.58.1.3 devid

UINT16 devid

5.58.1.4 handle UINT16 handle characteristic value handle 5.58.1.5 status UINT16 status

5.59 LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.59.1 Field Documentation

```
5.59.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.59.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.59.1.3 devid
```

UINT16 devid

5.59.1.4 handle UINT16 handle characteristic value handle 5.59.1.5 status UINT16 status

5.60 LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_CFM_T Struct Reference

```
#include <ble_gatt_if.h>
```

refer to LE_ERR_STATE in ble_err.h

Data Fields

- UINT8 att err
- UINT16 conn hdl
- UINT16 devid
- UINT16 err_hdl
- UINT16 len
- UINT16 status
- UINT8 * val

connection handle

5.60.1 Field Documentation

```
5.60.1.1 att_err

UINT8 att_err

0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h

5.60.1.2 conn_hdl

UINT16 conn_hdl
```

```
5.60.1.3 devid
UINT16 devid
device ID
5.60.1.4 err_hdl
UINT16 err_hdl
TBD
5.60.1.5 len
UINT16 len
value length
5.60.1.6 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
5.60.1.7 val
UINT8* val
value
       LE_GATT_MSG_SERVICE_INFO_IND_T Struct Reference
5.61
```

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 devid
- UINT16 end_hdl
- UINT8 format
- UINT16 start_hdl
- UINT16 uuid [8]

5.61.1 Field Documentation

5.61.1.1 conn_hdl UINT16 conn_hdl connection handle 5.61.1.2 devid UINT16 devid device ID 5.61.1.3 end_hdl UINT16 end_hdl end handle 5.61.1.4 format UINT8 format **UUID** type 5.61.1.5 start_hdl UINT16 start_hdl start handle 5.61.1.6 uuid UINT16 uuid[8] UUID

5.62 LE_GATT_MSG_SIGNED_WRITE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.62.1 Field Documentation

5.62.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.62.1.2 devid

UINT16 devid

device ID

5.62.1.3 handle

UINT16 handle

attribute handle

5.62.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.63 LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att_err
- UINT16 conn_hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.63.1 Field Documentation

```
5.63.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
5.63.1.2 conn_hdl
UINT16 conn_hdl
connection handle
5.63.1.3 devid
UINT16 devid
device ID
5.63.1.4 handle
UINT16 handle
characteristic value handle
5.63.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
      LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T Struct Reference
```

Data Fields

- UINT8 att_err
- UINT16 conn_hdl

#include <ble_gatt_if.h>

- UINT16 devid
- UINT16 handle
- UINT16 status

5.64.1 Field Documentation

```
5.64.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
5.64.1.2 conn_hdl
UINT16 conn_hdl
connection handle
5.64.1.3 devid
UINT16 devid
device ID
5.64.1.4 handle
UINT16 handle
attribute handle
5.64.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
```

5.65 LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CFM_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT8 att_err
- UINT16 conn hdl
- UINT16 devid
- UINT16 handle
- UINT16 status

5.65.1 Field Documentation

```
5.65.1.1 att_err
UINT8 att_err
0 is ok, others refer to LE_ATT_ERR_* in ble_att_if.h
5.65.1.2 conn_hdl
UINT16 conn_hdl
connection handle
5.65.1.3 devid
UINT16 devid
device ID
5.65.1.4 handle
UINT16 handle
characteristic value handle
5.65.1.5 status
UINT16 status
refer to LE_ERR_STATE in ble_err.h
       LE_GATT_MSG_WRITE_NO_RSP_CFM_T Struct Reference
5.66
```

Data Fields

• UINT16 conn hdl

#include <ble_gatt_if.h>

- UINT16 devid
- UINT16 handle
- UINT16 status

5.66.1 Field Documentation

5.66.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.66.1.2 devid

UINT16 devid

device ID

5.66.1.3 handle

UINT16 handle

attribute handle

5.66.1.4 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.67 LE_GATT_SERVICE_T Struct Reference

#include <ble_gatt_if.h>

Data Fields

- UINT16 endHdl
- LE_GATT_ATTR_T * pAttr
- UINT16 startHdl
- UINT16 svc_id

5.67.1 Field Documentation

5.67.1.1 endHdl UINT16 endHdl end handle 5.67.1.2 pAttr LE_GATT_ATTR_T* pAttr pointer attribute table 5.67.1.3 startHdl UINT16 startHdl start handle 5.67.1.4 svc_id UINT16 svc_id

5.68 LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T Struct Reference

```
#include <ble_smp_if.h>
```

Data Fields

service ID

- UINT16 conn_hdl
- BOOL enable

5.68.1 Field Documentation

5.68.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.68.1.2 enable

BOOL enable

enable or disable

5.69 LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT16 conn_hdl
- UINT16 status

5.69.1 Field Documentation

5.69.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.69.1.2 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.70 LE_SMP_MSG_OOB_DATA_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn_hdl

5.70.1 Field Documentation

5.70.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.71 LE_SMP_MSG_PAIRING_ACTION_IND_T Struct Reference

```
#include <ble_smp_if.h>
```

Data Fields

- UINT8 action
- UINT16 conn_hdl
- BOOL lost_bond
- UINT8 sc

5.71.1 Field Documentation

```
5.71.1.1 action
```

UINT8 action

refer to LE_SM_IO_CAP_* in ble_smp_if.h

5.71.1.2 conn_hdl

UINT16 conn_hdl

connection handle

5.71.1.3 lost_bond

BOOL lost_bond

remote lost bond

5.71.1.4 sc

UINT8 sc

secure connection

5.72 LE_SMP_MSG_PAIRING_COMPLETE_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT8 authenticated
- UINT8 bonded
- UINT16 conn_hdl
- LE_BT_ADDR_T peer_id_addr
- UINT8 sc
- UINT16 status

5.72.1 Field Documentation

5.72.1.1 authenticated

UINT8 authenticated

authenticated

5.72.1.2 bonded

UINT8 bonded

bonded

5.72.1.3 conn_hdl

UINT16 conn_hdl

connection handle

5.72.1.4 peer_id_addr

LE_BT_ADDR_T peer_id_addr

peer device address

5.72.1.5 sc

UINT8 sc

secure connection

5.72.1.6 status

UINT16 status

refer to LE_ERR_STATE in ble_err.h

5.73 LE_SMP_MSG_PASSKEY_DISPLAY_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT16 conn_hdl
- UINT32 passkey

5.73.1 Field Documentation

5.73.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.73.1.2 passkey

UINT32 passkey

passkey

5.74 LE_SMP_MSG_PASSKEY_INPUT_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn hdl

5.74.1 Field Documentation

5.74.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.75 LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

• UINT16 conn_hdl

5.75.1 Field Documentation

5.75.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.76 LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IND_T Struct Reference

#include <ble_smp_if.h>

Data Fields

- UINT8 bondable
- UINT16 conn_hdl
- UINT8 keypress
- UINT8 mitm
- UINT8 sc

5.76.1 Field Documentation

5.76.1.1 bondable UINT8 bondable bonding 5.76.1.2 conn_hdl UINT16 conn_hdl connection handle 5.76.1.3 keypress

5.76.1.4 mitm

UINT8 keypress

keypress status

UINT8 mitm

MITM

5.76.1.5 sc

UINT8 sc

secure connection

5.77 LE_SMP_MSG_USER_CONFIRM_IND_T Struct Reference

```
#include <ble_smp_if.h>
```

Data Fields

- UINT32 confirm_num
- UINT16 conn_hdl

5.77.1 Field Documentation

o o ==_o	
5.77.1.1 confirm_num	
UINT32 confirm_num	
confirm number	
5.77.1.2 conn_hdl	
UINT16 conn_hdl	
connection handle	
<pre>5.78 LE_SMP_SC_OOB_DATA_T Struct Reference #include <ble_smp_if.h></ble_smp_if.h></pre>	
Data Fields	
UINT8 confirm [16]UINT8 rand [16]	
5.78.1 Field Documentation	
5.78.1.1 confirm	
UINT8 confirm[16]	
confirm data	
5.78.1.2 rand	
UINT8 rand[16]	

5.79 LE_SYS_MSG_BUF_OVERFLOW_T Struct Reference

#include <ble_msg.h>

random data

Data Fields

• UINT16 conn_hdl

5.79.1 Field Documentation

5.79.1.1 conn_hdl

UINT16 conn_hdl

connection handle

5.80 mw_blewifi_cbs_store_t Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

• uint8_t manufacture_name [STA_INFO_MAX_MANUF_NAME_SIZE]

5.80.1 Field Documentation

5.80.1.1 manufacture_name

uint8_t manufacture_name[STA_INFO_MAX_MANUF_NAME_SIZE]

5.81 mw_wifi_auto_connect_ap_info_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- u8 ap_channel
- u16 beacon_interval
- u8 bssid [MAC_ADDR_LEN]
- u16 capabilities
- u8 dtim_prod
- u8 fast_connect
- bool free_ocpy
- s8 hid_ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 hid_ssid_len
- u64 latest_beacon_rx_time
- s8 passphrase [64]
- u8 psk [32]
- u8 rsn_ie [256]
- s8 rssi
- s8 ssid [IEEE80211_MAX_SSID_LEN+1]
- u8 ssid_len
- u8 supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

5.81.1 Field Documentation

5.81.1.1 ap_channel

u8 ap_channel

5.81.1.2 beacon_interval

ul6 beacon_interval

5.81.1.3 bssid

u8 bssid[MAC_ADDR_LEN]

5.81.1.4 capabilities

u16 capabilities

5.81.1.5 dtim_prod

u8 dtim_prod

5.81.1.6 fast_connect

u8 fast_connect

5.81.1.7 free_ocpy

bool free_ocpy

5.81.1.8 hid_ssid

s8 hid_ssid[IEEE80211_MAX_SSID_LEN+1]

5.81.1.9 hid_ssid_len

u8 hid_ssid_len

5.81.1.10 latest_beacon_rx_time

u64 latest_beacon_rx_time

5.81.1.11 passphrase

s8 passphrase[64]

5.81.1.12 psk

u8 psk[32]

```
5.81.1.13 rsn_ie
u8 rsn_ie[256]
5.81.1.14 rssi
s8 rssi
5.81.1.15 ssid
s8 ssid[IEEE80211_MAX_SSID_LEN+1]
5.81.1.16 ssid_len
u8 ssid_len
5.81.1.17 supported_rates
u8 supported_rates[IEEE80211_MAX_SUPPORTED_RATES]
5.81.1.18 wpa_data
wpa_ie_data_t wpa_data
5.81.1.19 wpa_ie
u8 wpa_ie[257]
       mw_wifi_sta_info_t Struct Reference
5.82
```

Generated by Doxygen

#include <controller_wifi_com.h>

Data Fields

- uint8_t au8Dot11MACAddress [MAC_ADDR_LEN]
- uint8_t u8SkipDtimPeriods

5.82.1 Field Documentation

5.82.1.1 au8Dot11MACAddress

uint8_t au8Dot11MACAddress[MAC_ADDR_LEN]

5.82.1.2 u8SkipDtimPeriods

uint8_t u8SkipDtimPeriods

5.83 MwFimAutoConnectCFG_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- bool flag
- s8 front
- u8 max_save_num
- s8 rear
- u8 targetldx

5.83.1 Field Documentation

5.83.1.1 flag

bool flag

5.83.1.2 front

s8 front

5.83.1.3 max_save_num

u8 max_save_num

5.83.1.4 rear

s8 rear

5.83.1.5 targetIdx

u8 targetIdx

5.84 rx_eapol_data Struct Reference

#include <controller_wifi_com.h>

Data Fields

- u8 frame_buffer [384]
- unsigned int frame_length

5.84.1 Field Documentation

5.84.1.1 frame_buffer

u8 frame_buffer[384]

5.84.1.2 frame_length

unsigned int frame_length

5.85 S_WIFI_MLME_SCAN_CFG Struct Reference

#include <controller_wifi_com_patch.h>

Data Fields

- scan_report_t * ptScanReport
- E_WIFI_MLME_SCAN_TYPE tScanType
- uint32_t u32ActiveScanDur
- uint32_t u32PassiveScanDur
- uint8_t u8aBssid [MAC_ADDR_LEN]
- uint8_t u8aSsid [IEEE80211_MAX_SSID_LEN+1]
- uint8_t u8Channel
- uint8_t u8MaxScanApNum
- uint8_t u8ResendCnt

5.85.1 Detailed Description

The parameter of MLME_CMD_SCAN

5.85.2 Field Documentation

5.85.2.1 ptScanReport

scan_report_t* ptScanReport

The scan report which filled by MSQ, report to APS

5.85.2.2 tScanType

E_WIFI_MLME_SCAN_TYPE tScanType

scan type. active, passive, or mix mode

5.85.2.3 u32ActiveScanDur

uint32_t u32ActiveScanDur

Scan duration per scan counter in channel. units: millisecond

5.85.2.4 u32PassiveScanDur

uint32_t u32PassiveScanDur

Scan duration per channel. units: millisecond

5.85.2.5 u8aBssid

uint8_t u8aBssid[MAC_ADDR_LEN]

Not supported yet. MAC address of AP

5.85.2.6 u8aSsid

uint8_t u8aSsid[IEEE80211_MAX_SSID_LEN+1]

Not supported yet. SSID of AP

5.85.2.7 u8Channel

uint8_t u8Channel

Only specific channel or scan all channels

5.85.2.8 u8MaxScanApNum

uint8_t u8MaxScanApNum

Max scan AP number. When scanned AP number over this value, MSQ will drop the AP with smallest RSSI value

5.85.2.9 u8ResendCnt

uint8_t u8ResendCnt

Send probe req counter per channel when active scan. After send probe req, it will wait active scan time, and then send next probe req. The total time will be increased by a factor of this value

5.86 scan_info_t Struct Reference

#include <controller_wifi_com.h>

Data Fields

- uint8_t ap_channel
- uint16_t beacon_interval
- uint8_t bssid [MAC_ADDR_LEN]
- uint16_t capabilities
- uint8_t dtim_prod
- unsigned char free_ocpy
- uint64_t latest_beacon_rx_time
- u8 rsn_ie [256]
- int8_t rssi
- char ssid [IEEE80211_MAX_SSID_LEN+1]
- uint8_t ssid_len
- uint8_t supported_rates [IEEE80211_MAX_SUPPORTED_RATES]
- wpa_ie_data_t wpa_data
- u8 wpa_ie [257]

5.86.1 Field Documentation

5.86.1.1 ap_channel

uint8_t ap_channel

5.86.1.2 beacon_interval

uint16_t beacon_interval

5.86.1.3 bssid

uint8_t bssid[MAC_ADDR_LEN]

5.86.1.4 capabilities

uint16_t capabilities

5.86 scan_info_t Struct Reference 5.86.1.5 dtim_prod uint8_t dtim_prod 5.86.1.6 free_ocpy unsigned char free_ocpy 5.86.1.7 latest_beacon_rx_time

uint64_t latest_beacon_rx_time

5.86.1.8 rsn_ie

u8 rsn_ie[256]

5.86.1.9 rssi

int8_t rssi

5.86.1.10 ssid

char ssid[IEEE80211_MAX_SSID_LEN+1]

5.86.1.11 ssid_len

uint8_t ssid_len

5.86.1.12 supported_rates

uint8_t supported_rates[IEEE80211_MAX_SUPPORTED_RATES]

5.86.1.13 wpa_data

```
wpa_ie_data_t wpa_data
```

5.86.1.14 wpa_ie

u8 wpa_ie[257]

5.87 scan_report_t Struct Reference

```
#include <controller_wifi_com.h>
```

Data Fields

- scan_info_t * pScanInfo
- u32 uScanApNum

5.87.1 Field Documentation

5.87.1.1 pScanInfo

```
scan_info_t* pScanInfo
```

5.87.1.2 uScanApNum

u32 uScanApNum

5.88 T_RfCmd Struct Reference

```
#include <controller_wifi.h>
```

Data Fields

- int iArgc
- $char * saArgv [RF_CMD_PARAM_NUM]$
- uint32_t u32Type

5.88.1 Field Documentation

5.88.1.1 iArgc

int iArgc

5.88.1.2 saArgv

char* saArgv[RF_CMD_PARAM_NUM]

5.88.1.3 u32Type

uint32_t u32Type

5.89 T_RfEvt Struct Reference

#include <controller_wifi.h>

Data Fields

- void * pParam
- uint16_t u16RfMode
- uint16_t u16RxCnt
- uint16_t u16RxCrcOkCnt
- uint32_t u32Freq
- uint32_t u32Mode
- uint32_t u32RfChannel
- uint32_t u32Type
- uint8_t u8Freq
- uint8_t u8lpcEnable
- uint8_t u8Len
- uint8_t u8Pkt
- uint8_t u8Reserved
- uint8_t u8Status
- uint8_t u8Unicast

5.89.1 Field Documentation

5.89.1.1 pParam

void* pParam

5.89.1.2 u16RfMode

uint16_t u16RfMode

5.89.1.3 u16RxCnt

uint16_t u16RxCnt

5.89.1.4 u16RxCrcOkCnt

uint16_t u16RxCrcOkCnt

5.89.1.5 u32Freq

uint32_t u32Freq

5.89.1.6 u32Mode

uint32_t u32Mode

5.89.1.7 u32RfChannel

uint32_t u32RfChannel

5.89.1.8 u32Type

uint32_t u32Type

5.89.1.9 u8Freq uint8_t u8Freq 5.89.1.10 u8lpcEnable uint8_t u8IpcEnable 5.89.1.11 u8Len uint8_t u8Len 5.89.1.12 u8Pkt uint8_t u8Pkt 5.89.1.13 u8Reserved uint8_t u8Reserved 5.89.1.14 u8Status uint8_t u8Status

wifi_active_scan_time_t Struct Reference 5.90

Range of active scan times per channel.

#include <wifi_types.h>

5.89.1.15 u8Unicast

uint8_t u8Unicast

Data Fields

- uint32_t max
- uint32_t min

5.90.1 Detailed Description

Range of active scan times per channel.

5.90.2 Field Documentation

5.90.2.1 max

```
uint32_t max
```

maximum active scan time per channel, units: millisecond, maximum values 1500ms may cause station to disconnect from AP and are not recommended.

5.90.2.2 min

```
uint32_t min
```

minimum active scan time per channel, units: millisecond

5.91 wifi_ap_config_t Struct Reference

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t auth_mode
- uint16_t beacon_interval
- uint8_t channel
- wifi_cipher_type_t encrypt_type
- uint8_t max_connection
- uint8_t password [WIFI_LENGTH_PASSPHRASE]
- uint8_t password_length
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t ssid_hidden
- uint8_t ssid_length

5.91.1 Detailed Description

This structure is the Wi-Fi configuration for initialization for Soft-AP mode.

5.91.2 Field Documentation

```
5.91.2.1 auth_mode
```

```
wifi_auth_mode_t auth_mode
```

The authentication mode.

5.91.2.2 beacon_interval

```
uint16_t beacon_interval
```

Beacon interval, 100 \sim 60000 ms, default 100 ms

5.91.2.3 channel

uint8_t channel

The channel of Soft-AP.

5.91.2.4 encrypt_type

```
wifi_cipher_type_t encrypt_type
```

The encryption mode.

5.91.2.5 max_connection

uint8_t max_connection

Max number of stations allowed to connect in, default 4, max 4

5.91.2.6 password

```
uint8_t password[WIFI_LENGTH_PASSPHRASE]
```

The password of the Soft-AP.

5.91.2.7 password_length

```
uint8_t password_length
```

The length of the password.

5.91.2.8 ssid

```
uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID]
```

The SSID of the Soft-AP.

5.91.2.9 ssid_hidden

```
uint8_t ssid_hidden
```

Broadcast SSID or not, default 0, broadcast the SSID

5.91.2.10 ssid_length

```
uint8_t ssid_length
```

The length of the SSID.

5.92 wifi_auto_connect_info_t Struct Reference

This structure is the Wi-Fi auto connect for save in the flash (FIM).

```
#include <wifi_types.h>
```

Data Fields

- uint8_t ap_channel
- uint16_t beacon_interval
- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- · uint16 t capabilities
- uint8_t dtim_prod
- uint8_t fast_connect
- char hid_ssid [WIFI_MAX_LENGTH_OF_SSID]
- int8_t rssi
- char ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t supported_rates [WIFI_MAX_SUPPORTED_RATES]

5.92.1 Detailed Description

This structure is the Wi-Fi auto connect for save in the flash (FIM).

5.92.2 Field Documentation

5.92.2.1 ap_channel uint8_t ap_channel 5.92.2.2 beacon_interval uint16_t beacon_interval 5.92.2.3 bssid uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH] 5.92.2.4 capabilities uint16_t capabilities 5.92.2.5 dtim_prod uint8_t dtim_prod 5.92.2.6 fast_connect uint8_t fast_connect 5.92.2.7 hid_ssid

Generated by Doxygen

char hid_ssid[WIFI_MAX_LENGTH_OF_SSID]

5.92.2.8 rssi

int8_t rssi

5.92.2.9 ssid

char ssid[WIFI_MAX_LENGTH_OF_SSID]

5.92.2.10 supported_rates

uint8_t supported_rates[WIFI_MAX_SUPPORTED_RATES]

5.93 wifi_cmd_t Struct Reference

#include <controller_wifi.h>

Data Fields

- u32 arg1:8
- u32 cmd_type:8
- void * prvData
- u32 reserved:16

5.93.1 Field Documentation

5.93.1.1 arg1

u32 arg1

5.93.1.2 cmd_type

u32 cmd_type

5.93.1.3 prvData

void* prvData

5.93.1.4 reserved

u32 reserved

5.94 wifi_config_t Union Reference

Wi-Fi configuration for initialization.

```
#include <wifi_types.h>
```

Data Fields

- wifi_ap_config_t ap_config
- wifi_sta_config_t sta_config

5.94.1 Detailed Description

Wi-Fi configuration for initialization.

5.94.2 Field Documentation

5.94.2.1 ap_config

```
wifi_ap_config_t ap_config
```

The configurations for the AP. It should be set when the wifi_mode_t is WIFI_MODE_AP .

5.94.2.2 sta_config

```
wifi_sta_config_t sta_config
```

The configurations for the STA. It should be set when the wifi_mode_t is WIFI_MODE_STA.

5.95 wifi_event_info_t Union Reference

```
wifi_event_info_t
#include <wifi_event.h>
Data Fields
   • wifi_event_sta_connected_t connected
   • wifi_event_sta_disconnected_t disconnected
   • wifi_event_sta_got_ip_t got_ip
   • wifi_event_sta_scan_done_t scan_done
5.95.1 Detailed Description
wifi_event_info_t
5.95.2 Field Documentation
5.95.2.1 connected
wifi_event_sta_connected_t connected
station connected to AP
5.95.2.2 disconnected
wifi_event_sta_disconnected_t disconnected
station disconnected to AP
5.95.2.3 got_ip
wifi_event_sta_got_ip_t got_ip
station got IP, first time got IP or when IP is changed
5.95.2.4 scan_done
wifi_event_sta_scan_done_t scan_done
```

station scan (APs) done

5.96 wifi_event_sta_connected_t Struct Reference

```
wifi_event_sta_connected_t
#include <wifi_event.h>
Data Fields
   • wifi_auth_mode_t authmode
   • uint8_t bssid [6]
   • uint8_t channel
   • uint8_t ssid [32]
    • uint8_t ssid_len
5.96.1 Detailed Description
wifi_event_sta_connected_t
5.96.2 Field Documentation
5.96.2.1 authmode
wifi_auth_mode_t authmode
5.96.2.2 bssid
uint8_t bssid[6]
BSSID of connected AP
5.96.2.3 channel
uint8_t channel
channel of connected AP
5.96.2.4 ssid
```

uint8_t ssid[32]

SSID of connected AP

5.96.2.5 ssid_len uint8_t ssid_len SSID length of connected AP 5.97 wifi_event_sta_disconnected_t Struct Reference wifi_event_sta_disconnected_t #include <wifi_event.h>

Data Fields

- uint8_t bssid [6]
- uint8_t reason
- uint8_t ssid [32]
- uint8_t ssid_len

5.97.1 Detailed Description

wifi_event_sta_disconnected_t

5.97.2 Field Documentation

```
5.97.2.1 bssid
```

uint8_t bssid[6]

BSSID of disconnected AP

5.97.2.2 reason

uint8_t reason

reason of disconnection

5.97.2.3 ssid

uint8_t ssid[32]

SSID of disconnected AP

```
5.97.2.4 ssid_len

uint8_t ssid_len

SSID length of disconnected AP
```

5.98 wifi_event_sta_got_ip_t Struct Reference

```
#include <wifi_event.h>
```

Data Fields

• bool ip_changed

5.98.1 Field Documentation

```
5.98.1.1 ip_changed
```

bool ip_changed

5.99 wifi_event_sta_scan_done_t Struct Reference

```
wifi_event_sta_scan_done_t
#include <wifi_event.h>
```

Data Fields

- uint8_t number
- uint8_t scan_id
- uint32_t status

5.99.1 Detailed Description

wifi_event_sta_scan_done_t

5.99.2 Field Documentation

5.99.2.1 number

uint8_t number

5.99.2.2 scan_id

uint8_t scan_id

5.99.2.3 status

uint32_t status

status of scanning APs

5.100 wifi_evt_t Struct Reference

#include <controller_wifi.h>

Data Fields

- uint32_t evt_type
- void * prvData

5.100.1 Field Documentation

5.100.1.1 evt_type

uint32_t evt_type

5.100.1.2 prvData

void* prvData

5.101 wifi_fast_scan_threshold_t Struct Reference

Structure describing parameters for a Wi-Fi fast scan.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t authmode
- int8_t rssi

5.101.1 Detailed Description

Structure describing parameters for a Wi-Fi fast scan.

5.101.2 Field Documentation

5.101.2.1 authmode

```
wifi_auth_mode_t authmode
```

The weakest authmode to accept in the fast scan mode

5.101.2.2 rssi

int8_t rssi

The minimum rssi to accept in the fast scan mode

5.102 wifi_init_config_t Struct Reference

WiFi stack configuration parameters.

```
#include <wifi_types.h>
```

Data Fields

- wifi_event_notify_cb_t event_handler
- int magic

5.102.1 Detailed Description

WiFi stack configuration parameters.

5.102.2 Field Documentation

5.102.2.1 event_handler

```
wifi_event_notify_cb_t event_handler
```

WiFi event handler

5.102.2.2 magic

int magic

WiFi init magic number, it should be the last field

5.103 wifi_scan_config_t Struct Reference

Parameters for an SSID scan.

```
#include <wifi_types.h>
```

Data Fields

- uint8_t * bssid
- uint8_t channel
- wifi_scan_time_t scan_time
- wifi_scan_type_t scan_type
- bool show_hidden
- uint8_t * ssid

5.103.1 Detailed Description

Parameters for an SSID scan.

5.103.2 Field Documentation

```
5.103.2.1 bssid
uint8_t* bssid
MAC address of AP
5.103.2.2 channel
uint8_t channel
channel, scan the specific channel
5.103.2.3 scan_time
wifi_scan_time_t scan_time
scan time per channel
5.103.2.4 scan_type
wifi_scan_type_t scan_type
scan type, active or passive
5.103.2.5 show_hidden
bool show_hidden
enable to scan AP whose SSID is hidden
5.103.2.6 ssid
uint8_t* ssid
SSID of AP
```

5.104 wifi_scan_info_t Struct Reference

This structure defines the inforamtion of scanned APs.

```
#include <wifi_types.h>
```

Data Fields

- wifi_auth_mode_t auth_mode
- uint16_t beacon_interval
- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- uint16_t capability_info
- uint8_t channel
- uint8_t dtim_period
- wifi_cipher_type_t group_cipher
- wifi_cipher_type_t pairwise_cipher
- int rss
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- uint8_t ssid_length

5.104.1 Detailed Description

This structure defines the inforamtion of scanned APs.

5.104.2 Field Documentation

```
5.104.2.1 auth_mode
```

```
wifi_auth_mode_t auth_mode
```

Please refer to the definition of wifi_auth_mode_t.

5.104.2.2 beacon_interval

uint16_t beacon_interval

Indicates the beacon interval.

5.104.2.3 bssid

uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH]

AP's MAC address.

5.104.2.4 capability_info

uint16_t capability_info

The Capability Information field contains a number of subfields that are used to indicate requested or advertised optional capabilities.

5.104.2.5 channel uint8_t channel The channel used. 5.104.2.6 dtim_period uint8_t dtim_period The DTIM Period indicates the number of beacon intervals between successive DTIMs. If all TIMs are DTIMs, the DTIM Period field has the value 1. 5.104.2.7 group_cipher wifi_cipher_type_t group_cipher group cipher of AP 5.104.2.8 pairwise_cipher wifi_cipher_type_t pairwise_cipher pairwise cipher of AP, Please refer to the definition of #wifi_encrypt_type_t. 5.104.2.9 rssi int rssi Records the RSSI value when probe response is received. 5.104.2.10 ssid uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID] Stores the predefined SSID. 5.104.2.11 ssid_length

Generated by Doxygen

Length of the SSID.

uint8_t ssid_length

5.105 wifi_scan_list_t Struct Reference

This structure defines the list of scanned APs with their corresponding information.

```
#include <wifi_types.h>
```

Data Fields

- wifi_scan_info_t ap_record [WIFI_MAX_SCAN_AP_NUM]
- int num

5.105.1 Detailed Description

This structure defines the list of scanned APs with their corresponding information.

5.105.2 Field Documentation

```
5.105.2.1 ap_record
```

```
wifi_scan_info_t ap_record[WIFI_MAX_SCAN_AP_NUM]
```

The information about an AP obtained through the scan result is stored

5.105.2.2 num

int num

number of AP in the list

5.106 wifi_scan_time_t Union Reference

Aggregate of active & passive scan time per channel.

```
#include <wifi_types.h>
```

Data Fields

- wifi_active_scan_time_t active
- uint32_t passive

5.106.1 Detailed Description

Aggregate of active & passive scan time per channel.

5.106.2 Field Documentation

5.106.2.1 active

```
wifi_active_scan_time_t active
```

active scan time per channel, units: millisecond.

5.106.2.2 passive

```
uint32_t passive
```

passive scan time per channel, units: millisecond, maximum values 1500ms may cause station to disconnect from AP and are not recommended.

5.107 wifi_sta_config_t Struct Reference

This structure is the Wi-Fi configuration for initialization for STA mode.

```
#include <wifi_types.h>
```

Data Fields

- uint8_t bssid [WIFI_MAC_ADDRESS_LENGTH]
- uint8_t bssid_present
- uint8_t password [WIFI_LENGTH_PASSPHRASE]
- uint8_t password_length
- wifi_scan_method_t scan_method
- wifi_sort_method_t sort_method
- uint8_t ssid [WIFI_MAX_LENGTH_OF_SSID]
- · uint8_t ssid_length
- · wifi_fast_scan_threshold_t threshold

5.107.1 Detailed Description

This structure is the Wi-Fi configuration for initialization for STA mode.

5.107.2 Field Documentation

The SSID of the target AP.

```
5.107.2.1 bssid
uint8_t bssid[WIFI_MAC_ADDRESS_LENGTH]
The MAC address of the target AP.
5.107.2.2 bssid_present
uint8_t bssid_present
The BSSID is present if it is set to 1. Otherwise, it is set to 0.
5.107.2.3 password
uint8_t password[WIFI_LENGTH_PASSPHRASE]
The password of the target AP.
5.107.2.4 password_length
uint8_t password_length
The length of the password. If the length is 64, the password is regarded as PMK.
5.107.2.5 scan_method
wifi_scan_method_t scan_method
do all channel scan or fast scan
5.107.2.6 sort_method
wifi_sort_method_t sort_method
sort the connect AP in the list by rssi or security mode
5.107.2.7 ssid
uint8_t ssid[WIFI_MAX_LENGTH_OF_SSID]
```

5.107.2.8 ssid_length

uint8_t ssid_length

The length of the SSID.

5.107.2.9 threshold

wifi_fast_scan_threshold_t threshold

When scan_method is set to WIFI_FAST_SCAN, only APs which have an auth mode that is more secure than the selected auth mode and a signal stronger than the minimum RSSI will be used.

5.108 wifi_wpa_ie_data_t Struct Reference

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

#include <wifi_types.h>

Data Fields

- · int capabilities
- int group_cipher
- int key_mgmt
- int mgmt_group_cipher
- uint32_t num_pmkid
- · int pairwise_cipher
- const uint8_t * pmkid
- int proto

5.108.1 Detailed Description

This structure is the Wi-Fi auto connect with wpa information for save in the flash (FIM).

5.108.2 Field Documentation

5.108.2.1 capabilities

int capabilities

5.108.2.8 proto

int proto

5.108.2.2 group_cipher int group_cipher 5.108.2.3 key_mgmt int key_mgmt 5.108.2.4 mgmt_group_cipher int mgmt_group_cipher 5.108.2.5 num_pmkid uint32_t num_pmkid 5.108.2.6 pairwise_cipher int pairwise_cipher 5.108.2.7 pmkid const uint8_t* pmkid

Index

```
_wpa_ie_data, 147
                                                           {\sf LE\_GATT\_MSG\_FIND\_ALL\_CHAR\_DESC\_CF} \leftarrow
    capabilities, 147
                                                                M T, 192
    group cipher, 147
                                                           LE GATT MSG FIND ALL PRIMARY SERVI←
    key mgmt, 147
                                                                CE_CFM_T, 193
    mgmt_group_cipher, 148
                                                           \mathsf{LE\_GATT\_MSG\_FIND\_CHARACTERISTIC\_CF} \leftarrow
    num_pmkid, 148
                                                                M T, 194
    pairwise cipher, 148
                                                           LE_GATT_MSG_FIND_INCLUDED_SERVICE_←
    pmkid, 148
                                                                CFM_T, 195
    proto, 148
                                                           LE GATT MSG FIND PRIMARY SERVICE B←
                                                                Y UUID CFM T, 196
action
                                                           LE GATT MSG PREPARE WRITE RELIABL←
    LE_SMP_MSG_PAIRING_ACTION_IND_T, 216
                                                                E CFM T, 202
active
                                                           {\sf LE\_GATT\_MSG\_READ\_CHAR\_VAL\_BY\_UUID} \leftarrow
    wifi_scan_time_t, 253
                                                                 CFM_T, 203
addr
                                                           {\sf LE\_GATT\_MSG\_READ\_CHARACTERISTIC\_V} {\leftarrow}
    LE_BT_ADDR_T, 157
                                                                ALUE_CFM_T, 204
    {\sf LE\_CM\_MSG\_ADVERTISE\_REPORT\_IND\_} {\leftarrow}
                                                           {\sf LE\_GATT\_MSG\_READ\_LONG\_CHAR\_VAL\_C} \leftarrow
         T, 160
                                                                FM T, 205
addr_type
                                                           LE GATT MSG READ MULTIPLE CHAR VA
    {\sf LE\_CM\_MSG\_ADVERTISE\_REPORT\_IND\_} {\leftarrow}
                                                                L_CFM_T, 206
                                                           {\sf LE\_GATT\_MSG\_WRITE\_CHAR\_VAL\_RELIAB} {\leftarrow}
ap_channel
                                                                LE CFM T, 210
    auto conn info t, 151
                                                           {\sf LE\_GATT\_MSG\_WRITE\_CHAR\_VALUE\_CFM} \leftarrow
    mw wifi auto connect ap info t, 223
                                                                 _T, 211
    scan info t, 230
                                                           {\sf LE\_GATT\_MSG\_WRITE\_LONG\_CHAR\_VALU} \leftarrow
    wifi_auto_connect_info_t, 239
                                                                E_CFM_T, 212
ap_config
                                                       att op
    wifi config t, 241
                                                            LE GATT MSG OPERATION TIMEOUT T, 201
ap_record
                                                       au8Dot11MACAddress
    wifi_scan_list_t, 252
                                                           mw_wifi_sta_info_t, 226
arg1
                                                       auth mode
    wifi_cmd_t, 240
                                                           wifi_ap_config_t, 237
asso data, 148
                                                           wifi_scan_info_t, 250
    eap_workaround, 149
                                                       authenticated
    eapol_flags, 149
                                                           LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
    group_cipher, 149
                                                                217
    key_mgmt, 149
                                                       authmode
    leap, 149
                                                           wifi event sta connected t, 243
    mgmt_group_cipher, 149
                                                           wifi fast scan threshold t, 247
    non leap, 150
                                                       auto_conn_info_t, 150
    pairwise_cipher, 150
                                                           ap_channel, 151
    passphrase, 150
                                                           beacon_interval, 151
    proto, 150
                                                           bssid, 151
    psk, 150
                                                           capabilities, 151
    psk set, 150
                                                           dtim prod, 151
att err
                                                           fast connect, 152
    LE GATT MSG CHARACTERISTIC VAL IND←
                                                           free ocpy, 152
          T, 188
    LE\_GATT\_MSG\_EXECUTE\_WRITE\_RELIABL \hookleftarrow
                                                           hid ssid, 152
         E_CFM_T, 191
                                                           hid_ssid_len, 152
```

latest_beacon_rx_time, 152	GAP_ADTYPE_128BIT_COMPLETE, 19
passphrase, 152	GAP_ADTYPE_128BIT_MORE, 19
psk, 152	GAP_ADTYPE_16BIT_COMPLETE, 19
rsn_ie, 152	GAP_ADTYPE_16BIT_MORE, 20
rssi, 153	GAP ADTYPE 32BIT COMPLETE, 20
ssid, 153	GAP ADTYPE 32BIT MORE, 20
ssid_len, 153	GAP_ADTYPE_3D_INFO_DATA, 20
supported_rates, 153	GAP_ADTYPE_ADV_INTERVAL, 20
wpa_data, 153	GAP_ADTYPE_APPEARANCE, 20
wpa_ie, 153	GAP ADTYPE FLAGS BREDR NOT SUPPO↔
auto_connect_cfg_t, 153	RTED, 20
flag, 154	GAP_ADTYPE_FLAGS_GENERAL, 21
front, 154	GAP_ADTYPE_FLAGS_LIMITED, 21
max_save_num, 154	GAP ADTYPE FLAGS, 20
pFCInfo, 154	GAP_ADTYPE_LE_BD_ADDR, 21
rear, 154	GAP_ADTYPE_LE_BD_ADDR, 21 GAP_ADTYPE_LE_ROLE, 21
retryCount, 154	
targetldx, 155	GAP_ADTYPE_LOCAL_NAME_COMPLETE, 21
uFCApNum, 155	GAP_ADTYPE_LOCAL_NAME_SHORT, 21
515 411 451 6	GAP_ADTYPE_MANUFACTURER_SPECIFIC, 21
BLE ALL APIs, 9	GAP_ADTYPE_OOB_CLASS_OF_DEVICE, 21
LeSmpGetBondIdFromAddr, 9	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HAS↔
BLE CM APIS, 10	HC, 22
LE_CM_MSG_ADD_TO_RESOLVING_LIST_C↔	GAP_ADTYPE_OOB_SIMPLE_PAIRING_RAN↔
FM_T, 11	DR, 22
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T, 11	GAP_ADTYPE_POWER_LEVEL, 22
	GAP_ADTYPE_PUBLIC_TARGET_ADDR, 22
LE_CM_MSG_CANCEL_CONNECTION_CFM_T, 11	GAP_ADTYPE_RANDOM_TARGET_ADDR, 22
	GAP_ADTYPE_SERVICE_DATA_128BIT, 22
LE_CM_MSG_CLEAR_RESOLVING_LIST_CF↔	GAP_ADTYPE_SERVICE_DATA_32BIT, 22
M_T, 12	GAP_ADTYPE_SERVICE_DATA, 22
LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T, 12	GAP_ADTYPE_SERVICES_LIST_128BIT, 23
LE_CM_MSG_CREATE_CONNECTION_CFM_T, 12	GAP_ADTYPE_SERVICES_LIST_16BIT, 23
LE_CM_MSG_ENTER_ADVERTISING_CFM_T,	GAP_ADTYPE_SIGNED_DATA, 23
12	GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256,
LE_CM_MSG_ENTER_SCANNING_CFM_T, 12	23
LE_CM_MSG_EXIT_ADVERTISING_CFM_T, 12	GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256,
LE_CM_MSG_EXIT_SCANNING_CFM_T, 12	23
LE_CM_MSG_PHY_UPDATE_COMPLETE_IN↔	GAP_ADTYPE_SLAVE_CONN_INTERVAL_RA↔
D_T, 12	NGE, 23
LE_CM_MSG_REMOVE_FROM_RESOLVING_←	GAP_ADTYPE_SM_OOB_FLAG, 23
LIST_CFM_T, 13	GAP_ADTYPE_SM_TK, 23
LE_CM_MSG_REMOVE_FROM_WHITE_LIST↔	GAP_PUBLIC_ADDR, 24
_CFM_T, 13	GAP_RAND_ADDR_NRPA, 24
OT M_T, TO LE_CM_MSG_SET_ADVERTISING_DATA_CF↔	GAP_RAND_ADDR_RPA, 24
M_T, 13	GAP_RAND_ADDR_STATIC, 24
LE CM MSG SET ADVERTISING PARAMS ↔	GAP_SCAN_TYPE_ACTIVE, 24
CFM_T, 13	GAP_SCAN_TYPE_PASSIVE, 24
LE_CM_MSG_SET_CHANNEL_MAP_CFM_T, 13	GAP_TX_PWR_CURR_VAL, 24
LE_CM_MSG_SET_DEFAULT_PHY_CFM_T, 13	GAP_TX_PWR_MAX_VAL, 24
LE_CM_MSG_SET_RANDOM_ADDRESS_CF↔	GAPBOND_IO_CAP_DISPLAY_ONLY, 25
M T, 13	GAPBOND_IO_CAP_DISPLAY_YES_NO, 25
LE_CM_MSG_SET_RPA_TIMEOUT_CFM_T, 13	GAPBOND_IO_CAP_KEYBOARD_DISPLAY, 25
LE_CM_MSG_SET_SCAN_PARAMS_CFM_T, 14	GAPBOND_IO_CAP_KEYBOARD_ONLY, 25
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T,	GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT,
14	25
LeCmInit, 15	GAPBOND_PAIRING_MODE_INITIATE, 25
BLE GAP APIs, 17	GAPBOND_PAIRING_MODE_NO_PAIRING, 25

	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ,	GATT_REPORT_REF_UUID, 46
	25	GATT_SECONDARY_SERVICE_UUID, 46
	LE_GAP_ADV_MAX_SIZE, 26	GATT_SERV_CHAR_CFG_UUID, 47
	LeGapAddToResolvingList, 26	GATT_VALID_RANGE_UUID, 47
	LeGapAddToWhiteList, 26	gcCharAggregateUuid, 70
	LeGapAdvertisingEnable, 27	gcCharExtPropUuid, 70
	LeGapCentralConnectReq, 27	gcCharFormatUuid, 71
	LeGapCentralSetDataChannel, 27	gcCharUserDescUuid, 71
	LeGapClearResolvingList, 29	gcCharacteristicUuid, 70
	LeGapClearWhiteList, 29	gcClientCharConfigUuid, 71
	LeGapConnParaRequestRsp, 29	gcExtReportRefUuid, 71
	LeGapConnUpdateRequest, 30	gcIncludeUuid, 71
	LeGapConnUpdateResponse, 30	gcPrimaryServiceUuid, 71
	LeGapConnectCancelReq, 29	gcReportRefUuid, 71
	LeGapDisconnectReq, 31	gcSecondaryServiceUuid, 71
	LeGapGenRandAddr, 31	gcServerCharConfigUuid, 72
	LeGapGetBtAddr, 31	gcValidRangeUuid, 72
	LeGapReadAdvChannelTxPower, 31	INCLUDE_DECL_UUID128, 47
	LeGapReadChannelMap, 32	INCLUDE_DECL_UUID128_ATTR_VAL, 47
	LeGapReadPhy, 32	INCLUDE_DECL_UUID16_ATTR_VAL, 47
	LeGapReadResolvingListSize, 32	INCLUDE_DECL_UUINT16, 47
	LeGapReadRssi, 32	LE_ATT_UUID_SIZE, 47
	LeGapReadTxPower, 33	LE_GATT_CHAR_PROP_AUTH, 48
	LeGapReadWhiteListSize, 33	LE_GATT_CHAR_PROP_BCAST, 48
	LeGapRemoveFromWhiteList, 33	LE_GATT_CHAR_PROP_EXT_PROP, 48
	LeGapScanningReq, 34	LE_GATT_CHAR_PROP_IND, 48
	LeGapSetAdvData, 34	LE_GATT_CHAR_PROP_NTF, 48
	LeGapSetAdvParameter, 35	LE_GATT_CHAR_PROP_RD, 48
	LeGapSetConnParameter, 35	LE_GATT_CHAR_PROP_WR_NO_RESP, 49
	LeGapSetDataChannelPduLen, 35	LE_GATT_CHAR_PROP_WR, 48
	LeGapSetDefaultPhy, 36	LE_GATT_CLIENT_CFG_INDICATION, 49
	LeGapSetPhy, 36	LE_GATT_CLIENT_CFG_NOTIFICATION, 49
	LeGapSetRandAddr, 36	LE_GATT_EXT_PROP_RELIABLE_WR, 49
	LeGapSetRpaTimeout, 37	LE_GATT_EXT_PROP_WR_AUX, 49
	LeGapSetStaticAddr, 37	LE_GATT_FLAG_PREPARE_WRITE, 49
	LeSetScanParameter, 37	LE_GATT_FLAG_WRITE_CMD, 49
	LeSetScanRspData, 38	LE_GATT_FLAG_WRITE_REQ, 49
BLE	GATT APIs, 39	LE_GATT_PERM_AUTH_READABLE, 50
	CHAR_AGGREGATE_DESCRIPTOR, 43	LE_GATT_PERM_AUTH_WRITABLE, 50
	CHAR_CLIENT_CONFIG_DESCRIPTOR, 43	LE_GATT_PERM_NONE, 50
	CHAR_DECL_UUID16_ATTR_VAL, 44	LE_GATT_PERM_READ, 50
	CHAR_EXT_PROP_DESCRIPTOR, 44	LE_GATT_PERM_RELIABLE_WRITE, 50
	CHAR_PRESENT_FORMAT_DESCRIPTOR, 44	LE_GATT_PERM_WRITE_CMD, 50
	CHAR_SERVER_CONFIG_DESCRIPTOR, 44	LE_GATT_PERM_WRITE_REQ, 50
	CHAR_USER_DESC_DESCRIPTOR, 44	LE_GATT_PERMIT_AUTHEN_READ, 50
	CHARACTERISTIC_DECL_UUID128, 44	LE_GATT_PERMIT_AUTHEN_WRITE, 51
	CHARACTERISTIC_DECL_UUID16, 45	LE_GATT_PERMIT_AUTHOR_READ, 51
	CHARACTERISTIC_UUID128, 45	LE_GATT_PERMIT_AUTHOR_WRITE, 51
	CHARACTERISTIC_UUID16, 45	LE_GATT_PERMIT_ENCRYPT_READ, 51
	GATT_CHAR_AGG_FORMAT_UUID, 45	LE_GATT_PERMIT_ENCRYPT_WRITE, 51
	GATT_CHAR_EXT_PROPS_UUID, 45	LE_GATT_PERMIT_READABLE, 51
	GATT_CHAR_FORMAT_UUID, 45	LE_GATT_PERMIT_READ, 51
	GATT_CHAR_USER_DESC_UUID, 46	LE_GATT_PERMIT_SC_AUTHEN_READ, 51
	GATT_CHARACTERISTIC_UUID, 46	LE_GATT_PERMIT_SC_AUTHEN_WRITE, 52
	GATT_CLIENT_CHAR_CFG_UUID, 46	LE_GATT_PERMIT_WRITABLE, 52
	GATT_EXT_REPORT_REF_UUID, 46	LE_GATT_PERMIT_WRITE, 52
	GATT_INCLUDE_UUID, 46	LeGattAccessReadRsp, 54
	GATT_PRIMARY_SERVICE_UUID, 46	LeGattAccessWriteRsp, 54

LoGattChangoAttr\/al_55	MESSAGE BULID, 75
LeGattChangeAttrVal, 55 LeGattCharValConfirmation, 55	MESSAGE_BOLID, 75 MESSAGE DATA BULID, 75
LeGattCharValIndicate, 56	MESSAGE_DATA_BOLID, 75 MESSAGE_OFFSET, 76
	-
LeGattCharValNotify, 56	MESSAGEID, 76
LeGattExchangeMtuReq, 57	MESSAGE, 76
LeGattExchangeMtuRsp, 57	MSGLOCK, 77
LeGattExecuteWriteCharValReliable, 57	MSGSUBID, 77
LeGattFindAllCharDescriptor, 58	MSGTIMER, 77
LeGattFindAllCharacteristic, 58	MsgData, 77
LeGattFindAllPrimaryService, 59	MsgLock, 77
LeGattFindCharacteristicByUuid, 59	T_HOUR, 76
LeGattFindIncludedService, 60	T_MIN, 76
LeGattFindPrimaryServiceByUuid, 60	T_SEC, 76
LeGattGetAttrHandle, 60	TASKHANDLER, 77
LeGattGetAttrVal, 61	TASKPACK, 78
LeGattGetAttrValLen, 61	TASK, 77
LeGattGetAttrValMaxLen, 63	Task, 77
LeGattInit, 63	BLE SMP APIs, 85
LeGattModifyAttrVal, 64	LE_MAX_BOND_COUNT, 86
LeGattPrepareWriteCharValReliable, 64	LE_SM_IO_CAP_DISP_ONLY, 86
LeGattReadCharValByUuid, 65	LE_SM_IO_CAP_DISP_YES_NO, 86
LeGattReadCharValue, 65	LE_SM_IO_CAP_KEYBOARD_DISP, 86
LeGattReadLongCharVal, 66	LE_SM_IO_CAP_KEYBOARD_ONLY, 87
LeGattReadMultipleCharVal, 66	LE_SM_IO_CAP_NO_IO, 87
LeGattRegisterIncludeService, 66	LE_SM_PAIR_MITM_NO, 87
LeGattRegisterService, 67	LE_SM_PAIR_MITM_YES, 87
LeGattSignedWriteNoRsp, 67	LE_SM_PAIR_OOB_NO, 87
LeGattStopCurrentProcedure, 68	LE_SM_PAIR_OOB_YES, 87
LeGattWriteCharVal, 68	LE_SM_PAIR_SC_NO, 87
LeGattWriteCharValReliable, 69	LE_SM_PAIR_SC_YES, 87
LeGattWriteLongCharVal, 69	LeSmpInit, 89
LeGattWriteNoRsp, 70	LeSmpOobAuthDataRsp, 89
PRIMARY_SERVICE_DECL_UUID128, 52	LeSmpOobPresent, 89
PRIMARY_SERVICE_DECL_UUID16, 52	LeSmpPasskeyInput, 90
SECONDARY_SERVICE_DECL_UUID128, 52	LeSmpScOobComputeConfirmVal, 90
SECONDARY_SERVICE_DECL_UUID16, 52	LeSmpScOobDataRsp, 90
BLE MSG APIs, 73	LeSmpSecurityReq, 91
LE_ATT_MSG_BASE, 74	LeSmpSecurityRsp, 91
LE_CM_MSG_BASE, 74	LeSmpSetDefaultConfig, 92
LE_GATT_MSG_BASE, 74	LeSmpUserConfirmRsp, 92
LE_HCI_MSG_BASE, 75	bd_addr
LE_L2CAP_MSG_BASE, 75	LE_CM_MSG_READ_BD_ADDR_CFM_T, 169
LE_SMP_MSG_BASE, 75	beacon_interval
LE SYS MSG BASE, 75	auto_conn_info_t, 151
LeCancelAllMessage, 78	mw_wifi_auto_connect_ap_info_t, 223
LeCancelAllSubMessage, 79	scan info t, 230
LeCancelFirstMessage, 79	wifi_ap_config_t, 237
LeCancelFirstSubMessage, 79	wifi_auto_connect_info_t, 239
LeGetSubMsgld, 80	wifi_scan_info_t, 250
LeHostCreateTask, 80	bondable
LeHostMessageLoop, 81	LE_SMP_MSG_SLAVE_SECURITY_REQUES
LeSendMessage, 81	T_IND_T, 219
LeSendMessageAfter, 81	bonded
LeSendMessageUnlock, 82	LE SMP MSG PAIRING COMPLETE IND T,
LeSendSubMessage, 82	217
LeSendSubMessageAfter, 83	bssid
LeSendSubMessageUnlock, 83	auto_conn_info_t, 151
MESSAGE_ALLOCATE, 75	mw_wifi_auto_connect_ap_info_t, 223
WESSINGE_RECOUNTE, IS	

scan_info_t, 230	conn_hdl
wifi_auto_connect_info_t, 239	LE_CM_CONNECTION_COMPLETE_IND_T, 158
wifi_event_sta_connected_t, 243	LE_CM_MSG_CONN_PARA_REQ_T, 161
wifi_event_sta_disconnected_t, 244	LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔
wifi_scan_config_t, 248	ND_T, 162
wifi_scan_info_t, 250	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 163
wifi_sta_config_t, 254	LE_CM_MSG_DISCONNECT_COMPLETE_IN↔
bssid_present	D T, 165
wifi_sta_config_t, 254	LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,
	165
CHAR_AGGREGATE_DESCRIPTOR	LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,
BLE GATT APIs, 43	166
CHAR_CLIENT_CONFIG_DESCRIPTOR	LE_CM_MSG_LTK_REQ_IND_T, 168
BLE GATT APIs, 43	LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,
CHAR_DECL_UUID16_ATTR_VAL	170
BLE GATT APIs, 44	LE_CM_MSG_READ_PHY_CFM_T, 171
CHAR_EXT_PROP_DESCRIPTOR	LE CM MSG READ RSSI CFM T, 172
BLE GATT APIs, 44	LE_CM_MSG_READ_TX_POWER_CFM_T, 173
CHAR_PRESENT_FORMAT_DESCRIPTOR	LE CM MSG SET DATA LENGTH CFM T,
BLE GATT APIs, 44	174
CHAR_SERVER_CONFIG_DESCRIPTOR	LE_CM_MSG_SET_PHY_CFM_T, 175
BLE GATT APIs, 44	LE CM MSG SIGNAL UPDATE REQ T, 176
CHAR_USER_DESC_DESCRIPTOR	LE_GATT_MSG_ACCESS_READ_IND_T, 183
BLE GATT APIs, 44	LE_GATT_MSG_ACCESS_WRITE_IND_T, 184
CHARACTERISTIC_DECL_UUID128	LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_←
BLE GATT APIs, 44	IND_T, 185
CHARACTERISTIC_DECL_UUID16	LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔
BLE GATT APIs, 45	FO_IND_T, 186
CHARACTERISTIC_UUID128	LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔
BLE GATT APIs, 45	_T, 188
CHARACTERISTIC_UUID16	LE_GATT_MSG_CONFIRMATION_CFM_T, 189
BLE GATT APIs, 45	LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 190
capabilities	
_wpa_ie_data, 147	LE_GATT_MSG_EXCHANGE_MTU_IND_T, 190
auto_conn_info_t, 151	LE_GATT_MSG_EXECUTE_WRITE_RELIABL F. CEM. T. 101
mw_wifi_auto_connect_ap_info_t, 223	E_CFM_T, 191
scan_info_t, 230	LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF↔
wifi_auto_connect_info_t, 239	M_T, 192
wifi_wpa_ie_data_t, 255	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI
capability_info	CE_CFM_T, 193
wifi_scan_info_t, 250	LE_GATT_MSG_FIND_CHARACTERISTIC_CF
ch_map	M_T, 194
LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,	LE_GATT_MSG_FIND_INCLUDED_SERVICE_←
170	CFM_T, 195
channel	LE_GATT_MSG_FIND_PRIMARY_SERVICE_B↔
wifi_ap_config_t, 237	Y_UUID_CFM_T, 196
wifi_event_sta_connected_t, 243	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔
wifi_scan_config_t, 249	ND_T, 197
wifi_scan_info_t, 250	LE_GATT_MSG_INDICATE_IND_T, 198
channel_map	LE_GATT_MSG_NOTIFY_CFM_T, 199
LE_GAP_ADVERTISING_PARAM_T, 178	LE_GATT_MSG_NOTIFY_IND_T, 200
client_rx_mtu	LE_GATT_MSG_OPERATION_TIMEOUT_T, 201
LE_GATT_MSG_EXCHANGE_MTU_IND_T, 190	LE_GATT_MSG_PREPARE_WRITE_RELIABL↔
cmd_type	E_CFM_T, 202
wifi_cmd_t, 240	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔
confirm	_CFM_T, 203
LE_SMP_SC_OOB_DATA_T, 221	LE_GATT_MSG_READ_CHARACTERISTIC_V↔
confirm_num	ALUE_CFM_T, 204
LE_SMP_MSG_USER_CONFIRM_IND_T, 220	${\sf LE_GATT_MSG_READ_LONG_CHAR_VAL_C} {\leftarrow}$

FM_T, 205	LE_GATT_MSG_EXCHANGE_MTU_IND_T, 191
LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔	LE_GATT_MSG_EXECUTE_WRITE_RELIABL←
L_CFM_T, 206	E_CFM_T, 191
LE_GATT_MSG_SERVICE_INFO_IND_T, 208	${\sf LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF} {\leftarrow}$
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 209	M_T, 192
LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔ LE_CFM_T, 210	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔ CE_CFM_T, 193
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔	LE_GATT_MSG_FIND_CHARACTERISTIC_CF
T, 211	M T, 194
LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔	LE_GATT_MSG_FIND_INCLUDED_SERVICE_
E_CFM_T, 212	CFM_T, 195
LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 213	${\sf LE_GATT_MSG_FIND_PRIMARY_SERVICE_B} \leftarrow$
LE_SMP_MSG_ENCRYPTION_CHANGE_IND↔	Y_UUID_CFM_T, 196
_T, 214	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔
LE_SMP_MSG_ENCRYPTION_REFRESH_IND↔	ND_T, 197
_T, 215	LE_GATT_MSG_INDICATE_IND_T, 199
LE_SMP_MSG_OOB_DATA_REQUEST_IND_T,	LE_GATT_MSG_NOTIFY_CFM_T, 200
215	LE_GATT_MSG_NOTIFY_IND_T, 200
LE_SMP_MSG_PAIRING_ACTION_IND_T, 216	LE_GATT_MSG_OPERATION_TIMEOUT_T, 202
LE_SMP_MSG_PAIRING_COMPLETE_IND_T,	${\sf LE_GATT_MSG_PREPARE_WRITe_RELIABL} {\leftarrow}$
217	E_CFM_T, 202
LE_SMP_MSG_PASSKEY_DISPLAY_IND_T, 218	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔
LE_SMP_MSG_PASSKEY_INPUT_IND_T, 218	_CFM_T, 203
LE_SMP_MSG_SC_OOB_DATA_REQUEST_I↔	$LE_GATT_MSG_READ_CHARACTERISTIC_V \!\!\leftarrow\!\!$
ND_T, 219	ALUE_CFM_T, 204
LE_SMP_MSG_SLAVE_SECURITY_REQUES←	${\sf LE_GATT_MSG_READ_LONG_CHAR_VAL_C} \leftarrow$
T_IND_T, 220	FM_T, 205
LE_SMP_MSG_USER_CONFIRM_IND_T, 221	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
LE_SYS_MSG_BUF_OVERFLOW_T, 222	L_CFM_T, 206
conn_interval	LE_GATT_MSG_SERVICE_INFO_IND_T, 208
LE_CM_CONNECTION_COMPLETE_IND_T, 158	LE_GATT_MSG_SIGNED_WRITE_CFM_T, 209
conn_latency	LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔
LE_CM_CONNECTION_COMPLETE_IND_T, 158	LE_CFM_T, 210
connected	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔
wifi_event_info_t, 242	_T, 211
current_rx_mtu	${\sf LE_GATT_MSG_WRITe_LONG_CHAR_VALU} {\leftarrow}$
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 190	E_CFM_T, 212
	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 213
data	direct_addr
LE_CM_MSG_ADVERTISE_REPORT_IND_←	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
T, 160	164
dev_id	direct_addr_type
LE_CM_CONNECTION_COMPLETE_IND_T, 158	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
devid	164
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	disconnected
166	wifi_event_info_t, 242
LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,	dtim_period
166	wifi_scan_info_t, 251
LE_CM_MSG_LTK_REQ_IND_T, 168	dtim_prod
LE_GATT_MSG_ACCESS_READ_IND_T, 183	auto_conn_info_t, 151
LE_GATT_MSG_ACCESS_WRITE_IND_T, 184	mw_wifi_auto_connect_ap_info_t, 223
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_←	scan_info_t, 230
IND_T, 185	wifi_auto_connect_info_t, 239
LE_GATT_MSG_CHARACTERISTIC_DECL_IN←	
FO_IND_T, 186	eap_workaround
LE_GATT_MSG_CHARACTERISTIC_VAL_IND	asso_data, 149
_T, 188	eapol_flags
LE_GATT_MSG_CONFIRMATION_CFM_T, 189	asso_data, 149
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 190	ediv

LE_CM_MSG_LTK_REQ_IND_T, 168	LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_
enable	IND_T, 185
LE_SMP_MSG_ENCRYPTION_CHANGE_IND↔	LE_GATT_MSG_CHARACTERISTIC_DECL_IN
_T, 214	FO_IND_T, 186
enabled LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔ ND T, 198
166	LE_GATT_MSG_SERVICE_INFO_IND_T, 208
LE_CM_MSG_ENCRYPTION_REFRESH_IND_T,	frame_buffer
167	rx_eapol_data, 227
encrypt_type	frame_length
wifi_ap_config_t, 237	rx_eapol_data, 227
end_hdl	free_ocpy
_ LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔	auto_conn_info_t, 152
ND_T, 197	mw_wifi_auto_connect_ap_info_t, 224
LE_GATT_MSG_SERVICE_INFO_IND_T, 208	scan_info_t, 231
endHdl	front
LE_GATT_SERVICE_T, 213	auto_connect_cfg_t, 154
Enumeration, 141	MwFimAutoConnectCFG_t, 226
wifi_auth_mode_t, 141	CAD ADTUDE 120DIT COMDITEE
wifi_bandwidth_t, 143	GAP_ADTYPE_128BIT_COMPLETE BLE GAP APIs, 19
wifi_cipher_type_t, 143	GAP ADTYPE 128BIT MORE
wifi_event_t, 143	BLE GAP APIs, 19
wifi_mode_t, 144	GAP_ADTYPE_16BIT_COMPLETE
wifi_reason_code_t, 144	BLE GAP APIs, 19
wifi_scan_method_t, 145	GAP_ADTYPE_16BIT_MORE
wifi_scan_type_t, 145	BLE GAP APIs, 20
wifi_sort_method_t, 146	GAP_ADTYPE_32BIT_COMPLETE
err_hdl LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔	BLE GAP APIs, 20
E CFM T, 191	GAP ADTYPE 32BIT MORE
LE_GATT_MSG_READ_MULTIPLE_CHAR_VA	BLE GAP APIs, 20
L_CFM_T, 207	GAP_ADTYPE_3D_INFO_DATA
event	BLE GAP APIs, 20
event_msg_t, 155	GAP_ADTYPE_ADV_INTERVAL
event_handler	BLE GAP APIs, 20
wifi_init_config_t, 248	GAP_ADTYPE_APPEARANCE
event_msg_t, 155	BLE GAP APIs, 20
event, 155	GAP_ADTYPE_FLAGS_BREDR_NOT_SUPPORTED
length, 155	BLE GAP APIs, 20
param, 156	GAP_ADTYPE_FLAGS_GENERAL
event_type	BLE GAP APIs, 21
${\sf LE_CM_MSG_ADVERTISE_REPORT_IND_} {\leftarrow}$	GAP_ADTYPE_FLAGS_LIMITED
T, 160	BLE GAP APIS, 21
evt_type	GAP_ADTYPE_FLAGS BLE GAP APIs, 20
wifi_evt_t, 246	GAP_ADTYPE_LE_BD_ADDR
fast_connect	BLE GAP APIs, 21
auto_conn_info_t, 152	GAP_ADTYPE_LE_ROLE
mw_wifi_auto_connect_ap_info_t, 224	BLE GAP APIs, 21
wifi_auto_connect_info_t, 239	GAP_ADTYPE_LOCAL_NAME_COMPLETE
filter_policy	BLE GAP APIs, 21
LE_GAP_ADVERTISING_PARAM_T, 178	GAP_ADTYPE_LOCAL_NAME_SHORT
LE_GAP_SCAN_PARAM_T, 181	BLE GAP APIs, 21
flag	GAP_ADTYPE_MANUFACTURER_SPECIFIC
auto_connect_cfg_t, 154	BLE GAP APIs, 21
LE_GATT_MSG_ACCESS_WRITE_IND_T, 184	GAP_ADTYPE_OOB_CLASS_OF_DEVICE
MwFimAutoConnectCFG_t, 226	BLE GAP APIs, 21
format	GAP_ADTYPE_OOB_SIMPLE_PAIRING_HASHC
LE_GATT_ATTR_T, 182	BLE GAP APIs, 22

GAP_ADTYPE_OOB_SIMPLE_PAIRING_RANDR	GAPBOND_PAIRING_MODE_NO_PAIRING
BLE GAP APIs, 22	BLE GAP APIs, 25
GAP_ADTYPE_POWER_LEVEL	GAPBOND_PAIRING_MODE_WAIT_FOR_REQ
BLE GAP APIs, 22	BLE GAP APIs, 25
GAP_ADTYPE_PUBLIC_TARGET_ADDR	GATT_CHAR_AGG_FORMAT_UUID
BLE GAP APIs, 22	BLE GATT APIs, 45
GAP_ADTYPE_RANDOM_TARGET_ADDR	GATT_CHAR_EXT_PROPS_UUID
BLE GAP APIs, 22	BLE GATT APIs, 45
GAP_ADTYPE_SERVICE_DATA_128BIT	GATT_CHAR_FORMAT_UUID
BLE GAP APIs, 22	BLE GATT APIs, 45
GAP_ADTYPE_SERVICE_DATA_32BIT	GATT CHAR USER DESC UUID
BLE GAP APIs, 22	BLE GATT APIs, 46
GAP_ADTYPE_SERVICE_DATA	GATT_CHARACTERISTIC_UUID
BLE GAP APIs, 22	BLE GATT APIS, 46
GAP_ADTYPE_SERVICES_LIST_128BIT	GATT_CLIENT_CHAR_CFG_UUID
BLE GAP APIs, 23	BLE GATT APIS, 46
GAP_ADTYPE_SERVICES_LIST_16BIT	GATT_EXT_REPORT_REF_UUID
BLE GAP APIs, 23	BLE GATT APIs, 46
GAP_ADTYPE_SIGNED_DATA	GATT_INCLUDE_UUID
BLE GAP APIs, 23	BLE GATT APIs, 46
GAP_ADTYPE_SIMPLE_PAIRING_HASHC_256	GATT_PRIMARY_SERVICE_UUID
BLE GAP APIs, 23	BLE GATT APIs, 46
GAP_ADTYPE_SIMPLE_PAIRING_RANDR_256	GATT_REPORT_REF_UUID
BLE GAP APIs, 23	BLE GATT APIs, 46
GAP_ADTYPE_SLAVE_CONN_INTERVAL_RANGE	GATT_SECONDARY_SERVICE_UUID
BLE GAP APIs, 23	BLE GATT APIs, 46
GAP_ADTYPE_SM_OOB_FLAG	GATT_SERV_CHAR_CFG_UUID
BLE GAP APIs, 23	BLE GATT APIs, 47
GAP_ADTYPE_SM_TK	GATT_VALID_RANGE_UUID
BLE GAP APIs, 23	BLE GATT APIs, 47
GAP_PUBLIC_ADDR	gcCharAggregateUuid
BLE GAP APIs, 24	BLE GATT APIs, 70
GAP_RAND_ADDR_NRPA	gcCharExtPropUuid
BLE GAP APIs, 24	BLE GATT APIs, 70
•	
GAP_RAND_ADDR_RPA	gcCharFormatUuid
BLE GAP APIS, 24	BLE GATT APIs, 71
GAP_RAND_ADDR_STATIC	gcCharUserDescUuid
BLE GAP APIs, 24	BLE GATT APIs, 71
GAP_SCAN_TYPE_ACTIVE	gcCharacteristicUuid
BLE GAP APIs, 24	BLE GATT APIs, 70
GAP_SCAN_TYPE_PASSIVE	gcClientCharConfigUuid
BLE GAP APIs, 24	BLE GATT APIs, 71
GAP_TX_PWR_CURR_VAL	gcExtReportRefUuid
BLE GAP APIs, 24	BLE GATT APIs, 71
GAP_TX_PWR_MAX_VAL	gcIncludeUuid
BLE GAP APIs, 24	BLE GATT APIs, 71
GAPBOND_IO_CAP_DISPLAY_ONLY	gcPrimaryServiceUuid
BLE GAP APIs, 25	BLE GATT APIs, 71
GAPBOND_IO_CAP_DISPLAY_YES_NO	gcReportRefUuid
BLE GAP APIs, 25	BLE GATT APIs, 71
GAPBOND_IO_CAP_KEYBOARD_DISPLAY	gcSecondaryServiceUuid
BLE GAP APIs, 25	BLE GATT APIs, 71
GAPBOND_IO_CAP_KEYBOARD_ONLY	gcServerCharConfigUuid
BLE GAP APIs, 25	BLE GATT APIs, 72
GAPBOND_IO_CAP_NO_INPUT_NO_OUTPUT	gcValidRangeUuid
BLE GAP APIs, 25	BLE GATT APIs, 72
GAPBOND_PAIRING_MODE_INITIATE	got_ip
BLE GAP APIs, 25	wifi_event_info_t, 242

group_cipher	hap_ssid, 157
_wpa_ie_data, 147	hap_en
asso_data, 149	hap_control_t, 156
wifi_scan_info_t, 251	hap_final_index
wifi_wpa_ie_data_t, 255	hap_control_t, 156
handle	hap_index
LE_CM_MSG_SET_DISCONNECT_CFM_T, 175	hap_control_t, 157
LE_GATT_ATTR_T, 182	hap_ssid
LE_GATT_MSG_ACCESS_READ_IND_T, 183	hap_control_t, 157
LE_GATT_MSG_ACCESS_WRITE_IND_T, 184	hid_ssid
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_	auto_conn_info_t, 152
IND T, 185	mw_wifi_auto_connect_ap_info_t, 224
LE_GATT_MSG_CHARACTERISTIC_DECL_IN↔	wifi_auto_connect_info_t, 239
FO_IND_T, 187	hid_ssid_len
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	auto_conn_info_t, 152
T, 188	mw_wifi_auto_connect_ap_info_t, 224
LE GATT MSG CONFIRMATION CFM T, 189	iArgc
LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF↔	T_RfCmd, 233
M T, 192	INCLUDE DECL UUID128
LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔	BLE GATT APIs, 47
CE CFM T, 193	INCLUDE_DECL_UUID128_ATTR_VAL
LE_GATT_MSG_FIND_CHARACTERISTIC_CF↔	BLE GATT APIs, 47
M_T, 194	INCLUDE_DECL_UUID16_ATTR_VAL
LE_GATT_MSG_FIND_INCLUDED_SERVICE_	BLE GATT APIs, 47
CFM_T, 195	INCLUDE_DECL_UUINT16
LE_GATT_MSG_FIND_PRIMARY_SERVICE_B↔	BLE GATT APIs, 47
Y_UUID_CFM_T, 196	identifier
LE_GATT_MSG_INCLUDE_SERVICE_INFO_I ←	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176
ND_T, 198	interval
LE_GATT_MSG_INDICATE_IND_T, 199	LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔
LE_GATT_MSG_NOTIFY_CFM_T, 200	ND_T, 162
LE_GATT_MSG_NOTIFY_IND_T, 201	LE_GAP_SCAN_PARAM_T, 181
LE_GATT_MSG_PREPARE_WRITE_RELIABL↔	interval_max
E_CFM_T, 202	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔	LE_GAP_ADVERTISING_PARAM_T, 179
_CFM_T, 203	LE_GAP_CONN_PARAM_T, 180
${\sf LE_GATT_MSG_READ_CHARACTERISTIC_V} {\leftarrow}$	interval_min
ALUE_CFM_T, 204	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176
${\sf LE_GATT_MSG_READ_LONG_CHAR_VAL_C} {\leftarrow}$	LE_GAP_ADVERTISING_PARAM_T, 179
FM_T, 205	LE_GAP_CONN_PARAM_T, 180
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 209	ip_changed
LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔	wifi_event_sta_got_ip_t, 245
LE_CFM_T, 210	itv_max
LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔	LE_CM_MSG_CONN_PARA_REQ_T, 161
_T, 211	LE_CONN_PARA_T, 177
LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔	itv_min
E_CFM_T, 212	LE_CM_MSG_CONN_PARA_REQ_T, 161
LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 213	LE_CONN_PARA_T, 177
hap_ap_info hap_control_t, 156	kov mamt
hap_bitvector	key_mgmt
hap_control_t, 156	_wpa_ie_data, 147
hap_control_t, 156	asso_data, 149 wifi_wpa_ie_data_t, 256
hap_ap_info, 156	
hap_bitvector, 156	keypress LE_SMP_MSG_SLAVE_SECURITY_REQUES↔
hap_en, 156	T_IND_T, 220
hap_final_index, 156	1_1140_1, 440
hap_index, 157	LE_ATT_MSG_BASE
1 = 1	

BLE MSG APIs, 74	direct_addr_type, 164
LE_ATT_UUID_SIZE	peer_addr, 164
BLE GATT APIs, 47	peer_addr_type, 164
LE_BT_ADDR_T, 157	rssi, 164
addr, 157	LE_CM_MSG_DISCONNECT_COMPLETE_IND_T,
type, 157	164
LE_CM_CONNECTION_COMPLETE_IND_T, 158	conn_hdl, 165
conn_hdl, 158	reason, 165
conn_interval, 158	status, 165 LE CM MSG ENCRYPTION CHANGE IND T, 165
conn_latency, 158	conn_hdl, 165
dev_id, 158 peer_addr, 158	devid, 166
peer_addr_type, 159	enabled, 166
role, 159	status, 166
status, 159	LE_CM_MSG_ENCRYPTION_REFRESH_IND_T, 166
supervison_timeout, 159	conn_hdl, 166
LE_CM_MSG_ADD_TO_RESOLVING_LIST_CFM_T	devid, 166
BLE CM APIs, 11	enabled, 167
LE_CM_MSG_ADD_TO_WHITE_LIST_CFM_T	status, 167
BLE CM APIs, 11	LE_CM_MSG_ENTER_ADVERTISING_CFM_T
LE_CM_MSG_ADVERTISE_REPORT_IND_T, 159	BLE CM APIs, 12
addr, 160	LE CM MSG ENTER SCANNING CFM T
addr_type, 160	BLE CM APIs, 12
data, 160	LE_CM_MSG_EXIT_ADVERTISING_CFM_T
event_type, 160	BLE CM APIs, 12
len, 160	LE_CM_MSG_EXIT_SCANNING_CFM_T
rssi, 160	BLE CM APIs, 12
LE_CM_MSG_BASE	LE_CM_MSG_INIT_COMPLETE_CFM_T, 167
BLE MSG APIs, 74	status, 167
LE_CM_MSG_CANCEL_CONNECTION_CFM_T	LE_CM_MSG_LTK_REQ_IND_T, 167
BLE CM APIs, 11	conn_hdl, 168
LE_CM_MSG_CLEAR_RESOLVING_LIST_CFM_T	devid, 168
BLE CM APIs, 12	ediv, 168
LE_CM_MSG_CLEAR_WHITE_LIST_CFM_T	rand, 168
BLE CM APIs, 12	LE_CM_MSG_PHY_UPDATE_COMPLETE_IND_T
LE_CM_MSG_CONN_PARA_REQ_T, 160	BLE CM APIs, 12
conn_hdl, 161	LE_CM_MSG_READ_ADV_TX_POWER_CFM_T, 168
itv_max, 161	pwr level, 169
itv_min, 161	status, 169
latency, 161	LE_CM_MSG_READ_BD_ADDR_CFM_T, 169
sv_tmo, 161	bd_addr, 169
LE_CM_MSG_CONN_UPDATE_COMPLETE_IND_T,	status, 169
161	LE_CM_MSG_READ_CHANNEL_MAP_CFM_T, 170
conn_hdl, 162	ch_map, 170
interval, 162	conn hdl, 170
latency, 162	status, 170
status, 162	LE_CM_MSG_READ_PHY_CFM_T, 170
supervision_timeout, 162	conn_hdl, 171
LE_CM_MSG_CREATE_CONNECTION_CFM_T	rx_phy, 171
BLE CM APIs, 12	status, 171
LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 162	tx_phy, 171
conn_hdl, 163	${\tt LE_CM_MSG_READ_RESOLVING_LIST_SIZE_CF} \leftarrow$
max_rx_octets, 163	M_T, 171
max_rx_time, 163	size, 171
max_tx_octets, 163	status, 171
max_tx_time, 163	LE_CM_MSG_READ_RSSI_CFM_T, 172
LE_CM_MSG_DIRECT_ADV_REPORT_IND_T, 163	conn_hdl, 172
direct_addr, 164	rssi, 172

ototuo 170	channel map 170
status, 172	channel_map, 178
LE_CM_MSG_READ_TX_POWER_CFM_T, 172	filter_policy, 178
conn_hdl, 173	interval_max, 179
status, 173	interval_min, 179
tx_power, 173	own_addr_type, 179
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM_T,	peer_addr, 179
173	peer_addr_type, 179
size, 173	type, 179
status, 174	LE GAP CONN PARAM T, 179
LE_CM_MSG_REMOVE_FROM_RESOLVING_LIST←	interval_max, 180
_CFM_T	interval_min, 180
BLE CM APIs, 13	latency, 180
LE_CM_MSG_REMOVE_FROM_WHITE_LIST_CFM←	supervision_timeout, 180
T	
_	LE_GAP_SCAN_PARAM_T, 180
BLE CM APIS, 13	filter_policy, 181
LE_CM_MSG_SET_ADVERTISING_DATA_CFM_T	interval, 181
BLE CM APIs, 13	own_addr_type, 181
LE_CM_MSG_SET_ADVERTISING_PARAMS_CFM↔	type, 181
_T	window, 181
BLE CM APIs, 13	LE_GATT_ATTR_T, 181
LE_CM_MSG_SET_CHANNEL_MAP_CFM_T	format, 182
BLE CM APIs, 13	handle, 182
LE_CM_MSG_SET_DATA_LENGTH_CFM_T, 174	len, 182
conn hdl, 174	maxLen, 182
status, 174	pUuid, 182
LE_CM_MSG_SET_DEFAULT_PHY_CFM_T	•
	pVal, 182
BLE CM APIs, 13	permit, 182
LE_CM_MSG_SET_DISCONNECT_CFM_T, 174	LE_GATT_CHAR_PROP_AUTH
handle, 175	BLE GATT APIs, 48
status, 175	LE_GATT_CHAR_PROP_BCAST
LE_CM_MSG_SET_PHY_CFM_T, 175	BLE GATT APIs, 48
conn_hdl, 175	LE_GATT_CHAR_PROP_EXT_PROP
status, 175	BLE GATT APIs, 48
LE_CM_MSG_SET_RANDOM_ADDRESS_CFM_T	LE_GATT_CHAR_PROP_IND
BLE CM APIs, 13	BLE GATT APIs, 48
LE CM MSG SET RPA TIMEOUT CFM T	LE GATT CHAR PROP NTF
BLE CM APIs, 13	BLE GATT APIs, 48
LE_CM_MSG_SET_SCAN_PARAMS_CFM_T	LE GATT CHAR PROP RD
BLE CM APIs, 14	BLE GATT APIs, 48
LE_CM_MSG_SET_SCAN_RSP_DATA_CFM_T	LE_GATT_CHAR_PROP_WR_NO_RESP
BLE CM APIs, 14	BLE GATT APIS, 49
LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176	LE_GATT_CHAR_PROP_WR
conn_hdl, 176	BLE GATT APIs, 48
identifier, 176	LE_GATT_CLIENT_CFG_INDICATION
interval_max, 176	BLE GATT APIs, 49
interval_min, 176	LE_GATT_CLIENT_CFG_NOTIFICATION
slave_latency, 176	BLE GATT APIs, 49
timeout_multiplier, 176	LE_GATT_EXT_PROP_RELIABLE_WR
LE_CM_REQ_STATUS_T, 177	BLE GATT APIs, 49
status, 177	LE_GATT_EXT_PROP_WR_AUX
LE_CONN_PARA_T, 177	BLE GATT APIs, 49
itv_max, 177	LE_GATT_FLAG_PREPARE_WRITE
itv_min, 177	BLE GATT APIS, 49
latency, 178	LE_GATT_FLAG_WRITE_CMD
sv_timeout, 178	BLE GATT APIs, 49
LE_GAP_ADV_MAX_SIZE	LE_GATT_FLAG_WRITE_REQ
BLE GAP APIs, 26	BLE GATT APIs, 49
LE_GAP_ADVERTISING_PARAM_T, 178	LE_GATT_MSG_ACCESS_READ_IND_T, 183

conn_hdl, 183	LE_GATT_MSG_FIND_ALL_CHAR_DESC_CFM_T,
devid, 183	192
handle, 183	att_err, 192
offset, 183	conn_hdl, 192
LE_GATT_MSG_ACCESS_WRITE_IND_T, 183	devid, 192
conn_hdl, 184	handle, 192
devid, 184	status, 193
flag, 184	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVICE_
handle, 184	CFM_T, 193
len, 184	att_err, 193
offset, 184	conn_hdl, 193
pVal, 185	devid, 193
LE_GATT_MSG_BASE	handle, 193
BLE MSG APIs, 74	status, 194
LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_IND_T,	LE_GATT_MSG_FIND_CHARACTERISTIC_CFM_T, 194
185	att_err, 194
conn_hdl, 185	conn_hdl, 194
devid, 185	devid, 194
format, 185	handle, 194
handle, 185	status, 195
uuid, 186	LE_GATT_MSG_FIND_INCLUDED_SERVICE_CFM↔
LE_GATT_MSG_CHARACTERISTIC_DECL_INFO_I ND_T_100	_T, 195
ND_T, 186	att_err, 195
conn_hdl, 186	conn_hdl, 195
devid, 186 format, 186	devid, 195
handle, 187	handle, 195
property, 187	status, 196
uuid, 187	${\sf LE_GATT_MSG_FIND_PRIMARY_SERVICE_BY_U} {\leftarrow}$
val_hdl, 187	UID_CFM_T, 196
LE_GATT_MSG_CHARACTERISTIC_VAL_IND_T, 187	att_err, 196
att_err, 188	conn_hdl, 196
conn_hdl, 188	devid, 196
devid, 188	handle, 196
handle, 188	status, 197
len, 188	LE_GATT_MSG_INCLUDE_SERVICE_INFO_IND_T,
offset, 188	197 conn_hdl, 197
val, 188	devid, 197
LE_GATT_MSG_CONFIRMATION_CFM_T, 189	end_hdl, 197
conn_hdl, 189	format, 198
devid, 189	handle, 198
handle, 189	start_hdl, 198
LE_GATT_MSG_EXCHANGE_MTU_CFM_T, 189	uuid, 198
conn_hdl, 190	LE_GATT_MSG_INDICATE_IND_T, 198
current_rx_mtu, 190	conn hdl, 198
devid, 190	devid, 199
LE_GATT_MSG_EXCHANGE_MTU_IND_T, 190	handle, 199
client_rx_mtu, 190	len, 199
conn_hdl, 190	val, 199
devid, 191	LE_GATT_MSG_NOTIFY_CFM_T, 199
LE_GATT_MSG_EXECUTE_WRITE_RELIABLE_CF↔	conn_hdl, 199
M_T, 191	devid, 200
att_err, 191	handle, 200
conn_hdl, 191	status, 200
devid, 191	LE_GATT_MSG_NOTIFY_IND_T, 200
err_hdl, 191	conn_hdl, 200
status, 192	devid, 200

handle, 201	att_err, 210
len, 201	conn_hdl, 210
val, 201	devid, 210
LE_GATT_MSG_OPERATION_TIMEOUT_T, 201	handle, 210
att_op, 201	status, 210
conn_hdl, 201	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM_T, 210
devid, 202	att_err, 211
LE_GATT_MSG_PREPARE_WRITE_RELIABLE_CF↔	conn_hdl, 211
M T, 202	devid, 211
att_err, 202	handle, 211
conn_hdl, 202	status, 211
devid, 202	LE_GATT_MSG_WRITE_LONG_CHAR_VALUE_CF↔
handle, 202	M_T, 211
	att_err, 212
status, 203	
LE_GATT_MSG_READ_CHAR_VAL_BY_UUID_CF↔	conn_hdl, 212
M_T, 203	devid, 212
att_err, 203	handle, 212
conn_hdl, 203	status, 212
devid, 203	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 212
handle, 203	conn_hdl, 213
status, 204	devid, 213
LE_GATT_MSG_READ_CHARACTERISTIC_VALU←	handle, 213
E_CFM_T, 204	status, 213
att_err, 204	LE_GATT_PERM_AUTH_READABLE
conn_hdl, 204	BLE GATT APIs, 50
devid, 204	LE_GATT_PERM_AUTH_WRITABLE
handle, 204	BLE GATT APIs, 50
status, 205	LE_GATT_PERM_NONE
LE_GATT_MSG_READ_LONG_CHAR_VAL_CFM_T,	BLE GATT APIs, 50
205	LE_GATT_PERM_READ
att_err, 205	BLE GATT APIs, 50
conn_hdl, 205	LE_GATT_PERM_RELIABLE_WRITE
devid, 205	BLE GATT APIs, 50
handle, 205	LE_GATT_PERM_WRITE_CMD
status, 206	BLE GATT APIs, 50
LE_GATT_MSG_READ_MULTIPLE_CHAR_VAL_C↔	LE_GATT_PERM_WRITE_REQ
FM_T, 206	BLE GATT APIs, 50
att_err, 206	LE_GATT_PERMIT_AUTHEN_READ
conn_hdl, 206	BLE GATT APIs, 50
devid, 206	LE_GATT_PERMIT_AUTHEN_WRITE
err_hdl, 207	BLE GATT APIs, 51
len, 207	LE_GATT_PERMIT_AUTHOR_READ
status, 207	BLE GATT APIs, 51
val, 207	LE GATT PERMIT AUTHOR WRITE
LE_GATT_MSG_SERVICE_INFO_IND_T, 207	BLE GATT APIs, 51
conn_hdl, 208	LE_GATT_PERMIT_ENCRYPT_READ
devid, 208	BLE GATT APIs, 51
end_hdl, 208	LE GATT PERMIT ENCRYPT WRITE
format, 208	BLE GATT APIs, 51
start_hdl, 208	LE_GATT_PERMIT_READABLE
uuid, 208	BLE GATT APIs, 51
LE_GATT_MSG_SIGNED_WRITE_CFM_T, 208	LE_GATT_PERMIT_READ
conn_hdl, 209	BLE GATT PERMIT SC AUTHEN PEAD
devid, 209	LE_GATT_PERMIT_SC_AUTHEN_READ
handle, 209	BLE GATT APIS, 51
status, 209	LE_GATT_PERMIT_SC_AUTHEN_WRITE
LE_GATT_MSG_WRITE_CHAR_VAL_RELIABLE_C↔	BLE GATT APIS, 52
FM_T, 209	LE_GATT_PERMIT_WRITABLE

BLE GATT APIs, 52	status, 217
LE_GATT_PERMIT_WRITE	LE_SMP_MSG_PASSKEY_DISPLAY_IND_T, 218
BLE GATT APIs, 52	conn_hdl, 218
LE_GATT_SERVICE_T, 213	passkey, 218
endHdl, 213	LE_SMP_MSG_PASSKEY_INPUT_IND_T, 218
pAttr, 214	conn_hdl, 218
startHdl, 214	LE_SMP_MSG_SC_OOB_DATA_REQUEST_IND_T,
svc_id, 214	219
LE_HCI_MSG_BASE	conn_hdl, 219
BLE MSG APIs, 75	LE_SMP_MSG_SLAVE_SECURITY_REQUEST_IN↔
LE_L2CAP_MSG_BASE	D_T, 219
BLE MSG APIs, 75	bondable, 219
LE_MAX_BOND_COUNT	conn_hdl, 220
BLE SMP APIs, 86	keypress, 220
LE_SM_IO_CAP_DISP_ONLY	mitm, 220
BLE SMP APIs, 86	sc, 220
LE_SM_IO_CAP_DISP_YES_NO	LE_SMP_MSG_USER_CONFIRM_IND_T, 220
BLE SMP APIs, 86	confirm_num, 220
LE_SM_IO_CAP_KEYBOARD_DISP	conn_hdl, 221
BLE SMP APIs, 86	LE_SMP_SC_OOB_DATA_T, 221
LE_SM_IO_CAP_KEYBOARD_ONLY	confirm, 221
BLE SMP APIs, 87	rand, 221
LE_SM_IO_CAP_NO_IO	LE_SYS_MSG_BASE
BLE SMP APIs, 87	BLE MSG APIs, 75
LE_SM_PAIR_MITM_NO	LE_SYS_MSG_BUF_OVERFLOW_T, 221
BLE SMP APIs, 87	conn_hdl, 222
LE_SM_PAIR_MITM_YES	latency
BLE SMP APIs, 87	LE_CM_MSG_CONN_PARA_REQ_T, 161
LE_SM_PAIR_OOB_NO	LE_CM_MSG_CONN_UPDATE_COMPLETE_I ND_T_100
BLE SMP APIs, 87	ND_T, 162
LE_SM_PAIR_OOB_YES	LE_CONN_PARA_T, 178
BLE SMP APIs, 87	LE_GAP_CONN_PARAM_T, 180
LE_SM_PAIR_SC_NO	latest_beacon_rx_time
BLE SMP APIs, 87	auto_conn_info_t, 152
LE_SM_PAIR_SC_YES	mw_wifi_auto_connect_ap_info_t, 224
BLE SMP APIs, 87	scan_info_t, 231
LE_SMP_MSG_BASE	LeCancelAllMessage
BLE MSG APIs, 75	BLE MSG APIs, 78
LE_SMP_MSG_ENCRYPTION_CHANGE_IND_T, 214	LeCancelAllSubMessage
conn_hdl, 214	BLE MSG APIs, 79
enable, 214	LeCancelFirstMessage
LE_SMP_MSG_ENCRYPTION_REFRESH_IND_T,	BLE MSG APIs, 79
215	LeCancelFirstSubMessage
conn_hdl, 215	BLE MSG APIs, 79
status, 215	LeCmInit
LE_SMP_MSG_OOB_DATA_REQUEST_IND_T, 215	BLE CM APIs, 15
conn_hdl, 215	LeGapAddToResolvingList BLE GAP APIs, 26
LE_SMP_MSG_PAIRING_ACTION_IND_T, 216	LeGapAddToWhiteList
action, 216	BLE GAP APIs, 26
conn_hdl, 216	
lost_bond, 216	LeGapAdvertisingEnable BLE GAP APIs, 27
SC, 216	
LE_SMP_MSG_PAIRING_COMPLETE_IND_T, 217	LeGapCentralConnectReq BLE GAP APIs, 27
authenticated, 217 bonded, 217	
	LeGapCentralSetDataChannel BLE GAP APIs, 27
conn_hdl, 217 peer_id_addr, 217	LeGapClearResolvingList
	BLE GAP APIs, 29
sc, 217	DLE GAF AFIS, 43

LeGapClearWhiteList	LeGattCharValConfirmation
BLE GAP APIs, 29	BLE GATT APIs, 55
LeGapConnParaRequestRsp	LeGattCharValIndicate
BLE GAP APIs, 29	BLE GATT APIs, 56
LeGapConnUpdateRequest	LeGattCharValNotify
BLE GAP APIs, 30	BLE GATT APIs, 56
LeGapConnUpdateResponse	LeGattExchangeMtuReq
BLE GAP APIs, 30	BLE GATT APIs, 57
LeGapConnectCancelReq	LeGattExchangeMtuRsp
BLE GAP APIs, 29	BLE GATT APIs, 57
LeGapDisconnectReq	LeGattExecuteWriteCharValReliable
BLE GAP APIs, 31	BLE GATT APIs, 57
LeGapGenRandAddr	LeGattFindAllCharDescriptor
BLE GAP APIs, 31	BLE GATT APIs, 58
LeGapGetBtAddr	LeGattFindAllCharacteristic
BLE GAP APIs, 31	BLE GATT APIs, 58
LeGapReadAdvChannelTxPower	LeGattFindAllPrimaryService
BLE GAP APIs, 31	BLE GATT APIs, 59
LeGapReadChannelMap	LeGattFindCharacteristicByUuid
BLE GAP APIs, 32	BLE GATT APIs, 59
LeGapReadPhy	LeGattFindIncludedService
BLE GAP APIs, 32	BLE GATT APIs, 60
LeGapReadResolvingListSize	LeGattFindPrimaryServiceByUuid
BLE GAP APIs, 32	BLE GATT APIs, 60
LeGapReadRssi	LeGattGetAttrHandle
BLE GAP APIs, 32	BLE GATT APIs, 60
LeGapReadTxPower	LeGattGetAttrVal
BLE GAP APIs, 33	BLE GATT APIs, 61
LeGapReadWhiteListSize	LeGattGetAttrValLen
BLE GAP APIs, 33	BLE GATT APIs, 61
LeGapRemoveFromWhiteList	LeGattGetAttrValMaxLen
BLE GAP APIs, 33	BLE GATT APIs, 63
LeGapScanningReq	LeGattInit
BLE GAP APIs, 34	BLE GATT APIs, 63
LeGapSetAdvData	LeGattModifyAttrVal
BLE GAP APIs, 34	BLE GATT APIs, 64
LeGapSetAdvParameter	LeGattPrepareWriteCharValReliable
BLE GAP APIs, 35	BLE GATT APIs, 64
LeGapSetConnParameter	LeGattReadCharValByUuid
BLE GAP APIs, 35	BLE GATT APIs, 65
LeGapSetDataChannelPduLen	LeGattReadCharValue
BLE GAP APIs, 35	BLE GATT APIs, 65
LeGapSetDefaultPhy	LeGattReadLongCharVal
BLE GAP APIs, 36	BLE GATT APIs, 66
LeGapSetPhy	LeGattReadMultipleCharVal
BLE GAP APIs, 36	BLE GATT APIs, 66
LeGapSetRandAddr	LeGattRegisterIncludeService
BLE GAP APIs, 36	BLE GATT APIs, 66
LeGapSetRpaTimeout	
·	LeGattRegisterService
BLE GAP APIs, 37	BLE GATT APIs, 67
LeGapSetStaticAddr	LeGattSignedWriteNoRsp
BLE GAP APIs, 37	BLE GATT APIs, 67
LeGattAccessReadRsp	LeGattStopCurrentProcedure
BLE GATT APIs, 54	BLE GATT APIs, 68
LeGattAccessWriteRsp	LeGattWriteCharVal
BLE GATT APIs, 54	BLE GATT APIs, 68
LeGattChangeAttrVal	LeGattWriteCharValReliable
BLE GATT APIs, 55	BLE GATT APIs, 69

LeGattWriteLongCharVal	LE_GATT_MSG_NOTIFY_IND_T, 201
BLE GATT APIs, 69	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
LeGattWriteNoRsp	L_CFM_T, 207
BLE GATT APIs, 70	length
LeGetSubMsgld	event_msg_t, 155
BLE MSG APIs, 80	lost_bond
LeHostCreateTask	LE_SMP_MSG_PAIRING_ACTION_IND_T, 216
BLE MSG APIs, 80	
LeHostMessageLoop	MESSAGE_ALLOCATE
BLE MSG APIs, 81	BLE MSG APIs, 75
LeSendMessage	MESSAGE_BULID
	BLE MSG APIs, 75
BLE MSG APIs, 81	MESSAGE_DATA_BULID
LeSendMessageAfter	BLE MSG APIs, 75
BLE MSG APIs, 81	MESSAGE OFFSET
LeSendMessageUnlock	BLE MSG APIs, 76
BLE MSG APIs, 82	MESSAGEID
LeSendSubMessage	BLE MSG APIs, 76
BLE MSG APIs, 82	MESSAGE
LeSendSubMessageAfter	BLE MSG APIs, 76
BLE MSG APIs, 83	MSGLOCK
LeSendSubMessageUnlock	
BLE MSG APIs, 83	BLE MSG APIs, 77
LeSetScanParameter	MSGSUBID
BLE GAP APIs, 37	BLE MSG APIs, 77
LeSetScanRspData	MSGTIMER
BLE GAP APIs, 38	BLE MSG APIs, 77
LeSmpGetBondIdFromAddr	magic
BLE ALL APIs, 9	wifi_init_config_t, 248
	manufacture_name
LeSmpInit	mw_blewifi_cbs_store_t, 222
BLE SMP APIs, 89	max
LeSmpOobAuthDataRsp	wifi_active_scan_time_t, 236
BLE SMP APIs, 89	max_connection
LeSmpOobPresent	wifi_ap_config_t, 237
BLE SMP APIs, 89	max rx octets
LeSmpPasskeyInput	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 163
BLE SMP APIs, 90	max_rx_time
LeSmpScOobComputeConfirmVal	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 163
BLE SMP APIs, 90	max save num
LeSmpScOobDataRsp	auto_connect_cfg_t, 154
BLE SMP APIs, 90	MwFimAutoConnectCFG t, 227
LeSmpSecurityReq	max_tx_octets
BLE SMP APIs, 91	LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 163
LeSmpSecurityRsp	
BLE SMP APIs, 91	max_tx_time LE_CM_MSG_DATA_LEN_CHANGE_IND_T, 163
LeSmpSetDefaultConfig	
BLE SMP APIs, 92	maxLen
LeSmpUserConfirmRsp	LE_GATT_ATTR_T, 182
·	mgmt_group_cipher
BLE SMP APIs, 92	_wpa_ie_data, 148
leap	asso_data, 149
asso_data, 149	wifi_wpa_ie_data_t, 256
len	min
$LE_CM_MSG_ADVERTISE_REPORT_IND_{\leftarrow}$	wifi_active_scan_time_t, 236
T, 160	mitm
LE_GATT_ATTR_T, 182	LE_SMP_MSG_SLAVE_SECURITY_REQUES↔
LE_GATT_MSG_ACCESS_WRITE_IND_T, 184	T_IND_T, 220
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	MsgData
	BLE MSG APIs, 77
LE_GATT_MSG_INDICATE_IND_T, 199	MsgLock

BLE MSG APIs, 77	BLE GATT APIs, 52
mw blewifi cbs store t, 222	PRIMARY_SERVICE_DECL_UUID16
manufacture_name, 222	BLE GATT APIs, 52
mw_wifi_auto_connect_ap_info_t, 222	pScanInfo
ap_channel, 223	scan_report_t, 232
beacon_interval, 223	pUuid
bssid, 223	•
capabilities, 223	LE_GATT_ATTR_T, 182
•	pVal
dtim_prod, 223	LE_GATT_ATTR_T, 182
fast_connect, 224	LE_GATT_MSG_ACCESS_WRITE_IND_T, 185
free_ocpy, 224	pairwise_cipher
hid_ssid, 224	_wpa_ie_data, 148
hid_ssid_len, 224	asso_data, 150
latest_beacon_rx_time, 224	wifi_scan_info_t, 251
passphrase, 224	wifi_wpa_ie_data_t, 256
psk, 224	param
rsn_ie, 224	event_msg_t, 156
rssi, 225	passive
ssid, 225	wifi_scan_time_t, 253
ssid_len, 225	passkey
supported_rates, 225	LE SMP MSG PASSKEY DISPLAY IND T, 218
wpa_data, 225	passphrase
wpa_ie, 225	asso_data, 150
mw_wifi_sta_info_t, 225	auto_conn_info_t, 152
au8Dot11MACAddress, 226	
u8SkipDtimPeriods, 226	mw_wifi_auto_connect_ap_info_t, 224
MwFimAutoConnectCFG_t, 226	password
flag, 226	wifi_ap_config_t, 237
front, 226	wifi_sta_config_t, 254
max_save_num, 227	password_length
rear, 227	wifi_ap_config_t, 237
	wifi_sta_config_t, 254
targetldx, 227	peer_addr
non_leap	LE_CM_CONNECTION_COMPLETE_IND_T, 158
asso_data, 150	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
	164
num	LE_GAP_ADVERTISING_PARAM_T, 179
wifi_scan_list_t, 252	peer_addr_type
num_pmkid	LE_CM_CONNECTION_COMPLETE_IND_T, 159
_wpa_ie_data, 148	LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,
wifi_wpa_ie_data_t, 256	164
number	LE_GAP_ADVERTISING_PARAM_T, 179
wifi_event_sta_scan_done_t, 245	peer_id_addr
	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
offset	217
LE_GATT_MSG_ACCESS_READ_IND_T, 183	permit
LE_GATT_MSG_ACCESS_WRITE_IND_T, 184	•
LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔	LE_GATT_ATTR_T, 182
_T, 188	pmkid
own_addr_type	_wpa_ie_data, 148
LE_GAP_ADVERTISING_PARAM_T, 179	wifi_wpa_ie_data_t, 256
LE_GAP_SCAN_PARAM_T, 181	property
	LE_GATT_MSG_CHARACTERISTIC_DECL_IN←
pAttr	FO_IND_T, 187
LE_GATT_SERVICE_T, 214	proto
pFCInfo	_wpa_ie_data, 148
auto_connect_cfg_t, 154	asso_data, 150
pParam	wifi_wpa_ie_data_t, 256
T_RfEvt, 233	prvData
PRIMARY_SERVICE_DECL_UUID128	wifi_cmd_t, 240
_ _ _ _	

wifi_evt_t, 246	u8aBssid, 229
psk	u8aSsid, 229
asso_data, 150	SECONDARY_SERVICE_DECL_UUID128
auto_conn_info_t, 152	BLE GATT APIs, 52
mw_wifi_auto_connect_ap_info_t, 224	SECONDARY_SERVICE_DECL_UUID16
psk_set	BLE GATT APIs, 52
asso_data, 150	saArgv
ptScanReport	T_RfCmd, 233
S_WIFI_MLME_SCAN_CFG, 228	SC
pwr_level	LE_SMP_MSG_PAIRING_ACTION_IND_T, 216
LE_CM_MSG_READ_ADV_TX_POWER_CFM↔	LE SMP MSG PAIRING COMPLETE IND T,
_T, 169	
_1, 109	217
rand	LE_SMP_MSG_SLAVE_SECURITY_REQUES↔
	T_IND_T, 220
LE_CM_MSG_LTK_REQ_IND_T, 168	scan_done
LE_SMP_SC_OOB_DATA_T, 221	wifi_event_info_t, 242
rear	scan id
auto_connect_cfg_t, 154	wifi_event_sta_scan_done_t, 246
MwFimAutoConnectCFG_t, 227	scan_info_t, 229
reason	ap channel, 230
LE_CM_MSG_DISCONNECT_COMPLETE_IN↔	· -
D_T, 165	beacon_interval, 230
wifi_event_sta_disconnected_t, 244	bssid, 230
	capabilities, 230
reserved	dtim_prod, 230
wifi_cmd_t, 241	free_ocpy, 231
retryCount	latest_beacon_rx_time, 231
auto_connect_cfg_t, 154	rsn_ie, 231
role	
LE_CM_CONNECTION_COMPLETE_IND_T, 159	rssi, 231
rsn_ie	ssid, 231
auto_conn_info_t, 152	ssid_len, 231
mw_wifi_auto_connect_ap_info_t, 224	supported_rates, 231
	wpa_data, 231
scan_info_t, 231	wpa_ie, 232
rssi	scan_method
auto_conn_info_t, 153	wifi_sta_config_t, 254
LE_CM_MSG_ADVERTISE_REPORT_IND_←	scan_report_t, 232
T, 160	pScanInfo, 232
LE_CM_MSG_DIRECT_ADV_REPORT_IND_T,	uScanApNum, 232
164	•
LE_CM_MSG_READ_RSSI_CFM_T, 172	scan_time
mw_wifi_auto_connect_ap_info_t, 225	wifi_scan_config_t, 249
scan_info_t, 231	scan_type
wifi_auto_connect_info_t, 239	wifi_scan_config_t, 249
wifi_fast_scan_threshold_t, 247	show_hidden
	wifi_scan_config_t, 249
wifi_scan_info_t, 251	size
rx_eapol_data, 227	LE_CM_MSG_READ_RESOLVING_LIST_SIZE↔
frame_buffer, 227	
frame_length, 227	_CFM_T, 171
rx_phy	LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM↔
LE_CM_MSG_READ_PHY_CFM_T, 171	_T, 173
	slave_latency
S_WIFI_MLME_SCAN_CFG, 228	LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176
ptScanReport, 228	sort_method
tScanType, 228	wifi_sta_config_t, 254
u32ActiveScanDur, 228	ssid
u32PassiveScanDur, 228	auto_conn_info_t, 153
u8Channel, 229	mw_wifi_auto_connect_ap_info_t, 225
u8MaxScanApNum, 229	scan_info_t, 231
u8ResendCnt, 229	wifi_ap_config_t, 238

wifi_auto_connect_info_t, 240	LE_GATT_MSG_FIND_ALL_PRIMARY_SERVI↔
wifi_event_sta_connected_t, 243	CE_CFM_T, 194
wifi_event_sta_disconnected_t, 244	LE_GATT_MSG_FIND_CHARACTERISTIC_CF↔
wifi_scan_config_t, 249	M_T, 195
wifi_scan_info_t, 251	${\sf LE_GATT_MSG_FIND_INCLUDED_SERVICE_} {\leftarrow}$
wifi_sta_config_t, 254	CFM_T, 196
ssid hidden	LE_GATT_MSG_FIND_PRIMARY_SERVICE_B↔
wifi_ap_config_t, 238	Y_UUID_CFM_T, 197
ssid len	LE_GATT_MSG_NOTIFY_CFM_T, 200
auto_conn_info_t, 153	LE_GATT_MSG_PREPARE_WRITE_RELIABL←
mw_wifi_auto_connect_ap_info_t, 225	E_CFM_T, 203
scan_info_t, 231	LE_GATT_MSG_READ_CHAR_VAL_BY_UUID↔
wifi_event_sta_connected_t, 243	_CFM_T, 204
wifi_event_sta_disconnected_t, 244	LE_GATT_MSG_READ_CHARACTERISTIC_V↔
ssid_length	ALUE_CFM_T, 205
wifi_ap_config_t, 238	LE_GATT_MSG_READ_LONG_CHAR_VAL_C↔
wifi scan info t, 251	FM_T, 206
wifi_sta_config_t, 254	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
sta_config	L_CFM_T, 207
wifi_config_t, 241	LE_GATT_MSG_SIGNED_WRITE_CFM_T, 209
start_hdl	LE_GATT_MSG_WRITE_CHAR_VAL_RELIAB↔
LE_GATT_MSG_INCLUDE_SERVICE_INFO_I←	LE_CFM_T, 210
ND T, 198	LE_GATT_MSG_WRITE_CHAR_VALUE_CFM↔
LE_GATT_MSG_SERVICE_INFO_IND_T, 208	_T, 211
startHdl	LE_GATT_MSG_WRITE_LONG_CHAR_VALU↔
LE_GATT_SERVICE_T, 214	E_CFM_T, 212
status	LE_GATT_MSG_WRITE_NO_RSP_CFM_T, 213
LE_CM_CONNECTION_COMPLETE_IND_T, 159	${\sf LE_SMP_MSG_ENCRYPTION_REFRESH_IND} {\leftarrow}$
LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔	_T, 215
ND T, 162	LE_SMP_MSG_PAIRING_COMPLETE_IND_T,
LE_CM_MSG_DISCONNECT_COMPLETE_IN←	217
D_T, 165	wifi_event_sta_scan_done_t, 246
LE_CM_MSG_ENCRYPTION_CHANGE_IND_T,	supervision_timeout
166	LE_CM_MSG_CONN_UPDATE_COMPLETE_I↔
LE CM MSG ENCRYPTION REFRESH IND T,	ND_T, 162
167	LE_GAP_CONN_PARAM_T, 180
LE_CM_MSG_INIT_COMPLETE_CFM_T, 167	supervison_timeout
LE_CM_MSG_READ_ADV_TX_POWER_CFM↔	LE_CM_CONNECTION_COMPLETE_IND_T, 159
_T, 169	supported_rates
LE CM MSG READ BD ADDR CFM T, 169	auto_conn_info_t, 153
LE_CM_MSG_READ_CHANNEL_MAP_CFM_T,	mw_wifi_auto_connect_ap_info_t, 225
170	scan_info_t, 231
LE_CM_MSG_READ_PHY_CFM_T, 171	wifi_auto_connect_info_t, 240
LE_CM_MSG_READ_RESOLVING_LIST_SIZE←	sv_timeout
_CFM_T, 171	LE_CONN_PARA_T, 178
LE_CM_MSG_READ_RSSI_CFM_T, 172	sv_tmo
LE_CM_MSG_READ_TX_POWER_CFM_T, 173	LE_CM_MSG_CONN_PARA_REQ_T, 161
LE_CM_MSG_READ_WHITE_LIST_SIZE_CFM↔	svc_id
T, 174	LE_GATT_SERVICE_T, 214
LE_CM_MSG_SET_DATA_LENGTH_CFM_T,	T HOUR
174	BLE MSG APIs, 76
LE_CM_MSG_SET_DISCONNECT_CFM_T, 175	T MIN
LE_CM_MSG_SET_PHY_CFM_T, 175	BLE MSG APIs, 76
LE_CM_REQ_STATUS_T, 177	T_RfCmd, 232
LE_GATT_MSG_EXECUTE_WRITE_RELIABL↔	iArgc, 233
E CFM T, 192	saArgv, 233
LE_GATT_MSG_FIND_ALL_CHAR_DESC_CF↔	u32Type, 233
M_T, 193	T_RfEvt, 233
IVI_1, 100	

pParam, 233	u32Type
u16RfMode, 234	T_RfCmd, 233
u16RxCnt, 234	T_RfEvt, 234
u16RxCrcOkCnt, 234	u8Channel
u32Freq, 234	S_WIFI_MLME_SCAN_CFG, 229
u32Mode, 234	u8Freq
u32RfChannel, 234	T_RfEvt, 234
u32Type, 234	u8lpcEnable
u8Freq, 234	T_RfEvt, 235
u8lpcEnable, 235	u8Len
u8Len, <mark>235</mark>	T_RfEvt, 235
u8Pkt, 235	u8MaxScanApNum
u8Reserved, 235	S WIFI MLME SCAN CFG, 229
u8Status, 235	
	u8Pkt
u8Unicast, 235	T_RfEvt, 235
T_SEC	u8ResendCnt
BLE MSG APIs, 76	S_WIFI_MLME_SCAN_CFG, 229
TASKHANDLER	u8Reserved
BLE MSG APIs, 77	T_RfEvt, 235
TASKPACK	u8SkipDtimPeriods
BLE MSG APIs, 78	mw_wifi_sta_info_t, 226
TASK	u8Status
BLE MSG APIs, 77	T RfEvt, 235
•	-
tScanType	u8Unicast
S_WIFI_MLME_SCAN_CFG, 228	T_RfEvt, 235
targetldx	u8aBssid
auto_connect_cfg_t, 155	S_WIFI_MLME_SCAN_CFG, 229
MwFimAutoConnectCFG_t, 227	u8aSsid
Task	S_WIFI_MLME_SCAN_CFG, 229
BLE MSG APIs, 77	uFCApNum
threshold	auto_connect_cfg_t, 155
wifi_sta_config_t, 255	uScanApNum
- _	•
timeout_multiplier	scan_report_t, 232
LE_CM_MSG_SIGNAL_UPDATE_REQ_T, 176	uuid
tx_phy	LE_GATT_MSG_CHAR_DESCRIPTOR_INFO_←
LE_CM_MSG_READ_PHY_CFM_T, 171	IND_T, 186
tx_power	LE GATT MSG CHARACTERISTIC DECL IN↔
LE_CM_MSG_READ_TX_POWER_CFM_T, 173	FO_IND_T, 187
type	LE_GATT_MSG_INCLUDE_SERVICE_INFO_I↔
LE_BT_ADDR_T, 157	ND_T, 198
LE_GAP_ADVERTISING_PARAM_T, 179	LE_GATT_MSG_SERVICE_INFO_IND_T, 208
LE_GAP_SCAN_PARAM_T, 181	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
LL_GAI _OOAN_I AIIAW_I, TOT	val
u1CDfMada	
u16RfMode	LE_GATT_MSG_CHARACTERISTIC_VAL_IND↔
T_RfEvt, 234	_T, 188
u16RxCnt	LE GATT MSG INDICATE IND T, 199
T_RfEvt, 234	LE_GATT_MSG_NOTIFY_IND_T, 201
u16RxCrcOkCnt	
	LE_GATT_MSG_READ_MULTIPLE_CHAR_VA↔
T_RfEvt, 234	L_CFM_T, 207
u32ActiveScanDur	val_hdl
S_WIFI_MLME_SCAN_CFG, 228	LE_GATT_MSG_CHARACTERISTIC_DECL_IN←
u32Freq	FO IND T, 187
T_RfEvt, 234	10_1110_1, 107
	WIELADI- 00
u32Mode	WIFI APIs, 93
T_RfEvt, 234	WIFI_BEACON_INTERVAL_LENGTH, 94
u32PassiveScanDur	WIFI_CAPABILITY_INFO_LENGTH, 94
S_WIFI_MLME_SCAN_CFG, 228	WIFI LENGTH 802 11, 95
u32RfChannel	WIFI LENGTH PASSPHRASE, 95
	-
T_RfEvt, 234	WIFI_MAC_ADDRESS_LENGTH, 95

	WIFI_MAX_LENGTH_OF_SSID, 95	wifi_config_get_listen_interval_fp_t, 108
	WIFI_MAX_SCAN_AP_NUM, 95	wifi_config_get_mac_address, 119
	WIFI_MAX_SUPPORTED_RATES, 95	wifi_config_get_mac_address_api, 136
	wifi_ap_record_t, 96	wifi_config_get_mac_address_fp_t, 108
	wifi_auto_connet_mode_e, 96	wifi_config_get_opmode, 120
	wifi_event_notify_cb_t, 96	wifi_config_get_opmode_api, 136
	wifi_event_process_handler, 96	wifi_config_get_opmode_fp_t, 108
	wifi_install_default_event_handlers, 97	wifi_config_get_skip_dtim, 120
	wifi_register_event_handler, 97	wifi_config_get_ssid, 120
WIF	Common APIs, 99	wifi_config_get_ssid_api, 136
	wifi_event_cb_t, 99	wifi_config_get_ssid_fp_t, 108
	wifi event loop init, 99	wifi_config_set_bandwidth, 121
	wifi_event_loop_send, 100	
	wifi_event_loop_set_cb, 100	wifi_config_set_bandwidth_api, 137
	wifi_event_process_handler, 101	wifi_config_set_bandwidth_fp_t, 108
\ \ /I⊏I	STA APIs, 102	wifi_config_set_bssid, 121
VVII		wifi_config_set_bssid_api, 137
	WIFI_READY_TIME, 106	wifi_config_set_bssid_fp_t, 108
	wifi_auto_connect_clear_ap_info, 113	wifi_config_set_channel, 121
	wifi_auto_connect_clear_ap_info_api, 134	wifi_config_set_channel_api, 137
	wifi_auto_connect_clear_ap_info_fp_t, 106	wifi config set channel fp t, 108
	wifi_auto_connect_get_ap_info, 114	wifi_config_set_dtim_interval, 122
	wifi_auto_connect_get_ap_info_api, 135	wifi_config_set_dtim_interval_api, 137
	wifi_auto_connect_get_ap_info_fp_t, 106	wifi_config_set_dtim_interval_fp_t, 108
	wifi_auto_connect_get_ap_num, 114	wifi_config_set_listen_interval, 122
	wifi_auto_connect_get_ap_num_api, 135	
	wifi_auto_connect_get_ap_num_fp_t, 106	wifi_config_set_listen_interval_api, 137
	wifi_auto_connect_get_mode, 115	wifi_config_set_listen_interval_fp_t, 109
	wifi_auto_connect_get_mode_api, 135	wifi_config_set_mac_address, 122
	wifi_auto_connect_get_mode_fp_t, 106	wifi_config_set_mac_address_api, 137
	wifi_auto_connect_init, 115	wifi_config_set_mac_address_fp_t, 109
	wifi_auto_connect_init_api, 135	wifi_config_set_opmode, 123
	wifi_auto_connect_init_fp_t, 106	wifi_config_set_opmode_api, 137
	wifi_auto_connect_reset, 115	wifi_config_set_opmode_fp_t, 109
		wifi_config_set_skip_dtim, 123
	wifi_auto_connect_reset_api, 135	wifi_config_set_ssid, 123
	wifi_auto_connect_reset_fp_t, 107	wifi_config_set_ssid_api, 137
	wifi_auto_connect_set_ap_num, 116	wifi_config_set_ssid_fp_t, 109
	wifi_auto_connect_set_ap_num_api, 135	wifi_connection_connect, 124
	wifi_auto_connect_set_ap_num_fp_t, 107	wifi_connection_connect_api, 138
	wifi_auto_connect_set_mode, 116	
	wifi_auto_connect_set_mode_api, 135	wifi_connection_connect_fp_t, 109
	wifi_auto_connect_set_mode_fp_t, 107	wifi_connection_connect_from_ac_index, 124
	wifi_auto_connect_start, 117	wifi_connection_connect_from_ac_list, 125
	wifi_auto_connect_start_api, 135	wifi_connection_disconnect_ap, 125
	wifi_auto_connect_start_fp_t, 107	wifi_connection_disconnect_ap_api, 138
	wifi_config_get_bandwidth, 117	wifi_connection_disconnect_ap_fp_t, 109
	wifi_config_get_bandwidth_api, 136	wifi_connection_disconnect_sta, 126
	wifi config get bandwidth fp t, 107	wifi_connection_disconnect_sta_api, 138
	wifi_config_get_bssid, 118	wifi connection disconnect sta fp t, 109
	wifi_config_get_bssid_api, 136	wifi_connection_get_rssi, 126
	wifi_config_get_bssid_fp_t, 107	wifi_connection_get_rssi_api, 138
		wifi_connection_get_rssi_fp_t, 110
	wifi_config_get_channel, 118	.
	wifi_config_get_channel_api, 136	wifi_connection_register_event_handler, 127
	wifi_config_get_channel_fp_t, 107	wifi_connection_register_event_handler_api, 138
	wifi_config_get_dtim_interval, 119	wifi_connection_register_event_handler_fp_t, 110
	wifi_config_get_dtim_interval_api, 136	wifi_connection_scan_start, 127
	wifi_config_get_dtim_interval_fp_t, 107	wifi_connection_scan_start_api, 138
	wifi_config_get_listen_interval, 119	wifi_connection_scan_start_fp_t, 110
	wifi config get listen interval api. 136	wifi connection unregister event handler, 127

	MUELADI- 04
wifi_connection_unregister_event_handler_api,	WIFI APIs, 94
138	WIFI_LENGTH_802_11
wifi_connection_unregister_event_handler_fp_t,	WIFI APIs, 95
110	WIFI_LENGTH_PASSPHRASE
wifi_convert_auth_mode, 128	WIFI APIs, 95
wifi convert auth mode api, 138	WIFI_MAC_ADDRESS_LENGTH
wifi_convert_auth_mode_fp_t, 110	WIFI APIs, 95
wifi_deinit, 128	WIFI MAX LENGTH OF SSID
	WIFI APIs, 95
wifi_deinit_api, 139	•
wifi_deinit_fp_t, 110	WIFI_MAX_SCAN_AP_NUM
wifi_event_handler_t, 110	WIFI APIs, 95
wifi_fast_connect_get_mode, 128	WIFI_MAX_SUPPORTED_RATES
wifi_fast_connect_get_mode_api, 139	WIFI APIs, 95
wifi_fast_connect_get_mode_fp_t, 111	WIFI_READY_TIME
wifi_fast_connect_set_mode, 129	WIFI STA APIs, 106
wifi_fast_connect_set_mode_api, 139	wifi_active_scan_time_t, 235
wifi fast connect set mode fp t, 111	max, 236
wifi_fast_connect_start, 129	min, 236
wifi_fast_connect_start_api, 139	wifi_ap_config_t, 236
wifi_fast_connect_start_fp_t, 111	auth_mode, 237
wifi_get_config, 130	beacon_interval, 237
wifi_get_config_api, 139	channel, 237
wifi_get_config_fp_t, 111	encrypt_type, 237
wifi_init, 130	max_connection, 237
wifi_init_api, 139	password, 237
wifi_init_complete_cb_t, 111	password_length, 237
wifi_init_fp_t, 112	ssid, 238
wifi_result_t, 112	ssid_hidden, 238
wifi_scan_get_ap_list, 131	ssid_length, 238
wifi_scan_get_ap_list_api, 139	wifi_ap_record_t
wifi_scan_get_ap_list_fp_t, 112	WIFI APIs, 96
wifi_scan_get_ap_num, 131	wifi_auth_mode_t
wifi_scan_get_ap_num_api, 139	Enumeration, 141
wifi_scan_get_ap_num_fp_t, 112	wifi auto connect clear ap info
wifi_scan_get_ap_records, 132	WIFI STA APIs, 113
wifi_scan_get_ap_records_api, 140	wifi auto connect clear ap info api
wifi_scan_get_ap_records_fp_t, 112	WIFI STA APIs, 134
wifi_scan_scan_stop, 132	wifi_auto_connect_clear_ap_info_fp_t
wifi_scan_start, 132	WIFI STA APIs, 106
wifi_scan_start_api, 140	wifi_auto_connect_get_ap_info
wifi_scan_start_fp_t, 112	WIFI STA APIs, 114
wifi_scan_stop_api, 140	wifi_auto_connect_get_ap_info_api
wifi_scan_stop_fp_t, 112	WIFI STA APIs, 135
wifi_set_config, 133	wifi_auto_connect_get_ap_info_fp_t
wifi_set_config_api, 140	WIFI STA APIs, 106
wifi_set_config_fp_t, 113	wifi_auto_connect_get_ap_num
wifi_sta_get_ap_info, 133	WIFI STA APIs, 114
wifi_sta_get_ap_info_api, 140	wifi_auto_connect_get_ap_num_api
wifi_sta_get_ap_info_fp_t, 113	WIFI STA APIs, 135
wifi_start, 134	wifi_auto_connect_get_ap_num_fp_t
wifi_start_api, 140	WIFI STA APIs, 106
wifi_start_fp_t, 113	wifi_auto_connect_get_mode
wifi_stop, 134	WIFI STA APIs, 115
wifi_stop_api, 140	wifi_auto_connect_get_mode_api
wifi_stop_fp_t, 113	WIFI STA APIs, 135
WIFI_BEACON_INTERVAL_LENGTH	wifi_auto_connect_get_mode_fp_t
WIFI APIs, 94	WIFI STA APIs, 106
WIFI_CAPABILITY_INFO_LENGTH	wifi_auto_connect_info_t, 238
	····uuto_oo:ioot_iiio_t, 200

ap_channel, 239	WIFI STA APIs, 118
beacon_interval, 239	wifi_config_get_bssid_api
bssid, 239	WIFI STA APIs, 136
capabilities, 239	wifi_config_get_bssid_fp_t
dtim_prod, 239	WIFI STA APIs, 107
fast_connect, 239	wifi_config_get_channel
hid_ssid, 239	WIFI STA APIs, 118
rssi, 239	wifi_config_get_channel_api
ssid, 240	WIFI STA APIs, 136
supported_rates, 240	wifi_config_get_channel_fp_t
wifi_auto_connect_init	WIFI STA APIs, 107
WIFI STA APIs, 115	wifi_config_get_dtim_interval
wifi_auto_connect_init_api	WIFI STA APIs, 119
WIFI STA APIs, 135	wifi_config_get_dtim_interval_api
wifi_auto_connect_init_fp_t	WIFI STA APIS, 136
WIFI STA APIs, 106	wifi_config_get_dtim_interval_fp_t
wifi_auto_connect_reset	WIFI STA APIs, 107
WIFI STA APIs, 115	wifi_config_get_listen_interval WIFI STA APIs, 119
wifi_auto_connect_reset_api WIFI STA APIs, 135	wifi_config_get_listen_interval_api
wifi_auto_connect_reset_fp_t	WIFI STA APIs, 136
WIFI STA APIs, 107	wifi_config_get_listen_interval_fp_t
wifi_auto_connect_set_ap_num	WIFI STA APIs, 108
WIFI STA APIs, 116	wifi_config_get_mac_address
wifi_auto_connect_set_ap_num_api	WIFI STA APIs, 119
WIFI STA APIs, 135	wifi_config_get_mac_address_api
wifi_auto_connect_set_ap_num_fp_t	WIFI STA APIs, 136
WIFI STA APIs, 107	wifi_config_get_mac_address_fp_t
wifi_auto_connect_set_mode	WIFI STA APIs, 108
WIFI STA APIs, 116	wifi_config_get_opmode
wifi_auto_connect_set_mode_api	WIFI STA APIs, 120
WIFI STA APIs, 135	wifi_config_get_opmode_api
wifi_auto_connect_set_mode_fp_t	WIFI STA APIs, 136
WIFI STA APIs, 107	wifi_config_get_opmode_fp_t
wifi_auto_connect_start	WIFI STA APIs, 108
WIFI STA APIs, 117	wifi_config_get_skip_dtim
wifi_auto_connect_start_api	WIFI STA APIs, 120
WIFI STA APIs, 135	wifi_config_get_ssid
wifi_auto_connect_start_fp_t	WIFI STA APIs, 120
WIFI STA APIs, 107	wifi_config_get_ssid_api
wifi_auto_connet_mode_e	WIFI STA APIs, 136
WIFI APIs, 96	wifi_config_get_ssid_fp_t
wifi_bandwidth_t	WIFI STA APIs, 108
Enumeration, 143	wifi_config_set_bandwidth
wifi_cipher_type_t	WIFI STA APIs, 121
Enumeration, 143	wifi_config_set_bandwidth_api
wifi_cmd_t, 240	WIFI STA APIs, 137
arg1, 240	wifi_config_set_bandwidth_fp_t
cmd_type, 240	WIFI STA APIs, 108
prvData, 240	wifi_config_set_bssid
reserved, 241	WIFI STA APIs, 121
wifi_config_get_bandwidth	wifi_config_set_bssid_api
WIFI STA APIs, 117	WIFI STA APIs, 137
wifi_config_get_bandwidth_api	wifi_config_set_bssid_fp_t
WIFI STA APIs, 136	WIFI STA APIs, 108
wifi_config_get_bandwidth_fp_t	wifi_config_set_channel
WIFI STA APIs, 107	WIFI STA APIs, 121
wifi_config_get_bssid	wifi_config_set_channel_api

WIFI STA APIs, 137	wifi_connection_disconnect_sta_fp_t
wifi_config_set_channel_fp_t	WIFI STA APIs, 109
WIFI STA APIs, 108	wifi_connection_get_rssi
wifi_config_set_dtim_interval	WIFI STA APIs, 126
WIFI STA APIs, 122	wifi_connection_get_rssi_api
wifi_config_set_dtim_interval_api	WIFI STA APIs, 138
WIFI STA APIs, 137	wifi_connection_get_rssi_fp_t
wifi_config_set_dtim_interval_fp_t	WIFI STA APIs, 110
WIFI STA APIs, 108	wifi connection register event handler
•	WIFI STA APIs, 127
wifi_config_set_listen_interval	•
WIFI STA APIs, 122	wifi_connection_register_event_handler_api
wifi_config_set_listen_interval_api	WIFI STA APIs, 138
WIFI STA APIs, 137	wifi_connection_register_event_handler_fp_t
wifi_config_set_listen_interval_fp_t	WIFI STA APIs, 110
WIFI STA APIs, 109	wifi_connection_scan_start
wifi_config_set_mac_address	WIFI STA APIs, 127
WIFI STA APIs, 122	wifi_connection_scan_start_api
wifi_config_set_mac_address_api	WIFI STA APIs, 138
WIFI STA APIs, 137	wifi_connection_scan_start_fp_t
wifi_config_set_mac_address_fp_t	WIFI STA APIs, 110
WIFI STA APIs, 109	wifi connection unregister event handler
wifi_config_set_opmode	WIFI STA APIs, 127
WIFI STA APIs, 123	wifi_connection_unregister_event_handler_api
wifi_config_set_opmode_api	WIFI STA APIs, 138
WIFI STA APIs, 137	wifi_connection_unregister_event_handler_fp_t
wifi_config_set_opmode_fp_t	WIFI STA APIs, 110
WIFI STA APIs, 109	wifi_convert_auth_mode
wifi_config_set_skip_dtim	WIFI STA APIs, 128
WIFI STA APIs, 123	wifi_convert_auth_mode_api
wifi_config_set_ssid	WIFI STA APIs, 138
WIFI STA APIs, 123	wifi_convert_auth_mode_fp_t
wifi_config_set_ssid_api	WIFI STA APIs, 110
WIFI STA APIs, 137	wifi_deinit
wifi_config_set_ssid_fp_t	WIFI STA APIs, 128
WIFI STA APIs, 109	wifi_deinit_api
wifi_config_t, 241	WIFI STA APIs, 139
ap_config, 241	wifi_deinit_fp_t
sta_config, 241	WIFI STA APIs, 110
wifi_connection_connect	wifi_event_cb_t
WIFI STA APIs, 124	WIFI Common APIs, 99
wifi connection connect api	wifi_event_handler_t
WIFI STA APIs, 138	WIFI STA APIs, 110
wifi_connect_on_connect_fp_t	wifi_event_info_t, 242
WIFI STA APIs, 109	connected, 242
wifi_connection_connect_from_ac_index	disconnected, 242
WIFI STA APIs, 124	got_ip, 242
wifi_connection_connect_from_ac_list	scan_done, 242
WIFI STA APIs, 125	wifi_event_loop_init
wifi_connection_disconnect_ap	WIFI Common APIs, 99
WIFI STA APIs, 125	wifi_event_loop_send
wifi_connection_disconnect_ap_api	WIFI Common APIs, 100
WIFI STA APIs, 138	wifi_event_loop_set_cb
wifi_connection_disconnect_ap_fp_t	WIFI Common APIs, 100
WIFI STA APIs, 109	wifi_event_notify_cb_t
wifi_connection_disconnect_sta	WIFI APIs, 96
WIFI STA APIs, 126	wifi_event_process_handler
wifi_connection_disconnect_sta_api	WIFI APIs, 96
WIFI STA APIs, 138	WIFI Common APIs, 101

	10. 1. 1. 1. 1.
wifi_event_sta_connected_t, 243	wifi_init_fp_t
authmode, 243	WIFI STA APIs, 112
bssid, 243	wifi_install_default_event_handlers
channel, 243	WIFI APIs, 97
ssid, 243	wifi mode t
ssid_len, 243	Enumeration, 144
wifi_event_sta_disconnected_t, 244	wifi_reason_code_t
bssid, 244	Enumeration, 144
reason, 244	wifi_register_event_handler
ssid, 244	WIFI APIs, 97
ssid_len, 244	wifi_result_t
wifi_event_sta_got_ip_t, 245	WIFI STA APIs, 112
ip_changed, 245	wifi_scan_config_t, 248
wifi_event_sta_scan_done_t, 245	bssid, 248
number, 245	channel, 249
scan_id, 246	scan_time, 249
status, 246	scan_type, 249
wifi_event_t	show_hidden, 249
Enumeration, 143	ssid, 249
wifi_evt_t, 246	wifi_scan_get_ap_list
evt_type, 246	WIFI STA APIs, 131
prvData, 246	wifi_scan_get_ap_list_api
wifi fast connect get mode	WIFI STA APIs, 139
WIFI STA APIs, 128	wifi_scan_get_ap_list_fp_t
wifi_fast_connect_get_mode_api	WIFI STA APIs, 112
WIFI STA APIs, 139	
	wifi_scan_get_ap_num
wifi_fast_connect_get_mode_fp_t	WIFI STA APIs, 131
WIFI STA APIs, 111	wifi_scan_get_ap_num_api
wifi_fast_connect_set_mode	WIFI STA APIs, 139
WIFI STA APIs, 129	wifi_scan_get_ap_num_fp_t
wifi_fast_connect_set_mode_api	WIFI STA APIs, 112
WIFI STA APIs, 139	wifi_scan_get_ap_records
wifi_fast_connect_set_mode_fp_t	WIFI STA APIs, 132
WIFI STA APIs, 111	wifi_scan_get_ap_records_api
wifi_fast_connect_start	WIFI STA APIs, 140
WIFI STA APIs, 129	wifi_scan_get_ap_records_fp_t
wifi_fast_connect_start_api	WIFI STA APIs, 112
WIFI STA APIs, 139	wifi_scan_info_t, 249
wifi fast connect start fp t	auth mode, 250
WIFI STA APIs, 111	beacon_interval, 250
wifi fast scan threshold t, 247	bssid, 250
authmode, 247	capability info, 250
	• •
rssi, 247	channel, 250
wifi_get_config	dtim_period, 251
WIFI STA APIs, 130	group_cipher, 251
wifi_get_config_api	pairwise_cipher, 251
WIFI STA APIs, 139	rssi, 251
wifi_get_config_fp_t	ssid, 251
WIFI STA APIs, 111	ssid_length, 251
wifi_init	wifi_scan_list_t, 252
WIFI STA APIs, 130	ap_record, 252
wifi_init_api	num, 252
WIFI STA APIs, 139	wifi_scan_method_t
wifi_init_complete_cb_t	Enumeration, 145
WIFI STA APIs, 111	wifi_scan_scan_stop
	WIFI STA APIs, 132
wifi_init_config_t, 247	
event_handler, 248	wifi_scan_start
magic, 248	WIFI STA APIs, 132

wifi_scan_start_api	window
WIFI STA APIs, 140	LE_GAP_SCAN_PARAM_T, 181
wifi_scan_start_fp_t	wpa_data
WIFI STA APIs, 112	auto_conn_info_t, 153
wifi_scan_stop_api	mw_wifi_auto_connect_ap_info_t, 225
WIFI STA APIs, 140	scan_info_t, 231
wifi_scan_stop_fp_t	wpa_ie
WIFI STA APIs, 112	auto_conn_info_t, 153
wifi_scan_time_t, 252	mw_wifi_auto_connect_ap_info_t, 225
active, 253	scan_info_t, 232
passive, 253	
wifi_scan_type_t	
Enumeration, 145	
wifi_set_config	
WIFI STA APIs, 133	
wifi_set_config_api	
WIFI STA APIs, 140	
wifi_set_config_fp_t	
WIFI STA APIs, 113	
wifi_sort_method_t	
Enumeration, 146	
wifi_sta_config_t, 253	
bssid, 254	
bssid_present, 254	
password, 254	
password_length, 254	
scan_method, 254	
sort_method, 254	
ssid, 254	
ssid_length, 254	
threshold, 255	
wifi_sta_get_ap_info	
WIFI STA APIs, 133	
wifi_sta_get_ap_info_api	
WIFI STA APIs, 140	
wifi_sta_get_ap_info_fp_t	
WIFI STA APIs, 113	
wifi_start	
WIFI STA APIs, 134	
wifi_start_api	
WIFI STA APIs, 140	
wifi_start_fp_t	
WIFI STA APIs, 113	
wifi_stop	
WIFI STA APIs, 134	
wifi_stop_api	
WIFI STA APIs, 140	
wifi_stop_fp_t	
WIFI STA APIs, 113	
wifi_wpa_ie_data_t, 255	
capabilities, 255	
group_cipher, 255	
key_mgmt, 256	
mgmt_group_cipher, 256	
num_pmkid, 256	
pairwise_cipher, 256	
pmkid, 256	
proto, 256	