
Command Reference: CalculateTimeSeriesStatistic()

Calculate time series statistic

Version 09.08.01, 2010-09-15

The CalculateTimeSeriesStatistic() command calculates a statistic for a time series (typically a single value) and optionally adds the result to a table (see the NewTable() command). Multiple time series can be processed. The sample from each time series consists of data values for the full period or a shorter period if specified for the command. Missing values are typically ignored unless significant for the statistic(e.g., Statistic=MissingCount).

The following dialog is used to edit the command and illustrates the command syntax. Most statistics do not require additional input; however, those that do utilize the Value* parameters to specify additional information.



CalculateTimeSeriesStatistic() Command Editor

The command syntax is as follows:

CalculateTimeSeriesStatistic(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
TSList	 Indicates the list of time series to be processed, one of: AllMatchingTSID – all time series that match the TSID (single TSID or TSID with wildcards). AllTS – all time series before the command. EnsembleID – all time series in the ensemble. FirstMatchingTSID – the first time series that matches the TSID (single TSID or TSID with wildcards). LastMatchingTSID – the last time series that matches the TSID (single TSID or TSID with wildcards). SelectedTS – the time series selected with the SelectTimeSeries () command. 	AllTS
TSID	The time series identifier or alias for the time series to be processed, using the * wildcard character to match multiple time series.	Required if TSList=*TSID.
EnsembleID	The ensemble to be processed, if processing an ensemble.	Required if TSList=EnsembleID.
Statistic	Statistic to compute, one of the following: Count - number of data values total, including missing and non-missing DeficitMax - the maximum deficit value (where deficit is mean minus value) DeficitMean - the mean deficit value (where deficit is mean minus value) DeficitMin - the minimum deficit value (where deficit is mean minus value) DeficitSeqLengthMax - the maximum number of sequential intervals where each value is less than the mean (for example maximum drought length) DeficitSeqLengthMean - the mean number of sequential intervals where each value is less than the mean (for example mean drought length) DeficitSeqLengthMin - the minimum number of sequential intervals where each value is less than the mean (for example minimum drought length) DeficitSeqLengthMin - the minimum drought length) DeficitSeqMin - the maximum sum of sequential values where each value is less than	None – must be specified.

Parameter	Description	Default
	the mean (for example maximum drought water	
	volume)	
	DeficitSeqMean – the mean of the sum of	
	sequential values where each value is less than	
	the mean (for example mean drought water	
	volume) • DeficitSeqMin - the minimum sum of	
	DeficitSeqMin – the minimum sum of sequential values where each value is less than	
	the mean (for example minimum drought water	
	volume)	
	• Lag-1AutoCorrelation - the	
	autocorrelation between values and the those	
	that follow in the next time step, given by:	
	$r_k = \underline{\Sigma_{i=1}}^{N-k} \underline{(Y_i - Y_{mean})(Y_{i+k} - Y_{mean})}$	
	$\sum_{i=I}^{N} (Y_i - Y_{mean})^2$	
	Last – last non-missing value	
	Max – maximum value	
	Mean – mean value	
	• Min – minimum value	
	MissingCount – number of missing values	
	MissingPercent – percent of values that are missing.	
	are missingNonmissingCount – number of non-missing	
	values	
	NonmissingPercent - percent of values	
	that are not missing	
	NqYY – restricted to daily data and typically	
	used to analyze return interval of low flows,	
	requires values of N, YY, and number of missing	
	allowed to be specified with Value parameters	
	 (see Statistic Details table below) Skew – skew coefficient, as follows: 	
	$Cs = \frac{N \sum_{i=1}^{N} (Y_i - Y_{mean})^2}{N \sum_{i=1}^{N} (Y_i - Y_{mean})^2}$	
	$\frac{(n-1)(n-2)s^3}{(n-1)(n-2)s^3}$	
	where $s = $ standard deviation	
	StdDev – standard deviation	
	SurplusMin – the maximum surplus value	
	(where surplus is value minus mean)	
	SurplusMean – the mean surplus value (where surplus is value minus mean)	
	(where surplus is value minus mean)SurplusMin – the minimum surplus value	
	(where surplus is value minus mean)	
	SurplusSeqLengthMax – the maximum	
	number of sequential intervals where each value	
	is greater than the mean (for example maximum	
	water surplus length)	
	SurplusSeqLengthMean – the mean	
	number of sequential intervals where each value	

Parameter	Description	Default
	is greater than the mean (for example mean water surplus length) • SurplusSeqLengthMin – the minimum number of sequential intervals where each value is greater than the mean (for example minimum water surplus length) • SurplusSeqMin – the maximum sum of sequential values where each value is greater than the mean (for example maximum water surplus volume) • SurplusSeqMean – the mean of the sum of sequential values where each value is greater than the mean (for example mean water surplus volume) • SurplusSeqMin – the minimum sum of sequential values where each value is greater than the mean (for example minimum water surplus volume) • Variance – variance	
Value1	Input data required by the statistic. Currently the dialog does not check the value for correctness – it is checked when the statistic is computed.	See Statistic Details table below.
Value2	Input data required by the statistic. Currently the dialog does not check the value for correctness – it is checked when the statistic is computed.	See Statistic Details table below.
Value3	Input data required by the statistic. Currently the dialog does not check the value for correctness – it is checked when the statistic is computed.	See Statistic Details table below.
AnalysisStart	The date/time to start analyzing data.	Full period is analyzed.
AnalysisEnd	The date/time to end analyzing data.	Full period is analyzed.
TableID	Identifier for table that receives the statistic.	Optional – table output is not required.
TableTSIDColumn	Table column name that is used to look up the time series. If a matching TSID is not found, a row will be added to the table. If a TSID is found, the statistic cell value for the time series is modified.	Optional – table output is not required.
TableTSIDFormat	The specification to format the time series identifier to insert into the TSID column. Use the format choices and other characters to define a unique identifier.	Time series alias if available, or the time series identifier.
TableStatistic Column	Table column name to receive the statistic value. If not found in the table, a new column is added automatically.	Optional – table output is not required.

The following table provides additional information about specific statistics, in particular to describe how the statistic is computed and whether additional input needs to be provided with Value command parameters.

Statistic Details

Statistic	Description	Required Values
Statistic NqYY	This statistic is typically used to evaluate the return period of low flows and is implemented only for daily data. The N indicates the number of daily values to be averaged and YY indicates the return interval. For example, 7q10 indicates the flow corresponding to the 10-year recurrence interval for minimum average daily flow (for 7 days) in a year. This statistic is computed as follows, using 7q10 as an example: 1. Determine the number of years to be analyzed (from analysis period command parameters or time series data). 2. For each year, loop through each day from January 1 to December 31. Compute an average flow by averaging 7 days, in this case with 3 values on each side of the current day and including the current day. If at the end of the year, use 3 values from adjoining years. The number of missing data allowed is controlled by the Value3 command parameter. 3. For the year, save the minimum 7-day average. 4. Utilize the minimum values for all years, with log-Pearson Type III distribution, to determine the value for the 10-	Value1 – specify the number of daily values to be averaged. Currently this must be an odd number to allow bracketing the current day. Value2 – specify the return interval (e.g., 10). Value3 – specify the number of missing values allowed in the average (e.g., 0 for most rigorous analysis). It may be useful to set this value if, for
	year recurrence interval. See http://pubs.usgs.gov/sir/2008/5126/section3.html for a description of NqYY and "Hydrology for Engineers, 3 rd	example, a single daily value is available in the time series, for example
	Edition," Linsley, Kohler, Paulhus for a description of log-Pearson Type III distribution.	entered on the first day of the month.
All other statistics	Described above.	No additional input values are needed.

The following example illustrates how to use the command to compute the 7q10 statistic for daily flow:

```
TS linsley = ReadDateValue(InputFile="Data\linsley.dv")
NewTable(TableID="Table1",Columns="TSID,string;7q10,double")
CalculateTimeSeriesStatistic(Statistic="NqYY",Value1=7,Value2=10,Value3=6,
    TableID="Table1",TableTSIDColumn="TSID",TableStatisticColumn="7q10")
WriteTableToDelimitedFile(TableID="Table1",
OutputFile="Results/Test_CalculateTimeSeriesStatistic_7q10_linsley_out.csv")
```

CalculateTimeSeriesStatistic	()	Command
	١,	Communication

TSTool Documentation

This page is intentionally blank.