

MicroPMU Installation and User's Manual

Revision 1.1



PSL

Power Sensors Ltd.

980 Atlantic Ave

Alameda CA 94501 USA

www.PowerStandards.com

WARNING: Death, serious injury, or fire hazard could result from improper connection or operation of this instrument. Carefully read and understand manual before connecting this instrument.

AVERTISSEMENT: Si l'instrument est mal connecté, la mort, des blessures graves, ou un danger d'incendie peuvent s'en suivre. Lisez attentivement le manuel avant de connecter l'instrument.

WARNUNG: Der falsche Anschluß dieses Gerätes kann Tod, schwere Verletzungen oder Feuer verursachen. Bevor Sie dieses Instrument anschließen, müssen Sie die Anleitung lesen und verstanden haben.

ADVERTENCIA: Una conexión incorrecta de este instrumento puede producir la muerte, lesiones graves y riesgo de incendio. Lea y entienda el manual antes de conectar.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. Installation, service, and maintenance of your PQube 3 must only be done by an expert for electrical installations.

© 2008-2016 Power Standards Lab. All rights reserved. No parts of this document may be copied, reproduced, or translated to another language without the prior written consent of Power Standards Laboratory. "PQube" is a registered trademark of Power Standards Lab. "Windows" "Excel", and "PowerPoint" are registered trademarks of Microsoft Corporation.

The information contained in this document is subject to change without notice.

PSL MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR USE.

PSL shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. If you do not accept this limitation on liability, please return the product to PSL prior to use.

Produced in the United States of America.

Symbol	Meaning
	Caution. Consult this manual in all cases where this symbol is marked, in order to find out the nature of the potential hazards and any actions which have to be taken to avoid them.
	Caution. Risk of electric shock
	Alternating current
	Alternating current (a.c.) or direct current (d.c.)
	Double or Reinforced insulation
	Functional earth terminal <u>not</u> relied on for safety

Table of Contents

Introduction	7
What is a MicroPMU?	7
What do I need to turn my PQube 3 into a MicroPMU?	8
Installation	11
Quickstart Guide	11
Wiring Diagrams	16
Single Phase L-N	16
Delta (3-phase no neutral)	16
Overview of connections and controls.....	17
Disconnect mains prior to servicing.....	17
Setting Up Your MicroPMU	18
Getting Started	18
1. Update the firmware to the latest version.....	18
2. Configure your MicroPMU	22
3. Navigating the touchscreen display.....	22
4. Verify IP address	25
5. Verify GPS lock status.....	25
Accessing Data From Your MicroPMU	26
Access the web interface	26
Binary files	27
Using PMU Connection Tester	31
Setting Up OpenPDC	34
Maintenance.....	42
Turning Off Your MicroPMU	42
Replacing Your MicroPMU's Battery	42
Cleaning Instructions.....	42
Micro-PMU Specifications	43
Appendix 1: Setup File Guide	46
Device Setup.....	46
Event Triggering.....	51
Network Configuration	59

Trend Setup	64
--------------------------	-----------

Table of Figures

Figure 1 Micro PMU	7
Figure 2 Micro PMU and Power Supply	8
Figure 3 MicroPMU and GPS Antenna	9
Figure 4 GPS Antenna	9
Figure 5 MicroPMU and UPS module.....	10
Figure 6 Typical Micro PMU with GPS, Power Supply and UPS.....	11
Figure 7 GPS Connections.....	11
Figure 8 Ethernet Network Connection	12
Figure 9 MPU Power Terminals	14
Figure 10 PM1 Top View - 100-240VAC Terminals.....	14
Figure 11 PM1 Rear View - 100 - 240VAC Terminals.....	14
Figure 12 Power over Ethernet Port.....	14
Figure 13 Main input monitoring Teminals.....	15
Figure 14 Slngle Phase Terminations.....	16
Figure 15 Three Phase Terminations	16
Figure 16 Micro PMU Connections.....	17
Figure 17 xxx.PQ3 file copied to USB thumb drive	18
Figure 18 After successful update, the xxx.PQ3 file is renamed with the date/time of installation	18
Figure 19 Configuration Web page.....	19
Figure 20 Plug in a USB thumb drive	22
Figure 21 Home Screen	22
Figure 22 Navigation Keys	22
Figure 23 System Navigation.....	23
Figure 24 Electrical Metering	24
Figure 25 Voltage Metering.....	24
Figure 26 Current Metering.....	24
Figure 27 Actions Screen	24
Figure 28 Network Address Screen	25
Figure 29 GPS tracking details.....	25
Figure 30 Web Metering page	26
Figure 31 Location of binary .dat files.....	28
Figure 32 Binary to csv converter	28
Figure 33 Converted csv files.....	29
Figure 34 MicroPMU converted data	30
Figure 35 MicroPMU Connection Test (settings A)	31
Figure 36 MicroPMU Connection Test (settings B)	31
Figure 37 MicroPMU server connection settings	32
Figure 38 Network Adaptor Settings	33
Figure 39 Datastream	33
Figure 40 Metering page	34
Figure 41 Open PDC manager	35
Figure 42 Network Connection String	35
Figure 43 IPv4 settings	36
Figure 44 Device ID Code and IEEE C37 settings.....	36
Figure 45 Configuration Request	37
Figure 46 Configuration Summary.....	37

Figure 47 Finalizing Configuration	38
Figure 48 Successful Configuration.....	38
Figure 49 Editing Device Configuration	39
Figure 50 Open PDC 'skip disable real-time data.....	39
Figure 51 Data streaming	40
Figure 52 Monitor Device Outputs	40
Figure 53 Graphical measurements.....	40

Introduction

What is a MicroPMU?

Synchrophasor measurements have traditionally been used to observe the flow of power between generators across transmission lines. To do this, Phasor Measurement Units (PMUs) measure the phase angle of the voltage between two locations. PMUs are synchronized to a GPS clock, allowing for measurements that are accurate to the degree, or 1/360th of a cycle. They transmit a constant stream of data to a central computer called a Phasor Data Concentrator (PDC).

But to measure the effects of renewable energy sources, synchrophasor measurements must be made at the distribution level, where changes in phase angle are more minute. To effectively measure the effects of renewable energy sources on the distribution lines, a more accurate and precise microsynchrophasor (MicroPMU) is required.

At the heart of the MicroPMU is the PQube® 3 Power Quality and Energy Analyzer.



Figure 1 Micro PMU

It is convenient to think of the PQube 3 as a combination of a power disturbance monitor, a power meter, a power recorder, and a digital camera – it combines the best features of all four.

Your PQube 3 records disturbances on the mains circuit: sags/dips, swells, interruptions, frequency variations, and disturbances on two analog input channels. It also records impulses, waveform snapshots, unbalance, flicker, and THD, and trend data (strip charts and cumulative statistics).

When equipped with the appropriate add-on modules, your PQube 3 becomes a MicroPMU.

What do I need to turn my PQube 3 into a MicroPMU?

At the bare minimum, you will need the main PQube 3 unit, plus the MS1 MicroSynchrophasor module and GPS1 receiver, with the PSL-provided custom GPS cable (RJ-45 on one end, 8-pin terminal block on the other).

IMPORTANT: Installation, service, and maintenance of your MicroPMU must only be done by an expert for electrical installations.¹

Additional optional modules are available. They snap into your PQube 3 to provide additional features. To choose modules for your application, you'll need to answer a few simple questions:

- Do you need to power your PQube 3 from 100~240Vac (50/60Hz)?
- Do you need battery backup in the event of a power outage?
- Do you want to record the environmental conditions in addition to everything about the electric power?

PM1 Power Manager Module – Power the device from the wall outlet (optional)



Figure 2 Micro PMU and Power Supply

If you want to power your MicroPMU from the wall outlet (100~240Vac), you'll need an optional PM1 Power Manager module.

¹ This is a requirement for Japanese safety standard approvals.

MS1 MicroSynchrophasor Module and GPS1 Receiver (required)

If you need ultra-precise GPS timestamps, or if you want to perform micro-synchrophasor measurements, connect the MS1 Sync module with the GPS1 receiver to the left side of your MicroPMU.



Figure 3 MicroPMU and GPS Antenna

The MS1 module interfaces with the GPS1 receiver to provide your MicroPMU with ultra-precise GPS timing.



Figure 4 GPS Antenna

The GPS1 receiver locks onto GPS satellites in the sky to provide your MicroPMU with ultra-precise GPS timing. It is designed to be weather-resistant and you can install it outside using optional mounting hardware. It has 600V isolation at both ends of the cable for safety.

UPS1 Module - Backup your PQube 3 during a power outage (optional)



Figure 5 MicroPMU and UPS module

Connect the UPS1 Battery Backup module to your MicroPMU to provide up to 30 minutes of ride-through during a power outage. It can be used with or without a PM1 module.

Installation

Quickstart Guide

① Assemble your modules together

Snap in the MS1 module to the left of your PQube 3. If using a PM1 module and/or UPS1 module, snap them into the right side of your PQube 3.



Figure 6 Typical Micro PMU with GPS, Power Supply and UPS

② GPS setup

Your GPS cable has an 8-pin terminal block on one end and an RJ-45 jack on the other end. The 8-pin terminal block plugs into the back of your MS1 module, the other end plugs into the GPS1 receiver.




Figure 7 GPS Connections



IMPORTANT: Do not plug the RJ-45 end of the GPS cable into a network switch or router.

Place the GPS1 receiver in an area with direct line of sight to the sky. For maximum exposure to satellites, mount it on the roof. If mounting near a window, make sure your MicroPMU locks onto at least 4 satellites. To view the number of satellites, from the main menu go to System, Advanced, and then GPS.

If necessary, you can extend the GPS cable using a standard RJ-45 coupler and an Ethernet cable.

③ Provide a network connection for your MicroPMU

Plug in a standard Ethernet cable between your MicroPMU and a network switch/hub/router, or cellular modem. If you will be archiving the phasor data into a database or PDC (phasor data concentrator), make sure your MicroPMU is on the same network as your database, or set up a public IP address for your MicroPMU.



Figure 8 Ethernet Network Connection

By default, your MicroPMU is configured for DHCP, which means the network is responsible for assigning an IP address to your MicroPMU.

If necessary, you can set your MicroPMU to use a Fixed IP address in the Network_Setup section of your Setup.ini file.

```
;-----  
[Network_Setup]  
;-----  
  
; ----- Valid Values: Use_DHCP Use_Fixed_IP  
IP_Address_Method=Use_DHCP  
Publish_IP_Address=ON  
  
;-----  
[Fixed_IP]  
;-----  
  
; ----- This section is ignored if the IP_Address_Method is set to  
Use_DHCP  
IP_Address=172.17.69.20  
IP_Gateway=172.17.1.1
```

```
IP_Mask=255.255.255.0  
IP_DNS1=8.8.8.8  
IP_DNS2=8.8.4.4
```

④

Connect instrument power wires

You have several options for powering your MicroPMU:

- Low voltage ±24 – 48VDC or 24VAC instrument power terminals on main module



Figure 9 MPU Power Terminals

- PM1 AC Input Terminals 100~240VAC (CAT II)
- Make sure the power is OFF before servicing



these terminals.



Figure 11 PM1 Rear View -
100 - 240VAC Terminals



Figure 10 PM1 Top View -
100-240VAC Terminals

- Connect an ethernet cable to a PoE (Power over Ethernet) port



Figure 12 Power over Ethernet Port

5

Connect wires to mains AC terminals



Make sure the power is OFF before servicing these terminals. Connect the wires to the high voltage terminal block on the rear side of your MicroPMU. They will be labeled L1, L2, L3, N, and Ground.

IMPORTANT: You **must** ensure that the ground wire is connected to your MicroPMU. This is critical for accurate phase angle measurements.



Figure 13 Main input monitoring Terminals

Refer to wiring diagrams on following pages for sample single-phase and 3-phase installations.

Wiring Diagrams

Single Phase L-N




Figure 14 Single Phase Terminations

Delta (3-phase no neutral)




Figure 15 Three Phase Terminations

Overview of connections and controls




Figure 16 MicroPMU Connections

A	Coin-cell battery
B	SD memory card and adjacent High-Speed USB 2.0 port
C	Touchscreen display
D	Signal relay outputs. One is standard on all PQube 3's.
E	Analog inputs. Maximum ± 60 V to earth. Can be used as differential inputs.
F	Earth – functional. Used as the reference voltage.
G	Digital input. 60-volt tolerant. 1.5-volt threshold. Wetted with 2.4V at 3 microamps.
H	Power inputs. 24VAC, or 24VDC to 48VDC (either polarity) nominal. 20VA max.

I	RJ-45 Ethernet port. 48V PoE compatible.
J	USB ports – For use with PSL accessories including temperature and humidity sensors.
K	Current transformer inputs – 0.333V nominal
L	L1, L2, L3 voltage inputs. 1000Vrms max phase-to-phase (equivalent to 600Vrms phase-to-earth)
M	Neutral terminal – optional connection
N	Not connected
P	Earth – functional. Used as the reference voltage.

Disconnect mains prior to servicing

Always disconnect all mains connections, and verify disconnections, prior to servicing.

Setting Up Your MicroPMU

Getting Started

1. Update the firmware to the latest version

As of September, 2016, the latest firmware version is **3.4.0**.

To check the firmware version on your MicroPMU, from the main menu go to System, then Info. Download the latest firmware at <http://micro-pmu.com/firmware>

For links to the latest firmware, contact support@powerstandards.com.

With USB thumb drive

Copy the xxx.PQ3 file onto a USB thumb drive, and then insert it into your MicroPMU. The update process will begin automatically and the device will reboot within a few minutes.

To confirm successful installation, remove the USB drive after reboot (from Main Menu press Actions, then Eject). The xxx.PQ3 file will be renamed to xxx.PQ3<install date of update>




Figure 17 xxx.PQ3 file copied to USB thumb drive




Figure 18 After successful update, the xxx.PQ3 file is renamed with the date/time of installation

Updating MicroMPU over the web

If you know your MicroPMU's IP address, enter it into the address bar of your web browser.

Firmware

Go to the Commands page to upload the new firmware. Your MicroPMU will automatically reset after installing the update.




Figure 19 Configuration Web page

Setup.ini

The setup.ini can be down and uploaded via the webpage shown in the figure above. Your MicroPMU will automatically reset after updating the setup.ini.

uPMU SETUP.INI editor configurator

The link below will download the MicroPMU configurator.

http://powersensorsltd.com/Download/uPMU Configurator_3_4_2_8.zip

Recommended Settings

PSL recommends setting the PQube ID, Location Name, Note 1, and Note 2 in the [PQube_Information] section at the top.

Set the Power_Configuration as necessary for your application.

For single-phase outlets with a Neutral conductor, use Single_Phase_L1_N.

For 3-phase without Neutral use Delta. For 3-phase with Neutral use Wye or Star.

```
; ----- PQube 3 from Power Sensors Ltd.  
; ----- www.powersensorsltd.com  
; ----- PQube 3 Version 3.4
```

```
;-----
[ PQube_Information ]
;-----
; ----- Assign a unique identifier for your PQube 3
PQube_ID="P3001697"

; ----- Describe the place where your PQube 3 is installed
Location_Name="PSL Staging Room"

; ----- Optional additional information about your PQube 3
Note_1="PSL Alameda"
Note_2="USA"

; ----- Duration in minutes of battery back up before your PQube 3
automatically shuts down
; ----- This applies only if your PQube has a UPS module
; ----- Valid values: 3 to 30, typical value 5
UPS_Time_In_Minutes=5

; ----- Capacity of the battery pack connected to the UPS2 module. If
there are several battery packs connected,
; ----- the capacity is the total capacity for all packs together
; ----- Note: This parameter is ignored if a UPS1 module is connected to
the PQube3.
; ----- Valid values: 2500 to 7500, default is 2500
UPS_Model=None
UPS_Battery_Capacity_In_mAhh=

; ----- Your PQube 3's internal fan turns on when the CPU temperature
exceeds this threshold.
; ----- Valid values: integer between 40 and 60, typical value 55
Fan_Temperature_Threshold_in_DegC=60

; ----- Choose the language for web pages, screen display, and graphs
generated by your PQube 3.
PQube_Primary_Language=English-American
PQube_Secondary_Language=None

;-----
[Data_Backup]
;-----
; ----- If enabled, your PQube 3 will perform a measurement data backup
from its memory
; ----- to either the extractable microSDCard or to the USB thumb drive.
; ----- the copy occurs once a day, if the media is present in its slot.

; ----- Valid Values: OFF, ON. Default is OFF
Enable_Data_Backup=OFF

; ----- Valid Values: No_backup, USB, SDCARD, Default is No_backup
Data_Backup_to=No_backup

;-----
[Nominal_Inputs]
;-----
; ----- Choose the nominal value of the mains voltage measured in volts,
taking into account transformer ratios if applicable
```

```
; ----- Valid Values: AUTO, positive value between 69 and 800000
; ----- AUTO sets the nominal voltage using the actual voltages at the
mains AC terminals during startup and rounds to the nearest standard
worldwide voltage.
; ----- Examples of values when using transformer ratios: 11000, 12470,
33000

; ----- Typical values for Phase to Phase voltage are 208, 380, 400, 480
Nominal_Phase_To_Phase_Voltage=AUTO

; ----- Typical values for Phase to Neutral voltage are 100, 120, 230,
277
Nominal_Phase_To_Neutral_Voltage=AUTO

; ----- Valid Values: 50, 60
Nominal_Frequency=60
```

By default, your MicroPMUs are set to DHCP, which relies on the router or modem to assign an IP address. If your network does not support DHCP, you need to set your MicroPMU to use a fixed IP address. Go to the [Network_Setup] and [Fixed_IP] sections and enter the appropriate settings.

```
;-----
[Network_Setup]
;-----

; ----- Valid Values: Use_DHCP Use_Fixed_IP
IP_Address_Method=Use_DHCP
Publish_IP_Address=ON

;-----
[Fixed_IP]
;-----

; ----- This section is ignored if the IP_Address_Method is set to Use_DHCP
IP_Address=172.17.69.20
IP_Gateway=172.17.1.1
IP_Mask=255.255.255.0
IP_DNS1=8.8.8.8
IP_DNS2=8.8.4.4
```

2. Configure your MicroPMU

As an alternative to the web interface the MicroMPU can be updated via the High-Speed USB 2.0 port on the front on the MircoMPU as show below;

With USB thumb drive

Use the provided Setup.ini file to make device configuration changes to your MicroPMU. This file can be modified with a simple text editor and saved onto a USB thumb drive. Make sure this file is named Setup.ini and place it in the root directory of your USB drive. Your MicroPMU will recognize the file, reboot, and apply the new settings when you plug in the USB thumb drive.



Figure 20 Plug in a USB thumb drive

To verify that your MicroPMU accepted the new setup file, eject the USB drive after reboot and it will be renamed to SetupYYYYMMDDHHMM to reflect the date/time these settings were applied.

3. Navigating the touchscreen display

Use the touchscreen on your PQube 3 to navigate through all of the displays. You can view live meters, recent events, system information, and perform actions like ejecting removable media and rebooting the unit.



Figure 21 Home Screen


Use the back button on the lower-left corner of the touchscreen to go back up a level. Use the Home button (2nd from left) to move back to the main screen



Figure 22 Navigation Keys

SYSTEM

Shows details such as Date /Time, network settings, firmware version & GPS status.



METERS

In this latest new firmware you can view the Voltage and Current magnitudes here.



Figure 24 Electrical Metering



Figure 25 Voltage Metering



Figure 26 Current Metering

ACTIONS

Go to this screen to reboot the unit or eject USB drives.




Figure 27 Actions Screen

4. Verify IP address

After updating the firmware and setup file, the first thing you should verify is that the IP address is correct. From the main menu, go to System, then Network.



Figure 28 Network Address Screen

5. Verify GPS lock status

If this is your first time turning on your MicroPMU, it may take up to 1 hour for it to obtain GPS and phase lock. From the main menu, go to System, Advanced, then GPS.




Figure 29 GPS tracking details

You need to wait until both the GPS Lock and Phase Lock fields read Yes. At this moment your MicroPMU has synchronized its internal timing mechanisms to GPS and it will automatically begin generating phasor data.

Accessing Data From Your MicroPMU

Access the web interface

Type in the IP address of your MicroPMU in the web browser, and the main Status page will be displayed. The PQube ID, Location Name, Note 1, and Note 2 values that you entered in your setup file will appear on the main status page. Figure 19 Configuration Web page.

The magnitudes of your voltages and currents, as well as the mains frequency are available from the Meters page shown below in Figure 30 Web Metering page.

From the Commands page you can perform system tasks including system reset, uploading a new setup file, and updating the firmware.

The screenshot shows a web browser window titled 'PQube 3- PSL micro'. The address bar displays the URL '172.17.4.200/html_meters.cgi'. The left sidebar has two tabs: 'Diagnostics' (selected) and 'Commands'. The main content area is divided into two sections:

- Meters**: A table listing various electrical parameters and their values. The table has two columns: 'Meter' and 'Value'.

Meter	Value
L1-E Fundamental	120.977V
L1-E Fundamental Angle	0.000deg
L2-E Fundamental	0.229V
L2-E Fundamental Angle	86.630deg
L3-E Fundamental	0.041V
L3-E Fundamental Angle	83.974deg
L1-Amp Fundamental	0.515A
L1-Amp Fundamental Angle	12.970deg
L2-Amp Fundamental	0.557A
L2-Amp Fundamental Angle	0.223deg
L3-Amp Fundamental	0.557A
L3-Amp Fundamental Angle	0.403deg
Frequency	60.016Hz
- GPS Lock Status**: A table showing the status of GPS locks and a status value. The table has two columns: 'Meter' and 'Value'.

Meter	Value
Phase Lock	Yes
GPS Lock	Yes
Status	52.7

At the bottom of the page, a message reads 'Waiting for 172.17.4.200...'.

Figure 30 Web Metering page

Binary files

Your MicroPMU automatically saves phasor data to disk as binary files. These binary .dat files are stored in folders that are sorted by Year, Month, Day, and Hour. You can access these files via FTP.

By default, each binary file contains 5 minutes of data. You can change the interval in the MicroSynchrophasor_Settings section of your setup file.

Your MicroPMU has a built-in FTP server which you can access using an FTP client. PSL recommends FileZilla, available as a free download from <https://filezilla-project.org/>.

Your MicroPMU has a built-in plain FTP server which you can access using any standard FTP client.

There are 5 different FTP accounts available.

1. ftp_user_1, ftp_user_2, ftp_user_3

Use these accounts to access events, trends, and logs.

2. ftp_config

Use this account to upload a new setup file. After the upload is complete, your MicroPMU will automatically reboot and load your new settings. You can also retrieve your MicroPMU's existing setup file using this account.

3. ftp_updater

You can upload new firmware to your MicroPMU using this account. After the upload is complete, your MicroPMU will automatically reboot and install the new firmware.

By default, each FTP account is disabled. To enable access for a particular account, you will need to specify a password for that account.

In the MicroPMU Configurator program, go to the Network Setup tab and locate the FTP Profiles section.

Select the FTP account you would like to use, and hit the Enable button. Specify a password (at least 8 characters long) and save your Setup file. After uploading your setup file, that FTP account will be available for you to use.




Figure 31 Location of binary .dat files

Converting the binary data to CSV

Ultimately, the binary data will be directly imported into a database. In the meantime, we have prepared a simple conversion program that will transform the binary files into CSV format, which you can open in Microsoft Excel.

Download **Binary .dat to .csv file converter.exe** from the provided link below.

<http://www.powersensorsltd.com/outputs/PSL%20microPMU%20Binary%20File%20Conversion%20Utility%20v0.1.exe>

1. Enter the serial number of your MicroPMU in the first field
2. Choose the folder on your PC where the binary files are stored
3. Choose a destination folder for your CSVs
4. Press the **Convert .dat files to .csv files** button




Figure 32 Binary to csv converter

In the destination folder, you will find CSV files each spanning 5 seconds. The file-naming convention is YYYYMMDDHHMMSS-P300xxxx.




Figure 33 Converted csv files

Description of binary files

As soon as the MicroPMU begins running, it will start generating the binary .dat files. The file-naming convention is sync_data_sec_#.dat. Each file spans 5 seconds at the absolute time clock (12:00:00, 12:00:05, 12:00:10, and so on).

We record 120 phase angle measurements per second, so each file should contain 600 measurements, assuming data was recorded for the entire time period.

	Sample rate	Date stamp	Time stamp	Lock state	L1-E voltage RMS fundamental magnitude	L1-E voltage fundamental angle
1	8.333333	5/7/2014	22:34:35	2	122.8528	324.545
2	8.333333	5/7/2014	22:34:35	2	122.7504	324.5523
3	8.333333	5/7/2014	22:34:35	2	122.8433	324.5736
4	8.333333	5/7/2014	22:34:35	2	122.8358	324.5906
5	8.333333	5/7/2014	22:34:35	2	122.8104	324.6013
6	8.333333	5/7/2014	22:34:35	2	122.7555	324.6269
7	8.333333	5/7/2014	22:34:35	2	122.7611	324.6691
8	8.333333	5/7/2014	22:34:35	2	122.7528	324.7055
9	8.333333	5/7/2014	22:34:35	2	122.8198	324.7456
10	8.333333	5/7/2014	22:34:35	2	122.6987	324.7605
11	8.333333	5/7/2014	22:34:35	2	122.8422	324.8257
12	8.333333	5/7/2014	22:34:35	2		

Figure 34 MicroPMU converted data

Using PMU Connection Tester

The connection tester can be downloaded from the link below;

<https://pmuconnectiontester.codeplex.com/>

1. Configure PMU Connection Tester

From the Settings tab, set the following options:

'Force IPv4' to True and 'SkipDisableRealTime' to True as shown below




Figure 35 MicroPMU Connection Test (settings A)




Figure 36 MicroPMU Connection Test (settings B)

2. Set the Connection Parameters

At the main window, enter the IP address, Port, and Device ID Code of your MicroPMU. Select IEEE C37.118.2-2011 protocol from the dropdown.

If you don't know your IP address, go to System, then Network. Device Port and Device ID Code are defined in the C37_Communications_Settings section at the bottom of your Setup.ini file.




Figure 37 MicroPMU server connection settings

Underneath Port, click Network Interface and make sure the proper network adapter is selected.




Figure 38 Network Adaptor Settings

3. Turn on the datastream

Press Connect to watch the dataframes begin streaming into the program.




Figure 39 Datastream

Setting Up OpenPDC

1. Wait for Meters to appear on web page

After you have uploaded the latest firmware and setup file, launch the webpage and go to Meters. Assuming you have voltage connected to the mains AC terminals, you'll see some values appear after several minutes.

Meter	Value
L1-E Fundamental	120.977V
L1-E Fundamental Angle	0.000deg
L2-E Fundamental	0.229V
L2-E Fundamental Angle	86.630deg
L3-E Fundamental	0.041V
L3-E Fundamental Angle	83.974deg
L1-Amp Fundamental	0.515A
L1-Amp Fundamental Angle	12.970deg
L2-Amp Fundamental	0.557A
L2-Amp Fundamental Angle	0.223deg
L3-Amp Fundamental	0.557A
L3-Amp Fundamental Angle	0.403deg
Frequency	60.016Hz

Meter	Value
Phase Lock	Yes
GPS Lock	Yes
Status	52.7

Figure 40 Metering page

When values appear in the Meters page, this means your MicroPMU has synchronized to a sufficient number of GPS satellites and the various internal processes have synchronized enough to the point where you can start viewing phasor data.

2. Add a new input device to OpenPDC

Launch OpenPDC Manager. From the main menu, go to Inputs, Input Device Wizard.




Figure 41 Open PDC manager

3. Set the network connection string

Click on the Connection String icon.




Figure 42 Network Connection String

Enter all of the network parameters for your MicroPMU and hit Save. Make sure Force IPv4 is checked.




Figure 43 IPv4 settings

4. Set ID Code and Protocol

Back at the Input Device Wizard window, set the Device ID Code and choose IEEE C37.118.2-2011 as the Device Protocol. Then click Next;




Figure 44 Device ID Code and IEEE C37 settings

5. Request Configuration from your MicroPMU

At Step 2, click Request Configuration and you should see a successful confirmation window.




Figure 45 Configuration Request




Figure 46 Configuration Summary

Hit Next after receiving the configuration from your MicroPMU.

6. Finalize Configuration

OpenPDC will automatically import the name specified in the Station_Name tag from your setup file, but you can change it here if necessary.




Figure 47 Finalizing Configuration

When you are done, hit Finish to save the device configuration.




Figure 48 Successful Configuration

7. Edit Device Configuration

From the main menu, go to Inputs, then Browse Input Devices. You will see the MicroPMU that you just added in the previous step. Click on the Station Name of your MicroPMU.




Figure 49 Editing Device Configuration

Make sure Skip Disable Real-time Data is checked. Hit Save when completed.




Figure 50 Open PDC 'skip disable real-time data'

Check the Enabled box to begin streaming data from your MicroPMU to OpenPDC.




Figure 51 Data streaming

IMPORTANT! If you wish to stop the datastream, you will have to come back to this window and uncheck the Enabled box. Simply closing the OpenPDC Manager will not stop the datastream.

8. Verify the data coming in from your MicroPMU

From the main menu, go to Monitoring, then Monitor Device Outputs. After 5 seconds you will see some values coming in from your MicroPMU.




Figure 52 Monitor Device Outputs

Then go to Monitoring, and Graph Measurements. Check the desired parameters in the left frame and you will automatically see the graph update with the selected parameters.




Figure 53 Graphical measurements

Questions? Contact us at support@powerstandards.com.

Maintenance

Turning Off Your MicroPMU

Your MicroPMU is designed to be a permanently installed monitor. It does not have an on/off switch because it is designed to run continuously. If you need to turn off your MicroPMU, remove instrument power (either the power screw terminals on your PQube 3, the optional PM1 Power Supply Module, or both). Your MicroPMU will automatically initiate graceful shutdown to prevent any write damage to flash. If you have a UPS module installed, your MicroPMU will continue to run for the allotted amount of time (30 minutes by default). To immediately power down your MicroPMU while on backup power from the UPS module, go to the Actions screen and press Reboot.

Replacing Your MicroPMU's Battery

Your MicroPMU uses a user-replaceable, non-rechargeable lithium-manganese coin cell battery to back up the system clock in the event of instrument power loss. PSL recommends replacing this battery every 10 years. Before replacing the lithium battery, always remember to power off the device first, disconnect mains connections, and verify disconnections.

To replace the battery, insert a small flat-head screwdriver to pry up the label near the USB port and microSD card slot. Remove the old battery and install the new one. It is not possible to install the battery with the wrong polarity.



Follow all applicable federal, state, and local regulations when disposing of the used battery.



Disconnect power to the device before replacing the battery.

Replace battery with Renata, Type CR2477N only. Use of another battery may present a risk of fire or explosion. This part must be supplied only by PSL or PSL agents.

Cleaning Instructions

If necessary, wipe the accessible parts of your MicroPMU with a slightly damp cloth. Do not use abrasives or chemical cleaners.

Micro-PMU Specifications

Reference conditions for factory tests: 19~25°C, 10%~60% RH, steady-state 10/12 cycle signals. ±1/2 display count on all accuracies

MAINS VOLTAGE MEASURING CHANNELS

Connection	L1, L2, L3, N PQube3 screw terminals (max torque 5 inch-pounds (0,6Nm))
Frequency Range	Nominal 50 Hz, 60 Hz.
Mains Configuration	Single-phase, split-single-phase, delta, wye/star. User selected or auto-selected.
Range of Nominal Input Voltage	100 VAC ~ 960 VAC L-L (69 VAC ~ 480 VAC L-N). User selected or auto-selected.
Measurement Channels	Line-to-Earth, Neutral-to-Earth
Sampling Rate	25,600 s/s @ 50Hz and 30,720 s/s @ 60Hz
Measurement Range	0 VAC ~ 750VAC L-N (0 VAC ~ 1300 VAC L-L)
Isolation	PQube3 tested up to 5100VAC isolation to Earth. UL/IEC 61010 test pending.
Installation Category	CAT IV UL/IEC 61010 for voltages up to 300 VAC L-N (equivalent to 480 VAC L-L), CAT III for voltages up to 600VAC L-N. Pollution degree 2. UL/IEC 61010 test pending.

CURRENT INPUT CHANNELS

Measurement Type	External current transformer, voltage-type secondary – Screw terminal (Max torque 2 inch-pounds (0,25Nm))
CT Input Ratio Range	1:1 to 50000:1
Nominal Input	0.333 V RMS
Input Impedance	33.3kΩ
Crest Factor	3.5 ($\pm 1.17 \text{ Vpk}$)
Sampling Rate	Same rate as mains voltage measuring channels
Wire Connection	Min. 28AWG (0,8 mm ²), Max. 16AWG (1,31mm ²). 600V UL- recognized insulation required

POWER MEASUREMENTS

Definitions

Watts (power)	Sum of true instantaneous per-phase power.
Volt-Amps (apparent power)	Sum of per-phase product of RMS voltage and RMS current, taken over the measurement interval.
Power Factor	True power factor—ratio of Watts to Volt-Amps
VARs (volt-amps reactive)	Fundamental VARs

INSTRUMENT POWER SUPPLY

PQube 3 main power supply (Screw Terminals)	(AC or DC) PQube3 POWER screw terminals
--	---

AC Input Voltage Range	24VAC ± 10% 50/60 Hz
AC Input Current Rating	1.5A
DC Input Voltage Range	±24-48VDC ±10% (polarity independent)
DC Input Current Rating	1A
Power Consumption	20W max
Isolation	>150VDC isolation to all other circuits
PQube 3 – POE - Power Over Ethernet	
Input Voltage Range	37-57VDC
Power Consumption	15W max
PM1 Power Manager Module (optional)	
AC Input Range	100~240VAC ± 10%. 50/60 Hz
AC Input Current Rating	400mA
Auxiliary DC Power Output	24VDC isolated, up to 5.15W max
Power Consumption	20W max

COMMUNICATIONS

RJ-45 Ethernet	
Connection	Standard RJ-45 socket (wired Ethernet).
Protocols	.
Web Server	Real-time meters. All events, trends and statistics recordings. Includes GIF graphs, CSV spreadsheet files, PQDIF, HTML and XML summaries.
FTP Server	File Transfer Protocol. Transfers files from PQube3 SD card to and from any computer.

OPERATING ENVIRONMENT



Ambient Conditions - Operating	Minimum -20°C, Maximum 45°C at 9W power draw, derate to 40°C at 15W power draw, 5% RH ~ 95% RH non-condensing, indoor use
Altitude	Maximum 2000 meters above sea level
Overvoltage Category	For mains measuring terminals, Overvoltage Category III. For PM1 input terminals, Overvoltage Category II.
Pollution Degree	2
Transient Voltages	100kHz ring wave, 6 kV pk, IEC 61180, IEC 61000-4-5. Applied to voltage measuring terminals with Performance Evaluation Class 1. (When applied to optional power supply mains terminal, supply's fuse may operate in PE Class 3 at test levels greater than 4 kV.)
EFT Burst Immunity	4 kV pk, IEC 61000-4-4, Performance Evaluation Class 1. Applied to power measuring terminals and optional PS1 power supply mains terminals.
RF Field Strength Immunity	3V / m, IEC 61000-4-3 Test Level 2.

Magnetic Field Strength Immunity 30A / m, IEC 61000-4-8 Test Level 4.

Ingress Protection Rating (IP Rating) IP20H, IEC 60529.

Appendix 1: Setup File Guide

Device Setup

Setup.ini Tags	Comments	Valid Values	Example
[PQube_Information]	General Information about your PQube		
PQube_ID="PSL PQube in PSL Cal Lab"	The unique identifier will appear on all output information. Quotation marks ("") are required.	Any combination of letters, numbers, spaces and special characters up to 63 characters	
Location_Name="PSL Calibration Lab" Note_1="PSL PQube – General Demonstrator" Note_2="(Located in PSL Calibration Lab)"	Appears on all Event/Snapshot and Trends and Statistics recordings. Quotation marks ("") are required.	Any combination of letters, numbers, spaces and special characters up to 63 characters	
Power_Configuration=AUTO*	Set this tag to AUTO if you want your PQube to automatically choose its Power Configuration based on the voltage it finds on its input terminals when it starts up. Alternatively, you can specify exactly which power configuration you would like your PQube to lock onto. *AUTO not yet available for this tag	AUTO* Single_Phase_L1_N Single_Phase_L1_L2 Split_Phase Star Wye Delta	
Time_Zone=PST	Enter the time zone where your PQube is located. UTC sometimes called Greenwich Mean Time (GMT)	Any combination of 3 or 4 capital letters	

Offset_From_UTC_In_Hours=	Choose the number of hours your PQube should add or subtract from UTC to calculate your local time, if you are using SNTP protocol to set your PQube's time. For example, the offset from UTC in Pacific Standard Time is -8.	-12 to +13	
[Nominal_Inputs]			
Nominal_Phase_To_Phase_Voltage=AUTO* Nominal_Phase_To_Neutral_Voltage=AUTO*	By default, your PQube will automatically detect your nominal voltage if it is one of the following: Phase-Neutral 69V, 120V, 230V, 277V, 350V, or 400V Phase-Phase 69V, 100V, 200V, 208V, 240V, 400V, 480V, 600V, or 690V If using Potential Transformers, you will need to enter the nominal voltage multiplied by the ratio. *AUTO not yet available for this tag	AUTO* Any number between 50 to 400 for Phase-Neutral Any number between 50 to 690 for Phase-Phase	Nominal_Phase_To_Phase_Voltage= 110 If using a 1000:1 Potential Transformer: Nominal_Phase_To_Phase_Voltage= 11000
Nominal_Frequency=AUTO*	By default, your PQube will automatically detect your nominal frequency if it is 50, 60, or 400 Hz. You can also manually set the frequency to 50, 60, or any frequency between 320 and 560Hz. *AUTO not yet available for this tag	AUTO* 50 60 Any number between 320 to 560	
[Channels]			
Record_Phase_To_Phase_Channels=AUTO Record_Phase_To_Neutral_Channels=AUTO	If your Power Configuration includes a neutral conductor, your PQube will automatically be set to record Phase-Neutral channels. If your Power Configuration includes multiple phases, it will automatically record Phase-Phase channels in the Meters (on display, webpage, and Modbus), GIFs, and CSV files.	AUTO ON OFF	

Record_AN1_E_Channel=AUTO Record_AN2_E_Channel=AUTO Record_AN1_AN2_Channel=AUTO Record_DIG1_Channel=AUTO	The AUTO setting records the Analog and Digital Input channels if Events are enabled on these channels.	AUTO ON OFF	
Record_Flicker=ON Record_Voltage THD=ON Record_Current_TDD=ON Record_Voltage_Unbalance=ON Record_Current_Unbalance=ON	Toggles recordings for the selected parameters. When set to ON, the selected parameter will show up in the Meters (display, webpage, and Modbus), as well as the GIF and CSV files. You might want to toggle some of these parameters OFF in order to reduce file size and bandwidth.	ON OFF	
Record_Phase_Current=OFF Record_Neutral_Current=OFF Record_Earth_Current=OFF Record_I6_Current=OFF Record_I7_Current=ON Record_I8_Current=OFF	New tags in PQube 3. You can choose to show or hide any or all of the 8 current channels.	ON OFF	
[Measurement_Setup]			
Enable_10_Second_Frequency=OFF	Default setting is OFF. With OFF setting, the frequency measurement interval is 1 second. Set this tag ON to change the frequency interval to 10 seconds, per the methods in IEC 61000-4-30 Class A Clause 5.1. This also affects the resolution of frequency events.	ON OFF	
Enable_Aggregation_Report=OFF	Set this tag ON to enable 10-minute and 2-hour interval trend recordings in a separate CSV file, per the requirements of IEC 61000-4-30 Class A.	ON OFF	
Voltage_Range="HIGH"	By default, all the ranges are set to HIGH. High range sets the full scale voltage to xxx volts.	HIGH	

Neutral_Voltage_Range="HIGH"	For current, HIGH range = $\pm 10V$ peak. LOW range = 0.333Vrms.	LOW	
Current_Range="HIGH"			
Analog_1_Range="HIGH"	The analog range, acceptable values are HIGH (100V Range) or LOW (10V Range)	HIGH	
Analog_2_Range="HIGH"		LOW	
Analog_3_Range="HIGH"			
Analog_4_Range="HIGH"			
Flicker_Lamp_Voltage=230	Sets the lamp voltage rating for your flicker measurements, per the requirements of IEC 61000-4-15 Ed. 2 Class F1.	120 230	
[Potential_Transformers]	This allows you to express amplitudes measured at the primary of the transformer.		
Potential_Transformer_Ratio=1:1	You can use fractional values such as 1250.5:120. The PT ratio will appear on the display, webpage, and the CSV header. If the PT ratio is high enough, your PQube will automatically switch the units to kV or MV.	From 1:1 to 50000:1	
[Current_Transformers]	Allows you to express the amplitude of currents measured at the primary of the current transformer.		
Current_Transformer_Ratio=1:1 Neutral_Current_Transformer_Ratio=1:1 Earth_Current_Transformer_Ratio=1:1 L6_Current_Transformer_Ratio=1:1 L7_Current_Transformer_Ratio=1:1 L8_Current_Transformer_Ratio=1:1	When using PSL CTs with 0.333V secondary rating, the second number is the voltage. You can use fractional values such as 100.35:0.333 If the CT ratio is high enough, your PQube will automatically switch the units to kA.	From 1:1 to 50000:1	
[Analog_Ratios]			



AN1-E_Channel_Ratio=1:1 AN2-E_Channel_Ratio=1:1	You can use fractional values.	From 1:1 to 10000:1	
Analog_Measurement_Mode=DC_RMS	<p>Set value to DC_RMS when measuring DC signals on the Analog channels. The computation for the "avg" trend value will be the mathematical mean over 10/12 cycles, synchronized to the AC mains frequency.</p> <p>Set value to AC_RMS when measuring AC signals on the Analog channels. The computation for the "avg" trend value is the root-mean-square over 10/12 cycles, synchronized to the AC mains frequency.</p>	DC_RMS AC_RMS	
Analog_1_Channel_Name=AN1-E Analog_1_Channel_Unit=V Analog_2_Channel_Name=AN2-E Analog_2_Channel_Unit=A Analog_3_Channel_Name=AN3-E Analog_3_Channel_Unit=V Analog_4_Channel_Name=AN4-E Analog_4_Channel_Unit=A	Use these tags to customize your channel names and units.	<p>Valid names can be up to 5 characters.</p> <p>Valid units are:</p> <p>"V", "A", "W", "DEG", "%", "NONE"</p>	
[Probe_Configuration]			
Probe_1_Serial_Number = E3001065 Probe_1_Channel_Name = In Probe_2_Serial_Number = E3001141 Probe_2_Channel_Name = Out	Enter the serial numbers of your ENV1 or ENV2 probes here. You can also assign a custom name to help you identify which probes are installed at each location.	<p>Serial Number: E300xxxx</p> <p>Valid names can be up to 5 characters.</p>	


Event Triggering

Setup.ini Tags	Comments	Valid Values	Example
[Phase_To_Neutral_Events]			
Phase_To_Neutral_Events=AUTO	Use the AUTO setting to let your PQube decide to record Phase-Neutral events. If your Power Configuration includes a Neutral conductor, your PQube will record Phase-Neutral events.	AUTO ON OFF	
Phase_To_Neutral_Dip_Threshold_In_Percent=90.00 Phase_To_Neutral_Swell_Threshold_In_Percent=110.00 Phase_To_Neutral_Interruption_Threshold_In_Percent=10.00 Phase_To_Neutral_Event_Hysteresis_In_Percent=2.00	Set thresholds for Voltage Dips, Swells, and Interruptions. Percent refers to Percent remaining of nominal voltage.	For dips, any number between 0 and 100. For swells, any number greater than 100. For hysteresis, any number up to 100.	
[Phase_To_Phase_Events]			
Phase_To_Phase_Events=AUTO	Use the AUTO setting to let your PQube infer to record Phase-Phase events or not. If your Power Configuration includes multiple phases, your PQube will record Phase-Phase events.	AUTO ON OFF	
Phase_To_Phase_Dip_Threshold_In_Percent=90.00 Phase_To_Phase_Swell_Threshold_In_Percent=110.00 Phase_To_Phase_Interruption_Threshold_In_Percent=10.00 Phase_To_Phase_Event_Hysteresis_In_Percent=2.00	Set thresholds for Voltage Dips, Swells, and Interruptions. Percent refers to Percent remaining of nominal voltage.	For dips, any number between 0 and 100. For swells, any number greater than 100. For hysteresis, any number up to 100.	

[Snapshot_Events]			
Waveform_Snapshot_Interval_In_Hours=24	<p>Your PQube is scheduled to record a Snapshot of your electric power at this interval.</p> <p>When the interval is 24 hours, your PQube will take a Snapshot of your power at 12 noon every day.</p>	OFF 3 6 24	
Waveform_Snapshot_At_Startup=OFF	Set this tag to ON to take a Snapshot of your electric power every time your PQube is powered on or reset.	ON OFF	
[AN1_E_Events]			
AN1_E_Events=OFF	<p>Set this tag to ON or OFF to toggle event triggering on your AN1-E channel.</p> <p>Set the value to USER_COUNTER to increment a counter every time an event occurs on this channel (no events, waveforms, or RMS envelopes will be generated).</p>	ON OFF USER_COUNTER	
AN1_E_Dip_Threshold_In_Volts=2.00 AN1_E_Swell_Threshold_In_Volts=60.00 AN1_E_Event_Hysteresis_In_Volts=0.5	Set event detection thresholds for Analog channel 1.	Use the values after being transformed by the Analog ratios, not the actual voltage coming into the Analog terminals.	
[AN2_E_Events]			
AN2_E_Events=OFF	<p>Set this tag to ON or OFF to toggle event triggering on your AN2-E channel.</p> <p>Set the value to USER_COUNTER to increment a counter every time an event occurs on this channel (no events, waveforms, or RMS envelopes will be generated).</p>	ON OFF USER_COUNTER	
AN2_E_Dip_Threshold_In_Volts=2.00 AN2_E_Swell_Threshold_In_Volts=60.00 AN2_E_Event_Hysteresis_In_Volts=0.5	Set event detection thresholds for Analog channel 2.	Use the values after being transformed by the Analog ratios, not the	


		actual voltage coming into the Analog terminals.	
[AN1_AN2_Events]			
AN1_AN2_Events=OFF	<p>Set this tag to ON or OFF to toggle event triggering on your AN1-AN2 channel.</p> <p>Set the value to USER_COUNTER to increment a counter every time an event occurs on this channel (no events, waveforms, or RMS envelopes will be generated).</p>	ON OFF USER_COUNTER	
AN1_AN2_Dip_Threshold_In_Volts=2.00 AN1_AN2_Swell_Threshold_In_Volts=60.00 AN1_AN2_Event_Hysteresis_In_Volts=0.5	Set event detection thresholds for AN1-AN2 voltage.	Use the values after being transformed by the Analog ratios, not the actual voltage coming into the Analog terminals.	
[Frequency_Events]			
Frequency_Events=ON	Enable or disable events for frequency.	ON OFF	
Underfrequency_Threshold_In_Percent=99.50 Overfrequency_Threshold_In_Percent=100.50 Frequency_Event_Hysteresis_In_Percent=0.20	Set thresholds for frequency event detection here.	<p>For underfrequency events, any value between 0 and 100.</p> <p>For overfrequency events, any value above 100.</p> <p>For hysteresis, any value between 0 and 100.</p>	
[Phase_Current_Events]			
Phase_Current_Events=OFF	Trigger events for current on L1, L2, and/or L3.	ON OFF	
Phase_Current_Level_Threshold_In_Amps=AUTO Phase_Current_Level_Hysteresis_In_Amps=AUTO	<p>Set the level threshold here. Your PQube will record an event when the current crosses above this level.</p> <p>AUTO sets the threshold to your full-scale current. To determine your full-scale current, multiply your</p>	AUTO Any positive number (in amps).	

	<p>CT ratio by the full-scale input rating of your current inputs (0.333V for LOW range, $\pm 10\text{Vpk}$ for high range).</p> <p>Example: $\text{CT ratio} = 100\text{A}:0.333\text{V}$ $\text{Full-scale of current input}=0.333\text{V}$ $100:0.333 * 0.333 = 100\text{A}$</p> <p>AUTO for hysteresis defaults to 4% of threshold.</p>		
Phase_Current_Inrush_Threshold_In_Amps=AUTO Phase_Current_Inrush_Threshold_In_Cycles=2	<p>Set the inrush threshold here. Your PQube will record an event when the increase of current exceeds the Inrush_Threshold_In_Amps value, within a period of the Inrush_Threshold_In_Cycles or less.</p>	<p>AUTO</p> <p>Any value greater than 0 for inrush threshold in amps.</p> <p>Any integer value greater than 0 for inrush threshold in cycles.</p>	
[Neutral_Current_Events]			
Neutral_Current_Events=OFF	Trigger events for current on the Neutral channel.	ON OFF	
Neutral_Current_Level_Threshold_In_Amps=AUTO Neutral_Current_Level_Hysteresis_In_Amps=AUTO	<p>Set the level threshold here. Your PQube will record an event when the current crosses above this level.</p> <p>AUTO sets the threshold to your full-scale current. To determine your full-scale current, multiply your CT ratio by the full-scale input rating of your current inputs (0.333V for LOW range, $\pm 10\text{Vpk}$ for high range).</p> <p>Example: $\text{CT ratio} = 100\text{A}:0.333\text{V}$</p>	<p>AUTO</p> <p>Any positive number in amps.</p>	

	Full-scale of current input=0.333V 100:0.333 * 0.333 = 100A AUTO for hysteresis defaults to 4% of threshold.		
Neutral_Current_Inrush_Threshold_In_Amps=AUTO Neutral_Current_Inrush_Threshold_In_Cycles=2	Set the inrush threshold here. Your PQube will record an event when the increase of current exceeds the Inrush_Threshold_In_Amps value, within a period of the Inrush_Threshold_In_Cycles or less.	AUTO Any value greater than 0 for inrush threshold in amps. Any integer value greater than 0 for inrush threshold in cycles.	
[Earth_Current_Events]			
Earth_Current_Events=OFF	Trigger Earth Current events.	ON OFF	
Earth_Current_Level_Threshold_In_Amps=AUTO Earth_Current_Level_Hysteresis_In_Amps=AUTO	Set the level threshold here. Your PQube will record an event when the current crosses above this level. AUTO sets the threshold to your full-scale current. To determine your full-scale current, multiply your CT ratio by the full-scale input rating of your current inputs (0.333V for LOW range, ±10Vpk for high range). Example: CT ratio = 100A:0.333V Full-scale of current input=0.333V 100:0.333 * 0.333 = 100A AUTO for hysteresis defaults to 4% of threshold.	AUTO Any positive number in amps.	
Earth_Current_Inrush_Threshold_In_Amps=AUTO	Set the inrush threshold here. Your PQube will record an event when the increase of current exceeds the Inrush_Threshold_In_Amps value,	AUTO	

Earth_Current_Inrush_Threshold_In_Cycles=2	within a period of the Inrush_Threshold_In_Cycles or less.	Any value greater than 0 for inrush threshold in amps. Any integer value greater than 0 for inrush threshold in cycles.	
[DIG1_Events]			
Enable_DIG1_Dip_Event=OFF Enable_DIG1_Swell_Event=OFF	Trigger events on the DIG1 channel. WARNING: Do not enable both DIG1_Dip and DIG1_Swell events at the same time. It will result in an infinitely long event which will prevent your PQube from recording waveform and RMS graphs for other events.	ON OFF	
DIG1_Dip_Threshold=0.5 DIG1_Swell_Threshold=0.5 DIG1_Event_Hysteresis=0.1		Any number between 0 and 1.	
[Waveshape_Change_Events]			
Waveshape_Change_Events=ON	Trigger a Waveshape Change when the voltage waveform changes abruptly. This is useful for detecting power factor correction capacitor switching.	ON OFF	
Voltage_Threshold_In_Percent_Of_Nominal=20.00 Duration_Threshold_In_Percent_Of_Cycle=10.00	Uses the "Floating Window" algorithm. Each Nth sample of the present cycle defines the threshold for the Nth sample of the next cycle. If the voltage change from one cycle to the next exceeds the selected threshold, for the selected duration or longer, a Waveshape Change will be triggered.	For voltage threshold, any number up to 100. For duration threshold, any number to 100.	
[External_Probe_Events]			

Probe_1_Overtemperature_Events=ON Probe_1_Undertemperature_Events=OFF Probe_1_Undertemperature_Threshold_in_Deg_C=0 Probe_1_Overtemperature_Threshold_in_Deg_C=50 Probe_1_Temperature_Event_Hysteresis_in_Deg_C=2 Probe_1_High_Humidity_Events=OFF Probe_1_Low_Humidity_Events=OFF Probe_1_Low_Humidity_Threshold_in_Percent_RH=0 Probe_1_High_Humidity_Threshold_in_Percent_RH=100 Probe_1_Humidity_Event_Hysteresis_in_Percent_RH=2 Probe_2_Overtemperature_Events=OFF Probe_2_Undertemperature_Events=OFF Probe_2_Undertemperature_Threshold_in_Deg_C=0 Probe_2_Overtemperature_Threshold_in_Deg_C=50 Probe_2_Temperature_Event_Hysteresis_in_Deg_C=2 Probe_2_High_Humidity_Events=OFF Probe_2_Low_Humidity_Events="OFF" Probe_2_Low_Humidity_Threshold_in_Percent_RH=0 Probe_2_High_Humidity_Threshold_in_Percent_RH=100 Probe_2_Humidity_Event_Hysteresis_in_Percent_RH=2 [Major_Dip_Events]	Show pop ups, recent event screens, and event depth duration based on temperature/humidity thresholds from either channel.	ON OFF For temperature events, any number in degrees C. For humidity events, any number in %RH.	
---	--	--	--

Major_Dip_Threshold_Settings=OFF	<p>Major Dips are defined by the selected depth/duration curve. This is useful for emulating PSL's PQ1 Power Quality Relay.</p> <p>When a dip exceeds the thresholds as specified by the selected standard, it will be characterized as a Major Dip.</p>	OFF ITIC CBEMA SEMI F47 STANDARD SAMSUNG_POWER_VACCINE MIL_STD_704E MIL_STD_1399 CUSTOM Refer to Appendix 2 for Major Dip curves.	
Major_Dip_Threshold_Level_1_in_Percent=OFF Major_Dip_Threshold_Level_1_Duration_in_Seconds=0 Major_Dip_Threshold_Level_2_in_Percent=OFF Major_Dip_Threshold_Level_2_Duration_in_Seconds=0 Major_Dip_Threshold_Level_3_in_Percent=OFF Major_Dip_Threshold_Level_3_Duration_in_Seconds=0 Major_Dip_Threshold_Level_4_in_Percent=OFF Major_Dip_Threshold_Level_4_Duration_in_Seconds=0	<p>This configuration is only valid if you set the Major_Dip_Threshold_Setting to CUSTOM for the user to create their own custom threshold. Each additional threshold has to be lower than the previous, and each duration has to be shorter.</p> <p>Example of valid Usage:</p> <pre>Major_Dip_Threshold_Level_1_in_Percent=80 Major_Dip_Threshold_Level_1_Duration_in_Seconds=5 Major_Dip_Threshold_Level_2_in_Percent=50 Major_Dip_Threshold_Level_2_Duration_in_Seconds=0.5</pre> <p>Example of invalid Usage:</p> <pre>Major_Dip_Threshold_Level_1_in_Percent=70 Major_Dip_Threshold_Level_1_Duration_in_Seconds=2 Major_Dip_Threshold_Level_2_in_Percent=80 Major_Dip_Threshold_Level_2_Duration_in_Seconds=1</pre>		
[Mains_Signaling]*	*Mains Signaling not yet available.		

Mains_Signaling_Events=OFF	Set up Mains Signaling events (also called ripple control) according to the requirements of IEC 61000-4-30 Class A Section 5.10.		
Mains_Signaling_Threshold=60			
Mains_Signaling_Duration_In_Seconds=60			
Mains_Signaling_Channel=L1	Define which channel to monitor the Mains Signaling frequency.	L1 L2 L3	
Mains_Signaling_Harmonic_In_Hz=	Specify the Mains Signaling frequency of interest.		

Network Configuration

Setup.ini Tags	Comments	Valid Values	Example
[Network_Setup]			
IP_Address_Method=Use_DHCP	If you are automatically assigned an IP address by your network, use DHCP. If you are using a static IP, use Fixed IP.	Use_DHCP Use_Fixed_IP	
[Fixed_IP]			
IP_Address= IP_Mask= IP_Gateway= IP_DNS1= IP_DNS2=	Enter your IP address information here. This information is ignored if DHCP is selected.		
[Outgoing_Email]	Parameters for receiving emails from your PQube 3.		
Send_Email_On_Recording=OFF	Receive an email notification whenever your PQube resets, records an Event or Snapshot, or generates Trends and Statistics.	ON OFF	

Send_Reset_Emails=OFF Send_Events_Emails=OFF Send_Trends_Emails=OFF	Choose which types of emails you want from your PQube. Useful for reducing your data usage by receiving only the types of emails that you need.	ON OFF	
Email_To_1=recipient1@serveraddress.com, recipient2@serveraddress.com	Specify the email recipients who will be receiving emails from this PQube. Add multiple addresses, separated by commas.		
Relay_Host=[mail.serveraddress.com]:25 Use_SSL=NO Reply_To=pqubeemail@pqube.com Reply_To_Password=pqubeemailpassword SMTPS_IP_And_Port=	IMPORTANT: Your PQube needs its own e-mail account. Do not try to share your personal e-mail account with your PQube – if you do, it will try very hard to receive all of your e-mails. You can get a free, temporary PQube e-mail account from PSL. Contact support@powerstandards.com		
Email_Body_Type=Human_Readable_HTML	Select the format of the email body.	Human_Readable_HTML Human_Readable_Text Machine_Readable_XML	
[Incoming_Email]	Parameters for sending email commands to your PQube 3.		
Incoming_Email=OFF	Allow your PQube to receive incoming email.	ON OFF	
Check_Every_N_Seconds=100	Set how often your PQube will check for incoming mail. IMPORTANT: For PQube 3, this interval is in seconds, not minutes.		
[Incoming_Email_Filter]			
Subject_Must_Begin_With=PQube3	Your PQube will only accept incoming emails when the Subject begins with this keyword. This is another layer of security for your PQube.		Subject: PQube3 Firmware Update Subject: PQube3 Send Logs Subject: PQube3 Reset PQube

Email_Must_Be_From_1= Email_Must_Be_From_2= Email_Must_Be_From_3= Email_Must_Be_From_4= Email_Must_Be_From_5=	If this list is left blank, then your PQube will accept emails from anyone. If any email addresses are added to this list, then your PQube will only accept emails from recipients on this list.		
[Email_Client_1]			
Enable=YES Server= Port= Protocol= Provider=PSL Server_Options= User= Options= Password=	[From Thomas] What is the difference between these tags and the ones in the Outgoing Email section?		
[Modbus]			
Modbus_Slave_Device_Address=1			
Modbus_TCP_port=502			
Modbus_Register_Start_Address=7000			
Byte_Order=BIG_ENDIAN	Big Endian byte order stores the most significant number in the first byte. Little Endian byte order stores the least significant number in the first byte.	BIG_ENDIAN LITTLE_ENDIAN	
[Output_Formatting]			
Decimal_Separator="."	Set the Decimal, Date, Time, and CSV separator characters here. These affect the PQube display,		

Date_Separator="/" Time_Separator ":" CSV_Separator ","	the meters on the web interface, emails, and output files. NOTE: You must still use a decimal point for all numbers that you enter in the Setup.ini file.		
[SNMP_Settings]			
Trap_Receiver=172.17.6.181 SNMP_Port=1161	Set the IP address and port of the SNMP Manager.		
SNMP_Trap_Version=v3 SNMP_V1_V2_Community_Name=public SNMP_V3_Security_Level=AuthPriv SNMP_V3_User_Name=MD5DESUser SNMP_V3_Auth_Protocol=MD5 SNMP_V3_Auth_Password=MD5UserPassword SNMP_V3_Priv_Protocol=DES SNMP_V3_Priv_Password=DESUserPassword	Choose SNMP v2c or v3 and define SNMP settings.		
[Services_Enabled]			
SNMPD=ON SNMPD_Traps=ON HTTP_Commands_Page=ON Incoming_Email=ON	Toggle various services on or off here.	ON OFF	
[SNTP_Settings]			
Enable_SNTP=OFF	Synchronize your PQube's time clock using SNTP	ON OFF	

SNTP_Server=pool.ntp.org			
SNTP_Update_Interval_In_Hours=24		1 to 168	
[NTP_Settings]			
Enable_NTP=OFF	Synchronize your PQube's time clock using NTP (more accurate than SNTP).	ON OFF	
NTP_Server=north-america.pool.ntp.org			
[Web_Server_Settings]			
Web_Server=ON	Enable your PQube's HTTP Web Server	ON OFF	
Web_Server_port=DEFAULT			
Require_HTTP_Authorization=OFF HTTP_User_Name= HTTP_Password=	Restrict general access to your PQube's Web Server		
Require_HTTP_Admin_Authorization=ON HTTP_Admin_User_Name=admin HTTP_Admin_Password=admin	Restrict access to the Commands section of your PQube's Web Server.		

Trend Setup

Setup.ini Tags	Comments	Valid Values	Example
[Trend_Settings]			
Enable_Daily_Trends=ON Enable_Weekly_Trends=ON Enable_Monthly_Trends=ON	Daily Trends and Statistics are recorded every midnight. Weekly Trends and Statistics are recorded every midnight between Sunday and Monday using ISO 8601 methods. Monthly Trends and Statistics are recorded every midnight after the last day of the month.	ON OFF	
Trend_Individual_Phases=ON	If OFF, your PQube records worst-case and average of all phases. If ON, your PQube also records the values of individual phases. This data is available for Voltage, Current, and Power.	ON OFF	
Omit_Flagged_Mains_Voltages_From_Stats=OFF	Disturbances on your power line can skew your statistics, so you may opt to omit these values when your PQube is processing statistics data.	ON OFF	
Unbalance_Component_To_Trend=NEGATIVE	Choose which unbalance component to trend. Only applies if IEC or GB unbalance method is selected.	NEGATIVE ZERO	
Trend_Harmonic_Interval_In_Minutes=OFF	Specify the recording interval for harmonics trending. Your PQube will take a 10/12 cycle sample of data every 10 or 15 minutes. NOTE: Your PQube automatically adjusts the sampling rate to 128 samples per cycle if you turn this on.	OFF 10 15	
Power_Polarity_of_Interest=Positive	Set to Positive for power consumption, set to negative for power generation, or set to BOTH if you are monitoring consumption and generation.	POSITIVE NEGATIVE BOTH	
Min_Volts_of_Interest_in_Percent_of_Nominal=AUTO	Set the minimum and maximum voltage for viewing in Trends and Statistics recordings if the AUTO setting does not provide a suitable graph.	AUTO Any number [percent]	

Max_Volts_of_Interest_in_Percent_of_Nominal =AUTO	<p>The AUTO setting is determined by the Voltage Dip and Swell thresholds.</p> <p>Your PQube intentionally does not auto-scale the Trends and Statistics graphs. This makes it easy to visually compare trends recorded at different times.</p> <p>With auto-scaling, it is difficult to compare two graphs.</p>		
Min_Current_of_Interest_in_Amps=AUTO Max_Current_of_Interest_in_Amps=AUTO	<p>Set the minimum and maximum current for viewing in Trends and Statistics recordings if the AUTO setting does not provide a suitable graph.</p> <p>The AUTO setting is determined by your full-scale current.</p>	AUTO Any number [amps]	
Min_Earth_Current_of_Interest_in_Amps=AUTO Max_Earth_Current_of_Interest_in_Amps=AUTO	<p>If your PQube is calculating the Earth Current, AUTO sets the Max_Earth_Current_of_Interest_in_Amps to 5% of the Max_Current_of_Interest_in_Amps value.</p> <p>If measuring the Earth Current with a current transformer, the AUTO setting is determined by your CT ratio and the nominal current rating of your current sensing module.</p>	AUTO Any number [amps]	
Min_Frequency_of_Interest_in_Percent_of_Nominal =AUTO Max_Frequency_of_Interest_in_Percent_of_Nominal =AUTO	The AUTO values are determined by the Underfrequency and Overfrequency thresholds.	AUTO Any number [Hz]	
Min_AN1_E_of_Interest_in_RMS_volts=AUTO Max_AN1_E_of_Interest_in_RMS_volts=AUTO	The AUTO values are determined by the Dip and Swell thresholds on Analog Channel 1.	AUTO Any number [volts]	
Min_AN2_E_of_Interest_in_RMS_volts=AUTO Max_AN2_E_of_Interest_in_RMS_volts=AUTO	The AUTO values are determined by the Dip and Swell thresholds on Analog Channel 2.	AUTO Any number [volts]	
Min_AN1_AN2_of_Interest_in_RMS_volts=AUTO Max_AN1_AN2_of_Interest_in_RMS_volts=AUTO	The AUTO values are determined by the AN1-AN2 Dip and Swell thresholds.	AUTO Any number [volts]	
Min_Temperature_of_Interest_in_Degrees_C=0 Max_Temperature_of_Interest_in_Degrees_C=50	Set the minimum and maximum temperature for viewing in Trends and Statistics recordings if the AUTO setting does not provide a suitable graph.	Any number [degrees °C]	

Min_Humidity_of_Interest_in_%_RH=0	Set the minimum and maximum relative humidity in % for viewing in Trends and Statistics recordings.	Any number [%RH]	
Max_Humidity_of_Interest_in_%_RH=100			
Max_Voltage_Unbalance_of_Interest_in_Percent=10%	Set the full scale Voltage Unbalance in Trends and Statistics recordings.	Any number [%]	
Max_Current_Unbalance_of_Interest_in_Percent=99%	Set the full scale Current Unbalance in Trends and Statistics recordings.	Any number [%]	
Max_Voltage THD_of_Interest_in_Percent=10%	Set the full scale THD voltage in Trends and Statistics recordings.	Any number [%]	
Max_Current_TDD_of_Interest_in_Percent=25%	Set the full scale TDD current in Trends and Statistics recordings.	Any number [%]	
Max_Flicker_of_Interest=4	Set the full scale RMS Flicker in Trends and Statistics recordings.	Any number	