

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

INTEGRATED CONTROL PANEL (ICP)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Integrated Control Panel (ICP). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Information and Entertainment System](#)

(415-01 Information and Entertainment System, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B10B8-94	Push Buttons - Unexpected operation	▪ Integrated control panel switch stuck active ▪ Integrated control panel internal failure	▪ Test the operation of the integrated control panel switches ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new integrated control panel
U0055-88	Vehicle Communication Bus D - Bus off	▪ Medium speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0300-00	Internal Control Module Software Incompatibility - No sub type information	▪ Central junction box is not configured correctly ▪ Integrated control panel is not configured correctly ▪ Integrated control panel internal failure	▪ Using the manufacturer approved diagnostic system, re-configure the central junction box with the latest level software ▪ Using the manufacturer approved diagnostic system, re-configure the integrated control panel with the latest level software ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new integrated control panel
U201A-57	Control Module Main Calibration Data - Invalid/incomplete software component	▪ Integrated control panel software invalid/corrupt ▪ Integrated control panel internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, re-configure the integrated control panel with the latest level software ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new integrated control panel

U2300-54	Central Configuration - Missing calibration	▪ Car configuration file mismatch with vehicle specification ▪ Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest ▪ Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U2300-55	Central Configuration - Not configured	▪ Integrated control panel is not configured correctly ▪ Car configuration file mismatch with vehicle specification ▪ Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Using the manufacturer approved diagnostic system, re-configure the integrated control panel with the latest level software ▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest ▪ Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body)

			circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U2300-56	Central Configuration - Invalid/incomplete configuration	▪ Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest