

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

TELEPHONE INTERFACE MODULE (TIM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Telephone Interface Module (TIM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Information and Entertainment System](#)

(415-00 Information and Entertainment System - General Information, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B100E-25	Video Input "A" - Signal shape/waveform failure	Navigation video signal circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the navigation video signal circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B1183-96	Video Encoder - Component internal failure	Telephone interface module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new telephone interface module
U0001-81	High Speed CAN Communication Bus - Invalid serial data received	- Invalid data received from the touch screen - Invalid data received from the navigation control module	- Using the manufacturer approved diagnostic system, check the touch screen for related DTCs and refer to the relevant DTC index - Using the manufacturer approved diagnostic system, check the navigation control module for related DTCs and refer to the relevant DTC index
U0001-82	High Speed CAN Communication Bus - Alive/sequence counter incorrect / not updated	- Invalid data received from the touch screen - Invalid data received from the navigation control module	- Using the manufacturer approved diagnostic system, check the touch screen for related DTCs and refer to the relevant DTC index - Using the manufacturer approved diagnostic system, check the navigation control module for related DTCs and refer to the relevant DTC index
U0001-87	High Speed CAN Communication Bus - Missing message	Missing message from the touch screen	Using the manufacturer approved diagnostic system, check the snapshot data for details of the missing message. Check the touch

		Missing message from the navigation control module	screen for related DTCs and refer to the relevant DTC index Using the manufacturer approved diagnostic system, check the snapshot data for details of the missing message. Check the navigation control module for related DTCs and refer to the relevant DTC index
U0001-88	High Speed CAN Communication Bus - Bus off	Private high speed CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the private high speed CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0010-88	Medium Speed CAN Communication Bus - Bus off	Medium speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0011-82	Medium Speed CAN Communication Bus Performance - Alive/sequence counter incorrect / not updated	Invalid data received from another control module via the medium speed CAN bus (comfort)	Using the manufacturer approved diagnostic system, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0011-87	Medium Speed CAN Communication Bus Performance - Missing message	Missing message from another control module via the medium speed CAN bus (comfort)	Using the manufacturer approved diagnostic system, check the snapshot data to determine the missing message source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index

U0300-00	Internal Control Module Software Incompatibility - No sub type information	Car configuration file mismatch with vehicle specification	Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary
U0400-92	Invalid Data Received - Performance or incorrect operation	Invalid road speed signal received	Using the manufacturer approved diagnostic system, check the anti-lock brake system control module for related DTCs and refer to the relevant DTC index
U1A01-82	Communication Link - Alive/sequence counter incorrect / not updated	Telephone interface module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new telephone interface module
U1A01-88	Communication Link - Bus off	Telephone interface module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new telephone interface module
U1A4B-47	Control Module Processor B - Watchdog/safety MicroController failure	Telephone interface module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new telephone interface module
U2015-57	Control Module Boot Software - Invalid/incomplete software component	Telephone interface module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the telephone interface module with the latest level software
U2017-57	Control Module Software #2 - Invalid/incomplete software component	Telephone interface module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the telephone interface module with the latest level software
U201A-54	Control Module Main Calibration Data - Missing calibration	Telephone interface module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the telephone interface module with the latest level software

U2020-14	Phone Holder Baseplate Detection - Circuit short to ground or open	▪ Audio video input/output panel circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the audio video input/output panel circuits for short circuit to ground, short circuit to power, open circuit, high resistance
U2100-00	Initial Configuration Not Complete - No sub type information	▪ Telephone interface module is not configured correctly	▪ Using the manufacturer approved diagnostic system, re-configure the telephone interface module with the latest level software
U2100-56	Initial Configuration Not Complete - Invalid/incomplete configuration	▪ Car configuration file mismatch with vehicle specification	▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary
U2101-00	Control Module Configuration Incompatible - No sub type information	▪ Car configuration file mismatch with vehicle specification	▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary