

fl2xui

Flightlog2kml GUI tool

Jonathan Hudson

(c) Jonathan Hudson 2022

Table of contents


1. fl2xui	3
1.1 Overview	3
1.1.1 Linux (dark theme)	3
1.1.2 MacOS	3
1.1.3 Windows	4
1.1.4 Features	4
1.2 User Interface	4
1.2.1 File / index selection area (1)	4
1.2.2 Visualisation Options (2)	5
1.2.3 Output Area (3)	5
1.2.4 Progress bar and Run button (4)	5
1.3 Defaults	5
1.4 Installation	5
1.4.1 Linux, FreeBSD	5
1.4.2 Windows	6
1.4.3 MacOS	6
1.5 Author and Licence	6

1.1 Overview


fl2xui is a cross-platform GUI for the flightlog2kml tool that converts (inav) flight logs to beautiful, annotated KML or KMZ files for visualisation in Google Earth.

fl2xui provides a consistent user interface across Linux, FreeBSD, MacOS and Windows.


1.1.1 Linux (dark theme)



1.1.2 MacOS




1.1.3 Windows



1.1.4 Features

- Multiple logs (Blackbox, OTX/ETX CSV)
- Summary information
- · Easy access to common visualisation options.

1.2 User Interface



1.2.1 File / index selection area (1)

• Log...: Opens a file chooser to select log files. Multiple files may be selected. The files may be a combination of Blackbox logs or OpenTX / EdgeTX CSV logs.

- Output...: Opens a file chooser to select the output directory. The defaults (no selection) are:
 - Linux, FreeBSD, MacOS: Current (working) directory, typically \$HOME when launched from a desktop environment.
 - Windows: "Documents" (e.g. C:\Users\USERNAME\Documents).
- Mission...: Optional mission file (single selection). MW XML format (e.g. from mwp or inav configurator.
- Index : If 0 (default), processes all logs in (each) file; if non zero, processes a single log at the specified index.

1.2.2 Visualisation Options (2)



Drag and drop

On Linux / FreeBSD, you can also drag and drop logs and mission files into this area, at least with the Gnome desktop environment.

- DMS: Display positions as degrees / minutes / seconds (DD:MM:SS.sss) vice decimal degress (DD.dddddd).
- Extrude: Extrude flight points the ground.
- Efficiency Layer: Include an efficiency layer in the output.
- RSSI as default : Set the RSSI layer as the default (vice Flight Mode).
- KML : Generate uncompressed KML (vice compressed KMZ).
- Gradient : Select the colour gradient for RSSI / Efficiency layer)
 - · Red shades of red
 - Green / Red Green (best) to red (worst)
 - Yellow / Orange / Red Yellow (best) to red (worst) via orange

1.2.3 Output Area (3)

• Output Area: Scrolled window showing process or error messages.

1.2.4 Progress bar and Run button (4)

- Run button is enabled when log files have been selected
- \bullet An oscillating progress bar is displayed when a conversion is in process (after clicking "Run").

1.3 Defaults

The defaults for run time options are taken from the flightlog2kml configuration file:

- POSIX OS : ~/.config/fl2x/config.json
- Windows : %LOCALAPPDATA%\fl2x\config.json

See also flight2kml wiki example.

1.4 Installation

1.4.1 Linux, FreeBSD

- Common GTK packages
- Debian package *.deb for Debian / Ubuntu and derivatives in fl2xui release area.
- Easily built from source

```
# Once (setup)
meson build --buildtype=release --strip --prefix=~/.local
# Build and install to ~/.local/bin (add to PATH if necessary)
```

or specify some other PATH element (/usr/bin, /usr/local/bin, ~/bin) meson install -C build

1.4.2 Windows

- Win64 Installer file in the fl2xui release area, creates a desktop shortcut launcher.
- \bullet Win64 Zip file in the fl2xui release area, provided with shortcut launcher.
- Can be built from source using Msys2 (as Linux).
- It is recommended that blackbox_decode and flightlog2kml are in the fl2xui\bin directory (as in the release archive).

1.4.3 MacOS

• Homebrew or similar environment is required to build from source (as Linux).

1.5 Author and Licence

(c) 2020 Jonathan Hudson

GPL v2 or later.