```
SPAN LENGTH BY STANDARD NDS METHOD
```

The standard NDS joist check limits the deflection/span for a given weight per square foot.

Given this, our procedure here is:

Hold deflection/span and weight per square foot constant and compute how the span changes when the boardwalk section parameters change relative to the reference boardwalk section.

According to the NDS equations for joists, for fixed weight per square foot:

deflection/span is directly proportional to:
 the cube of the span
 and
 the length of the tread
and inversely proportional to:
 the actual width of the stringer
 and
 the cube of the actual height of the stringer
 and
 the number of stringers
 and
 the elastic modulus of the wood

For simplicity of output, we set:

- H = effective height of stringers
 - = actual height of a stringer if NOT truss
 - = sum of actual heights of 'stringers' if truss
- W = sum of actual widths of stringers
 (typically number of stringers times actual
 width of one stringer)

Reference Section Values:

span = 8ft cross section = 2x8, actual 1.50in x 7.25in number of stringers = 2 tread length = 36in elastic modulus = 1600000 for No 1 Standard W = 3.0 H = 7.25

STANDA	ARD NON-	-TRUSS	SPAN I	LENGTH	IN FEET
W	3.50	5.50		9.25	11.25
3.00 3.50 4.00 4.50 5.00 5.50 6.00 7.50 8.00 8.50 9.00 16.00 24.00 36.00 42.00 48.00	3.86 4.07 4.25 4.42 4.58 4.73 4.87 5.00 5.12 5.24 5.36 5.46 5.57 6.75 7.72 8.84 9.31 9.73	6.07 6.39 6.68 6.95 7.20 7.43 7.65 7.85 8.05 8.24 8.42 8.59 8.75 10.60 12.14 13.89 14.63 15.29	8.00 8.42 8.81 9.16 9.49 9.79 10.08 10.35 10.61 11.09 11.32 11.54 13.98 16.00 18.32 19.28 20.16	10.21 10.75 11.23 11.68 12.10 12.49 12.86 13.21 13.54 14.15 14.44 14.72 17.83 20.41 23.37 24.60 25.72	17.90 21.69 24.83 28.42
		RUSS SI RIDGE I		NGTH IN S MUST	N FEET BE ***
****	** CHEC	KED BY	AN EN	GINEER	*****
Н	3.00	6.00	7.00	10.00	14.00
11.00 12.75 14.50 14.75 16.50 16.75 18.50 20.50 22.50	12.14 14.07 16.00 16.28 18.21 18.48 20.41 22.62 24.83	15.29 17.73 20.16 20.51 22.94 23.29 25.72 28.50 31.28	16.10 18.66 21.22 21.59 24.15 24.51 27.08 30.00 32.93	27.20 27.61 30.49	37.80

STANDARD MODULUS	OF ELASTIC	ITY SPAN L	ENGTH MULTIPLIER
type	E	multiplie	r
No 1 Dense	1800000	1.04	
No 1	1600000	1.00	
No 1 Non-Dense	1400000	0.96	

STANDARD TREAD LENGTH SPAN LENGTH MULTIPLIER length multiplier

- I
1.14
1.00
0.94
0.91

SPAN LENGTH BY ALTERNATE NDS METHOD

This is the same as the Standard NDS Method, except that instead of holding the weight per square foot constant, we hold total weight constant.

This method is NOT valid if the resulting span length is less that the reference length. For example, if the reference section can hold 3 people, this method calculates the span that can hold 3 people for other parameters, but if the result is 60% of the reference length, only 2 people will fit. So results less than the reference length are NOT given.

According to the NDS equations for joists, for fixed total weight:

deflection/span is directly proportional to:
 the square of the span
and inversely proportional to:
 the satual width of the stringer

the actual width of the stringer

the cube of the actual height of the stringer and $% \left(1\right) =\left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right)$

the number of stringers

The elastic modulus multiplier given below is different for the alternate method.

For simplicity of output, we set:

H = effective height of stringers

- = actual height of a stringer if NOT truss
- = sum of actual heights of 'stringers' if truss
- W = sum of actual widths of stringers
 (typically number of stringers times actual
 width of one stringer)

ALTERI	NATE NON-TRUSS SPAN LENGTH IN FEET
₩	H 3.50 5.50 7.25 9.25 11.25
3.00	8.00 11.53 15.46
3.50	8.64 12.45 16.70
4.00	9.24 13.31 17.86
4.50	9.80 14.12 18.94
5.00	10.33 14.88 19.96
5.50	10.83 15.61 20.94
6.00	11.31 16.30 21.87
6.50	11.78 16.97 22.76
7.00	8.07 12.22 17.61 23.62
7.50	8.36 12.65 18.23 24.45
8.00	8.63 13.06 18.83 25.25
8.50	8.90 13.47 19.41 26.03
9.00	9.16 13.86 19.97 26.78
16.00	12.21 18.48 26.63 35.71
24.00	14.95 22.63 32.61 43.74 9.30 18.31 27.71 39.94 53.57
42.00	10.04 19.78 29.93 43.14 57.86
48.00	10.73 21.14 32.00 46.12 61.85
	ERNATE TRUSS SPAN LENGTH IN FEET
***	THOSE SHIPSE SECTIONS HOSE SE
H 	3.00 6.00 7.00 10.00 14.00
11.00	14.95 21.14 22.84 27.30 32.30
12.75	18.66 26.39 28.50 34.06 40.30
14.50	22.63 32.00 34.56 41.31 48.88
14.75	23.22 32.83 35.46 42.38 50.15
16.50	27.47 38.84 41.96 50.15 59.34
16.75	28.09 39.73 42.91 51.29 60.69
18.50	32.61 46.12 49.81 59.54 70.44
20.50	38.04 53.79 58.10 69.45 82.17
22.50	43.74 61.85 66.81 79.85 94.48

ALIERNAIE MODULUS	OF ELASII	CITY SPAN LENG	IH MOLITPLIER	
type	E	multiplier		
No 1 Dense	1800000	1.06		
No 1	1600000	1.00		
No 1 Non-Dense	1400000	0.94		