



Technical Document

# PyD3XX Programmer's Guide

Version 1.1.5

Release Date: July 22, 2026

PyD3XX is a Python wrapper created by Hector Soto for FTDI's D3XX library. This technical document gives an overview of PyD3XX's Application Programming Interface (API).

Author: Hector Soto

Email: [hector.soto@ftdichip.com](mailto:hector.soto@ftdichip.com)

PyPi Repo: [PyD3XX](#) · [PyPI](#)

GitHub Repo: <https://github.com/S-Hector/PyD3XX>



## **Table of Contents**

|                                         |          |
|-----------------------------------------|----------|
| <b>1 - Introduction</b>                 | <b>5</b> |
| 1.1 - Driver Library Files              | 5        |
| 1.2 - Interfaces, Channels, & Endpoints | 6        |
| 1.3 - SetPrintLevel()                   | 6        |
| <b>2 - PyD3XX Functions</b>             | <b>7</b> |
| 2.1 - FT_CreateDeviceInfoList()         | 7        |
| 2.2 - FT_GetDeviceInfoList()            | 8        |
| 2.2B - FT_GetDeviceInfoDict()           | 9        |
| 2.3 - FT_GetDeviceInfoDetail()          | 10       |
| 2.4 - FT_ListDevices()                  | 11       |
| 2.5 - FT_Create()                       | 12       |
| 2.6 - FT_Close()                        | 13       |
| 2.7 - FT_WritePipe()                    | 14       |
| 2.8 - FT_ReadPipe()                     | 15       |
| 2.9 - FT_WritePipeEx()                  | 17       |
| 2.9B - FT_WritePipeAsync()              | 19       |
| 2.10 - FT_ReadPipeEx()                  | 22       |
| 2.10B - FT_ReadPipeAsync()              | 23       |
| 2.11 - FT_GetOverlappedResult()         | 26       |
| 2.12 - FT_InitializeOverlapped()        | 28       |
| 2.13 - FT_ReleaseOverlapped()           | 28       |
| 2.14 - FT_SetStreamPipe()               | 29       |
| 2.15 - FT_ClearStreamPipe()             | 30       |
| 2.16 - FT_SetPipeTimeout()              | 31       |
| 2.17 - FT_GetPipeTimeout()              | 32       |
| 2.18 - FT_AbortPipe()                   | 33       |
| 2.19 - FT_GetDeviceDescriptor()         | 34       |
| 2.20 - FT_GetConfigurationDescriptor()  | 35       |
| 2.21 - FT_GetInterfaceDescriptor()      | 36       |
| 2.21B - FT_GetStringDescriptor()        | 36       |
| 2.22 - FT_GetPipeInformation()          | 37       |
| 2.23 - FT_GetDescriptor()               | 38       |
| 2.24 - FT_ControlTransfer()             | 39       |
| 2.25 - FT_GetVIDPID()                   | 40       |



|                                       |           |
|---------------------------------------|-----------|
| 2.26 - FT_EnableGPIO()                | 40        |
| 2.27 - FT_WriteGPIO()                 | 41        |
| 2.28 - FT_ReadGPIO()                  | 42        |
| 2.29 - FT_SetGPIOPull()               | 42        |
| 2.30 - FT_SetNotificationCallback()   | 43        |
| 2.31 - FT_ClearNotificationCallback() | 45        |
| 2.32 - FT_GetChipConfiguration()      | 45        |
| 2.33 - FT_SetChipConfiguration()      | 46        |
| 2.34 - FT_IsDevicePath()              | 47        |
| 2.35 - FT_GetDriverVersion()          | 47        |
| 2.35B - GetDriverVersion()            | 48        |
| 2.36 - FT_GetLibraryVersion()         | 49        |
| 2.36B - GetLibraryVersion()           | 49        |
| 2.37 - FT_CycleDevicePort()           | 50        |
| 2.37B - FT_ResetDevicePort()          | 50        |
| 2.38 - FT_SetSuspendTimeout()         | 51        |
| 2.39 - FT_GetSuspendTimeout()         | 52        |
| 2.40 - FT_SetTransferParams()         | 53        |
| 2.41 - FT_GetTransferParams()         | 55        |
| 2.42 - FT_SetVIDPID()                 | 57        |
| <b>3 - PyD3XX Classes</b>             | <b>57</b> |
| 3.1 - FT_Buffer                       | 58        |
| 3.2 - FT_Device                       | 58        |
| 3.3 - FT_DeviceDescriptor             | 59        |
| 3.4 - FT_ConfigurationDescriptor      | 59        |
| 3.5 - FT_InterfaceDescriptor          | 60        |
| 3.6 - FT_StringDescriptor             | 60        |
| 3.7 - FT_EndpointDescriptor           | 61        |
| 3.8 - FT_Pipe                         | 61        |
| 3.9 - FT_Overlapped                   | 62        |
| 3.10 - FT_SetupPacket                 | 62        |
| 3.11 - FT_60XCONFIGURATION            | 63        |
| 3.12 - FT_PipeTransferConf            | 65        |
| 3.13 - FT_TransferConf                | 65        |
| <b>4 - QueueD3XX</b>                  | <b>66</b> |
| 4.1 - Queue (Class)                   | 66        |



|                                     |           |
|-------------------------------------|-----------|
| 4.2 - Queue.GetVersionQueueD3XX()   | 66        |
| 4.3 - Queue.CreateQueue()           | 67        |
| 4.4 - Queue.DestroyQueue()          | 68        |
| 4.5 - Queue.ReadQueue()             | 69        |
| 4.6 - Queue.WriteQueue()            | 70        |
| 4.7 - Queue.GetWriteStatus()        | 71        |
| <b>Appendix A - Miscellaneous</b>   | <b>74</b> |
| Linux D3XX Library Requirements     | 74        |
| PyD3XX Constants                    | 74        |
| Document References                 | 78        |
| <b>Appendix B - Version History</b> | <b>78</b> |

# 1 - Introduction

The PyD3XX Python package is a Python wrapper for Future Technology Devices International's (FTDI's) C language D3XX library. PyD3XX was created so you could easily import a Python API that is cross-compatible with Windows, Linux, & macOS, to interact with FTDI's FT600 and FT601 devices. PyD3XX's API was designed to closely follow the naming conventions of the original D3XX C library's API while requiring zero ctypes knowledge to effectively use PyD3XX.

This programmer's guide provides an overview of PyD3XX's functions and classes.

Some Linux systems may require extra setup before D3XX will work.

Setup Information Shortcut -> [Linux D3XX Library Requirements](#)

## 1.1 - Driver Library Files

PyD3XX comes with multiple D3XX dynamic library files for different operating systems and architectures. PyD3XX will automatically load whichever D3XX dynamic library file is necessary to run on the operating system and architecture it detects. Table 1.1.0 shows what D3XX dynamic library files are loaded for specific operating systems and architectures. For Windows, the older non-WinUSB drivers are designated as "Legacy" in Table 1.1.0.

| Operating System |              |              | Library Version | Library File        |
|------------------|--------------|--------------|-----------------|---------------------|
| Windows          | WinUSB       | 64-Bit (x64) | 1.4.0.1         | FTD3XXWU.dll        |
|                  |              | 32-bit (x86) | 1.4.0.1         | FTD3XXWU_32.dll     |
|                  |              | ARM          | 1.4.0.1         | FTD3XXWU_ARM.dll    |
|                  | Legacy       | 64-Bit (x64) | 1.3.0.10        | FTD3XX.dll          |
|                  |              | 32-bit (x86) | 1.3.0.4         | FTD3XX_32.dll       |
| Linux            | 64-Bit (x64) |              | 1.1.8           | libftd3xx.so        |
|                  | 32-bit (x86) |              | 1.1.8           | libftd3xx_32.so     |
|                  | ARM 64-bit   |              | 1.1.8           | libftd3xx_ARM.so    |
|                  | ARM 32-bit   |              | 1.1.8           | libftd3xx_ARM_32.so |
| macOS            | 64-Bit (x64) |              | 1.1.8           | libftd3xx.dylib     |
|                  | ARM          |              |                 |                     |

**Table 1.1.0 - D3XX Dynamic Library OS Associations**

Figure 1.1.0 shows how PyD3XX sits in your Windows application's hierarchy. If PyD3XX detects the WinUSB driver for FTDI's FT60X devices, it will load the WinUSB version of the D3XX library.




Figure 1.1.0 - PyD3XX Windows Hierarchy

## 1.2 - Interfaces, Channels, & Endpoints

FTDI's FT60X devices come with two interfaces, a communication interface and a data interface. The data interface can have up to 4 channels when the device is configured in FT600 mode. Each channel comes with a read and write endpoint, adding up to 8 total data endpoints for the data interface. The communication interface comes with two endpoints, a OUT BULK endpoint for receiving Session List commands from the host, and a IN INTERRUPT endpoint for Notification List commands.

| Interface | FIFO Index | Pipe Index | Channel | Endpoint/s | Description                                                                  |
|-----------|------------|------------|---------|------------|------------------------------------------------------------------------------|
| 0         | N/A        | 0          | N/A     | 0x01       | OUT BULK endpoint for Session List commands.                                 |
|           |            | 1          |         | 0x81       | IN INTERRUPT endpoint for Notification List commands.                        |
| 1         | 0-3        | 0,2,4,6    | 1-4     | 0x02-0x05  | OUT BULK endpoint for application write access. Writes data out to channels. |
|           |            | 1,3,5,7    |         | 0x82-0x85  | IN BULK endpoint for application read access. Reads data in from channels.   |

Table 1.2.0 - FT60X Interfaces, Channels, & Endpoints

## 1.3 - SetPrintLevel()

D3XX C API Equivalent = NONE. PyD3XX exclusive.

### Summary

Sets the PrintLevel behavior of PyD3XX. By default, PrintLevel is set to PRINT\_NONE, where PyD3XX will not print out any messages.

### Parameters

| Type | Name       | Description                                                 |
|------|------------|-------------------------------------------------------------|
| int  | PrintLevel | A bitmask controlling what messages PyD3XX will print.      |
|      |            | PRINT_NONE 0b00000 Print no messages.                       |
|      |            | PRINT_ERROR_CRITICAL 0b00001 Print critical error messages. |
|      |            | PRINT_ERROR_MAJOR 0b00010 Print major error messages.       |
|      |            | PRINT_ERROR_MINOR 0b00100 Print minor error messages.       |
|      |            | PRINT_ERROR_ALL 0b00111 Print all error messages.           |

|  |  |                   |         |                                       |
|--|--|-------------------|---------|---------------------------------------|
|  |  | PRINT_INFO_START  | 0b01000 | Print informational startup messages. |
|  |  | PRINT_INFO_DEVICE | 0b10000 | Print device information.             |
|  |  | PRINT_INFO_ALL    | 0b11000 | Print all informational messages.     |
|  |  | PRINT_ALL         | 0b11111 | Print all messages.                   |

## Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|              |                                                                        |        |                                                                                                                                                                                                                                                                                    |
|--------------|------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | PyD3XX.SetPrintLevel(PyD3XX.PRINT_ALL) # Make PyD3XX print everything. |        |                                                                                                                                                                                                                                                                                    |
| State        | Successfully loaded dynamic library file.                              | Output | PyD3XX - Startup INFO: DID NOT DETECT WinUSB: Will use D3XX dynamic library.<br>PyD3XX - Startup INFO: DETECTED 64-BIT PYTHON ENVIRONMENT: LOADING 64-bit dynamic library file & setting 64-bit argtypes.<br>PyD3XX - Startup INFO: Successfully loaded FTDI D3XX dynamic library. |

# 2 - PyD3XX Functions

This section goes over the available PyD3XX functions which can vary based on the operating system your Python code is running on. The "Platform" variable in PyD3XX is populated with one of the strings in Table 2.0.0 based off the operating system PyD3XX detected.

| Operating System | Platform |
|------------------|----------|
| Windows          | windows  |
| Linux            | linux    |
| Unknown OS       |          |
| macOS            | darwin   |

Table 2.0.0 - Platform String Values

## 2.1 - FT\_CreateDeviceInfoList()

D3XX C API Equivalent = FT\_CreateDeviceInfoList()

### Summary

Builds an internal device information list of all D3XX devices connected to the system and returns the total number of devices. The internal device information list does not change even if devices are added/removed from the system until FT\_CreateDeviceInfoList() is called again.

### Parameters

None

## Return Values

| Type | Name        | Description                                     |
|------|-------------|-------------------------------------------------|
| int  | Status      | FT_OK if successful.                            |
| int  | DeviceCount | Number of D3XX devices connected to the system. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                             |                               |                     |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|---------------------|
| Example Code | <pre>Status, DeviceCount = PyD3XX.FT_CreateDeviceInfoList() # Create a device info list. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE DEVICE INFO LIST: ABORTING")     exit() print(str(DeviceCount) + " Devices detected.") if (DeviceCount == 0):     print("NO DEVICES DETECTED: ABORTING")     exit()</pre> |                               |                     |
|              | State                                                                                                                                                                                                                                                                                                                                                       | One device.                   | Output              |
|              | No devices.                                                                                                                                                                                                                                                                                                                                                 | 1 Devices detected.           | 0 Devices detected. |
|              |                                                                                                                                                                                                                                                                                                                                                             | NO DEVICES DETECTED: ABORTING |                     |

## 2.2 – FT\_GetDeviceInfoList()

D3XX C API Equivalent = FT\_GetDeviceInfoList()

### Summary

Returns a list of FT\_Device objects and the number of D3XX devices in the list.

This function should only be called after calling FT\_CreateDeviceInfoList() which creates the list this function retrieves its device information from.

### Parameters

| Type | Name        | Description                                                                           |
|------|-------------|---------------------------------------------------------------------------------------|
| int  | DeviceCount | The number of devices you want to retrieve from the internal device information list. |

## Return Values

| Type            | Name    | Description                  |
|-----------------|---------|------------------------------|
| int             | Status  | FT_OK if successful.         |
| list[FT_Device] | Devices | A list of FT_Device objects. |

## Example Code



|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |        |                                                                                          |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, Devices = PyD3XX.FT_GetDeviceInfoList(DeviceCount) # This will create a list. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE DEVICE INFO LIST: ABORTING")     exit() for i in range(0, DeviceCount): # Get device info at each index from 0-&gt;(DeviceCount - 1).     if(Devices[i].Flags &amp; PyD3XX.FT_FLAGS_OPENED):         print("Device " + str(i) + " is opened by another process!")         continue # Device info not valid. Move onto next device.     print("---  Device " + str(i) + "  ---")</pre> |        |                                                                                          |
| State        | 2 unopened devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Output | <pre>---  Device 0  --- ---  Device 1  ---</pre>                                         |
|              | 1 open, 1 unopened.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |        | <pre>---  Device 0  --- Device 1 is opened by another process!</pre>                     |
|              | 2 opened devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |        | <pre>Device 0 is opened by another process! Device 1 is opened by another process!</pre> |

## 2.2B – FT\_GetDeviceInfoDict()

D3XX C API Equivalent = NONE. PyD3XX exclusive.

### Summary

Returns a dictionary of FT\_Device objects and the number of D3XX devices in the dictionary. This is meant as an alternative to FT\_GetDeviceInfoList() in the scenario where you want a Python dictionary instead of a Python list of FT\_Device objects.

This function should only be called after calling FT\_CreateDeviceInfoList() which creates the list this function retrieves its device information from.

### Parameters

| Type | Name        | Description                                                                           |
|------|-------------|---------------------------------------------------------------------------------------|
| int  | DeviceCount | The number of devices you want to retrieve from the internal device information list. |

### Return Values

| Type                 | Name    | Description                        |
|----------------------|---------|------------------------------------|
| int                  | Status  | FT_OK if successful.               |
| dict[int, FT_Device] | Devices | A dictionary of FT_Device objects. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |        |                                                                                          |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, Devices = PyD3XX.FT_GetDeviceInfoDict(DeviceCount) # This will create a Python dictionary.     if Status != PyD3XX.FT_OK:         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE DEVICE INFO LIST: ABORTING")         exit() for i in range(0, DeviceCount): # Get device info at each index from 0-&gt;(DeviceCount - 1).     if(Devices[i].Flags &amp; PyD3XX.FT_FLAGS_OPENED):         print("Device " + str(i) + " is opened by another process!")         continue # Device info not valid. Move onto next device.     print("---  Device " + str(i) + "  ---")</pre> |        |                                                                                          |
| State        | 2 unopened devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Output | <pre>---  Device 0  --- ---  Device 1  ---</pre>                                         |
|              | 1 open, 1 unopened.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |        | <pre>---  Device 0  --- Device 1 is opened by another process!</pre>                     |
|              | 2 opened devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |        | <pre>Device 0 is opened by another process! Device 1 is opened by another process!</pre> |

## 2.3 – FT\_GetDeviceInfoDetail()

D3XX C API Equivalent = FT\_GetDeviceInfoDetail()

### Summary

Returns an FT\_Device object that contains all of the information of the device recorded at the given index of the internal device information list. This does not create/open a device.

This function should only be called after calling FT\_CreateDeviceInfoList() which creates the list this function retrieves its device information from.

### Parameters

| Type | Name  | Description                                                                      |
|------|-------|----------------------------------------------------------------------------------|
| int  | Index | Index of the device entry to retrieve from the internal device information list. |

### Return Values

| Type      | Name         | Description                                                 |
|-----------|--------------|-------------------------------------------------------------|
| int       | Status       | FT_OK if successful.                                        |
| FT_Device | ReturnDevice | The FT_Device object with the retrieved device information. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                |                                        |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|----------------------------------------|
| Example Code | <pre>Status, Device = PyD3XX.FT_GetDeviceInfoDetail(0) # Get info of a device at index 0. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO GET INFO FOR DEVICE 0") else:     if(Device.Flags &amp; PyD3XX.FT_FLAGS_OPENED):         print("Device 0 is opened by another process!")     else:         if(Device.Type == PyD3XX.FT_DEVICE_601):             print("Device 0 is a FT601 device!")         elif(Device.Type == PyD3XX.FT_DEVICE_600):             print("Device 0 is a FT600 device!")</pre> |                                |                                        |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | FT600 connected.               | Device 0 is a FT600 device!            |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | FT601 connected.               | Device 0 is a FT601 device!            |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | FT60X open in another program. | Device 0 is opened by another process! |

## 2.4 - FT\_ListDevices()

D3XX C API Equivalent = FT\_ListDevices()

### Summary

Can return the total number of devices, the serial number or description of a single device, or return the serial number or description of multiple devices. This function will always return the Status integer. This function will also return either an integer, string, or list of strings.

### Parameters

| Type | Name       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------|------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int  | IndexCount | If (Flags & FT_LIST_BY_INDEX) != 0, then IndexCount is the index of the device whose serial number or description you want returned.<br>If (Flags & FT_LIST_ALL) != 0, then IndexCount is the number of devices you want to get the info of. This should never be more than the number of devices connected to the system.                                                                                                                                   |
| int  | Flags      | A bit field that controls what data you're requesting from FT_ListDevices.<br>FT_LIST_NUMBER_ONLY = Return the number of devices connected to the system.<br>FT_LIST_BY_INDEX = Return the serial number or description of the device at index IndexCount.<br>FT_LIST_ALL = Return a list of the serial number or description of IndexCount devices.<br>FT_OPEN_BY_SERIAL_NUMBER = Return serial number/s.<br>FT_OPEN_BY_DESCRIPTION = Return description/s. |

### Return Values

| Type | Name        | Description                                                                                            |
|------|-------------|--------------------------------------------------------------------------------------------------------|
| int  | Status      | FT_OK if successful. Status will always be returned.<br>Condition: (Flags & FT_LIST_NUMBER_ONLY) != 0  |
| int  | DeviceCount | The number of devices currently connected to the system.<br>Condition: (Flags & FT_LIST_BY_INDEX) != 0 |
| str  | SerialDesc  | If (Flags & FT_OPEN_BY_SERIAL_NUMBER) != 0, then it is the serial number                               |

|                                       |              |                                                                                                                                                                                                                                                                                       |
|---------------------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                       |              | of the device at the given index.<br>If (Flags & FT_OPEN_BY_DESCRIPTION) != 0, then it is the description of the device at the given index.<br>If there was an error, then it is FT_STATUS_STR[Status].                                                                               |
| Condition: (Flags & FT_LIST_ALL) != 0 |              |                                                                                                                                                                                                                                                                                       |
| list[str]                             | SeriDescList | If (Flags & FT_OPEN_BY_SERIAL_NUMBER) != 0, then it is list of IndexCount device's serial numbers.<br>If (Flags & FT_OPEN_BY_DESCRIPTION) != 0, then it is list of IndexCount device's descriptions.<br>If there was an error, then it is a list of IndexCount FT_STATUS_STR[Status]. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                    |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, Count = PyD3XX.FT_ListDevices(PyD3XX.NULL, PyD3XX.FT_LIST_NUMBER_ONLY) print("Device Count: " + str(Count)) Status, SerialNumber = PyD3XX.FT_ListDevices(0, PyD3XX.FT_LIST_BY_INDEX   PyD3XX.FT_OPEN_BY_SERIAL_NUMBER) print("Device 0 Serial Number: " + str(SerialNumber)) Status, Description = PyD3XX.FT_ListDevices(0, PyD3XX.FT_LIST_BY_INDEX   PyD3XX.FT_OPEN_BY_DESCRIPTION) print("Device 0 Description: " + str(Description)) Status, SerialNumbers = PyD3XX.FT_ListDevices(Count, PyD3XX.FT_LIST_ALL   PyD3XX.FT_OPEN_BY_SERIAL_NUMBER) for i in range(Count):     print("Device " + str(i) + " Serial Number: " + str(SerialNumbers[i])) Status, Descriptions = PyD3XX.FT_ListDevices(Count, PyD3XX.FT_LIST_ALL   PyD3XX.FT_OPEN_BY_DESCRIPTION) for i in range(Count):     print("Device " + str(i) + " Description: " + str(Descriptions[i]))</pre> |                                                                                                                                                                                                                                                                                                    |
| State        | Two devices connected.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Output<br>Device Count: 2<br>Device 0 Serial Number: 000000000001<br>Device 0 Description: FTDI SuperSpeed-FIFO Bridge<br>Device 0 Serial Number: 000000000001<br>Device 1 Serial Number: 44TXERgJa3h2IHD<br>Device 0 Description: FTDI SuperSpeed-FIFO Bridge<br>Device 1 Description: TestDevice |

## 2.5 - FT\_Create()

D3XX C API Equivalent = FT\_Create()

### Summary

Opens the given device by index, serial number, or description for sole use by your program. You must give this function an FT\_Device object created by FT\_GetDeviceInfoList(), FT\_GetDeviceInfoDict(), or FT\_GetDeviceInfoDetail().

### Parameters

| Type      | Name       | Description                                                                                         |
|-----------|------------|-----------------------------------------------------------------------------------------------------|
| int, str  | Identifier | The index, serial number, or description of the device you want to open.                            |
| int       | OpenFlag   | A flag that controls whether the function opens the device by index, serial number, or description. |
| FT_Device | Device     | The device you want to open.                                                                        |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                       |        |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|--------|
| Example Code | <pre>Status, Device = PyD3XX.FT_GetDeviceInfoDetail(0) # Get info of a device at index 0. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO GET INFO FOR DEVICE 0") print("Device (index, serial, desc): 0, " + Device.SerialNumber + ", " + Device.Description); Status = PyD3XX.FT_Create(0, PyD3XX.FT_OPEN_BY_INDEX, Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO OPEN DEVICE: ABORTING")     exit() PyD3XX.FT_Close(Device) print("Successfully opened and closed device by index!"); Status = PyD3XX.FT_Create("44TXERgJa3h2IHD", PyD3XX.FT_OPEN_BY_SERIAL_NUMBER, Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO OPEN DEVICE: ABORTING")     exit() PyD3XX.FT_Close(Device) print("Successfully opened and closed device by serial number!"); Status = PyD3XX.FT_Create("TestDevice", PyD3XX.FT_OPEN_BY_DESCRIPTION, Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO OPEN DEVICE: ABORTING")     exit() PyD3XX.FT_Close(Device) print("Successfully opened and closed device by description!");</pre> |                                       |        |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Device not in use by another program. | Output |

## 2.6 - FT\_Close()

D3XX C API Equivalent = FT\_Close()

### Summary

Closes a device opened by FT\_Create().

### Parameters

| Type      | Name   | Description                   |
|-----------|--------|-------------------------------|
| FT_Device | Device | The device you want to close. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                          |                   |                                                       |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|-------------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_Create(0, PyD3XX.FT_OPEN_BY_INDEX, Device) # Open the device. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO OPEN DEVICE: ABORTING")     exit() PyD3XX.FT_Close(Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CLOSE DEVICE: ABORTING")     exit() print("Successfully opened and closed device by index!");</pre> |                   |                                                       |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                    | Device connected. | Output                                                |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                          | No devices.       | FT_DEVICE_NOT_FOUND   FAILED TO OPEN DEVICE: ABORTING |

## 2.7 - FT\_WritePipe()

D3XX C API Equivalent = FT\_WritePipe()

### Summary

Write data from an FT\_Buffer object to a given pipe.

### Parameters

| Type                | Name                 | Description                                                                                                                                                                           |
|---------------------|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FT_Device           | Device               | The device whose pipe you want to write to.                                                                                                                                           |
| FT_Pipe   int       | Pipe_Endpoint        | <div>Windows</div> An FT_Pipe object of the pipe you want to write to. <div>Linux<br/>MacOS</div> An integer of the endpoint you want to write to.<br>Values 0x02-0x05 = Channels 1-4 |
| FT_Buffer           | Buffer               | The buffer whose data you'll write to the pipe.                                                                                                                                       |
| int                 | BufferLength         | The amount of data from the buffer that you want to write.                                                                                                                            |
| FT_Overlapped   int | Overlapped_TimeoutMs | <div>Windows</div> An FT_Overlapped structure if doing an asynchronous write or NULL for a synchronous write.                                                                         |

|  |  |                |                                                                                      |
|--|--|----------------|--------------------------------------------------------------------------------------|
|  |  | Linux<br>MacOS | An int for the number of milliseconds<br>FT_WritePipe can hang on before timing out. |
|--|--|----------------|--------------------------------------------------------------------------------------|

## Return Values

| Type | Name             | Description                                           |
|------|------------------|-------------------------------------------------------|
| int  | Status           | FT_OK if successful.                                  |
| int  | BytesTransferred | The number of bytes successfully written to the pipe. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |        |                                                                                                                                                        |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Pipes = {} for i in range(2): # Get in and out pipes for channel 1.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit() if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, int("0x82", 16), 1, 0) else:     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, PyD3XX.NULL) if(Status == PyD3XX.FT_OK):     ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)     print("Channel 1 = 0x" + ReadValue) else:     print(PyD3XX.FT_STATUS_STR[Status] + "   Failed to read data!: ABORTING")     exit() WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1) if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):     Status, BytesWrote = PyD3XX.FT_WritePipe(Device, int("0x02", 16), WriteBuffer, 1, 0) else:     Status, BytesWrote = PyD3XX.FT_WritePipe(Device, Pipes[0], WriteBuffer, 1, PyD3XX.NULL) if(Status == PyD3XX.FT_OK):     WriteValue = format(int.from_bytes(WriteBuffer.Value(), "little"), "x").zfill(1*2)     print("Wrote 0x" + WriteValue + " to Channel 1!") else:     print(PyD3XX.FT_STATUS_STR[Status] + "   Failed to write data!: ABORTING")     exit() </pre> |        |                                                                                                                                                        |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Output | <p>First success.</p> <p>Channel 1 = 0x01<br/>Wrote 0x02 to Channel 1!</p> <p>Second success.</p> <p>Channel 1 = 0x02<br/>Wrote 0x03 to Channel 1!</p> |

## 2.8 – FT\_ReadPipe()

D3XX C API Equivalent = FT\_ReadPipe()

## Summary

Returns an FT\_Buffer object with data read from a given pipe.

## Parameters

| Type                | Name                 | Description                                        |                                                                                          |
|---------------------|----------------------|----------------------------------------------------|------------------------------------------------------------------------------------------|
| FT_Device           | Device               | The device whose pipe you want to read from.       |                                                                                          |
| FT_Pipe   int       | Pipe_Endpoint        | Windows                                            | An FT_Pipe object of the pipe you want to read from.                                     |
|                     |                      | Linux<br>MacOS                                     | An integer of the endpoint you want to read from.<br>Values 0x82-0x85 = Channels 1-4     |
| int                 | BufferLength         | The amount of data you want to read from the pipe. |                                                                                          |
| FT_Overlapped   int | Overlapped_TimeoutMs | Windows                                            | An FT_Overlapped structure if doing an asynchronous read or NULL for a synchronous read. |
|                     |                      | Linux<br>MacOS                                     | An int for the number of milliseconds FT_ReadPipe can hang on before timing out.         |

## Return Values

| Type      | Name             | Description                                                          |
|-----------|------------------|----------------------------------------------------------------------|
| int       | Status           | FT_OK if successful.                                                 |
| FT_Buffer | Buffer           | The buffer with data read from the pipe.                             |
| int       | BytesTransferred | The number of bytes successfully read from the pipe into the buffer. |

## Example Code



Example Code

```
Pipes = {}
for i in range(2): # Get in and out pipes for channel 1.
    Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)
    if Status != PyD3XX.FT_OK:
        print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")
        exit()
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, int("0x82", 16), 1, 0)
else:
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, PyD3XX.NULL)
if(Status == PyD3XX.FT_OK):
    ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)
    print("Channel 1 = 0x" + ReadValue)
else:
    print(PyD3XX.FT_STATUS_STR[Status] + " | Failed to read data!: ABORTING")
    exit()
WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1)
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, BytesWrote = PyD3XX.FT_WritePipe(Device, int("0x02", 16), WriteBuffer, 1, 0)
else:
    Status, BytesWrote = PyD3XX.FT_WritePipe(Device, Pipes[0], WriteBuffer, 1, PyD3XX.NULL)
if(Status == PyD3XX.FT_OK):
    WriteValue = format(int.from_bytes(WriteBuffer.Value(), "little"), "x").zfill(1*2)
    print("Wrote 0x" + WriteValue + " to Channel 1!")
else:
    print(PyD3XX.FT_STATUS_STR[Status] + " | Failed to write data!: ABORTING")
    exit()
```

State

First success.

Second success.

Output

Channel 1 = 0x01  
Wrote 0x02 to Channel 1!

Channel 1 = 0x02  
Wrote 0x03 to Channel 1!

## 2.9 - FT\_WritePipeEx()

D3XX C API Equivalent = FT\_WritePipeEx()

### Summary

Write data from an FT\_Buffer object to a given pipe. FT\_WritePipeEx() has lower latency than FT\_WritePipe() for asynchronous transfers when used along with FT\_SetStreamPipe.

Note: FT\_WritePipeEx() supports a maximum buffer size of 1 MiB. This is to *“guarantee”* lower latencies.

### Parameters

| Type | Name | Description |
|------|------|-------------|
|------|------|-------------|

| FT_Device           | Device               | The device whose pipe you want to write to.                |                                                                                            |
|---------------------|----------------------|------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| FT_Pipe   int       | Pipe_FIFOindex       | Windows                                                    | An FT_Pipe object of the pipe you want to write to.                                        |
|                     |                      | Linux<br>MacOS                                             | An integer FIFO index of the channel you want to write to.<br>Values 0-3 = Channels 1-4    |
| FT_Buffer           | Buffer               | The buffer whose data you'll write to the pipe.            |                                                                                            |
| int                 | BufferLength         | The amount of data from the buffer that you want to write. |                                                                                            |
| FT_Overlapped   int | Overlapped_TimeoutMs | Windows                                                    | An FT_Overlapped structure if doing an asynchronous write or NULL for a synchronous write. |
|                     |                      | Linux<br>MacOS                                             | An int for the number of milliseconds FT_WritePipeEx can hang on before timing out.        |

### Return Values

| Type | Name             | Description                                           |
|------|------------------|-------------------------------------------------------|
| int  | Status           | FT_OK if successful.                                  |
| int  | BytesTransferred | The number of bytes successfully written to the pipe. |

### Example Code

Example Code

```
Pipes = {}
for i in range(2): # Get in and out pipes for channel 1.
    Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)
    if Status != PyD3XX.FT_OK:
        print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")
        exit()
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeEx(Device, 0, 1, 0)
else:
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeEx(Device, Pipes[1], 1, PyD3XX.NULL)
if(Status == PyD3XX.FT_OK):
    ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)
    print("Channel 1 = 0x" + ReadValue)
else:
    print("Failed to read data!: ABORTING")
    exit()
WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1)
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, BytesWrote = PyD3XX.FT_WritePipeEx(Device, 0, WriteBuffer, 1, 0)
else:
    Status, BytesWrote = PyD3XX.FT_WritePipeEx(Device, Pipes[0], WriteBuffer, 1, PyD3XX.NULL)
if(Status == PyD3XX.FT_OK):
    WriteValue = format(int.from_bytes(WriteBuffer.Value(), "little"), "x").zfill(1*2)
    print("Wrote 0x" + WriteValue + " to Channel 1!")
else:
    print("Failed to write data!: ABORTING")
    exit()
```

State

First success.

Second success.

Output

Channel 1 = 0x01  
Wrote 0x02 to Channel 1!

Channel 1 = 0x02  
Wrote 0x03 to Channel 1!

## 2.9B - FT\_WritePipeAsync()

D3XX C API Equivalent = FT\_WritePipeAsync()

WARNING - This function is exclusive to Linux/macOS systems.

### Summary

Asynchronously write data from an FT\_Buffer object to a given pipe.

### Parameters

| Type      | Name      | Description                                                                             |
|-----------|-----------|-----------------------------------------------------------------------------------------|
| FT_Device | Device    | The device whose pipe you want to write to.                                             |
| int       | FIFOindex | An integer FIFO index of the channel you want to write to.<br>Values 0-3 = Channels 1-4 |



---

---

|               |              |                                                             |
|---------------|--------------|-------------------------------------------------------------|
| FT_Buffer     | Buffer       | The buffer whose data you'll write to the pipe.             |
| int           | BufferLength | The amount of data from the buffer that you want to write.  |
| FT_Overlapped | Overlapped   | An FT_Overlapped structure for doing an asynchronous write. |

### Return Values

| Type | Name             | Description                                           |
|------|------------------|-------------------------------------------------------|
| int  | Status           | FT_OK if successful.                                  |
| int  | BytesTransferred | The number of bytes successfully written to the pipe. |

### Example Code

```

if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeAsync(Device, 0, 1, Overlaps[1])
else:
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, Overlaps[1])
Attempts = 0
Status = PyD3XX.FT_IO_INCOMPLETE
while(Status == PyD3XX.FT_IO_INCOMPLETE):
    Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[1], False)
    print("Waiting on input...")
    Attempts += 1
    time.sleep(1)
    if(Status == PyD3XX.FT_OK): break
    if(Attempts == 5):
        print(PyD3XX.FT_STATUS_STR[Status] + " | ERROR: Async read failed!")
        exit()
print(PyD3XX.FT_STATUS_STR[Status] + " | FT_ReadPipe was successful.")
ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)
print("Channel 1 = 0x" + ReadValue)

WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1)
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, BytesWrote = PyD3XX.FT_WritePipeAsync(Device, 0, WriteBuffer, 1, Overlaps[0])
else:
    Status, BytesWrote = PyD3XX.FT_WritePipe(Device, Pipes[0], WriteBuffer, 1, Overlaps[0])
Attempts = 0
Status = PyD3XX.FT_IO_INCOMPLETE
while(Status == PyD3XX.FT_IO_INCOMPLETE):
    Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[0], False)
    print("Waiting on output...")
    Attempts += 1
    time.sleep(1)
    if(Status == PyD3XX.FT_OK): break
    if(Attempts == 5):
        print(PyD3XX.FT_STATUS_STR[Status] + " | ERROR: Async write failed!")
        exit()
print(PyD3XX.FT_STATUS_STR[Status] + " | FT_WritePipe was successful.")
for i in range(2): # Release overlaps since we're done using them.
    Status = PyD3XX.FT_ReleaseOverlapped(Device, Overlaps[i])
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | WARNING: FAILED TO RELEASE OVERLAP " +
str(i))

```

|       |                 |        |                                                                                                                                                                                               |
|-------|-----------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State | First success.  | Output | Waiting on input...<br>FT_OK   FT_ReadPipe was successful.<br>Channel 1 = 0x01<br>Waiting on output...<br>Waiting on output...<br>FT_OK   FT_WritePipe was successful.                        |
|       | Second success. |        | Waiting on input...<br>Waiting on input...<br>FT_OK   FT_ReadPipe was successful.<br>Channel 1 = 0x02<br>Waiting on output...<br>Waiting on output...<br>FT_OK   FT_WritePipe was successful. |

## 2.10 - FT\_ReadPipeEx()

D3XX C API Equivalent = FT\_ReadPipeEx()

### Summary

Returns an FT\_Buffer object with data read from a given pipe. FT\_ReadPipeEx() has lower latency than FT\_ReadPipe() for asynchronous transfers when used along with FT\_SetStreamPipe.

### Parameters

| Type                | Name                 | Description                                        |                                                                                          |
|---------------------|----------------------|----------------------------------------------------|------------------------------------------------------------------------------------------|
| FT_Device           | Device               | The device whose pipe you want to read from.       |                                                                                          |
| FT_Pipe   int       | Pipe_FIFOindex       | Windows                                            | An FT_Pipe object of the pipe you want to read from.                                     |
|                     |                      | Linux<br>MacOS                                     | An integer FIFO index of the channel you want to read from.<br>Values 0-3 = Channels 1-4 |
| int                 | BufferLength         | The amount of data you want to read from the pipe. |                                                                                          |
| FT_Overlapped   int | Overlapped_TimeoutMs | Windows                                            | An FT_Overlapped structure if doing an asynchronous read or NULL for a synchronous read. |
|                     |                      | Linux<br>MacOS                                     | An int for the number of milliseconds FT_ReadPipeEx can hang on before timing out.       |

### Return Values

| Type      | Name             | Description                                                          |
|-----------|------------------|----------------------------------------------------------------------|
| int       | Status           | FT_OK if successful.                                                 |
| FT_Buffer | Buffer           | The buffer with data read from the pipe.                             |
| int       | BytesTransferred | The number of bytes successfully read from the pipe into the buffer. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |        |                                                                                                                                                        |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Pipes = {} for i in range(2): # Get in and out pipes for channel 1.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit() if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeEx(Device, 0, 1, 0) else:     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeEx(Device, Pipes[1], 1, PyD3XX.NULL) if(Status == PyD3XX.FT_OK):     ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)     print("Channel 1 = 0x" + ReadValue) else:     print("Failed to read data!: ABORTING")     exit() WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1) if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):     Status, BytesWrote = PyD3XX.FT_WritePipeEx(Device, 0, WriteBuffer, 1, 0) else:     Status, BytesWrote = PyD3XX.FT_WritePipeEx(Device, Pipes[0], WriteBuffer, 1, PyD3XX.NULL) if(Status == PyD3XX.FT_OK):     WriteValue = format(int.from_bytes(WriteBuffer.Value(), "little"), "x").zfill(1*2)     print("Wrote 0x" + WriteValue + " to Channel 1!") else:     print("Failed to write data!: ABORTING")     exit() </pre> |        |                                                                                                                                                        |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Output | <p>First success.</p> <p>Channel 1 = 0x01<br/>Wrote 0x02 to Channel 1!</p> <p>Second success.</p> <p>Channel 1 = 0x02<br/>Wrote 0x03 to Channel 1!</p> |

## 2.10B - FT\_ReadPipeAsync()

D3XX C API Equivalent = FT\_ReadPipeAsync()

### Summary

Returns an FT\_Buffer object with data asynchronously read from a given pipe.

### Parameters

| Type      | Name      | Description                                                                              |
|-----------|-----------|------------------------------------------------------------------------------------------|
| FT_Device | Device    | The device whose pipe you want to read from.                                             |
| int       | FIFOindex | An integer FIFO index of the channel you want to read from.<br>Values 0-3 = Channels 1-4 |



---

---

|               |              |                                                            |
|---------------|--------------|------------------------------------------------------------|
| int           | BufferLength | The amount of data you want to read from the pipe.         |
| FT_Overlapped | Overlapped   | An FT_Overlapped structure for doing an asynchronous read. |

### Return Values

| Type      | Name             | Description                                                          |
|-----------|------------------|----------------------------------------------------------------------|
| int       | Status           | FT_OK if successful.                                                 |
| FT_Buffer | Buffer           | The buffer with data read from the pipe.                             |
| int       | BytesTransferred | The number of bytes successfully read from the pipe into the buffer. |

### Example Code



```

if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeAsync(Device, 0, 1, Overlaps[1])
else:
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, Overlaps[1])
Attempts = 0
Status = PyD3XX.FT_IO_INCOMPLETE
while(Status == PyD3XX.FT_IO_INCOMPLETE):
    Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[1], False)
    print("Waiting on input...")
    Attempts += 1
    time.sleep(1)
    if(Status == PyD3XX.FT_OK): break
    if(Attempts == 5):
        print(PyD3XX.FT_STATUS_STR[Status] + " | ERROR: Async read failed!")
        exit()
print(PyD3XX.FT_STATUS_STR[Status] + " | FT_ReadPipe was successful.")
ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)
print("Channel 1 = 0x" + ReadValue)

WriteBuffer = PyD3XX.FT_Buffer.from_int(int.from_bytes(ReadBuffer.Value(), "little") + 1)
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, BytesWrote = PyD3XX.FT_WritePipeAsync(Device, 0, WriteBuffer, 1, Overlaps[0])
else:
    Status, BytesWrote = PyD3XX.FT_WritePipe(Device, Pipes[0], WriteBuffer, 1, Overlaps[0])
Attempts = 0
Status = PyD3XX.FT_IO_INCOMPLETE
while(Status == PyD3XX.FT_IO_INCOMPLETE):
    Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[0], False)
    print("Waiting on output...")
    Attempts += 1
    time.sleep(1)
    if(Status == PyD3XX.FT_OK): break
    if(Attempts == 5):
        print(PyD3XX.FT_STATUS_STR[Status] + " | ERROR: Async write failed!")
        exit()
print(PyD3XX.FT_STATUS_STR[Status] + " | FT_WritePipe was successful.")
for i in range(2): # Release overlaps since we're done using them.
    Status = PyD3XX.FT_ReleaseOverlapped(Device, Overlaps[i])
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | WARNING: FAILED TO RELEASE OVERLAP " +
str(i))

```

|       |                 |        |                                                                                                                                                                                               |
|-------|-----------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State | First success.  | Output | Waiting on input...<br>FT_OK   FT_ReadPipe was successful.<br>Channel 1 = 0x01<br>Waiting on output...<br>Waiting on output...<br>FT_OK   FT_WritePipe was successful.                        |
|       | Second success. |        | Waiting on input...<br>Waiting on input...<br>FT_OK   FT_ReadPipe was successful.<br>Channel 1 = 0x02<br>Waiting on output...<br>Waiting on output...<br>FT_OK   FT_WritePipe was successful. |

## 2.11 - FT\_GetOverlappedResult()

D3XX C API Equivalent = FT\_GetOverlappedResult()

### Summary

Returns the result of an overlapped operation to a pipe.

### Parameters

| Type          | Name    | Description                                                                                                                                                                                              |
|---------------|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FT_Device     | Device  | The device that had an overlapped operation done.                                                                                                                                                        |
| FT_Overlapped | Overlap | The overlapped structure that was used in a read/write operation.                                                                                                                                        |
| bool          | Wait    | True: FT_GetOverlappedResult() will hang until the read/write operation has completed.<br>False: FT_GetOverlappedResult() will immediately return whether the read/write operation has completed or not. |

### Return Values

| Type | Name              | Description                                                               |
|------|-------------------|---------------------------------------------------------------------------|
| int  | Status            | FT_OK if successful.                                                      |
| int  | LengthTransferred | The number of bytes successfully transferred in the read/write operation. |

### Example Code

```
Pipes = {}
Overlaps = {}
for i in range(2): # Get in and out pipes for channel 1 and create overlaps.
    Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)
    if Status != PyD3XX.FT_OK:
        print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")
        exit()
    Status, Overlaps[i] = PyD3XX.FT_InitializeOverlapped(Device)
    if(Status != PyD3XX.FT_OK):
        print("FAILED TO CREATE OVERLAP FOR PIPE " + str(i) + ": ABORTING")
        exit()
    Status = PyD3XX.FT_SetPipeTimeout(Device, Pipes[i], 100)
    if(Status != PyD3XX.FT_OK):
        print("WARNING: FAILED TO SET PIPE TIMEOUT TO 100")
        print("Status = " + PyD3XX.FT_STATUS_STR[Status])
if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeAsync(Device, 0, 1, Overlaps[1])
else:
    Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, Overlaps[1])
Attempts = 0
Status = PyD3XX.FT_IO_INCOMPLETE
while(Status == PyD3XX.FT_IO_INCOMPLETE):
    Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[1], False)
    print("Waiting on input...")
    Attempts += 1
    time.sleep(1)
    if((Status != PyD3XX.FT_OK) and (Status != PyD3XX.FT_IO_PENDING)) or (Attempts == 3):
        StatusAP = PyD3XX.FT_AbortPipe(Device, Pipes[1])
        if(StatusAP != PyD3XX.FT_OK):
            print("FT_AbortPipe failed!")
        else:
            print("Aborted read pipe!")
            break
print(PyD3XX.FT_STATUS_STR[Status] + " | Encountered error or FT_ReadPipe was successful.")
ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)
print("Channel 1 = 0x" + ReadValue)
for i in range(2): # Release overlaps since we're done using them.
    Status = PyD3XX.FT_ReleaseOverlapped(Device, Overlaps[i])
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | WARNING: FAILED TO RELEASE OVERLAP " +
str(i))
```

|       |                                             |        |                                                                                                                                      |
|-------|---------------------------------------------|--------|--------------------------------------------------------------------------------------------------------------------------------------|
| State | Successfully read one byte.                 | Output | Waiting on input...<br>FT_OK   Encountered error or FT_ReadPipe was successful.<br>Channel 1 = 0x01                                  |
|       | Overlapped read operation did not complete. |        | Waiting on input...<br>Aborted read pipe!<br>FT_IO_INCOMPLETE   Encountered error or FT_ReadPipe was successful.<br>Channel 1 = 0x00 |

## 2.12 - FT\_InitializeOverlapped()

D3XX C API Equivalent = FT\_InitializeOverlapped()

### Summary

Create an FT\_Overlapped object to be used asynchronously with the FT\_WritePipe and FT\_ReadPipe functions. The FT\_Overlapped object should be released with FT\_ReleaseOverlapped after it is no longer needed.

### Parameters

| Type      | Name   | Description                                                 |
|-----------|--------|-------------------------------------------------------------|
| FT_Device | Device | The device you want to create an FT_Overlapped object from. |

### Return Values

| Type          | Name    | Description                                                                                                                             |
|---------------|---------|-----------------------------------------------------------------------------------------------------------------------------------------|
| int           | Status  | FT_OK if successful.                                                                                                                    |
| FT_Overlapped | Overlap | The overlapped structure necessary for asynchronous read and write operations. Release with FT_ReleaseOverlapped when no longer needed. |

### Example Code

|              |                                                                                                                                                                                                   |        |                               |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------|
| Example Code | <pre>Status, Overlap = PyD3XX.FT_InitializeOverlapped(Device) if(Status != PyD3XX.FT_OK):     print("FAILED TO CREATE OVERLAP: ABORTING")     exit() print("Successfully created overlap!")</pre> |        |                               |
| State        | Success                                                                                                                                                                                           | Output | Successfully created overlap! |

## 2.13 - FT\_ReleaseOverlapped()

D3XX C API Equivalent = FT\_ReleaseOverlapped()

### Summary

Releases the resources used by an FT\_Overlapped object. Call this when an FT\_Overlapped object is no longer needed.

### Parameters

| Type | Name | Description |
|------|------|-------------|
|------|------|-------------|



|               |         |                                                 |
|---------------|---------|-------------------------------------------------|
| FT_Device     | Device  | The device you want to release an overlap from. |
| FT_Overlapped | Overlap | The overlap to be released.                     |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                         |         |                                                                           |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|---------------------------------------------------------------------------|
| Example Code | <pre>Status, Overlap = PyD3XX.FT_InitializeOverlapped(Device) if(Status != PyD3XX.FT_OK):     print("FAILED TO CREATE OVERLAP: ABORTING")     exit() print("Successfully created overlap!") Status = PyD3XX.FT_ReleaseOverlapped(Device, Overlap) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO RELEASE OVERLAP.") else:     print("Successfully released overlap!")</pre> |         |                                                                           |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                   | Success | Output<br>Successfully created overlap!<br>Successfully released overlap! |

## 2.14 – FT\_SetStreamPipe()

D3XX C API Equivalent = FT\_SetStreamPipe()

### Summary

Set the streaming protocol for pipes with a fixed transfer size in bytes.

Note: For the WinUSB drivers, the StreamSize parameter must be a multiple of the max packet size. Otherwise, future read calls will fail.

SuperSpeed: MaxPacketSize = 1024 bytes.

Hi-Speed: MaxPacketSize = 512 bytes.

Full Speed: MaxPacketSize = 64 bytes.

### Parameters

| Type      | Name          | Description                                                                                                                                                                |
|-----------|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FT_Device | Device        | The device you want to set a streaming protocol for.                                                                                                                       |
| bool      | AllWritePipes | True: Set the streaming protocol for all write pipes.<br>False: Ignore                                                                                                     |
| bool      | AllReadPipes  | True: Set the streaming protocol for all read pipes.<br>False: Ignore                                                                                                      |
| FT_Pipe   | Pipe          | If AllWritePipes & AllReadPipes are both False, then this specific pipe's streaming protocol is set. Otherwise this parameter is ignored and you should pass NULL instead. |
| int       | StreamSize    | Transfer size in bytes used for read/write operations.                                                                                                                     |

### Return Values

| Type | Name | Description |
|------|------|-------------|
|------|------|-------------|

|     |        |                      |
|-----|--------|----------------------|
| int | Status | FT_OK if successful. |
|-----|--------|----------------------|

### Example Code

|              |                                                                                                                                                                                                                                                |         |                                                        |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|--------------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_SetStreamPipe(Device, True, True, PyD3XX.NULL, 1024) if Status != PyD3XX.FT_OK:     print("FAILED TO SET STREAM SIZE FOR ALL PIPES.")     exit() else:     print("Stream size for all pipes set to 1024 bytes!")</pre> |         |                                                        |
|              | State                                                                                                                                                                                                                                          | Success | Output<br>Stream size for all pipes set to 1024 bytes! |

## 2.15 - FT\_ClearStreamPipe()

D3XX C API Equivalent = FT\_ClearStreamPipe()

### Summary

Clear the previously set streaming protocol transfer for pipes.

### Parameters

| Type      | Name          | Description                                                                                                                                                                    |
|-----------|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FT_Device | Device        | The device you want to clear a streaming protocol for.                                                                                                                         |
| bool      | AllWritePipes | True: Clear the streaming protocol for all write pipes.<br>False: Ignore                                                                                                       |
| bool      | AllReadPipes  | True: Clear the streaming protocol for all read pipes.<br>False: Ignore                                                                                                        |
| FT_Pipe   | Pipe          | If AllWritePipes & AllReadPipes are both False, then this specific pipe's streaming protocol is cleared. Otherwise this parameter is ignored and you should pass NULL instead. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |         |                                                                                                      |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Pipes = {} for i in range(2): # Get in and out pipes for channel 1.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i)     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit() Status = PyD3XX.FT_SetStreamPipe(Device, True, True, PyD3XX.NULL, 1) if Status != PyD3XX.FT_OK:     print("FAILED TO SET STREAM SIZE FOR ALL PIPES.")     exit() else:     print("Stream size for all pipes set to 1 byte!") Status = PyD3XX.FT_ClearStreamPipe(Device, False, False, Pipes[1]) if Status != PyD3XX.FT_OK:     print("FAILED TO CLEAR STREAM SIZE FOR CH1 READ PIPE.")     exit() else:     print("Cleared stream size for CH1 read pipe!") </pre> |         |                                                                                                      |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Success | <div>Output</div> Stream size for all pipes set to 1 byte!<br>Cleared stream size for CH1 read pipe! |

## 2.16 – FT\_SetPipeTimeout()

D3XX C API Equivalent = FT\_SetPipeTimeout()

### Summary

Sets the timeout value for a given FT\_Pipe object (endpoint). FT\_ReadPipe and FT\_WritePipe will timeout if they hang for however many seconds the timeout value is set to. If the FT\_Device is closed and re-opened, then the pipe timeout value will reset to the driver default.

### Parameters

| Type      | Name    | Description                                                       |
|-----------|---------|-------------------------------------------------------------------|
| FT_Device | Device  | The device whose FT_Pipe you want to change the timeout value of. |
| FT_Pipe   | Pipe    | The pipe (endpoint) you want to change the timeout value of.      |
| int       | Timeout | The new timeout value you want to set for the pipe (endpoint).    |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                   |                                                                                                                    |
|-----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Example Code                      | <pre> Pipes = {} for i in range(CHANNEL_COUNT * 2): # Set timeout of all pipes to 100.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i) # Get pipe information.     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit()     Status_SPT = PyD3XX.FT_SetPipeTimeout(Device, Pipes[i], 100)     if(PyD3XX.Platform == "windows"): # FT_GetPipeTimeout not in D3XX Linux library.         Status, TimeOut = PyD3XX.FT_GetPipeTimeout(Device, Pipes[i])         if (Status != PyD3XX.FT_OK) or (TimeOut != 100):             print("FAILED TO SET AND/OR CONFIRM PIPE TIMEOUT TO 100: ABORTING")             print("Status = " + PyD3XX.FT_STATUS_STR[Status] + "   Timeout = " + str(TimeOut))             exit()         if(Status_SPT != PyD3XX.FT_OK):             print("FAILED TO SET AND/OR CONFIRM PIPE TIMEOUT TO 100: ABORTING")             print("Status = " + PyD3XX.FT_STATUS_STR[Status] + "   Timeout = " + str(TimeOut))         else:             print("Successfully set timeout of pipe " + str(i) + " to 100!") </pre> |                                   |                                                                                                                    |
| State                             | <table border="1"> <tr> <td data-bbox="147 1014 475 1129">CHANNEL_COUNT = 1<br/>and success.</td><td data-bbox="475 1014 1546 1129"> Output <div>Successfully set timeout of pipe 0 to 100!</div> <div>Successfully set timeout of pipe 1 to 100!</div> </td></tr></table>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | CHANNEL_COUNT = 1<br>and success. | Output <div>Successfully set timeout of pipe 0 to 100!</div> <div>Successfully set timeout of pipe 1 to 100!</div> |
| CHANNEL_COUNT = 1<br>and success. | Output <div>Successfully set timeout of pipe 0 to 100!</div> <div>Successfully set timeout of pipe 1 to 100!</div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |                                   |                                                                                                                    |

## 2.17 – FT\_GetPipeTimeout()

D3XX C API Equivalent = FT\_GetPipeTimeout()

WARNING – This function is exclusive to Windows systems.

### Summary

Gets the timeout value for a given FT\_Pipe object (IN endpoint). This function is exclusive to Windows systems.

### Parameters

| Type      | Name   | Description                                                    |
|-----------|--------|----------------------------------------------------------------|
| FT_Device | Device | The device whose FT_Pipe you want to get the timeout value of. |
| FT_Pipe   | Pipe   | The pipe (endpoint) you want to get the timeout value of.      |

### Return Values

| Type | Name    | Description                                  |
|------|---------|----------------------------------------------|
| int  | Status  | FT_OK if successful.                         |
| int  | Timeout | The timeout value of the pipe (IN endpoint). |

### Example Code



|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |        |                                                                                          |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------|
| Example Code | <pre>Pipes = {} for i in range(CHANNEL_COUNT * 2): # Set timeout of all pipes to 100.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i) # Get pipe information.     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit()     Status_SPT = PyD3XX.FT_SetPipeTimeout(Device, Pipes[i], 100)     if(PyD3XX.Platform == "windows"): # FT_GetPipeTimeout not in D3XX Linux library.         Status, TimeOut = PyD3XX.FT_GetPipeTimeout(Device, Pipes[i])         if (Status != PyD3XX.FT_OK) or (TimeOut != 100):             print("FAILED TO SET AND/OR CONFIRM PIPE TIMEOUT TO 100: ABORTING")             print("Status = " + PyD3XX.FT_STATUS_STR[Status] + "   Timeout = " + str(TimeOut))             exit()         if(Status_SPT != PyD3XX.FT_OK):             print("FAILED TO SET AND/OR CONFIRM PIPE TIMEOUT TO 100: ABORTING")             print("Status = " + PyD3XX.FT_STATUS_STR[Status] + "   Timeout = " + str(TimeOut))         else:             print("Successfully set timeout of pipe " + str(i) + " to 100!")</pre> |        |                                                                                          |
| State        | CHANNEL_COUNT = 1<br>and success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Output | Successfully set timeout of pipe 0 to 100!<br>Successfully set timeout of pipe 1 to 100! |

## 2.18 – FT\_AbortPipe()

D3XX C API Equivalent = FT\_AbortPipe()

### Summary

Aborts the pending transfers for a pipe.

### Parameters

| Type      | Name   | Description                                                  |
|-----------|--------|--------------------------------------------------------------|
| FT_Device | Device | The device whose FT_Pipe you want to abort the transfers of. |
| FT_Pipe   | Pipe   | The pipe you want to abort the transfer of.                  |

### Return Values

| Type | Name              | Description                                  |
|------|-------------------|----------------------------------------------|
| int  | Status            | FT_OK if successful.                         |
| int  | LengthTransferred | The timeout value of the pipe (IN endpoint). |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |        |                                                                                                                                                                              |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipeAsync(Device, 0, 1, Overlaps[1]) else:     Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, Pipes[1], 1, Overlaps[1]) Status, BytesTransferred = PyD3XX.FT_GetOverlappedResult(Device, Overlaps[1], False) if(Status == PyD3XX.FT_IO_INCOMPLETE):     print("Waiting on input! Attempting FT_AbortPipe()...")     Status = PyD3XX.FT_AbortPipe(Device, Pipes[1])     if(Status != PyD3XX.FT_OK):         print("FT_AbortPipe failed!")     else:         print("FT_AbortPipe succeeded!") else:     print(PyD3XX.FT_STATUS_STR[Status] + "   Encountered error or FT_ReadPipe was successful.")     ReadValue = format(int.from_bytes(ReadBuffer.Value(), "little"), "x").zfill(1*2)     print("Channel 1 = 0x" + ReadValue) </pre> |        |                                                                                                                                                                              |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Output | <p>Waiting on input.</p> <p>Received 1 byte with value 0x01.</p>                                                                                                             |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |        | <p>Waiting on input! Attempting FT_AbortPipe()...</p> <p>FT_AbortPipe succeeded!</p> <p>FT_OK   Encountered error or FT_ReadPipe was successful.</p> <p>Channel 1 = 0x01</p> |

## 2.19 – FT\_GetDeviceDescriptor()

D3XX C API Equivalent = FT\_GetDeviceDescriptor()

### Summary

Get the USB device descriptor of a FT\_Device object.

### Parameters

| Type      | Name   | Description                                                  |
|-----------|--------|--------------------------------------------------------------|
| FT_Device | Device | The device whose USB device descriptor you want to retrieve. |

### Return Values

| Type                | Name             | Description                |
|---------------------|------------------|----------------------------|
| int                 | Status           | FT_OK if successful.       |
| FT_DeviceDescriptor | DeviceDescriptor | The USB device descriptor. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |        |                                                                                           |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, DeviceDescriptor = PyD3XX.FT_GetDeviceDescriptor(Device) #Status, DeviceDescriptor, BytesTransferred = PyD3XX.FT_GetDescriptor(Device, PyD3XX.FT_DEVICE_DESCRIPTOR_TYPE, 0) if Status != PyD3XX.FT_OK:     print("FAILED TO GET DEVICE DESCRIPTOR FOR DEVICE 0: ABORTING.")     exit() print("---  Device 0 Device Descriptor  ---") print("\tLength = " + str(DeviceDescriptor.bLength)) print("\tDescriptor Type = " + hex(DeviceDescriptor.bDescriptorType))</pre> |        |                                                                                           |
| State        | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Output | <pre>---  Device 0 Device Descriptor  ---     Length = 18     Descriptor Type = 0x1</pre> |

## 2.20 – FT\_GetConfigurationDescriptor()

D3XX C API Equivalent = FT\_GetConfigurationDescriptor()

### Summary

Get the USB configuration descriptor of a FT\_Device object.

### Parameters

| Type      | Name   | Description                                                         |
|-----------|--------|---------------------------------------------------------------------|
| FT_Device | Device | The device whose USB configuration descriptor you want to retrieve. |

### Return Values

| Type                       | Name                    | Description                       |
|----------------------------|-------------------------|-----------------------------------|
| int                        | Status                  | FT_OK if successful.              |
| FT_ConfigurationDescriptor | ConfigurationDescriptor | The USB configuration descriptor. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |        |                                                                                                 |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, ConfigurationDescriptor = PyD3XX.FT_GetConfigurationDescriptor(Device) #Status, ConfigurationDescriptor, BytesTransferred = PyD3XX.FT_GetDescriptor(Device, PyD3XX.FT_CONFIGURATION_DESCRIPTOR_TYPE, 0) if Status != PyD3XX.FT_OK:     print("FAILED TO GET THE CONFIGURATION DESCRIPTOR FOR DEVICE 0: ABORTING.")     exit() print("---  Device 0 Configuration Descriptor  ---") print("\tLength = " + str(ConfigurationDescriptor.bLength)) print("\tDescriptor Type = " + hex(ConfigurationDescriptor.bDescriptorType))</pre> |        |                                                                                                 |
| State        | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Output | <pre>---  Device 0 Configuration Descriptor  ---     Length = 9     Descriptor Type = 0x2</pre> |

## 2.21 - FT\_GetInterfaceDescriptor()

D3XX C API Equivalent = FT\_GetInterfaceDescriptor()

### Summary

Get the USB interface descriptor of a FT\_Device object.

### Parameters

| Type      | Name           | Description                                                     |
|-----------|----------------|-----------------------------------------------------------------|
| FT_Device | Device         | The device whose USB interface descriptor you want to retrieve. |
| int       | InterfaceIndex | The index of the interface descriptor you want to retrieve.     |

### Return Values

| Type                   | Name                | Description                   |
|------------------------|---------------------|-------------------------------|
| int                    | Status              | FT_OK if successful.          |
| FT_InterfaceDescriptor | InterfaceDescriptor | The USB interface descriptor. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |          |                                                                                 |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------|
| Example Code | <pre>Status, Interface = PyD3XX.FT_GetInterfaceDescriptor(Device, 1) # Index 0 is for proprietary protocols. Using 1 instead. #Status, Interface, BytesTransferred = PyD3XX.FT_GetDescriptor(Device, PyD3XX.FT_INTERFACE_DESCRIPTOR_TYPE, 1) if Status != PyD3XX.FT_OK:     print("FAILED TO GET INTERFACE INFO OF [1]: ABORTING")     exit() print("---  Interface 1  ---") print("\tLength = " + hex(Interface.bLength)) print("\tDescriptor Type = " + hex(Interface.bDescriptorType))</pre> |          |                                                                                 |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | Success. | Output                                                                          |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |          | <pre>---  Interface 1  ---       Length = 0x9       Descriptor Type = 0x4</pre> |

## 2.21B - FT\_GetStringDescriptor()

D3XX C API Equivalent = FT\_GetStringDescriptor()

### Summary

Get the USB string descriptor of a FT\_Device object.

### Parameters

| Type      | Name        | Description                                                  |
|-----------|-------------|--------------------------------------------------------------|
| FT_Device | Device      | The device whose USB string descriptor you want to retrieve. |
| int       | StringIndex | The index of the string descriptor you want to retrieve.     |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

|                     |                  |                            |
|---------------------|------------------|----------------------------|
| FT_StringDescriptor | StringDescriptor | The USB string descriptor. |
|---------------------|------------------|----------------------------|

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |          |                                                                                                                                         |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, StringDescriptor = PyD3XX.FT_GetStringDescriptor(Device, 2) #Status, StringDescriptor, BytesTransferred = PyD3XX.FT_GetDescriptor(Device, PyD3XX.FT_STRING_DESCRIPTOR_TYPE, 2) if Status != PyD3XX.FT_OK:     print("FAILED TO GET THE STRING DESCRIPTOR FOR DEVICE 0: ABORTING.")     exit() print("----  Device 0 String[2] Descriptor  ----") print("\tLength = " + str(StringDescriptor.bLength)) print("\tDescriptor Type = " + hex(StringDescriptor.bDescriptorType)) print("\tString = '" + StringDescriptor.szString + "'")</pre> |          |                                                                                                                                         |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Success. | Output                                                                                                                                  |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |          | <pre>---  Device 0 String[2] Descriptor  ---     Length = 56     Descriptor Type = 0x3     String = 'FTDI SuperSpeed-FIFO Bridge'</pre> |

## 2.22 - FT\_GetPipeInformation()

D3XX C API Equivalent = FT\_GetPipeInformation()

### Summary

Get an FT\_Pipe object from the given open FT\_Device object. The returned FT\_Pipe object will only contain valid pipe information if the FT\_Device object was previously opened by FT\_Create() and is still open.

Interface 1 (data interface) is for the data read and write pipes. Pipes with an even index are write pipes and pipes with an odd index are read pipes.

### Parameters

| Type      | Name           | Description                                                                          |
|-----------|----------------|--------------------------------------------------------------------------------------|
| FT_Device | Device         | The device you want to get an FT_Pipe from.                                          |
| int       | InterfaceIndex | The index of the interface you want to get a USB endpoint descriptor (FT_Pipe) from. |
| int       | PipeIndex      | The index of the pipe (FT_Pipe) you want to get from the given interface.            |

### Return Values

| Type    | Name   | Description                                                 |
|---------|--------|-------------------------------------------------------------|
| int     | Status | FT_OK if successful.                                        |
| FT_Pipe | Pipe   | An FT_Pipe object that can be used for read or write calls. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |        |                                                                                                                                                                                                                               |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Pipes = {} for i in range(CHANNEL_COUNT * 2): # Print info for all pipes for interface 1.     Status, Pipes[i] = PyD3XX.FT_GetPipeInformation(Device, 1, i) # Get pipe information.     if Status != PyD3XX.FT_OK:         print("FAILED TO GET PIPE INFO OF [1," + str(i) + "]: ABORTING")         exit()     print("---  Pipe " + str(i) + "  ---")     print("\tPipe Type = " + hex(Pipes[i].PipeType))     print("\tPipe ID = " + hex(Pipes[i].PipeID))     print("\tPipe MaxPacketSize = " + str(Pipes[i].MaximumPacketSize))     print("\tPipe Interval = " + str(Pipes[i].Interval)) </pre> |        |                                                                                                                                                                                                                               |
| State        | CHANNEL_COUNT = 1                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Output | <pre> ---  Pipe 0  ---     Pipe Type = 0x2     Pipe ID = 0x2     Pipe MaxPacketSize = 0     Pipe Interval = 4 ---  Pipe 1  ---     Pipe Type = 0x2     Pipe ID = 0x82     Pipe MaxPacketSize = 0     Pipe Interval = 4 </pre> |

## 2.23 – FT\_GetDescriptor()

D3XX C API Equivalent = FT\_GetDescriptor()

### Summary

Get a USB descriptor from a FT\_Device object. Returns any one of the following descriptor objects: FT\_DeviceDescriptor, FT\_ConfigurationDescriptor, FT\_StringDescriptor, FT\_InterfaceDescriptor.

**WARNING:** this is not a full equivalent of FT\_GetDescriptor() as it only returns four common descriptors. This function's implementation will likely change in the future to closer match the C library equivalent's ability to get uncommon USB descriptors. Use the dedicated functions FT\_GetDeviceDescriptor, FT\_GetConfigurationDescriptor, FT\_GetInterfaceDescriptor, FT\_GetStringDescriptor, and FT\_GetPipeInformation instead.

### Parameters

| Type      | Name           | Description                                           |
|-----------|----------------|-------------------------------------------------------|
| FT_Device | Device         | The device whose USB descriptor you want to retrieve. |
| int       | DescriptorType | The type of descriptor you want to retrieve.          |
| int       | Index          | The index of the descriptor you want to retrieve.     |

### Return Values

| Type | Name   | Description                                     |
|------|--------|-------------------------------------------------|
| int  | Status | FT_OK if successful. Status is always returned. |

|                                                              |                         |                                                       |
|--------------------------------------------------------------|-------------------------|-------------------------------------------------------|
| Condition: DescriptorType = FT_DEVICE_DESCRIPTOR_TYPE        |                         |                                                       |
| FT_DeviceDescriptor                                          | DeviceDescriptor        | The USB device descriptor.                            |
| Condition: DescriptorType = FT_CONFIGURATION_DESCRIPTOR_TYPE |                         |                                                       |
| FT_ConfigurationDescriptor                                   | ConfigurationDescriptor | The USB configuration descriptor.                     |
| Condition: DescriptorType = FT_STRING_DESCRIPTOR_TYPE        |                         |                                                       |
| FT_StringDescriptor                                          | StringDescriptor        | The USB string descriptor.                            |
| Condition: DescriptorType = FT_INTERFACE_DESCRIPTOR_TYPE     |                         |                                                       |
| FT_InterfaceDescriptor                                       | InterfaceDescriptor     | The USB interface descriptor.                         |
| Condition: Always                                            |                         |                                                       |
| int                                                          | LengthTransferred       | Number of bytes transferred to the descriptor buffer. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |          |                                                                                                                                         |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre>#Status, StringDescriptor = PyD3XX.FT_GetStringDescriptor(Device, 2) Status, StringDescriptor, BytesTransferred = PyD3XX.FT_GetDescriptor(Device, PyD3XX.FT_STRING_DESCRIPTOR_TYPE, 2) if Status != PyD3XX.FT_OK:     print("FAILED TO GET THE STRING DESCRIPTOR FOR DEVICE 0: ABORTING.")     exit() print("---  Device 0 String[2] Descriptor  ---") print("\tLength = " + str(StringDescriptor.bLength)) print("\tDescriptor Type = " + hex(StringDescriptor.bDescriptorType)) print("\tString = '" + StringDescriptor.szString + "'")</pre> |          |                                                                                                                                         |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Success. | Output                                                                                                                                  |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |          | <pre>---  Device 0 String[2] Descriptor  ---     Length = 56     Descriptor Type = 0x3     String = 'FTDI SuperSpeed-FIFO Bridge'</pre> |

## 2.24 - FT\_ControlTransfer()

D3XX C API Equivalent = FT\_ControlTransfer()

### Summary

Transmits control data over the default control endpoint.

### Parameters

| Type           | Name         | Description                                        |
|----------------|--------------|----------------------------------------------------|
| FT_Device      | Device       | The device you want to do a control transfer with. |
| FT_SetupPacket | SetupPacket  | The 8-byte setup packet.                           |
| FT_Buffer      | Buffer       | The buffer used for data transfer.                 |
| int            | BufferLength | The length of the buffer used for data transfer.   |

### Return Values

| Type | Name              | Description                      |
|------|-------------------|----------------------------------|
| int  | Status            | FT_OK if successful.             |
| int  | LengthTransferred | The number of bytes transferred. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |        |                                        |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|----------------------------------------|
| Example Code | <pre> Buffer = PyD3XX.FT_Buffer(1) SetupPacket = PyD3XX.FT_SetupPacket SetupPacket.RequestType = int("10000001", 2) SetupPacket.Request = 10 SetupPacket.Value = 0 SetupPacket.Index = 1 SetupPacket.Length = 1 Status, DataWritten = PyD3XX.FT_ControlTransfer(Device, SetupPacket, Buffer, 1) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO GET ALTERNATE SETTINGS OF INTERFACE 1 FROM DEVICE 0.") print("Alternate Settings of Interface 1: " + hex(int.from_bytes(Buffer.Value(), "little"))) </pre> |        |                                        |
| State        | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Output | Alternate Settings of Interface 1: 0x0 |

## 2.25 - FT\_GetVIDPID()

D3XX C API Equivalent = FT\_GetVIDPID()

### Summary

Get the vendor ID (VID) and product ID (PID) of an FT\_Device object. The device must be opened beforehand.

### Parameters

| Type      | Name   | Description                               |
|-----------|--------|-------------------------------------------|
| FT_Device | Device | The device you want get the VID & PID of. |

### Return Values

| Type | Name   | Description                         |
|------|--------|-------------------------------------|
| int  | Status | FT_OK if successful.                |
| int  | VID    | The vendor ID of the given device.  |
| int  | PID    | The product ID of the given device. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |        |                                |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|--------------------------------|
| Example Code | <pre> Status, Device = PyD3XX.FT_GetDeviceInfoDetail(0) # Get info of a device at index 0. Status = PyD3XX.FT_Create(0, PyD3XX.FT_OPEN_BY_INDEX, Device) # Open the device we're using. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO OPEN DEVICE: ABORTING")     exit() Status, VID, PID = PyD3XX.FT_GetVIDPID(Device) print("Device 0 (VID:PID) = " + format(VID, "x").zfill(4) + ":" + format(PID, "x").zfill(4)) </pre> |        |                                |
| State        | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Output | Device 0 (VID:PID) = 0403:601e |

## 2.26 - FT\_EnableGPIO()



D3XX C API Equivalent = FT\_EnableGPIO()

### Summary

Enable GPIO mode and set the input/output direction of the two GPIO pins.

### Parameters

| Type      | Name          | Description                                                                                                  |
|-----------|---------------|--------------------------------------------------------------------------------------------------------------|
| FT_Device | Device        | The device you want enable the GPIO of.                                                                      |
| int       | EnableMask    | Select which GPIO pins to enable. Bits 31-2 are ignored. 0 = ignore. 1 = enable.                             |
| int       | DirectionMask | Select which input/output direction the GPIO pins should have. Bits 31-2 are ignored. 0 = input. 1 = output. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                |          |                                                      |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_EnableGPIO(Device, int("11", 2), int("11", 2)) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO ENABLE GPIO OF DEVICE 0") else:     print("Successfully enabled GPIO[1:0] as outputs.");</pre> |          |                                                      |
|              | State                                                                                                                                                                                                                          | Success. | Output<br>Successfully enabled GPIO[1:0] as outputs. |

## 2.27 - FT\_WriteGPIO()

D3XX C API Equivalent = FT\_WriteGPIO()

### Summary

Set the output state of the GPIO0 and GPIO1 pins. Make sure FT\_EnableGPIO() is used beforehand to make the GPIO pins outputs.

### Parameters

| Type      | Name       | Description                                                                                                              |
|-----------|------------|--------------------------------------------------------------------------------------------------------------------------|
| FT_Device | Device     | The device whose GPIO pins you want to write to.                                                                         |
| int       | SelectMask | Select which GPIO pins to change the output state of. Bit 0 = GPIO0. Bit 1 = GPIO1. 1 = change output state. 0 = ignore. |
| int       | Data       | Data to write to the GPIO pins. Bit 0 = GPIO0. Bit 1 = GPIO1.                                                            |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                         |        |                                       |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_WriteGPIO(Device, int("11", 2), int("11", 2)) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO WRITE GPIO OF DEVICE 0") else:     print("Successfully wrote 0b11 to GPIO pins!");</pre> |        |                                       |
| State        | Success.                                                                                                                                                                                                                | Output | Successfully wrote 0b11 to GPIO pins! |

## 2.28 – FT\_ReadGPIO()

D3XX C API Equivalent = FT\_ReadGPIO()

### Summary

Read the state of the GPIO0 and GPIO1 pins. Make sure FT\_EnableGPIO() is used beforehand to make the GPIO pins inputs.

### Parameters

| Type      | Name   | Description                                       |
|-----------|--------|---------------------------------------------------|
| FT_Device | Device | The device whose GPIO pins you want to read from. |

### Return Values

| Type | Name   | Description                                                 |
|------|--------|-------------------------------------------------------------|
| int  | Status | FT_OK if successful.                                        |
| int  | Data   | Data read from the GPIO pins. Bit 0 = GPIO0. Bit 1 = GPIO1. |

### Example Code

|              |                                                                                                                                                                                                         |        |                  |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------|
| Example Code | <pre>Status, GPIO_Data = PyD3XX.FT_ReadGPIO(Device) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO READ GPIO OF DEVICE 0") else:     print("GPIO DATA = 0b" + format(GPIO_Data, "02b"))</pre> |        |                  |
| State        | GPIO[1:0] = 0b10                                                                                                                                                                                        | Output | GPIO DATA = 0b10 |

## 2.29 – FT\_SetGPIOPull()

D3XX C API Equivalent = FT\_SetGPIOPull()

### Summary

Set the internal resistor pull state of the GPIO0 and GPIO1 pins high, low, or hi-Z. This only works for revision B FT60X devices or newer.

### Parameters

| Type      | Name       | Description                                                        |
|-----------|------------|--------------------------------------------------------------------|
| FT_Device | Device     | The device whose GPIO pins you want to change the pull state of.   |
| Int       | SelectMask | Select which GPIO pins to change the pull state of. Bit 0 = GPIO0. |

|     |          |                                                                                                                                                                                                                        |
|-----|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     |          | Bit 1 = GPIO1. 1 = change pull state. 0 = ignore.                                                                                                                                                                      |
| int | PullMask | Control what pull state the GPIO pins are set to.<br>PullMask[1:0] = GPIO0 pull state, PullMask[3:2] = GPIO1 pull state.<br>0b00 = 50k ohm pull-down (default)<br>0b01 = Hi-Z<br>0b10 = 50k ohm pull-up<br>0b11 = Hi-Z |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                              |        |                                     |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_SetGPIOPull(Device, int("11", 2), int("1111", 2)) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO SET GPIO PULL OF DEVICE 0") else:     print("Successfully set GPIO pull to hi-Z!");</pre> |        |                                     |
| State        | Success.                                                                                                                                                                                                                     | Output | Successfully set GPIO pull to hi-Z! |

## 2.30 - FT\_SetNotificationCallback()

D3XX C API Equivalent = FT\_SetNotificationCallback()

### Summary

Set a callback function that will be called when any IN endpoint with no current ongoing read requests receive data. If notification messages are enabled for a specific channel, never make a FT\_ReadPipe call unless it is within the callback function for the exact number of bytes available in the IN endpoint.

### Parameters

| Type                                   | Name             | Description                                                        |
|----------------------------------------|------------------|--------------------------------------------------------------------|
| FT_Device                              | Device           | The device you want to set the callback notification function for. |
| typing.Callable[[int, int, int], None] | CallbackFunction | Your callback function.                                            |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

```
Status, ReadPipeCH1 = PyD3XX.FT_GetPipeInformation(Device, 1, 1)
if Status != PyD3XX.FT_OK:
    print("FAILED TO GET READ PIPE INFO OF CH1: ABORTING")
    exit()
def CallBackFunction(CallbackType: int, PipeID_GPIO0: int | bool, Length_GPIO1: int | bool):
    global NotificationCount
    NotificationCount += 1
    print("Received " + str(NotificationCount) + " notifications!")
    if(CallbackType == PyD3XX.E_FT_NOTIFICATION_CALLBACK_TYPE_DATA):
        print("CBF: You have " + str(Length_GPIO1) + " bytes to read at pipe " +
hex(PipeID_GPIO0) + "!")
        if(NotificationCount != 5): # Disable callback function.
            if(PyD3XX.Platform == "linux") or (PyD3XX.Platform == "darwin"):
                Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, int("0x82", 16),
Length_GPIO1, 0)
            else:
                Status, ReadBuffer, BytesRead = PyD3XX.FT_ReadPipe(Device, ReadPipeCH1,
Length_GPIO1, PyD3XX.NULL)
            else:
                Status = PyD3XX.FT_ClearNotificationCallback(Device) # Clear callback function so
we don't get called again.
                if Status != PyD3XX.FT_OK:
                    print(PyD3XX.FT_STATUS_STR[Status] + " | WARNING: FAILED TO CLEAR CALLBACK
FUNCTION OF DEVICE 0")
                elif(CallbackType == PyD3XX.E_FT_NOTIFICATION_CALLBACK_TYPE_GPIO):
                    print("CBF: GPIO 0 Status = " + str(PipeID_GPIO0) + " | GPIO 1 Status = " +
str(Length_GPIO1))
                return None

PyD3XX.FT_SetNotificationCallback(Device, CallBackFunction)
if Status != PyD3XX.FT_OK:
    print("FAILED TO SET CALLBACK FUNCTION OF DEVICE 0: ABORTING")
    exit()
print("This program will exit after at least 5 notifications or 5 seconds.")
Loops = 0
while((NotificationCount != 5) and not(Loops == 5)):
    time.sleep(1)
    Loops += 1;
print("Total Notifications Received: " + str(NotificationCount))
print("Seconds Passed: " + str(Loops))
```

|       |                                                                            |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------|----------------------------------------------------------------------------|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State | Channel 1 received five master writes while no read requests were ongoing. | Output | <p>This program will exit after at least 5 notifications or 5 seconds.</p> <p>Received 1 notifications!</p> <p>CBF: You have 4 bytes to read at pipe 0x82!</p> <p>Received 2 notifications!</p> <p>CBF: You have 2 bytes to read at pipe 0x82!</p> <p>Received 3 notifications!</p> <p>CBF: You have 4 bytes to read at pipe 0x82!</p> <p>Received 4 notifications!</p> <p>CBF: You have 4 bytes to read at pipe 0x82!</p> <p>Received 5 notifications!</p> <p>CBF: You have 4 bytes to read at pipe 0x82!</p> <p>Total Notifications Received: 5</p> <p>Seconds Passed: 1</p> |
|-------|----------------------------------------------------------------------------|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## 2.31 - FT\_ClearNotificationCallback()

D3XX C API Equivalent = FT\_ClearNotificationCallback()

### Summary

Clears the notification callback function set by FT\_SetNotificationCallback.

### Parameters

| Type      | Name   | Description                                                       |
|-----------|--------|-------------------------------------------------------------------|
| FT_Device | Device | The device you want clear the callback notification function for. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                              |        |                                                                            |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|----------------------------------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_ClearNotificationCallback(Device) # Clear callback function. print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO CLEAR CALLBACK FUNCTION OF DEVICE 0")</pre> |        |                                                                            |
| State        | Success.                                                                                                                                                                                     | Output |                                                                            |
|              | Failure.                                                                                                                                                                                     |        | FT_INVALID_HANDLE   WARNING: FAILED TO CLEAR CALLBACK FUNCTION OF DEVICE 0 |

## 2.32 - FT\_GetChipConfiguration()

D3XX C API Equivalent = FT\_GetChipConfiguration()

### Summary

Get the chip configuration of the given FT\_Device object.

## Parameters

| Type      | Name   | Description                                           |
|-----------|--------|-------------------------------------------------------|
| FT_Device | Device | The device you want to get the chip configuration of. |

## Return Values

| Type                | Name          | Description                                 |
|---------------------|---------------|---------------------------------------------|
| int                 | Status        | FT_OK if successful.                        |
| FT_60XCONFIGURATION | Configuration | The chip configuration of the given device. |

## Example Code

|              |                                                                                                                                                                                                                                                                                               |          |                                          |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------------------------------------------|
| Example Code | <pre>Status, ChipConfiguration = PyD3XX.FT_GetChipConfiguration(Device) # Get configuration. if Status != PyD3XX.FT_OK:     print("FAILED TO GET CHIP CONFIGURATION OF Device 0: ABORTING.")     exit() print("Device 0 Description: '" + ChipConfiguration.StringDescriptors[1] + "'")</pre> |          |                                          |
|              | State                                                                                                                                                                                                                                                                                         | Success. | Output<br>Device 0 Description: 'TEST 1' |

## 2.33 - FT\_SetChipConfiguration()

D3XX C API Equivalent = FT\_SetChipConfiguration()

### Summary

Set the chip configuration of the given FT\_Device object.

## Parameters

| Type                | Name          | Description                                           |
|---------------------|---------------|-------------------------------------------------------|
| FT_Device           | Device        | The device you want to set the chip configuration of. |
| FT_60XCONFIGURATION | Configuration | The chip configuration you want to set.               |

## Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                                                                                                                                                                                    |          |        |                                |                |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|--------|--------------------------------|----------------|
| Example Code   | <pre>Status, ChipConfiguration = PyD3XX.FT_GetChipConfiguration(Device) # Get chip configuration. if Status != PyD3XX.FT_OK:     print("FAILED TO GET CHIP CONFIGURATION OF Device 0: ABORTING.")     exit() print("Device 0 Description: '" + ChipConfiguration.StringDescriptors[1] + "'") if(ChipConfiguration.StringDescriptors[1] == "TEST 0"):     ChipConfiguration.StringDescriptors[1] = "TEST 1" else:     ChipConfiguration.StringDescriptors[1] = "TEST 0" Status = PyD3XX.FT_SetChipConfiguration(Device, ChipConfiguration) if Status != PyD3XX.FT_OK:     print("WARNING: FAILED TO SET CHIP CONFIGURATION OF DEVICE 0")</pre> |                                                                                                                                                                                    |          |        |                                |                |
|                | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <table><tr><td>Success.</td><td rowspan="2">Output</td><td>Device 0 Description: 'TEST 1'</td></tr><tr><td>Success again.</td><td>Device 0 Description: 'TEST 0'</td></tr></table> | Success. | Output | Device 0 Description: 'TEST 1' | Success again. |
| Success.       | Output                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Device 0 Description: 'TEST 1'                                                                                                                                                     |          |        |                                |                |
| Success again. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Device 0 Description: 'TEST 0'                                                                                                                                                     |          |        |                                |                |

## 2.34 - FT\_IsDevicePath()

D3XX C API Equivalent = FT\_IsDevicePath()

WARNING - This function is exclusive to Windows systems.

### Summary

Returns FT\_OK if the given device path matches the device path of the device handle.

### Parameters

| Type      | Name       | Description                               |
|-----------|------------|-------------------------------------------|
| FT_Device | Device     | The device you want to check the path of. |
| str       | DevicePath | The device path you want to compare.      |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                |        |                                                           |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_IsDevicePath(Device, DevicePath) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CONFIRM DEVICE PATH.") else:     print("SUCCESSFULLY CONFIRMED DEVICE PATH.")</pre> |        |                                                           |
|              | State                                                                                                                                                                                                                          |        |                                                           |
|              | Success.                                                                                                                                                                                                                       | Output | SUCCESSFULLY CONFIRMED DEVICE PATH.                       |
|              | Incorrect path.                                                                                                                                                                                                                |        | FT_INCORRECT_DEVICE_PATH   FAILED TO CONFIRM DEVICE PATH. |

## 2.35 - FT\_GetDriverVersion()

D3XX C API Equivalent = FT\_GetDriverVersion()

## Summary

Returns the D3XX kernel driver version number in 4 bytes formatted in 4-bit Binary-Coded Decimal (BCD). Example: 0x01457000 = 1.45.70.0.

## Parameters

| Type      | Name   | Description                                           |
|-----------|--------|-------------------------------------------------------|
| FT_Device | Device | The device you want get the kernel driver version of. |

## Return Values

| Type | Name          | Description                                     |
|------|---------------|-------------------------------------------------|
| int  | Status        | FT_OK if successful.                            |
| int  | DriverVersion | The driver version encoded in 4-bit BCD format. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                        |                      |        |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|--------|
| Example Code | <pre>Status, DriverVersion = PyD3XX.FT_GetDriverVersion(Device) print("Device 0 Driver Version: " + format((DriverVersion &amp; int("0xFF000000", 16)) &gt;&gt; 24, 'x') + '.' \       + format((DriverVersion &amp; int("0x00FF0000", 16)) &gt;&gt; 16, 'x') + '.' \       + format((DriverVersion &amp; int("0x0000FF00", 16)) &gt;&gt; 8, 'x') + '.' \       + format(DriverVersion &amp; int("0x000000FF", 16), 'x')       )</pre> |                      |        |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                  | Version = 0x01030010 | Output |

## 2.35B – GetDriverVersion()

D3XX C API Equivalent = NONE. PyD3XX exclusive.

## Summary

Returns the D3XX kernel driver version number as a string. Example: 0x01457000 = "1.45.70.0".

This is meant as an easier to use form of FT\_GetDriverVersion().

## Parameters

| Type      | Name   | Description                                           |
|-----------|--------|-------------------------------------------------------|
| FT_Device | Device | The device you want get the kernel driver version of. |

## Return Values

| Type | Name          | Description                     |
|------|---------------|---------------------------------|
| int  | Status        | FT_OK if successful.            |
| str  | DriverVersion | The driver version as a string. |

## Example Code



|              |                                                                                                                       |        |                                   |
|--------------|-----------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------|
| Example Code | <pre>Status, DriverVersion = PyD3XX.GetDriverVersion(Device) print("Device 0 Driver Version: " + DriverVersion)</pre> |        |                                   |
| State        | Version = 0x01030010                                                                                                  | Output | Device 0 Driver Version: 1.3.0.10 |

## 2.36 – FT\_GetLibraryVersion()

D3XX C API Equivalent = FT\_GetLibraryVersion()

### Summary

Returns the D3XX user driver library version number in 4 bytes formatted in 4-bit Binary-Coded Decimal (BCD) for Windows. Example: 0x01457000 = 1.45.70.0.

For Linux/macOS the library version is the version of libusb installed on the system.

### Parameters

None

### Return Values

| Type | Name          | Description                                             |
|------|---------------|---------------------------------------------------------|
| int  | Status        | FT_OK if successful.                                    |
| int  | DriverVersion | The driver library version encoded in 4-bit BCD format. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                 |        |                                   |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------|
| Example Code | <pre>Status, LibraryVersion = PyD3XX.FT_GetLibraryVersion() print("Device 0 Library Version: " + format((LibraryVersion &amp; int("0xFF000000", 16)) &gt;&gt; 24, 'x') + '.' \ + format((LibraryVersion &amp; int("0x00FF0000", 16)) &gt;&gt; 16, 'x') + '.' \ + format((LibraryVersion &amp; int("0x0000FF00", 16)) &gt;&gt; 8, 'x') + '.' \ + format(LibraryVersion &amp; int("0x000000FF", 16), 'x') )</pre> |        |                                   |
| State        | Version = 0x01030008                                                                                                                                                                                                                                                                                                                                                                                            | Output | Device 0 Library Version: 1.3.0.8 |

## 2.36B – GetLibraryVersion()

D3XX C API Equivalent = NONE. PyD3XX exclusive.

### Summary

Returns the D3XX user driver library version number as a string. Example: 0x01457000 = "1.45.70.0".

This is meant as an easier to use form of FT\_GetLibraryVersion().

## Parameters

None

## Return Values

| Type | Name          | Description                             |
|------|---------------|-----------------------------------------|
| int  | Status        | FT_OK if successful.                    |
| str  | DriverVersion | The driver library version as a string. |

## Example Code

|              |                                                                                                                     |        |                                   |
|--------------|---------------------------------------------------------------------------------------------------------------------|--------|-----------------------------------|
| Example Code | <pre>Status, LibraryVersion = PyD3XX.GetLibraryVersion() print("Device 0 Library Version: " + LibraryVersion)</pre> |        |                                   |
| State        | Version = 0x01030008                                                                                                | Output | Device 0 Library Version: 1.3.0.8 |

## 2.37 – FT\_CycleDevicePort()

D3XX C API Equivalent = FT\_CycleDevicePort()

### Summary

Makes the host system power cycle the device port so that the device re-enumerates.

## Parameters

| Type      | Name   | Description                                    |
|-----------|--------|------------------------------------------------|
| FT_Device | Device | The device whose port you want to power cycle. |

## Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|              |                                                                                                                                                                                                                                    |        |                                       |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_CycleDevicePort(Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO CYCLE PORT OF DEVICE 0") else:     print("Successfully cycled port of Device 0!")</pre> |        |                                       |
| State        | Success.                                                                                                                                                                                                                           | Output | Successfully cycled port of Device 0! |

## 2.37B – FT\_ResetDevicePort()

D3XX C API Equivalent = FT\_ResetDevicePort()

## Summary

Makes the host system reset the device port so that the device re-enumerates.

## Parameters

| Type      | Name   | Description                              |
|-----------|--------|------------------------------------------|
| FT_Device | Device | The device whose port you want to reset. |

## Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|              |                                                                                                                                                                                                                                   |          |                                                |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|------------------------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_ResetDevicePort(Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO RESET PORT OF DEVICE 0") else:     print("Successfully reset port of Device 0!")</pre> |          |                                                |
|              | State                                                                                                                                                                                                                             | Success. | Output<br>Successfully reset port of Device 0! |

## 2.38 - FT\_SetSuspendTimeout()

D3XX C API Equivalent = FT\_SetSuspendTimeout()

WARNING - This function is exclusive to Windows systems.

## Summary

Sets the USB Selective suspend timeout for the given FT\_Device. By default with unmodified drivers, devices have the suspend feature enabled with an idle timeout of 10 seconds. If the FT\_Device is closed and re-opened, then the idle timeout will reset to the driver default.

If you want your device to always output a CLK signal, you should disable USB selective suspend. FT\_SetSuspendTimeout is only available on Windows systems. This function will fail if the notification feature is enabled.

## Parameters

| Type      | Name    | Description                                                                                                            |
|-----------|---------|------------------------------------------------------------------------------------------------------------------------|
| FT_Device | Device  | The device you want to set the suspend timeout value of.                                                               |
| int       | Timeout | The new USB selective suspend idle timeout value in seconds. If set to 0, then USB selective suspend will be disabled. |

## Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                            |        |                                                                                                           |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|--------|-----------------------------------------------------------------------------------------------------------|
| Example Code | <pre>Status, ChipConfiguration = PyD3XX.FT_GetChipConfiguration(Device) # Get chip configuration. CallbackNotificationsEnabled = (ChipConfiguration.OptionalFeatureSupport &amp; PyD3XX.CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCHALL) != 0 if(PyD3XX.Platform != "windows"):     print("FT_SetSuspendTimeout is only available on Windows!")     exit() if(CallbackNotificationsEnabled != False): # Can only disable suspend timeout if callback notifications are disabled.     print("WARNING: Callback notifications are enabled!") Status = PyD3XX.FT_SetSuspendTimeout(Device, 0) # Disable suspend timeout. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO DISABLE SUSPEND MODE: ABORTING")     exit() Status, SuspendTimeout = PyD3XX.FT_GetSuspendTimeout(Device) if (Status != PyD3XX.FT_OK) or (SuspendTimeout != 0):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CONFIRM SUSPEND MODE: ABORTING")     exit() print("Successfully disabled suspend mode!");</pre> |                            |        |                                                                                                           |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Success.                   | Output | Successfully disabled suspend mode!                                                                       |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Not on Windows.            |        | FT_SetSuspendTimeout is only available on Windows!                                                        |
|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Notifications are enabled. |        | WARNING: Callback notifications are enabled!<br>FT_OTHER_ERROR   FAILED TO DISABLE SUSPEND MODE: ABORTING |

## 2.39 – FT\_GetSuspendTimeout()

D3XX C API Equivalent = FT\_GetSuspendTimeout()

WARNING – This function is exclusive to Windows systems.

### Summary

Returns the idle timeout value for USB Selective suspend for the given FT\_Device object.

FT\_GetSuspendTimeout is only available on Windows systems. This function will fail if the notification feature is enabled.

### Parameters

| Type      | Name   | Description                                              |
|-----------|--------|----------------------------------------------------------|
| FT_Device | Device | The device you want to get the suspend timeout value of. |

### Return Values

| Type | Name    | Description                                                                                               |
|------|---------|-----------------------------------------------------------------------------------------------------------|
| int  | Status  | FT_OK if successful.                                                                                      |
| int  | Timeout | The USB selective suspend idle timeout value in seconds.<br>If 0, then USB selective suspend is disabled. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |        |                                     |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------|
| Example Code | <pre> Status = PyD3XX.FT_SetSuspendTimeout(Device, 0) # Disable suspend timeout. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO DISABLE SUSPEND MODE: ABORTING")     exit() Status, SuspendTimeout = PyD3XX.FT_GetSuspendTimeout(Device) if (Status != PyD3XX.FT_OK) or (SuspendTimeout != 0):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CONFIRM SUSPEND MODE: ABORTING")     exit() print("Successfully disabled suspend mode!"); </pre> |        |                                     |
| State        | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Output | Successfully disabled suspend mode! |

## 2.40 - FT\_SetTransferParams()

D3XX C API Equivalent = FT\_SetTransferParams()

WARNING - This function is exclusive to Linux & macOS systems.

### Summary

Sets the transfer parameters for a specific channel before opening (calling FT\_Create() for) any device. Any call to FT\_Close() will reset transfer parameters for all channels back to their default, already opened devices are not affected.

### Parameters

| Type            | Name           | Description                                                                                                    |
|-----------------|----------------|----------------------------------------------------------------------------------------------------------------|
| FT_TransferConf | TransferParams | The transfer parameters you want to set for a channel.                                                         |
| int             | dwFifoID       | An integer FIFO index of the channel you want to set the transfer parameters for.<br>Values 0-3 = Channels 1-4 |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

```

TransferParams = {}
for i in range(CHANNEL_COUNT):
    Status, TransferParams[i] = PyD3XX.FT_GetTransferParams(i)
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | FAILED TO GET TRANSFER PARAMS: ABORTING")
        exit()
for j in range(PyD3XX.FT_PIPE_DIR_COUNT):
    TransferParams[0].pipe[j].fPipeNotUsed = True
    TransferParams[0].pipe[j].fNonThreadSafeTransfer = True
    TransferParams[0].pipe[j].bURBCount = int(TransferParams[0].pipe[j].bURBCount / 2 + j)
    TransferParams[0].pipe[j].wURBBufferCount = int(TransferParams[0].pipe[j].wURBBufferCount
/ 2 + j)
    TransferParams[0].pipe[j].dwURBBufferSize = int(TransferParams[0].pipe[j].dwURBBufferSize
/ 2 + j)
    TransferParams[0].pipe[j].dwStreamingSize = int(TransferParams[0].pipe[j].dwStreamingSize
/ 2 + j)
    TransferParams[0].fStopReadingOnURBUnderrun = True
    TransferParams[0].fKeepDeviceSideBufferAfterReopen = True
for i in range(CHANNEL_COUNT):
    Status = PyD3XX.FT_SetTransferParams(TransferParams[0], i)
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | FAILED TO SET TRANSFER PARAMS: ABORTING")
        exit()
for i in range(CHANNEL_COUNT):
    Status, TransferParams[i] = PyD3XX.FT_GetTransferParams(i)
    if Status != PyD3XX.FT_OK:
        print(PyD3XX.FT_STATUS_STR[Status] + " | FAILED TO GET TRANSFER PARAMS: ABORTING")
        exit()
    print("---| Channel " + str(i+1) + " NEW Transfer Params |---")
    print("  wStructSize = " + str(TransferParams[i].wStructSize) + " bytes")
    for j in range(PyD3XX.FT_PIPE_DIR_COUNT):
        print("    " + ("OUT" if (j == PyD3XX.FT_PIPE_DIR_OUT) else "IN") + " PIPE PARAMS")
        print("    " + ("Pipe is DISABLED!" if TransferParams[i].pipe[j].fPipeNotUsed else
"Pipe is ENABLED!"))
        print("    " + ("Pipe is NOT THREAD SAFE!" if
TransferParams[i].pipe[j].fNonThreadSafeTransfer else "Pipe is THREAD SAFE!"))
        print("    " + "bURBCount = " + str(TransferParams[i].pipe[j].bURBCount))
        print("    " + "wURBBufferCount = " + str(TransferParams[i].pipe[j].wURBBufferCount))
        print("    " + "dwURBBufferSize = " + str(TransferParams[i].pipe[j].dwURBBufferSize))
        print("    " + "dwStreamingSize = " + str(TransferParams[i].pipe[j].dwStreamingSize))
    print("  fStopReadingOnURBUnderrun = " +
str(TransferParams[i].fStopReadingOnURBUnderrun))
    print("  fKeepDeviceSideBufferAfterReopen = " +
str(TransferParams[i].fKeepDeviceSideBufferAfterReopen))

```

|       |                           |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------|---------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State | On Windows.               | Output | FT_OTHER_ERROR   FAILED TO GET TRANSFER PARAMS: ABORTING                                                                                                                                                                                                                                                                                                                                                                                                                          |
|       | Success with one channel. |        | <pre> ---  Channel 1 NEW Transfer Params  --- wStructSize = 56 bytes IN PIPE PARAMS   Pipe is DISABLED!   Pipe is NOT THREAD SAFE!   bURBCount = 4   wURBBufferCount = 128   dwURBBufferSize = 32768   dwStreamingSize = 536870912 OUT PIPE PARAMS   Pipe is DISABLED!   Pipe is NOT THREAD SAFE!   bURBCount = 5   wURBBufferCount = 129   dwURBBufferSize = 32769   dwStreamingSize = 536870913 fStopReadingOnURBUnderrun = True fKeepDeviceSideBufferAfterReopen = True </pre> |

## 2.41 - FT\_GetTransferParams()

D3XX C API Equivalent = FT\_GetTransferParams()

WARNING - This function is exclusive to Linux & macOS systems.

### Summary

Gets the last set transfer parameters for a specific channel given they haven't been reset by a FT\_Close() call. Any call to FT\_Close() will reset transfer parameters for all channels back to their default, already opened devices are not affected.

### Parameters

| Type | Name     | Description                                                                                                    |
|------|----------|----------------------------------------------------------------------------------------------------------------|
| int  | dwFifoID | An integer FIFO index of the channel you want to get the transfer parameters for.<br>Values 0-3 = Channels 1-4 |

### Return Values

| Type            | Name           | Description                                            |
|-----------------|----------------|--------------------------------------------------------|
| int             | Status         | FT_OK if successful.                                   |
| FT_TransferConf | TransferParams | The retrieved transfer parameters for a given channel. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> TransferParams = {} for i in range(CHANNEL_COUNT):     Status, TransferParams[i] = PyD3XX.FT_GetTransferParams(i)     if Status != PyD3XX.FT_OK:         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO GET TRANSFER PARAMS: ABORTING")         exit()     print("---  Channel " + str(i+1) + " DEFAULT Transfer Params  ---")     print("  wStructSize = " + str(TransferParams[i].wStructSize) + " bytes")     for j in range(PyD3XX.FT_PIPE_DIR_COUNT):         print("    " + ("OUT" if (j == PyD3XX.FT_PIPE_DIR_OUT) else "IN") + " PIPE PARAMS")         print("    " + ("Pipe is DISABLED!" if TransferParams[i].pipe[j].fPipeNotUsed else "Pipe is ENABLED!"))         print("    " + ("Pipe is NOT THREAD SAFE!" if TransferParams[i].pipe[j].fNonThreadSafeTransfer else "Pipe is THREAD SAFE!"))         print("    " + "bURBCount = " + str(TransferParams[i].pipe[j].bURBCount))         print("    " + "wURBBufferCount = " + str(TransferParams[i].pipe[j].wURBBufferCount))         print("    " + "dwURBBufferSize = " + str(TransferParams[i].pipe[j].dwURBBufferSize))         print("    " + "dwStreamingSize = " + str(TransferParams[i].pipe[j].dwStreamingSize))     print("  fStopReadingOnURBUnderrun = " + str(TransferParams[i].fStopReadingOnURBUnderrun))     print("  fKeepDeviceSideBufferAfterReopen = " + str(TransferParams[i].fKeepDeviceSideBufferAfterReopen)) </pre> |        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| State        | On Windows.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |        | FT_OTHER_ERROR   FAILED TO GET TRANSFER PARAMS: ABORTING                                                                                                                                                                                                                                                                                                                                                                                                                        |
|              | Success with one channel.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Output | <pre> ---  Channel 1 DEFAULT Transfer Params  --- wStructSize = 56 bytes IN PIPE PARAMS   Pipe is ENABLED!   Pipe is THREAD SAFE!   bURBCount = 8   wURBBufferCount = 256   dwURBBufferSize = 65536   dwStreamingSize = 1073741824 OUT PIPE PARAMS   Pipe is ENABLED!   Pipe is THREAD SAFE!   bURBCount = 8   wURBBufferCount = 256   dwURBBufferSize = 65536   dwStreamingSize = 1073741824 fStopReadingOnURBUnderrun = False fKeepDeviceSideBufferAfterReopen = False </pre> |



## 2.42 - FT\_SetVIDPID()

D3XX C API Equivalent = FT\_SetVIDPID()

WARNING - This function is exclusive to Linux & macOS systems.

### Summary

Registers a custom Vendor ID (VID) and Product ID (PID) combination, enabling plug-and-play detection of custom hardware.

### Parameters

| Type | Name  | Description                        |
|------|-------|------------------------------------|
| int  | dwVID | The custom Vendor ID to register.  |
| int  | dwPID | The custom Product ID to register. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |             |                                |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|--------------------------------|
| Example Code | <pre>Status = PyD3XX.FT_SetVIDPID(int("0x0403", 16), int("0x1234", 16)) # Add custom VID:PID. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO ADD VID:PID COMBINATION: ABORTING")     exit() Status, DeviceCount = PyD3XX.FT_CreateDeviceInfoList() # Create a device info list. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE DEVICE INFO LIST: ABORTING")     exit() if (DeviceCount == 0):     print("NO DEVICES DETECTED: ABORTING")     exit() Status, Device = PyD3XX.FT_GetDeviceInfoDetail(0) # Get info of a device at index 0. if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   WARNING: FAILED TO GET INFO FOR DEVICE 0") Status, VID, PID = PyD3XX.FT_GetVIDPID(Device) if Status != PyD3XX.FT_OK:     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO GET VID:PID COMBINATION: ABORTING")     exit() print("Device 0 (VID:PID) = " + format(VID, "x").zfill(4) + ":" + format(PID, "x").zfill(4))</pre> |             |                                |
|              | State                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | On Windows. | Output                         |
|              | Success.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |             | Device 0 (VID:PID) = 0403:1234 |

## 3 - PyD3XX Classes

All the classes defined in PyD3XX.

## 3.1 - FT\_Buffer

D3XX C API Equivalent = NONE. PyD3XX exclusive.

### Summary

A buffer that holds data to be written or data that was received for write/read functions like `FT_WritePipe()` and `FT_ReadPipe()`.

### Attributes

None

### Methods

| Name                        | Parameters           | Description                                                   |
|-----------------------------|----------------------|---------------------------------------------------------------|
| <code>__init__</code>       | Size: int            | Construct an <code>FT_Buffer</code> that can hold Size bytes. |
| <code>from_int</code>       | Integer: int         | Construct an <code>FT_Buffer</code> from an integer.          |
| <code>from_str</code>       | String: str          | Construct an <code>FT_Buffer</code> from an ASCII string.     |
| <code>from_bytearray</code> | ByteArray: bytearray | Construct an <code>FT_Buffer</code> from a bytearray.         |
| <code>from_bytes</code>     | Bytes: bytes         | Construct an <code>FT_Buffer</code> from bytes.               |
| <code>Value</code>          | None                 | Return the data of the buffer in a bytearray.                 |

## 3.2 - FT\_Device

D3XX C API Equivalent = `FT_DEVICE_LIST_INFO_NODE` / `FT_HANDLE`

### Summary

A class that holds the same information about a device as `FT_DEVICE_LIST_INFO_NODE` but is also used as a replacement for `FT_HANDLE` for function calls. You must initialize/obtain an `FT_Device` from functions like `FT_GetDeviceInfoDetail` or `FT_GetDeviceInfoList` for an `FT_Device` object to be valid and openable.

### Attributes

| Type      | Name         | Description                                                                                                                                                                                                          |
|-----------|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int   str | Handle       | The value of a valid <code>FT_HANDLE</code> as an integer or a string of an <code>FT_ERROR</code> like " <code>FT_OTHER_ERROR</code> ".                                                                              |
| int       | Flags        | A bitmask showing the status of the device.                                                                                                                                                                          |
|           |              | 0b001 FT_FLAGS_OPENED Device is opened by another program.                                                                                                                                                           |
|           |              | 0b010 FT_FLAGS_HISPEED Device is operating at USB Hi-Speed.<br>Note: Device could also be operating at USB Full Speed. If MaximumPacketSize from FT_Pipe is 512, it's USB Hi-Speed. If it's 64, it's USB Full Speed. |
|           |              | 0b100 FT_FLAGS_SUPERSPEED Device is operating at USB SuperSpeed.                                                                                                                                                     |
| int       | Type         | Represents what type of FT60X device the <code>FT_Device</code> is.                                                                                                                                                  |
|           |              | 0d3 FT_DEVICE_UNKNOWN Device type is unknown.                                                                                                                                                                        |
|           |              | 0d600 FT_DEVICE_600 Device is an FT600.                                                                                                                                                                              |
|           |              | 0d601 FT_DEVICE_601 Device is an FT601.                                                                                                                                                                              |
| int       | ID           | The device's ID. VID:PID combination. 0403:601F = 0x0403601F.                                                                                                                                                        |
| int       | LocID        | The device's location ID.                                                                                                                                                                                            |
| str       | SerialNumber | The device's serial number as a string.                                                                                                                                                                              |
| str       | Description  | The device's description as a string.                                                                                                                                                                                |

## Methods

None

## 3.3 – FT\_DeviceDescriptor

D3XX C API Equivalent = FT\_DEVICE\_DESCRIPTOR

### Summary

The USB device descriptor retrieved from an FT\_Device.

### Attributes

| Type | Name               | Description                                                                                                                                   |
|------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| int  | bLength            | The length of the device descriptor itself.                                                                                                   |
| int  | bDescriptorType    | The type of the descriptor itself.                                                                                                            |
| int  | bcdUSB             | The version of the USB specification the device conforms to.<br>0x0200 = USB 2.0, 0x0310 = USB 3.1, etc.                                      |
| int  | bDeviceClass       | The device's USB base class code.<br>More Info: <a href="https://www.usb.org/defined-class-codes">https://www.usb.org/defined-class-codes</a> |
| int  | bDeviceSubClass    | The device's USB sub class code.<br>More Info: <a href="https://www.usb.org/defined-class-codes">https://www.usb.org/defined-class-codes</a>  |
| int  | bDeviceProtocol    | The device's USB device protocol.<br>More Info: <a href="https://www.usb.org/defined-class-codes">https://www.usb.org/defined-class-codes</a> |
| int  | bMaxPacketSize0    | The max packet size of endpoint zero.                                                                                                         |
| int  | idVendor           | The device's vendor ID (VID).                                                                                                                 |
| int  | idProduct          | The device's product ID (PID).                                                                                                                |
| int  | bcdDevice          | The device's device-defined revision number.                                                                                                  |
| int  | iManufacturer      | The device's device-defined index of the string descriptor containing the name of the device's manufacturer.                                  |
| int  | iProduct           | The device's device-defined index of the string descriptor containing the device's description.                                               |
| int  | iSerialNumber      | The device's device-defined index of the string descriptor containing the device's serial number.                                             |
| int  | bNumConfigurations | The device's total number of possible configurations.                                                                                         |

## Methods

None

## 3.4 – FT\_ConfigurationDescriptor

D3XX C API Equivalent = FT\_CONFIGURATION\_DESCRIPTOR

### Summary

The USB configuration descriptor retrieved from an FT\_Device. FTDI D3XX devices support only one USB configuration.

### Attributes

| Type | Name            | Description                                                  |
|------|-----------------|--------------------------------------------------------------|
| int  | bLength         | The length of the configuration descriptor itself.           |
| int  | bDescriptorType | The type of the descriptor itself.                           |
| int  | wTotalLength    | The number of bytes needed to contain the full configuration |

|     |                     |                                                                                                                                                                                                                                                                                         |
|-----|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     |                     | descriptor. This length accounts for all interface, endpoint, class, and/or vendor-specific descriptors that are returned with the configuration descriptor.                                                                                                                            |
| int | bNumInterfaces      | The total number of interfaces supported by the configuration.                                                                                                                                                                                                                          |
| int | bConfigurationValue | The value used to select a configuration.                                                                                                                                                                                                                                               |
| int | iConfiguration      | The device's device-defined index of the string descriptor for this configuration.                                                                                                                                                                                                      |
| int | bmAttributes        | A bitmap describing the behavior of the configuration.                                                                                                                                                                                                                                  |
|     | bmAttributes[4:0]   | Bits 4-0. Reserved.                                                                                                                                                                                                                                                                     |
|     | bmAttributes[5]     | 0b1 = The configuration supports remote wakeup.                                                                                                                                                                                                                                         |
|     | bmAttributes[6]     | 0b1 = The configuration is self-powered.                                                                                                                                                                                                                                                |
|     | bmAttributes[7]     | 0b1 = The configuration is bus-powered.                                                                                                                                                                                                                                                 |
| int | MaxPower            | Power requirement of the device represented in 2mA units for USB 2.0 and 8mA units for USB 3.0.<br>USB 2.0 Example: MaxPower = 0d50 means device has a power requirement of 100mA (50 * 2).<br>USB 3.0 Example: MaxPower = 0d62 means device has a power requirement of 496mA (62 * 8). |

## Methods

None

## 3.5 – FT\_InterfaceDescriptor

D3XX C API Equivalent = FT\_INTERFACE\_DESCRIPTOR

## Summary

The USB interface descriptor retrieved from an FT\_Device.

## Attributes

| Type | Name               | Description                                                                                     |
|------|--------------------|-------------------------------------------------------------------------------------------------|
| int  | bLength            | The length of the interface descriptor itself.                                                  |
| int  | bDescriptorType    | The type of the descriptor itself.                                                              |
| int  | bInterfaceNumber   | The index number of the interface.                                                              |
| int  | bAlternateSetting  | The index number of the alternate setting of the interface.                                     |
| int  | bNumEndpoints      | The number of endpoints used by the interface, excluding the status endpoint.                   |
| int  | bInterfaceClass    | The class code of the device.                                                                   |
| int  | bInterfaceSubClass | The sub class code of the device.                                                               |
| int  | bInterfaceProtocol | The protocol code of the device.                                                                |
| int  | iInterface         | The device's device-defined index of the string descriptor containing the device's description. |

## Methods

None

## 3.6 – FT\_StringDescriptor

D3XX C API Equivalent = FT\_STRING\_DESCRIPTOR

## Summary

The USB string descriptor retrieved from an FT\_Device. Can hold a device, configuration, interface, class, vendor, or endpoint string descriptor.

#### Attributes

| Type | Name            | Description                                 |
|------|-----------------|---------------------------------------------|
| int  | bLength         | The length of the string descriptor itself. |
| int  | bDescriptorType | The type of the descriptor itself.          |
| str  | szString        | The string for the requested descriptor.    |

#### Methods

None

## 3.7 – FT\_EndpointDescriptor

D3XX C API Equivalent = FT\_ENDPOINT\_DESCRIPTOR

#### Summary

The USB endpoint descriptor retrieved from an FT\_Device.

#### Attributes

| Type | Name                  | Description                                                                                                                                               |
|------|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| int  | bLength               | The length of the endpoint descriptor itself.                                                                                                             |
| int  | bDescriptorType       | The type of the descriptor itself.                                                                                                                        |
| int  | bEndpointAddress      | The USB-defined endpoint address.                                                                                                                         |
|      | bEndpointAddress[3:0] | The endpoint number.                                                                                                                                      |
|      | bEndpointAddress[6:4] | Reserved                                                                                                                                                  |
|      | bEndpointAddress[7]   | 0 = OUT endpoint<br>1 = IN endpoint                                                                                                                       |
| int  | bmAttributes          | The attributes of the endpoint.                                                                                                                           |
|      | bmAttributes[1:0]     | 0b00 = This is a Control endpoint.<br>0b01 = This is an Isochronous endpoint.<br>0b10 = This is a Bulk endpoint.<br>0b11 = This is an Interrupt endpoint. |
|      | bmAttributes[3:2]     | 0b00 = No synchronization. Bits 5-4 are zero.<br>0b01 = Asynchronous.<br>0b10 = Adaptive.<br>0b11 = Synchronous.                                          |
|      | bmAttributes[5:4]     | 0b00 = Used for data.<br>0b01 = Used for feedback.<br>0b10 = Used for implicit feedback.<br>0b11 = Reserved.                                              |
|      | bmAttributes[7:6]     | Reserved.                                                                                                                                                 |
| int  | wMaxPacketSize        | The maximum packet size for this endpoint.                                                                                                                |
| int  | bInterval             | The polling interrupt for isochronous and interrupt endpoints.                                                                                            |

#### Methods

None

## 3.8 – FT\_Pipe

D3XX C API Equivalent = FT\_PIPE\_INFORMATION / ucPipeID

## Summary

An FT\_Device's IN or OUT endpoint. Used as an equivalent for ucPipeID in read/write functions like FT\_ReadPipe() and FT\_WritePipe(). FT\_Pipe is the read or write endpoint for one of the FT60X's channels.

## Attributes

| Type | Name              | Description                                                                 |
|------|-------------------|-----------------------------------------------------------------------------|
| int  | PipeType          | The type of the pipe.                                                       |
|      |                   | 0d0 FTPipeTypeControl This is a Control pipe.                               |
|      |                   | 0d1 FTPipeTypeIsochronous This is an Isochronous pipe.                      |
|      |                   | 0d2 FTPipeTypeBulk This is a Bulk pipe.                                     |
|      |                   | 0d3 FTPipeTypeInterrupt This is an Interrupt pipe.                          |
| int  | PipeId            | The pipe's ID.                                                              |
|      |                   | PipeId[3:0] The pipe's number.                                              |
|      |                   | PipeId[6:4] Reserved                                                        |
|      |                   | PipeId [7] 0 = This is a write (OUT) pipe.<br>1 = This is a read (IN) pipe. |
| int  | MaximumPacketSize | The maximum packet size for this pipe.                                      |
| int  | Interval          | The pipe's interrupt interval if used for callbacks.                        |

## Methods

None

## 3.9 – FT\_Overlapped

D3XX C API Equivalent = OVERLAPPED

## Summary

The equivalent of the OVERLAPPED structure used for asynchronous I/O operations.

## Attributes

| Type | Name                  | Description                                                                              |
|------|-----------------------|------------------------------------------------------------------------------------------|
| int  | Internal              | The status code for the I/O request.                                                     |
| int  | InternalHigh          | The number of bytes transferred for a successful I/O request.                            |
| int  | DummyUnion            | The address of the dummy union.                                                          |
| int  | DummyUnion_Offset     | The low-order part of the file position specified by the user to start the I/O request.  |
| int  | DummyUnion_OffsetHigh | The high-order part of the file position specified by the user to start the I/O request. |
| int  | DummyUnion_Pointer    | Reserved. Do not use.                                                                    |
| int  | Handle                | A handle to an event signaled by the system when the I/O operation has completed.        |

## Methods

None

## 3.10 – FT\_SetupPacket

D3XX C API Equivalent = FT\_SETUP\_PACKET

## Summary

The equivalent of a USB setup packet to perform standard device requests. You can find more information about setup packets and standard device requests in official USB specifications.

## Attributes

| Type | Name        | Description                          |
|------|-------------|--------------------------------------|
| int  | RequestType | The type of request to be performed. |
| int  | Request     | The request code.                    |
| int  | Value       | A request-specific value.            |
| int  | Index       | A request-specific value.            |
| int  | Length      | The number of bytes to transfer.     |

## Methods

None

## 3.11 - FT\_60XCONFIGURATION

D3XX C API Equivalent = FT\_60XCONFIGURATION

## Summary

Holds the chip configuration read from or to be written to a FT60X device.

## Attributes

| Type      | Name              | Description                                                                                                                                                                                                                                                                                                                                        |
|-----------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int       | VendorID          | The vendor ID. VID                                                                                                                                                                                                                                                                                                                                 |
| int       | ProductID         | The product ID. PID                                                                                                                                                                                                                                                                                                                                |
| list[str] | StringDescriptors | A list of string descriptors which are encoded in ASCII.<br>StringDescriptors[0] The manufacturer string, can hold a max of 15 characters.<br>StringDescriptors[1] The description string, can hold a max of 31 characters.<br>StringDescriptors[2] The serial number string, can hold a max of 15 characters.                                     |
| int       | bInterval         | The minimum latency in $2^{(bInterval-1)}$ USB frames. This is the minimum latency for notification callbacks and GPIO reads.<br>The minimum value is 1, and the maximum value is 16.<br>Example: bInterval=15 means a latency of $2^{14}$ USB frames. Since each frame is 125us, that is a minimum latency of 2.048 seconds ( $2^{14} * 125us$ ). |
| int       | PowerAttributes   | A bitmap describing the behavior of the configuration.<br>PowerAttributes[4:0] Bits 4-0. Reserved.<br>PowerAttributes[5] 0b1 = The device supports remote wakeup.<br>PowerAttributes[6] 0b1 = The device is self-powered.<br>PowerAttributes[7] 0b1 = The device is bus-powered.                                                                   |
| int       | PowerConsumption  | Power requirements of the device represented in 8mA units. PowerConsumption = 0d62 means device has a max power requirement of 496mA ( $62 * 8$ ).                                                                                                                                                                                                 |
| int       | Reserved2         | Reserved.                                                                                                                                                                                                                                                                                                                                          |
| int       | FIFOClock         | The clock speed of the FIFO.                                                                                                                                                                                                                                                                                                                       |

|     |                           |                                                                                                                                                                                                                    |
|-----|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|     |                           | 0d0 = 100 MHz.<br>0d1 = 66 MHz.                                                                                                                                                                                    |
| int | FIFOMode                  | The mode of the FIFO.<br>0d0 = 245 Mode.<br>0d1 = 600 Mode.                                                                                                                                                        |
| int | ChannelConfig             | The channel configuration.<br>0x0 = 4 Channels.<br>0x1 = 2 Channels.<br>0x2 = 1 Channel.<br>0x3 = 1 OUT Pipe.<br>0x4 = 1 IN Pipe.                                                                                  |
| int | OptionalFeatureSupport    | A bitmask representing support for optional features.                                                                                                                                                              |
| int | BatteryChargingGPIOConfig | A bitmask to disable or set GPIO states that indicate what power source type was detected. 0d0 = Disabled.<br>SDP = Standard Downstream Port.<br>CDP = Charging Downstream Port.<br>DCP = Dedicated Charging Port. |
|     |                           | BatteryChargingGPIOConfig[1:0] GPIO default state.                                                                                                                                                                 |
|     |                           | BatteryChargingGPIOConfig[3:2] SDP detected state.                                                                                                                                                                 |
|     |                           | BatteryChargingGPIOConfig[5:4] CDP detected state.                                                                                                                                                                 |
|     |                           | BatteryChargingGPIOConfig[7:6] DCP detected state.                                                                                                                                                                 |
| int | FlashEEPROMDetection      | Read only bit mask.                                                                                                                                                                                                |
| int | MSIO_Control              | Controls the drive strength of the FIFO pins.<br>Default value is 0x010800. Make sure to only alter the first byte of data.                                                                                        |
|     |                           | Byte0[3:0] Data pins' drive strength.<br>0d0 = 50 Ohm<br>0d1 = 35 Ohm<br>0d2 = 25 Ohm<br>0d3 = 18 Ohm                                                                                                              |
|     |                           | Byte0[7:4] CLK pin's drive strength.<br>0d0 = 50 Ohm<br>0d1 = 35 Ohm<br>0d2 = 25 Ohm<br>0d3 = 18 Ohm                                                                                                               |
| int | GPIO_Control              | Controls the drive strength of the GPIO pins.                                                                                                                                                                      |
|     |                           | GPIO Control GPIO00 Drive Strength GPIO01 Drive Strength                                                                                                                                                           |
|     |                           | 0x0000 50 Ohm 50 Ohm                                                                                                                                                                                               |
|     |                           | 0x0100 35 Ohm 50 Ohm                                                                                                                                                                                               |
|     |                           | 0x0200 25 Ohm 50 Ohm                                                                                                                                                                                               |
|     |                           | 0x0300 18 Ohm 50 Ohm                                                                                                                                                                                               |
|     |                           | 0x0400 50 Ohm 35 Ohm                                                                                                                                                                                               |
|     |                           | 0x0500 35 Ohm 35 Ohm                                                                                                                                                                                               |
|     |                           | 0x0600 25 Ohm 35 Ohm                                                                                                                                                                                               |
|     |                           | 0x0700 18 Ohm 35 Ohm                                                                                                                                                                                               |
|     |                           | 0x0800 50 Ohm 25 Ohm                                                                                                                                                                                               |
|     |                           | 0x0900 35 Ohm 25 Ohm                                                                                                                                                                                               |
|     |                           | 0x0A00 25 Ohm 25 Ohm                                                                                                                                                                                               |
|     |                           | 0x0B00 18 Ohm 25 Ohm                                                                                                                                                                                               |
|     |                           | 0x0C00 50 Ohm 18 Ohm                                                                                                                                                                                               |
|     |                           | 0x0D00 35 Ohm 18 Ohm                                                                                                                                                                                               |



|  |  |        |        |        |
|--|--|--------|--------|--------|
|  |  | 0x0E00 | 25 Ohm | 18 Ohm |
|  |  | 0x0F00 | 18 Ohm | 18 Ohm |

## Methods

None

## 3.12 – FT\_PipeTransferConf

D3XX C API Equivalent = FT\_PIPE\_TRANSFER\_CONF

## Summary

Data transfer options for a specific pipe. Only for Linux/macOS.

## Attributes

| Type | Name                   | Description                                                              |
|------|------------------------|--------------------------------------------------------------------------|
| bool | fPipeNotUsed           | If True, pipe is disabled and cannot be used for transfers.              |
| bool | fNonThreadSafeTransfer | If True, you must guarantee only one thread accesses the pipe at a time. |
| int  | bURBCount              | Number of concurrent URBs that can exist for the pipe.                   |
| int  | wURBBufferCount        | URB buffer count.                                                        |
| int  | dwURBBufferSize        | URB buffer size.                                                         |
| int  | dwStreamingSize        | Streaming size.                                                          |

## Methods

None

## 3.13 – FT\_TransferConf

D3XX C API Equivalent = FT\_TRANSFER\_CONF

## Summary

Data transfer options for a device. Only for Linux/macOS.

## Attributes

| Type                               | Name                      | Description                                                                                                                                                                                                                                                                                      |
|------------------------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int                                | wStructSize               | Size of FT_TRANSFER_CONF in bytes. Never edit this value.                                                                                                                                                                                                                                        |
| list[FT_PipeTransferConf]<br>  str | pipe                      | A list of two FT_PipeTransferConf objects for a given channel.<br>pipe[PyD3XX.FT_PIPE_DIR_OUT] = Pipe transfer options for the OUT endpoint/pipe of a channel.<br>pipe[PyD3XX.FT_PIPE_DIR_IN] = Pipe transfer options for the IN endpoint/pipe of a channel.<br>“FT_OTHER_ERROR” on other error. |
| bool                               | fStopReadingOnURBUnderrun | If True, stop reading on URB underrun.                                                                                                                                                                                                                                                           |
| bool                               | fBitBangMode              | fReserved1. Reserved. Never edit this value.                                                                                                                                                                                                                                                     |

|      |                                  |                                                              |
|------|----------------------------------|--------------------------------------------------------------|
| bool | fKeepDeviceSideBufferAfterReopen | If True, buffer is not flushed before re-opening the device. |
|------|----------------------------------|--------------------------------------------------------------|

## Methods

None

# 4 – QueueD3XX

This section goes over the PyD3XX.Queue submodule for creating multi-threaded data queues in Python. QueueD3XX is C library wrapper for D3XX and is used to implement the Queue submodule.

**WARNING: Do not recommend using this submodule on Linux or macOS. Underlying Linux & macOS libraries already give good performance using normal FTDI calls while using this submodule is less efficient & requires more setup (transfer parameters).**

## 4.1 – Queue (Class)

### Summary

A Queue class object represents a separate background thread that continuously queues up read/write requests for one pipe/endpoint of one FT60X device.

Queue objects must only be created via a call to Queue.CreateQueue(). When a Queue is created, a new thread is immediately made in the background that will continuously issue read/write pipe calls while the Queue is not full. When a Queue object is destroyed/invalidated, its background thread is destroyed & its resources freed up.

Some Queue methods will automatically destroy the Queue upon an error, invalidating the Queue object. Queue objects that have been destroyed/invalidated will cause methods to return FT\_INVALID\_PARAMETER if used. You can re-create the Queue for a pipe/endpoint if your Queue was destroyed/invalidated. When a Queue object is invalidated/destroyed, FT\_AbortPipe() is called.

Queue objects must be destroyed via Queue.DestroyQueue() before the handle it was made for is closed and before your program exits.

### Attributes

None

### Methods

None

## 4.2 – Queue.GetVersionQueueD3XX()

### Summary

Returns the QueueD3XX library version number as a string.

### Parameters

None

### Return Values

| Type | Name | Description |
|------|------|-------------|
|------|------|-------------|

|     |         |                                       |
|-----|---------|---------------------------------------|
| str | Version | The version of QueueD3XX as a string. |
|-----|---------|---------------------------------------|

### Example Code

|              |                                                                                |        |                              |
|--------------|--------------------------------------------------------------------------------|--------|------------------------------|
| Example Code | <pre>print("QueueD3XX Version = " + PyD3XX.Queue.GetVersionQueueD3XX());</pre> |        |                              |
| State        | N/A                                                                            | Output | QueueD3XX Version = 1.0.0.11 |

## 4.3 – Queue.CreateQueue()

### Summary

Creates a Queue object for the given FT\_Pipe of one FT\_Device.

### Parameters

| Type      | Name        | Description                                                                                                                                           |
|-----------|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| FT_Device | Device      | The device you want to create a queue for.                                                                                                            |
| FT_Pipe   | Pipe        | The pipe you want to create a queue for.                                                                                                              |
| int       | StreamSize  | The size of the individual read/write pipe requests your queue will make.                                                                             |
| int       | QueueLength | The max length of your queue. Up to QueueLength read/write requests will be held in the queue at one time.                                            |
| bool      | Fixed       | If True, FT_SetStreamPipe() is called to set the fixed stream size of your pipe to StreamSize.<br>If False, the stream size of the pipe is not fixed. |

### Return Values

| Type  | Name     | Description                     |
|-------|----------|---------------------------------|
| int   | Status   | FT_OK if successful.            |
| Queue | NewQueue | The newly created Queue object. |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |        |                                                                                                                                    |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Status, Pipe = PyD3XX.FT_GetPipeInformation(Device, 1, 0) if Status != PyD3XX.FT_OK:     print("FAILED TO GET PIPE INFO OF [1,0]: ABORTING")     exit() # PipeIndex is 0, which is channel 1 OUT/write endpoint. # Following queue will automatically queue up write requests when given data. Status, WriteQueue = PyD3XX.Queue.CreateQueue(Device, Pipe, STREAM_SIZE, QUEUE_SIZE, FIXED_TRANSFER_SIZE) if(Status != PyD3XX.FT_OK):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE WRITE QUEUE!")     exit() print("Successfully made write queue!") print("Size of Requests = " + str(STREAM_SIZE) + " bytes") print("Max Requests = " + str(QUEUE_SIZE)) print("Stream size is " + ("FIXED" if FIXED_TRANSFER_SIZE else "NOT FIXED")) </pre> |        |                                                                                                                                    |
| State        | Success                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Output | <p>Successfully made write queue!</p> <p>Size of Requests = 1024 bytes</p> <p>Max Requests = 5</p> <p>Stream size is NOT FIXED</p> |

## 4.4 – Queue.DestroyQueue()

### Summary

Destroys the given Queue object.

### Parameters

| Type  | Name  | Description                           |
|-------|-------|---------------------------------------|
| Queue | Queue | The Queue object you want to destroy. |

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

### Example Code

|              |                                                                                                                                                                                                                               |        |                                                       |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|-------------------------------------------------------|
| Example Code | <pre> Status = PyD3XX.Queue.DestroyQueue(WriteQueue) if(Status != PyD3XX.FT_OK):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO DESTROY WRITE QUEUE!")     exit() print("Successfully destroyed write queue!") </pre> |        |                                                       |
| State        | Given invalid Queue.                                                                                                                                                                                                          | Output | FT_INVALID_PARAMETER   FAILED TO DESTROY WRITE QUEUE! |
|              | Success                                                                                                                                                                                                                       |        | Successfully destroyed write queue!                   |

## 4.5 – Queue.ReadQueue()

### Summary

Retrieves the result & data of the oldest read request in the Queue. When this function returns FT\_OK, the oldest read request has been removed.

Automatically destroys/invalidates the given read Queue object if its return code is NOT one of the below. Write queue objects are ignored (not destroyed/invalidated).

FT\_OK, FT\_IO\_PENDING, FT\_IO\_INCOMPLETE, FT\_NO\_MORE\_ITEMS

FT\_AbortPipe() is automatically called if the read Queue object was destroyed/invalidated.

### Parameters

| Type  | Name   | Description                                                                                                       |
|-------|--------|-------------------------------------------------------------------------------------------------------------------|
| Queue | RQueue | The Queue object for the IN endpoint/read pipe that you want to read from.                                        |
| bool  | Wait   | If True, this method won't return until the queue is not empty.<br>If False, this method will return immediately. |

### Return Values

| Type      | Name             | Description                                                                                                                                                                                                                  |
|-----------|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int       | Status           | FT_OK if successful.<br>FT_IO_PENDING or FT_IO_INCOMPLETE if read request is not completed yet.<br>FT_NO_MORE_ITEMS if queue is empty & Wait was False.<br>FT_INVALID_PARAMETER if given Queue was a write queue or invalid. |
| FT_Buffer | Buffer           | Buffer filled with data read from Queue IF return value was FT_OK.                                                                                                                                                           |
| int       | BytesTransferred | Number of bytes transferred.                                                                                                                                                                                                 |

### Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |        |                                                                                                                                 |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> Status, Pipe = PyD3XX.FT_GetPipeInformation(Device, 1, 1) if Status != PyD3XX.FT_OK:     print("FAILED TO GET PIPE INFO OF [1,1]: ABORTING")     exit() # PipeIndex is 1, which is channel 1 IN/read endpoint. # Following queue will automatically queue up read requests. Status, ReadQueue = PyD3XX.Queue.CreateQueue(Device, Pipe, 1, QUEUE_SIZE, False) if(Status != PyD3XX.FT_OK):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO CREATE READ QUEUE!")     exit() print("Successfully made read queue!") while True:     Status, Buffer, BytesTransferred = PyD3XX.Queue.ReadQueue(ReadQueue, True)     if(Status != PyD3XX.FT_OK) and (Status != PyD3XX.FT_IO_INCOMPLETE) and (Status != PyD3XX.FT_IO_PENDING) and (Status != PyD3XX.FT_NO_MORE_ITEMS):         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO READ CHANNEL 1 PIPE!")         exit()     ReadValue = int.from_bytes(Buffer.Value(), "little")     print("Data In = " + str(ReadValue))     if ReadValue &gt;= 3:         print("Reached value 3, ending streaming!")         break </pre> |        |                                                                                                                                 |
| State        | Request timed out.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Output | FT_TIMEOUT   FAILED TO READ CHANNEL 1 PIPE!                                                                                     |
|              | Success                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |        | Successfully made read queue!<br>Data In = 0<br>Data In = 1<br>Data In = 2<br>Data In = 3<br>Reached value 3, ending streaming! |

## 4.6 – Queue.WriteQueue()

### Summary

Queues up the given FT\_Buffer into a write pipe request. Retrieves the result & sends the data of the newest write request to the queue. When this function returns FT\_OK, the newest write request has been added to the queue. Otherwise, the request hasn't been added to the queue.

### Parameters

| Type      | Name   | Description                                                                                    |
|-----------|--------|------------------------------------------------------------------------------------------------|
| Queue     | WQueue | The Queue object for the OUT endpoint/write pipe that you want to write to.                    |
| FT_Buffer | Buffer | Data to queue as a write request.                                                              |
| bool      | Wait   | If True, this method won't return until the given FT_Buffer has been added to the write queue. |

|  |  |                                                |
|--|--|------------------------------------------------|
|  |  | If False, this method will return immediately. |
|--|--|------------------------------------------------|

## Return Values

| Type | Name   | Description                                       |
|------|--------|---------------------------------------------------|
| int  | Status | FT_OK if successful.<br>FT_BUSY if queue is full. |

## Example Code

|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |        |                                                                                                                                 |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------|---------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre>ReadBuffer = PyD3XX.FT_Buffer.from_int(0) ReadValue = 0 while True:     WriteBuffer = PyD3XX.FT_Buffer.from_int(ReadValue + 1)     Status = PyD3XX.Queue.WriteQueue(WriteQueue, WriteBuffer, True) # Send write request.     if(Status != PyD3XX.FT_OK):         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO WRITE TO QUEUE!")         exit()     Status = PyD3XX.Queue.GetWriteStatus(WriteQueue, True) # Get status of the oldest write request     if(Status != PyD3XX.FT_OK):         print(PyD3XX.FT_STATUS_STR[Status] + "   LAST WRITE REQUEST FAILED!")         exit()     print("Data Out = " + str(ReadValue + 1))     Status, ReadBuffer, BytesTransferred = PyD3XX.Queue.ReadQueue(ReadQueue, True)     if(Status != PyD3XX.FT_OK) and (Status != PyD3XX.FT_IO_INCOMPLETE) and (Status != PyD3XX.FT_IO_PENDING) and (Status != PyD3XX.FT_NO_MORE_ITEMS):         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO READ CHANNEL 1 PIPE!")         exit()     ReadValue = int.from_bytes(ReadBuffer.Value(), "little")     print("Data In = " + str(ReadValue))     if ReadValue &gt;= 3:         print("Reached value 3, ending streaming!")         break</pre> |        |                                                                                                                                 |
| State        | Success                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Output | Data Out = 1<br>Data In = 1<br>Data Out = 2<br>Data In = 2<br>Data Out = 3<br>Data In = 3<br>Reached value 3, ending streaming! |

## 4.7 – Queue.GetWriteStatus()

### Summary

Retrieves the result of the oldest write request in the Queue. When this function returns FT\_OK, the oldest write request has been removed.

Automatically destroys/invalidates the given write Queue object if its return code is NOT one of the below. read queue objects are ignored (not destroyed/invalidated).

FT\_OK, FT\_IO\_PENDING, FT\_IO\_INCOMPLETE, FT\_NO\_MORE\_ITEMS

FT\_AbortPipe() is automatically called if the write Queue object was destroyed/invalidated.

### Parameters

| Type  | Name   | Description                                                                                                                      |
|-------|--------|----------------------------------------------------------------------------------------------------------------------------------|
| Queue | WQueue | The Queue object for the OUT endpoint/write pipe that you want to write to.                                                      |
| bool  | Wait   | If True, this method won't return until the oldest write request has finished.<br>If False, this method will return immediately. |

### Return Values

| Type | Name   | Description                                                                                                                                                                                                                  |
|------|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| int  | Status | FT_OK if successful.<br>FT_IO_PENDING or FT_IO_INCOMPLETE if write request is not completed yet.<br>FT_NO_MORE_ITEMS if queue is empty & Wait was False.<br>FT_INVALID_PARAMETER if given Queue was a read queue or invalid. |

### Example Code



|              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |         |                                                                                                                                              |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Example Code | <pre> ReadBuffer = PyD3XX.FT_Buffer.from_int(0) ReadValue = 0 while True:     WriteBuffer = PyD3XX.FT_Buffer.from_int(ReadValue + 1)     Status = PyD3XX.Queue.WriteQueue(WriteQueue, WriteBuffer, True) # Send write request.     if(Status != PyD3XX.FT_OK):         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO WRITE TO QUEUE!")         exit()     Status = PyD3XX.Queue.GetWriteStatus(WriteQueue, True) # Get status of the oldest write request     if(Status != PyD3XX.FT_OK):         print(PyD3XX.FT_STATUS_STR[Status] + "   LAST WRITE REQUEST FAILED!")         exit()     print("Data Out = " + str(ReadValue + 1))     Status, ReadBuffer, BytesTransferred = PyD3XX.Queue.ReadQueue(ReadQueue, True)     if(Status != PyD3XX.FT_OK) and (Status != PyD3XX.FT_IO_INCOMPLETE) and (Status != PyD3XX.FT_IO_PENDING) and (Status != PyD3XX.FT_NO_MORE_ITEMS):         print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO READ CHANNEL 1 PIPE!")         exit()     ReadValue = int.from_bytes(ReadBuffer.Value(), "little")     print("Data In = " + str(ReadValue))     if ReadValue &gt;= 3:         print("Reached value 3, ending streaming!")         break </pre> |         |                                                                                                                                              |
| State        | <table border="1"> <tr> <td data-bbox="147 1205 475 1470">Success</td><td data-bbox="475 1205 1546 1470"> <div>Output</div> <pre> Data Out = 1 Data In = 1 Data Out = 2 Data In = 2 Data Out = 3 Data In = 3 Reached value 3, ending streaming! </pre> </td></tr> </table>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Success | <div>Output</div> <pre> Data Out = 1 Data In = 1 Data Out = 2 Data In = 2 Data Out = 3 Data In = 3 Reached value 3, ending streaming! </pre> |
| Success      | <div>Output</div> <pre> Data Out = 1 Data In = 1 Data Out = 2 Data In = 2 Data Out = 3 Data In = 3 Reached value 3, ending streaming! </pre>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |         |                                                                                                                                              |

## 4.8 – Queue.FreeQueueD3XX()

### Summary

Automatically destroys all queues and cleans up the QueueD3XX library. Only call on program exit before any FT\_Device handles have been closed.

### Parameters

None

### Return Values

| Type | Name   | Description          |
|------|--------|----------------------|
| int  | Status | FT_OK if successful. |

## Example Code

|              |                                                                                                                                                                                                                                                                                              |         |                                         |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|-----------------------------------------|
| Example Code | <pre>import PyD3XX import PyD3XX.Queue Status = PyD3XX.Queue.FreeQueueD3XX() # Automatically destroys all queues and cleans up. if(Status != PyD3XX.FT_OK):     print(PyD3XX.FT_STATUS_STR[Status] + "   FAILED TO FREE QueueD3XX!")     exit() print("Successfully freed QueueD3XX!")</pre> |         |                                         |
| State        | <table border="1"> <tr> <td data-bbox="151 600 479 703">Success</td><td data-bbox="479 600 1542 703">Output<br/>Successfully freed QueueD3XX!</td></tr> </table>                                                                                                                             | Success | Output<br>Successfully freed QueueD3XX! |
| Success      | Output<br>Successfully freed QueueD3XX!                                                                                                                                                                                                                                                      |         |                                         |

## Appendix A - Miscellaneous

This section goes over miscellaneous information.

### Linux D3XX Library Requirements

For many Linux distros, the average user does not have read/write access to FT60X devices that are plugged in. This will cause critical functions like FT\_Create() to fail and return FT\_IO\_ERROR if the user does not have admin privileges.

#### Library Requirement Option 1 (One-time setup, create a rules file)

You can create a .rules file which only needs to be setup once and never needs to be updated so that any user can run your script successfully without admin privileges.

1. With administrator privileges (sudo), create a file named "51-ftd3xx.rules" with the below contents and put it in the "/etc/udev/rules.d/" directory.

```
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="601e", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="601f", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="602a", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="602b", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="602c", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="602d", MODE="0666"
SUBSYSTEM=="usb", ATTRS{idVendor}=="0403", ATTRS{idProduct}=="602f", MODE="0666"
```

2. Run "sudo udevadm control --reload-rules" to load the .rules file immediately.
3. Your user will now have read/write access to FT60X devices and can run your Python scripts with PyD3XX normally.

#### Library Requirement Option 2 (Always run Python script as admin)

If your user is not in a virtual environment, they can just use sudo when calling Python with your script.

If your user is in a virtual environment, they can do the below to run a script with sudo.  
(YourVENV) username@YourSystem:YourDirectory\$ sudo -E env PATH="\$PATH" python ./YourScript.py

### PyD3XX Constants

```
NULL = ctypes.c_void_p(0)
```

```
# FT_Status values.
FT_OK = 0
FT_INVALID_HANDLE = 1
FT_DEVICE_NOT_FOUND = 2
FT_DEVICE_NOT_OPENED = 3
FT_IO_ERROR = 4
FT_INSUFFICIENT_RESOURCES = 5
FT_INVALID_PARAMETER = 6
FT_INVALID_BAUD_RATE = 7
FT_DEVICE_NOT_OPENED_FOR_ERASE = 8
FT_DEVICE_NOT_OPENED_FOR_WRITE = 9
FT_FAILED_TO_WRITE_DEVICE = 10
FT_EEPROM_READ_FAILED = 11
FT_EEPROM_WRITE_FAILED = 12
FT_EEPROM_ERASE_FAILED = 13
FT_EEPROM_NOT_PRESENT = 14
FT_EEPROM_NOT_PROGRAMMED = 15
FT_INVALID_ARGS = 16
FT_NOT_SUPPORTED = 17
FT_NO_MORE_ITEMS = 18
FT_TIMEOUT = 19
FT_OPERATION_ABORTED = 20
FT_RESERVED_PIPE = 21
FT_INVALID_CONTROL_REQUEST_DIRECTION = 22
FT_INVALID_CONTROL_REQUEST_TYPE = 23
FT_IO_PENDING = 24
FT_IO_INCOMPLETE = 25
FT_HANDLE_EOF = 26
FT_BUSY = 27
FT_NO_SYSTEM_RESOURCES = 28
FT_DEVICE_LIST_NOT_READY = 29
FT_DEVICE_NOT_CONNECTED = 30
FT_INCORRECT_DEVICE_PATH = 31
FT_OTHER_ERROR = 32

# Describe dictionaries for easier error code conversion.
FT_STATUS_STR = {
    FT_OK: "FT_OK",
    FT_INVALID_HANDLE: "FT_INVALID_HANDLE",
    FT_DEVICE_NOT_FOUND: "FT_DEVICE_NOT_FOUND",
    FT_DEVICE_NOT_OPENED: "FT_DEVICE_NOT_OPENED",
    FT_IO_ERROR: "FT_IO_ERROR",
```

```
FT_INSUFFICIENT_RESOURCES: "FT_INSUFFICIENT_RESOURCES",
FT_INVALID_PARAMETER: "FT_INVALID_PARAMETER",
FT_INVALID_BAUD_RATE: "FT_INVALID_BAUD_RATE",
FT_DEVICE_NOT_OPENED_FOR_ERASE: "FT_DEVICE_NOT_OPENED_FOR_ERASE",
FT_DEVICE_NOT_OPENED_FOR_WRITE: "FT_DEVICE_NOT_OPENED_FOR_WRITE",
FT_FAILED_TO_WRITE_DEVICE: "FT_FAILED_TO_WRITE_DEVICE",
FT_EEPROM_READ_FAILED: "FT_EEPROM_READ_FAILED",
FT_EEPROM_WRITE_FAILED: "FT_EEPROM_WRITE_FAILED",
FT_EEPROM_ERASE_FAILED: "FT_EEPROM_ERASE_FAILED",
FT_EEPROM_NOT_PRESENT: "FT_EEPROM_NOT_PRESENT",
FT_EEPROM_NOT_PROGRAMMED: "FT_EEPROM_NOT_PROGRAMMED",
FT_INVALID_ARGS: "FT_INVALID_ARGS",
FT_NOT_SUPPORTED: "FT_NOT_SUPPORTED",
FT_NO_MORE_ITEMS: "FT_NO_MORE_ITEMS",
FT_TIMEOUT: "FT_TIMEOUT",
FT_OPERATION_ABORTED: "FT_OPERATION_ABORTED",
FT_RESERVED_PIPE: "FT_RESERVED_PIPE",
FT_INVALID_CONTROL_REQUEST_DIRECTION: "FT_INVALID_CONTROL_REQUEST_DIRECTION",
FT_INVALID_CONTROL_REQUEST_TYPE: "FT_INVALID_CONTROL_REQUEST_TYPE",
FT_IO_PENDING: "FT_IO_PENDING",
FT_IO_INCOMPLETE: "FT_IO_INCOMPLETE",
FT_HANDLE_EOF: "FT_HANDLE_EOF",
FT_BUSY: "FT_BUSY",
FT_NO_SYSTEM_RESOURCES: "FT_NO_SYSTEM_RESOURCES",
FT_DEVICE_LIST_NOT_READY: "FT_DEVICE_LIST_NOT_READY",
FT_DEVICE_NOT_CONNECTED: "FT_DEVICE_NOT_CONNECTED",
FT_INCORRECT_DEVICE_PATH: "FT_INCORRECT_DEVICE_PATH",
FT_OTHER_ERROR: "FT_OTHER_ERROR"
}

#^ FT_STATUS_STR[FT_OTHER_ERROR] == FT_STATUS_STR[32] == "FT_OTHER_ERROR"
FT_STATUS = {v: k for k, v in FT_STATUS_STR.items()}
#^ FT_STATUS["FT_OTHER_ERROR"] == FT_OTHER_ERROR == 32

FT_DEVICE_UNKNOWN = 3
FT_DEVICE_600 = 600
FT_DEVICE_601 = 601
FT_FLAGS_OPENED = 1
FT_FLAGS_HISPEED = 2
FT_FLAGS_SUPERSPEED = 4
FTPipeTypeControl = 0
FTPipeTypeIsochronous = 1
FTPipeTypeBulk = 2
FTPipeTypeInterrupt = 3
```

```
FT_LIST_NUMBER_ONLY = int("0x80000000", 16)
FT_LIST_BY_INDEX = int("0x40000000", 16)
FT_LIST_ALL = int("0x20000000", 16)
FT_OPEN_BY_SERIAL_NUMBER = int("0x00000001", 16)
FT_OPEN_BY_DESCRIPTION = int("0x00000002", 16)
FT_OPEN_BY_LOCATION = int("0x00000004", 16)
FT_OPEN_BY_GUID = int("0x00000008", 16)
FT_OPEN_BY_INDEX = int("0x00000010", 16)
FT_GPIO_DIRECTION_IN = 0
FT_GPIO_DIRECTION_OUT = 1
FT_GPIO_VALUE_LOW = 0
FT_GPIO_VALUE_HIGH = 1
FT_GPIO_0 = 0
FT_GPIO_1 = 1
E_FT_NOTIFICATION_CALLBACK_TYPE_DATA = 0
E_FT_NOTIFICATION_CALLBACK_TYPE_GPIO = 1
E_FT_NOTIFICATION_CALLBACK_TYPE_INTERRUPT = 2
CONFIGURATION_OPTIONAL_FEATURE_DISABLEALL = 0
CONFIGURATION_OPTIONAL_FEATURE_ENABLEBATTERYCHARGING = int("0x001", 16)
CONFIGURATION_OPTIONAL_FEATURE_DISABLECANCELSESSIONUNDERRUN = int("0x002", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCH1 = int("0x004", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCH2 = int("0x008", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCH3 = int("0x010", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCH4 = int("0x020", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLENOTIFICATIONMESSAGE_INCHALL = int("0x03C", 16)
CONFIGURATION_OPTIONAL_FEATURE_DISABLEUNDERRUN_INCH1 = int("0x040", 16)
CONFIGURATION_OPTIONAL_FEATURE_DISABLEUNDERRUN_INCH2 = int("0x080", 16)
CONFIGURATION_OPTIONAL_FEATURE_DISABLEUNDERRUN_INCH3 = int("0x100", 16)
CONFIGURATION_OPTIONAL_FEATURE_DISABLEUNDERRUN_INCH4 = int("0x200", 16)
CONFIGURATION_OPTIONAL_FEATURE_SUPPORT_ENABLE_FIFO_IN_SUSPEND = int("0x400", 16)
# available in RevB parts only
CONFIGURATION_OPTIONAL_FEATURE_SUPPORT_DISABLE_CHIP_POWERDOWN = int("0x800", 16)
# available in RevB parts only
CONFIGURATION_OPTIONAL_FEATURE_DISABLEUNDERRUN_INCHALL = int("0x3C0", 16)
CONFIGURATION_OPTIONAL_FEATURE_ENABLEALL = int("0xFFFF", 16)

FT_DEVICE_DESCRIPTOR_TYPE = int("0x01", 16)
FT_CONFIGURATION_DESCRIPTOR_TYPE = int("0x02", 16)
FT_STRING_DESCRIPTOR_TYPE = int("0x03", 16)
FT_INTERFACE_DESCRIPTOR_TYPE = int("0x04", 16)
FT_ENDPOINT_DESCRIPTOR_TYPE = int("0x05", 16) # THIS IS PYTHON API SPECIFIC.

FT_PIPE_DIR_IN = 0
```

```
FT_PIPE_DIR_OUT = 1
FT_PIPE_DIR_COUNT = 2
```

## Document References

D3XX Programmer's Guide (AN\_379): [Application Notes - FTDI](#)  
FT600Q-FT601Q SuperSpeed USB3.0 IC Datasheet: [USB IC Data Sheets - FTDI](#)

## Appendix B - Version History

This section goes over version history of this document and PyD3XX.

| Version | Date                             | Changes                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.0.0   | February 5 <sup>th</sup> , 2025  | Initial release.                                                                                                                                                                                                                                                                                                                                                                                                |
| 1.0.1   | February 10 <sup>th</sup> , 2025 | Updated sections 2.7 & 2.8; parameters table and example code were modified to reflect Linux operation.<br>Added paragraph at start of section 2 that goes over possible Platform string values.                                                                                                                                                                                                                |
| 1.0.2   | February 12 <sup>th</sup> , 2025 | Updated Table 1.1.0 to reflect there's no WinUSB dynamic library for 32-bit systems.<br>Added Table B.0.1 to track PyD3XX version history.<br>Fixed some table formatting and alignment.                                                                                                                                                                                                                        |
| 1.0.4   | April 8 <sup>th</sup> , 2025     | PyD3XX Programmer's Guide document will now be released synchronously with PyD3XX updates and share the same version number.<br>Section 1 was updated to reflect new driver library files packaged with PyD3XX.<br>Sections 2.8, 2.10, 2.10B: Fixed descriptions where write was used when read was meant.<br>Section 2.9B, 2.10B: Updated examples and descriptions to indicate overlapped object is required. |
| 1.0.5   | April 8 <sup>th</sup> , 2025     | No major change to document. PyD3XX was updated.                                                                                                                                                                                                                                                                                                                                                                |
| 1.0.6   | May 7 <sup>th</sup> , 2025       | Sections 2.38 & 2.39: Updated description for Device parameter to match function behavior.<br>Section 2.14: Added note about StreamSize limitation for the WinUSB drivers. Updated example code + output.                                                                                                                                                                                                       |
| 1.0.7   | July 30 <sup>th</sup> , 2025     | Table 1.2.0: Added pipe index column and renamed index column to FIFO index column.<br>Section 2.14: Clarified StreamSize note and mentioned Full Speed.<br>Section 3.2: Added note about Full Speed for the Flags attribute.                                                                                                                                                                                   |
| 1.0.8   | August 21 <sup>st</sup> , 2025   | Table 1.1.0: Updated D3XX WinUSB driver versions to 1.4.0.1.                                                                                                                                                                                                                                                                                                                                                    |
| 1.0.9   | November 3 <sup>rd</sup> , 2025  | No major change to document. PyD3XX was updated.                                                                                                                                                                                                                                                                                                                                                                |
| 1.1.0   | March 25 <sup>th</sup> , 2026    | Table 1.1.0: Updated D3XX driver versions & files.<br>Section 2.7: Fixed endpoint values mentioned in Parameters table.<br>Section 2.8: Fixed endpoint values mentioned in Parameters table.<br>Section 3.4: Updated description of MaxPower.<br>Added sections for FT_PipeTransferConf, FT_TransferConf, FT_SetTransferParams() & FT_GetTransferParams().<br>Added Section 4 for the new Queue submodule.      |
| 1.1.1   | April 7 <sup>th</sup> , 2026     | Section 4.3: Updated return values for CreateQueue().                                                                                                                                                                                                                                                                                                                                                           |

|       |                               |                                                                                                                                                                                                                              |
|-------|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.1.2 | April 27 <sup>th</sup> , 2026 | Table 1.1.0: Updated Linux & macOS D3XX library versions to 1.1.6.<br>Section 1: Added reference to Linux D3XX Library Requirements in Appendix A.<br>Updated Appendix A to include Linux install information.               |
| 1.1.3 | May 15 <sup>th</sup> , 2026   | Table 1.1.0: Removed macOS x86 entry as it was never valid. PyD3XX has not been modified to remove said library assignment.<br>Section 4: Updated warning to include macOS as extra precaution.                              |
| 1.1.4 | May 29 <sup>th</sup> , 2026   | Table 1.1.0: Updated Linux & macOS D3XX library versions to 1.1.7.<br>Section 4: Changed warning for macOS & Linux. Underlying library URB servicing issue was resolved.<br>Section 4.7: Updated Wait parameter description. |
| 1.1.5 | July 22 <sup>nd</sup> , 2026  | Table 1.1.0: Updated Linux & macOS D3XX library versions to 1.1.8.<br>Section 3.2: Updated table to include ID field which always existed but not previously documented.<br>Added section for FT_SetVIDPID().                |

**Table B.0.0 – Document History**

| Version | Date                             | Changes                                                                                                                                                                                                                                                                                       |
|---------|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.0.0   | July 16 <sup>th</sup> , 2024     | Initial release.                                                                                                                                                                                                                                                                              |
| 1.0.1   | July 16 <sup>th</sup> , 2024     | Initial release.                                                                                                                                                                                                                                                                              |
| 1.0.2   | February 10 <sup>th</sup> , 2025 | Fixed bugs on macOS & Linux.<br>Added GetDriverVersion() & GetLibraryVersion() functions.<br>Added FT_ResetDevicePort() function.                                                                                                                                                             |
| 1.0.3   | February 12 <sup>th</sup> , 2025 | PyD3XX no longer loads the WinUSB dynamic library file for 32-bit systems as it is only for 64-bit systems.<br>PyD3XX will now prioritize using the D3XX dynamic library over the WinUSB dynamic library if both drivers are installed.                                                       |
| 1.0.4   | April 8 <sup>th</sup> , 2025     | PyD3XX now prioritizes loading the WinUSB dynamic libraries from FTDI for Windows for all architectures.<br>D3XX library files packaged with PyD3XX have been updated.<br>PyD3XX now uses windll “stdcall” calling convention for Windows systems instead of cdll “cdecl” calling convention. |
| 1.0.5   | April 8 <sup>th</sup> , 2025     | Fixed bug on Linux & macOS with functions like FT_GetDeviceInfoList() not working correctly due to byte-misalignment by changing size of unsigned long and DWORD to match Windows.                                                                                                            |
| 1.0.6   | May 7 <sup>th</sup> , 2025       | Fixed byte misalignment issue when getting MaximumPacketSize in FT_GetPipeInformation().<br>Added major error message to FT_SetStreamPipe() that's triggered when an invalid stream size is set.                                                                                              |
| 1.0.7   | July 30 <sup>th</sup> , 2025     | Fixed allocated buffer size of pipe information struct in FT_GetPipeInformation().                                                                                                                                                                                                            |
| 1.0.8   | August 21 <sup>st</sup> , 2025   | Updated PyD3XX to not use local encoding when checking for drivers on start-up.<br>Updated Windows WinUSB D3XX library files to version 1.4.0.1.                                                                                                                                              |
| 1.0.9   | November 3 <sup>rd</sup> , 2025  | Adjusted FT_Device to fix segmentation fault on program exit for Linux ARM systems.                                                                                                                                                                                                           |

|       |                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.1.0 | March 25 <sup>th</sup> , 2026 | Updated applicable Linux & macOS library files to D3XX 1.1.5.<br>Added FT_PipeTransferConf & FT_TransferConf classes.<br>Added FT_SetTransferParams & FT_GetTransferParams().<br>Added Queue submodule that implements an alternative way to do multithreaded streaming.<br>Now use one singular multi-architecture D3XX library file for macOS x64 & ARM64.<br>Updated SIZE_CONFIGURATION_DESCRIPTOR to account for byte alignment.<br>Updated FT_GetVIDPID() to no longer use FT_GetDeviceDescriptor() workaround for Linux & macOS. |
| 1.1.1 | April 7 <sup>th</sup> , 2026  | Corrected Python type hints throughout library.<br>Updated CreateQueue() to always return tuple[int, Queue] even on error.                                                                                                                                                                                                                                                                                                                                                                                                             |
| 1.1.2 | April 27 <sup>th</sup> , 2026 | Updated Linux & macOS D3XX library versions to 1.1.6.<br>Updated error message of FT_SetTransferParams().                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 1.1.3 | May 15 <sup>th</sup> , 2026   | Added FTDI license to package to better conform to FTDI library distribution terms. Package code is still MIT & distributed libraries are still under separate FTDI license.<br>No functional changes made to library.                                                                                                                                                                                                                                                                                                                 |
| 1.1.4 | May 29 <sup>th</sup> , 2026   | Updated Linux & macOS D3XX library versions to 1.1.7.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 1.1.5 | July 22 <sup>nd</sup> , 2026  | Updated Linux & macOS D3XX library versions to 1.1.8.<br>Added FT_SetVIDPID().                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

**Table B.0.1 – PyD3XX History**