Setting	Description
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode ( <b>P</b> , <b>S</b> , <b>A</b> , or <b>M</b> ) selected.  • ★ (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness. A icondisplayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken.  • ★ (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released.  • ★ (SLOW SYNC.): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.
4 Sync	Choose whether the flash is timed to fire immediately after the shutter opens (#6/11/15T CURTAIN) or immediately before it closes (#6/12/2ND CURTAIN). 1ST CURTAIN is recommended in most circumstances.