Appendix Data-driven Mutation Testing: LuxSpace ADCS Case Study

This Appendix describe the procedures adopted to execute data-driven mutation testing on the LuxSpace ADCS case study system. Section 1 provide a detailed overview of the case study and the function targeted by data-driven mutation testing. Section 2 describes the fault models defined for the case study. Section 3 describes the integration of mutation probes into ADCS IF SW.

1. Overview of the case study

Data-driven mutation testing is applied to assess the quality of the test cases that exercise the ADCS software interface of the ESAIL system (hereafter, ADCS_IF_SW). In ESAIL, the ADCS_IF_SW is used to manage and collect data from hardware devices (e.g., sensors). Detailed specifications for the ADCS interface appear in the document *ESAIL-LXS-ICD-P-0184 ADCS IF SW External ICD*.




Figure 1: OBC-ADCS integration in ESAIL

Figure 1 provides an overview of the integration between ESAIL OBC and the ADCS board. ESAIL CSW (central software) runs on an onboard controller (OBC) with a Leon 3 microprocessor. The OBC is connected to ADCS interface boards (ADCS_IF_BOARD) through RS-422. The ADCS_IF_BOARD runs its own controller (ADCS_IF_SW). Each board processes data received from sensors and controls actuators. The ADCS_IF_SW is the

target of data-driven mutation testing and is the software layer where mutation probes are installed.

The ADCS_IF_SW implements functions used by the OBC to send data to devices (i.e., set their configuration) and functions that send devices data to the OBC.

The function of the ADCS_IF_SW that manages the communication between the ADCS and the OBC, i.e., *ObcRecvBlockCb*. The function is implemented in file *AdcsIf.c*.

The SVF simulator used for testing runs the OBC software but it simulates the behaviour of the ADCS_IF_SW. The ADCS_IF_SW is not executed inside the SVF but only simulated. The ESAIL system test suite contains test cases that exercise the integration between OBC and the ADCS_IF_SW but the ADCS_IF_SW is not actually run. The test suite that exercises the ADCS_IF_SW is one that should execute with hardware in the loop.

Since the functions that send data to the devices are tested with hardware in the loop, in the context of FAQAS, we will apply data-driven mutation testing only to verify the functions used by the ADCS to send data to the OBC.

Although in principle also messages from the OBC to the ADCS_IF_SW could be tested, the current test suite, which does not run the ADCS_IF_SW prevents it. Indeed, the simulator used in the current test suite makes assumptions about the messages received thus it would be very easy to break it by altering its input messages. To alter the messages sent from OBC to ADCS_IF_SW it would be necessary to (1) use a simulator that actually runs the ADCS_IF_SW or (2) target the test cases that include hardware in the loop.

Case (2) above, i.e., testing with hardware in the loop, is technically feasible because it is just a matter of deploying on the hardware a modified software that performs the mutation. However mutated packets may break some of the assumptions made when developing the software and thus break the hardware (e.g., altering the voltage of the board). For every mutation to be performed it might be necessary to ensure that the hardware is not going to be damaged. Such type of testing might thus be out of the budget for the current project and may require a dedicated project by itself.

The implementation of function *ObcRecvBlockCb* is shown in Section 1.1. It mainly consists of a switch command (line 138) that generates a response for the OBC after invoking a *data* generation method selected according to the request received on the data link. For example, Line 146 invokes method *GetIfStatus*, which prepares a response packet containing the information about the ADCS status.

Each data generation method receive as input an object of type std::vector (i.e., the object newBlock) that will be used to store the data to be sent to the OBC. The vector newBlock acts as a buffer; it contains elements of type UInt8, the length of the vector matches the size of the response message indicated in ESAIL-LXS-ICD-P-0184 (one element per byte). Table 1 reports, for each feature targeted by data-driven mutation testing, the page in ESAIL-LXS-ICD-P-0184 that describes the data format, the ADCS_IF_SW function that fill the content of message, and the size of the response message (i.e., the length of std::vector).

ADCS Feature	Page	ADCS_IF_SW function	Message size (bytes)
ADCS IF Status	19	GetIfStatus	6
ADCS IF HK	22	GetIfHk	37
GYTM - Gyroscope TM	34	GetGyroTm	21
MMTX - Magnetometer TX	41	GetMgtmTm	2
Sun Sensor TM	42	GetSsTm	48
SSTP - Sun Sensor Temperature	45	GetSsTemp	12
Reaction Wheel TX	50	GetRwTm	2
SpaceCraft HK	60	GetIfScHk	18
Magnetorquer Set PWM RSP	57	GetMgtqTm	39

Each invocation of a *data generation method* generates a response (i.e., the vector *newBlock*) that may either contain the desired result or an error code. The response generated in the first case is referred to as *nominal response message*, the response generated in the second case is an *error response message*. The reponse message is sent to the OBC through the invocation of function SendResponse (Lines 298 and 312). When an error code is generated, the data generation method returns *CR_Failure*. The response code is read by function *ObcRecvBlockCb* to determine if it is necessary to trim the buffer before sending back to OBC; this behaviour is handled by the parameter *true* passed to SendResponse (Line 312).

1.1 Function ObcRecvBlockCb

```
89 // -- OPENING ELEMENT--AdcsIf:: ObcRecvBlockCb-
 90 /// Function that is called when a block of data is received from the data link layer.
 91 /// @param block The received data block.
92 void AdcsIf::ObcRecvBlockCb(const std::vector<Smp::UInt8>& block)
        // MARKER: OPERATION BODY: START
        Trace(4, "Received command: 0x%s", OhbCommon::ByteUtils::BinToHex(block));
96
97
        if(!CheckRxEnabled())
98
99
            return;
       }
100
101
102
       std::vector<Smp::UInt8> newBlock(block);
104
       Smp::UInt8 cmdId = block[0]:
105
       Smp::UInt8 subcmdId = block[1]:
107
       && (forcedResponseSubcmdId == subcmdId || forcedResponseSubcmdId < 0))
108
109
110
            newBlock.resize(2);
112
            if(forcedResponseErrorCode >= 0)
113
            {
                // Generate forced error response
115
                Trace(2, "Generating forced response message with error code 0x%02X", forcedResponseErrorCode);
116
                newBlock.push back(forcedResponseErrorCode);
                SendResponse(newBlock, true);
117
            else
120
                // Generate forced valid response
121
               Trace(2, "Generating forced response message with data 0x%s", forcedResponseData.c_str()); for(unsigned int i = 0; i < forcedResponseData.length(); i += 2)
123
124
                    std::string byteString = forcedResponseData.substr(i, 2);
```

```
126
127
                       newBlock.push_back(strtol(byteString.c_str(), NULL, 16));
128
129
                  SendResponse(newBlock, false);
             }
             return;
131
132
       }
       bool processed = true;
CommandResult cr = CR_Failure;
134
135
        if(Status->ADRD || ((cmdId == 1) && (subcmdId < 3)))</pre>
137
138
              switch(cmdId)
           case 1:
{
140
141
                  switch(subcmdId)
143
144
                 case 0:
                  cr = GetIfStatus(newBlock);
}
146
147
                  break:
                  case 1:
{
    cr = GetIfHk(newBlock);
}
149
150
152
153
                  break:
                  case 2:
{
    cr = SetIfPower(newBlock);
155
156
                  break;
158
159
                  case 3:
                  cr = SetUnitStatus(newBlock);
}
161
162
                  break;
                  case 4:
{
    cr = SetConfiguration(newBlock);
}
164
165
167
168
                  case 5:
{
    cr = LclRetrigger(newBlock);
170
                  break;
```

```
174
                default:
175
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
176
177
            }
178
179
            break;
            case 4:
180
181
182
                switch(subcmdId)
183
                {
184
               case 0:
185
               {
186
                    cr = GetGyroTm(newBlock);
187
188
                break;
189
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
190
191
                    processed = false;
192
193
            }
194
            break;
195
            case 5:
            {
196
197
                switch(subcmdId)
198
               {
199
                case 0:
200
               {
201
                   cr = GetMgtmTm(newBlock);
202
203
                break;
204
                default:
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
205
206
                    processed = false;
207
            }
208
209
            break;
210
            case 6:
211
212
                switch(subcmdId)
213
                {
214
                case 0:
215
216
                    cr = GetSsTm(newBlock);
217
218
               break;
219
               case 1:
220
                    cr = GetSsTemp(newBlock);
221
222
223
               break;
```

```
224
                default:
225
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
226
                    processed = false;
227
228
            }
229
            break;
230
            case 7:
231
232
                switch(subcmdId)
233
                {
234
                case 0:
235
                {
                    cr = GetRwTm(newBlock);
236
                }
237
                break;
238
239
                default:
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
240
241
                    processed = false;
242
243
            }
244
            break;
245
            case 8:
246
            {
247
                switch(subcmdId)
248
                {
                case 0:
249
250
                {
251
                    cr = SetMgtqPwm(newBlock);
252
                    if(cr == CR_Success)
253
254
                        if(newBlock[2] == 0x55)
255
256
                             // Bypass Magnetometer response
257
                            newBlock.resize(2);
258
                            cr = GetMgtqTm(newBlock);
259
                        }
260
                        else
261
                        {
                            cr = BuildMgtmDataRequestCmd(newBlock);
262
                            cr = GetMgtmTm(newBlock);
263
264
265
                    }
266
                }
267
                break;
268
                default:
269
                    Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
270
                    processed = false;
271
                }
            }
272
```

```
case 9:
274
275
276
                switch(subcmdId)
277
                {
278
                case 0:
279
               {
280
                    cr = GetIfScHk(newBlock);
281
282
               break;
                default:
283
                   Log(Smp::Services::LMK_Warning, "Sub-command %u not implemented", subcmdId);
284
285
                    processed = false;
286
287
           }
288
           break;
289
           default:
               Log(Smp::Services::LMK_Warning, "Command %u not implemented", cmdId);
290
291
                processed = false;
292
293
       }
       switch(cr)
294
295
296
       case CR_Success:
297
298
            SendResponse(newBlock, false);
299
300
       break;
       case CR_InProgress:
301
302
            Trace(5, "Operation in progress");
303
304
305
       break;
306
       case CR_Failure:
307
308
            if(!processed)
309
            {
310
                newBlock.push_back(0x56);
311
           SendResponse(newBlock, true);
312
       }
313
314
       break;
315
       default:
            Log(Smp::Services::LMK_Error, "Command result %u not supported", cr);
316
317
       // MARKER: OPERATION BODY: END
318
319 }
320 // --CLOSING ELEMENT--AdcsIf::ObcRecvBlockCb--
```

2. Fault Model

In the case of ADCS_IF_SW we have defined a total of 18 fault models, two for each feature listed in Table 1. For each feature, one fault model captures the fault that might affect a nominal response message, one fault model captures the faults that might affect an error response message. In our experiments, however, we considered only the fault features known to be exercised by the SVF test suite, which are:

- IfStatus
- IfHK
- GYTM
- GYTMFailure
- SunSensorTM
- SunSensorTMFailure
- SSTP
- SSTPFailure
- SpaceCraftHK
- MagnetorquerSetPWMRSP

In the following sections we describe the fault models by providing for each byte of the response message (column *Byte*), the relevant bits (column *Bit*), a description of the information that is supposed to be transmitted by the byte (column *Description*), the type of data written on the byte (column *Type*), the fault classes that might affect the byte (column *Fault class*). We do not report the span of the item since it can be deducted from the table; indeed, descriptions that span over multiple rows correspond to data types that, to be loaded, require the readin of multiple data items. Concerning data types, the type DOUBLE is used for data items that internally to ESAIL are represented using the type Smp::Float64. On the channel, Smp:Float64 is transmitted as <*PTC*=3, *PCF*=6> Unsigned Integer 10bits, which in the code is represented with Smp::Int16.

For each fault class, we indicate the value of the parameters required to configure the corresponding mutation operator (see Table 2.1 of D2). We use the keyword @MIB to indicate that the parameter value should be derived from the MIB database for ESAIL, more precisely from the file OCP.dat. In the database, the min and max range value for the nominal cases are reported. For example, Figure 2 shows a portion of the OBC.dat from which we can determine that MIN and the MAX values for AIFN031U are 3 and 3.6, respectively. The delta (i.e., parameter D) is coincides with the lowest positive number that can be represented with the number of decimals appearing in the rage (e.g., 0.1 for AIFN031U and 0.01for AIFN031U). for For some of the data items in the table we report also the corresponding identifier in OBC.dat. Missing identifiers will be reported in the coming months while refining the approach; indeed, decisions on the data items to be addressed by the approach may change after the first preliminary tests.

AIFN030U	1	Н	24	33.53	AAA_OL80	1
AIFN031U	1	Н	3	3.6	AAA_OL80	1
AIFN032U	1	Н	3	3.6	AAA_OL80	1
		Figure	2: Portion of O	BC.dat		

In column Fault class, the label NONE indicates that we are not interested into performing data-driven mutation testing for that specific byte. In general, we do not target with data-driven mutation those data items that do not concern features covered by the test suite. These are typically data items that do not cause a crash of the on board software or data items used only for self-testing of the board.

Columns Byte, Bit, and Description match the columns of corresponding tables in *ESAIL-LXS-ICD-P-0184*.

2.1 ADCS IF Status

Byte	Bit	Description	Type	Fault class
1	20	Reset Source Provides information about last reset. The bit is cleared after the first read of the status 0 = No reset 1 = Power-on Reset 2 = External Reset (released by JTAG adapter) 3 = Watchdog Reset 4 = Brown-out Reset 5 = JTAG AVR Reset (logic reset by JTAG) 6 = Not used 7 = Not used ADCS IF ready This bit is set when ADCS is ready to read/write to units. In the boot of the ADCS IF shall be a time to initialize all modules and units. After initialization of the ADCS IF, modules and units, shall go to a ready state. While ADCS IF is not ready, the available commands are: • ASST • ASHK • ASCT	BIN	BF(MIN=3;MAX=3) BF(MIN=4;MAX=4) BF(MIN=5;MAX=7)
	4	OBC communication error This bit is set if a communication error between OBC and ADCS IF occurred in the last command. The bit is cleared after the first reading of the status 0 = No error 1 = Communication error		
	75	Unit communication error This bit is set if a communication error between ADCS IF and ADCS unit occurred. The bit is cleared after the first read of the status 0 = No error 1 = Communication error		
2	70	Unit in error Provides a list of units in error. 0 = No error 1 = Unit error Each bit is assigned to one unit: Bit 0 = Gyroscope unit Bit 1 = Reaction Wheel	BIN	BF(MIN=0;MAX=4)

		Bit 2 = Magnetorquer Bit 3 = Magnetometer Bit 4 = Sun Sensor		
3	70	Watchdog Reset Counter Watchdog Reset counter value. Increment in every watchdog reset. Value is stored in non-volatile memory To clear watchdog reset counter, shall be used the ASCF command.	INT	None: ESAIL OBC does not deal with anomalous values of reset counters. Thus we do not expect ESAIL test suite to fail in case of a high reset counter
4	70	Overall Reset Counter Overall reset counter value. Increment in every device reset. Value is stored in non-volatile memory To clear overall reset counter, shall be used the ASCF command.	INT	None: same as above.
	10	Gyroscope enable Enable/Disable status of nominal or redundant bus transceiver. 0 = Disabled both transceivers 1 = Enabled nominal transceiver only 2 = Enabled redundant transceiver only 3 = not existing (reserved for future needs)	BIN	BF(MIN=0;MAX=2) BF(MIN=2;MAX=4) BF(MIN=5;MAX=7)
5	42	Reaction Wheel enable Enabled/Disabled status of bus transceiver. 0 = Disabled transceiver 1 = Enabled transceiver 72 = not existing (reserved for future needs)		
	75	3 axis Magnetorquer enable General Enable/Disable status of the Magnetorquer Driver for all three axis. 0 = Disabled 1 = Enabled Bit assignement: Bit 0 = Enabled/Disabled Driver Bit 1 = 0 not used (reserved for future needs) Bit 2 = 0 not used (reserved for future needs)		
	10	Magnetometer enable Enable/Disable status of nominal or redundant bus transceiver. 0 = Disabled both transceivers 1 = Enabled nominal transceiver only 2 = Enabled redundant transceiver only 3 = not existing (reserved for future needs)	BIN	BF(MIN=0;MAX= 1) BF(MIN=2;MAX= 7)
6	72	Sun Sensor board ADC enable Enabled/Disabled Sun Sensor board ADC, see Note 3) 0 = Disabled 1 = Enabled Each bit is assigned to one ADC: Bit 0 = Enabled/Disabled ADC2		

Bit 1 = Enabled/Disabled ADC3	
Bit 2 = Enabled/Disabled ADC4	
Bit 3 = Enabled/Disabled ADC5	
Bit 4 = Enabled/Disabled ADC6	
Bit 5 = Enabled/Disabled ADC7	

2.2 ASHK - ADCS IF HK

Byte	Bit	Description	Type	Fault class
1	70	VCC1N		NONE
2	70	OBC Nominal transceiver circuit voltage		
3	70	VCC1R		NONE
4	70	OBC Redundant transceiver circuit voltage		NONE
5	70	VCC2		NONE
6	70	Gyroscope transceiver/UART circuit voltage		NONE
7	70	VCC3		NONE
8	70	Magnetometer transceiver/UART circuit voltage		NONE
9	70	VCC4		NONE
10	70	Reaction Wheel transceiver/UART circuit voltage		NONE
11	70	VCCa		NONE
12	70	Internal power supply (5.5V), measured with ADC0		NONE
13	70	VCCb		
14	70	Internal power supply (5.5V), measured with ADC1	DOUBLE	VAT(T=3.6;D=0.1)
ļ .	70	VBUS	DOLIDI E	ID: AIFN031U VAT(T= 33.53;D=0.01)
		Unit input bus voltage	DOUBLE	VAT(1= 33.53;D=0.01) VBT(T=24;D=1)
		Ont input ous voltage		OBSW336U
15	70			
				ID: AIFN030U (24-33.53)
				ASHK_VBUS - Unit In Bus Volt
16	70			
17	70	VCC5		NONE
18	70	Supply voltage for ADC2, ADC3, ADC4 and VCCB1. Sun-sensor PCB		NONE
19	70	VCC6		NONE
20	70	Supply voltage for ADC5, ADC6, ADC7 and VCCB2. Sun-sensor PCB		NONE
21	70	VCC5_IN		NONE
		LDO input voltage for ADC2, ADC3, ADC4 and		NONE
22	70	VCCB1. Sun-sensor PCB		NONE
23	70	VCC6_IN		NONE
		LDO input voltage for ADC5, ADC6, ADC7 and		NONE
24	70	VCCB2. Sun-sensor PCB		THE THE
				VAT(T=6;D=1)
		VCC_SW1		
25	70	SSB internal switched power supply, measured by		ID: AIFN035U (5-6)
		ADC3		ASHK_VCC_SW1 - SSB Sup
				Volt 1

26	70	Remark: the voltage VCC_SW is measured 2 times with two different ADC. This allows to compare the results and conclude for a drift in the ADC's.		
27	70	VCC_SW2 SSB internal switched power supply, measured by ADC6		NONE
28	70	Remark: the voltage VCC_SW is measured 2 times with two different ADC. This allows to compare the results and conclude for a drift in the ADC's.		NONE
29	70		DOUBLE	VOR(MIN=-20; MAX=50;D=1)
30	70	T_PCB_TEMP1 Main Board PCB Temperature, sensor 1 Temperature of VCC DC/DC regulator. Remark: 1/2 is measured on the same place, it's to compare the values to discover a measurement failure		AIFR037T? ID: AIFN037T (-20-50) ASHK_TMP1 - Main Brd Temp 1
31	70	T_PCB_TEMP2		
32	70	Main Board PCB Temperature, sensor 2 Temperature of VCC DC/DC regulator. Remark: 1/2 is measured on the same place, it's to compare the values to discover a measurement failure	DOUBLE	VOR(MIN=-20; MAX=50;D=1)AIFR038T? ID: AIFN038T (-20-50) ASHK_TMP2 - Main Brd Temp 2
			DOUBLE	VOR(MIN=-20; MAX=50;D=1)
33	70		DOUBLE	VOR(MIN20, MAX-30,D-1)
34	70	T_PCB_TEMP3a Sun Sensor Board PCB Temperature, sensor 3a. Temperature of VCC5 LDO regulator. Remark: 3a/b is measured on the same place, it's to compare the values to discover a measurement failure	DOUBLE	AIFR039T ID: AIFN039T (-20-50) ASHK_TMP3a - SSB PCB Temp 3a
35	70		DOUBLE	VOR(MIN=-20; MAX=50;D=1)
36	70	T_PCB_TEMP3b Sun Sensor Board PCB Temperature, sensor 3b. Temperature of VCC5 LDO regulator. Remark: 3a/b is measured on the same place, it's to compare the values to discover a measurement failure	DOUBLE	AIFR040T ID: AIFN040T (-20-50) ASHK_TMP3b - SSB PCB Temp 3b
37	70	T_PCB_TEMP4 Sun Sensor Board PCB Temperature, sensor 4. Temperature of VCC6 LDO regulator.	DOUBLE	VOR(MIN=-20; MAX=50;D=1) AIFR041T ID: AIFN041T (-20-50) ASHK_TMP4 - SSB PCB Temp 4

2.3 GYTM - Gyroscope TM

D	4	D'4	D ' 4'	T	T 14 1
By	te	Bit	Description	Type	Fault class

		Unit identifier Identification of the unit that addresses the	INT	BF(MIN=0,MAX=0)
1	70	message		
		0 = Nominal		
		1 = Redundant		
		Gyroscope Telemetry	HEX	NONE: the type of
		All telemetry data from Gyroscope.		data transmitted appear
		Message is the same sent from Gyroscope unit		to bee too much
212	7.0	without adding/removing data		complicate to be
212	70			mutated in such a way
				of triggering a test
				failure. Could be
				targeted in the future.

Byte	Bit	Description		
			HEX	IV(VALUE=0x51)
		Eman tyma		IV(VALUE=0x52)
1	70	Error type		IV(VALUE=0x53)
		•		IV(VALUE=0x54)
				IV(VALUE=0x56)

2.5 Sun Sensor TM

Byte	Bit	Description	Type	Fault class
1	70		DOUBLE	VAT(T=2.6;D=0.1)
2	70	Photodiode Q1 current ADC #3		ID: AIFN044I (0-2.6) SSTM_PXQ1 - pX Q1 Curr
3	70	Photodiode Q2	DOUBLE	VAT(T=2.6;D=0.1)
4	70	current ADC #3		ID: AIFN045I
5	70	Photodiode Q3	DOUBLE	VAT(T=2.6;D=0.1) ID: AIFN046I
6	70	current ADC #3		ID. AIF 10401
			DOUBLE	VAT(T=2.6;D=0.1)
7	70	Photodiode Q4 current ADC #3		ID: AIFN047I
8	70	current ADC #3		15.7111.70
9	70	Photodiode Q1	DOUBLE	VAT(T=2.6;D=0.1)
10	70	current ADC #2		ID: AIFN048I
11	70	Photodiode Q2	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #2		ID: AIFN049I
12	70		DOUBLE	VAT(T-2 (.D-0.1)
13	70	Photodiode Q3	DOUBLE	VAT(T=2.6;D=0.1)
14	70	current ADC #2		ID: AIFN050I
1.5	7 0		DOUBLE	VAT(T=2.6;D=0.1)
15	70	Photodiode Q4 current ADC #2		ID: AIFN051I
16	70			
17	70	Photodiode Q1	DOUBLE	VAT(T=2.6;D=0.1) ID: AIFN052I
18	70	current ADC #6		ID. AII 110321
			DOUBLE	VAT(T=2.6;D=0.1)
19	70	Photodiode Q2 current ADC #6		ID: AIFN053I
20	70	Current ADC #0		
21	7.0	Photodiode Q3	DOUBLE	VAT(T=2.6;D=0.1)
21	70	current ADC #6		ID: AIFN054I

22	70]		
22	7.0		DOUBLE	VAT(T=2.6;D=0.1)
23	70	Photodiode Q4 current ADC #6		ID: AIFN055I
24	70			
25	7.0		DOUBLE	VAT(T=2.6;D=0.1)
25	70	Photodiode Q1		ID: AIFN056I
26	70	current ADC #5		
27	70	DI 4 11 1 02	DOUBLE	VAT(T=2.6;D=0.1)
	/0	Photodiode Q2 current ADC #5		ID: AIFN057I
28	70	current ADC #5		
29	70	Dhotodic de O2	DOUBLE	VAT(T=2.6;D=0.1)
2)	70	Photodiode Q3 current ADC #5		ID: AIFN058I
30	70	Current ADC #3		
31	70	Photodicals O4	DOUBLE	VAT(T=2.6;D=0.1)
<i>J</i> 1	70	Photodiode Q4 current ADC #5		ID: AIFN059I
32	70			
33	70	Photodiada O1	DOUBLE	VAT(T=2.6;D=0.1)
	/	Photodiode Q1 current ADC #4		ID: AIFN060I
34	70			YVV TO (TO O (TO O ()
35	70	Photodiode Q2	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #4		ID: AIFN061I
36	70		DOLIDI E	WAT/T 2 (D. O.1)
37	70	Photodiode Q3	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #4		ID: AIFN062I
38	70		DOLIDI E	VAT/T_2 (.D. 0.1)
39	70	Photodiode Q4	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #4		ID: AIFN063I
40	70		DOLIDI E	VAT/T_2 (.D. 0.1)
41	70	Photodiode Q1	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #7		ID: AIFN064I
42	70		DOUBLE	VAT/T-2 (.D-0.1)
43	70	Photodiode Q2	DOUBLE	VAT(T=2.6;D=0.1)
		current ADC #7		ID: AIFN065I
44	70		DOUBLE	VAT/T-2 (.D-0.1)
45	70]	DOUBLE	VAT(T=2.6;D=0.1)

		Photodiode Q3 current ADC #7		ID: AIFN066I
46	70	current ADC #7		
47	70	Photodiode Q4 current ADC #7	DOUBLE	VAT(T=2.6;D=0.1) ID: AIFN067I
48	70			

Byte	Bit	Description	Type	Fault class
		Eman trans	HEX	IV(VALUE=0x51)
1	70	Error type		IV(VALUE=0x54)
		•		IV(VALUE=0x56)

2.6 SSTP - Sun Sensor Temperature

Byte	Bit	Description	Type	Fault class
1	70		DOUBLE	VOR(MIN=-
		1. 6		70;MAX=100;D=1)
2	70	Temperature reading from ADC #3		ID: AIFN068T (-70-100) SSTP TPXP - Temperature Xp
	70		DOUBLE	VOR(MIN=-70;
3		Temperature reading from		MAX=100;D=1)
		ADC #2		ID A LENGCOT
4	70	112 0 112		ID: AIFN069T
4	70		DOUBLE	VOD (MINI— 70.
5	70		DOUBLE	VOR(MIN=-70; MAX=100;D=1)
		Temperature reading from		WAX-100,D-1)
	70	ADC #6		
6				ID: AIFN070T
	70		DOUBLE	VOR(MIN=-70;
7		Tananamatana maadina form		MAX=100;D=1)
	70	Temperature reading from ADC #5		
8	70	TABE 113		ID: AIFN071T
	70		DOUBLE	VOR(MIN=-70;
9				MAX=100;D=1)
	7.0	Temperature reading from	<u> </u>	
10	70	ADC #4		ID: AIFN072T
10				1D. AII 110/21
1.1	70		DOUBLE	VOR(MIN=-70;
11		Temperature reading from		MAX=100;D=1)
	70	ADC #7		
12				ID: AIFN073T

Byte	Bit	Description	Type	Fault class
		Error type	HEX	IV(VALUE=0x51)
1	70	Enortype		IV(VALUE=0x54)
		•		IV(VALUE=0x56)

2.8 SpaceCraft HK

Byte	Bit	Description	Туре	Fault class
1	70	TMTC_SW1 Identifies the switching position of the TMTC switch 1: the voltage is ~1.1V for position A and 2.2V for position B. 0V or 3.3V will indicate a short or an	DOUBLE	VAT(T=3.3;D=0.1) VBT(T=0;D=0.1) ID: AIFN086X
2	70	interruption.		
3	70	TMTC_SW2 Identifies the switching position of the TMTC switch 2: the voltage is ~1.1V	DOUBLE	VOR(MIN=0.5;MAX= 2.75;D=0.01)
4	70	for position A and 2.2V for position B. 0V or 3.3V will indicate a short or an interruption.		ID: AIFN087X
5	70	SC_TEMP1 Temperature SC-TEMP1 of a sensor in the S/C structure	DOUBLE	VOR(MIN=0;MAX=50;D=1) ID: AIFN088T (0-50) SCHK_SCT1 - OBC Thermistor 1
6	70			
7	70	SC_TEMP2 Temperature SC-TEMP2 of a sensor in	DOUBLE	VOR(MIN=0;MAX=50;D=1)
8	70	the S/C structure		ID: AIFN089T
9	70	SC_TEMP3 Temperature SC-TEMP3 of a sensor in	DOUBLE	VOR(MIN=0;MAX=50;D=1)
10	70	the S/C structure		ID: AIFN090T
11	70	SC_TEMP4 Temperature SC-TEMP4 of a sensor in	DOUBLE	VOR(MIN=0;MAX=50;D=1)
12	70	the S/C structure		ID: AIFN091T
13	70	SC_TEMP5 Temperature SC-TEMP5 of a sensor in	DOUBLE	VOR(MIN =9.9253; MAX= 29.9979; D=0.0001)
14	70	the S/C structure		ID: AIFN092T

15	70	SC_TEMP6 Temperature SC-TEMP6 of a sensor in	DOUBLE	VOR(MIN =9.9253; MAX= 29.9979; D=0.0001)
16	70	the S/C structure		ID: AIFN093T

Byte	Bit	Description		
1	70	Error type	HEX	IV(VALUE=0x56)

2.9 Magnetorquer Set PWM RSP

Byte	Bit	Description	Type	Fault class
1	70	Unit identifier Magnetometer Identification of the Magnetometer unit that addresses the message $0 = \text{Nominal}$ $1 = \text{Redundant}$	BIN	BF(MIN=0;MAX=0)
2	70	Magnetometer Data request reply Byte1 Sync(LSB) (Note 1)		NONE: Not to address with the approach because the effect of a mutation is not predictable (the trasferred data is complex, e.g., signal).
3	70	Magnetometer Data request reply Byte2 Sync(MSB) (Note 1)		NONE: same as above.
4	70	Magnetometer Data request reply Byte3 RAdr (Note 1)		NONE: same as above.
5	70	Magnetometer Data request reply Byte4 Sadr (Note 1)		NONE: same as above.
6	70	Magnetometer Data request reply Byte5 ReplyMsg (Note 1)		NONE: same as above.
7	70	Magnetometer Data request reply Byte6 Bx Low (Note 1)		NONE: same as above.
8	70	Magnetometer Data request reply Byte7 Bx Middle		NONE: same as above.
9	70	Magnetometer Data request reply Byte8 CS error + Average + pos Clip X + neg Clip X + BX High (Note 1)		NONE: same as above.
10	70	Magnetometer Data request reply Byte9 By Low (Note 1)		NONE: same as above.
11	70	Magnetometer Data request reply Byte10 By Middle (Note 1)		NONE: same as above.
12	70	Magnetometer Data request reply Byte11 spare + pos Clip Y + neg Clip Y + BY High (Note 1)		NONE: same as above.
13	70	Magnetometer Data request reply Byte12 Bz Low (Note 1)		NONE: same as above.
14	70	Magnetometer Data request reply Byte13 Bz Middle (Note 1)		NONE: same as above.
15	70	Magnetometer Data request reply Byte14 spare + pos Clip Z + neg Clip Z + BZ High (Note 1)		NONE: same as above.
16	70	Magnetometer Data request reply Byte15 CS (Note 1)		NONE: same as above.
17	70	Magnetorquer nX Current - on Current MTXA_N when powered	DOUBLE	VOR(MIN=0.14,MAX= 0.21,D=0.01)

18	70			MT nX Curr - on
19	70	Magnetorquer nX Current - off	DOUBLE	VOR(MIN=0,MAX= 0.2,D=0.1)
20	70	Current MTXA_N when unpowered		AIFR075I MT nX Curr - off
21	70	Magnetorquer pX Current - on Current MTXA P when powered	DOUBLE	VOR(MIN=0.14,MAX= 0.21,D=0.01) AIFR076I
22	70	_ '		MT pX Curr - on
23	70	Magnetorquer pX Current - off	DOUBLE	VOR(MIN=0,MAX= 0.2,D=0.1)
24	70	Current MTXA_P when unpowered		AIFR077I MT pX Curr - off
25	70	Magnetorquer nY Current - on	DOUBLE	VOR(MIN=0.14,MAX= 0.21,D=0.01)
26	70	Current MTYA_N when powered		AIFR078I MT nY Curr - on
27	70	Magnetorquer nY Current - off	DOUBLE	VOR(MIN=0,MAX= 0.2,D=0.1)
28	70	Current MTYA_N when unpowered		AIFR079I MT nY Curr - off
29	70	Magnetorquer pY Current - on		VOR(MIN=0.14,MAX= 0.21,D=0.01)
30	70	Current MTYA_P when powered	DOUBLE	AIFR080I MT pY Curr - on
31	70	Magnetorquer pY Current - off	DOUBLE	VOR(MIN=0,MAX= 0.2,D=0.1)
32	70	Current MTYA_P when unpowered		AIFR081I MT pY Curr - off
33	70	7.6	DOUBLE	VOR(MIN=0.14,MAX= 0.21,D=0.01)
34	70	Magnetorquer nZ Current - on Current MTZA_N when powered		AIFR082I MT nZ Curr - on
35	70	Magnetorquer nZ Current - off	DOUBLE	VOR(MIN=0,MAX= 0.2,D=0.1)
36	70	Current MTZA_N when unpowered		AIFR083I MT nZ Curr - off
37	70	Magnetorquer pZ Current - on	DOUBLE	VOR(MIN=0.14,MAX= 0.21,D=0.01)
38	70	Current MTZA_P when powered		AIFR084I

				MT pZ Curr - on
			DOUBLE	VOR(MIN=0,MAX=
20	7.0	Magnetorquer pZ Current - off		0.2,D=0.1)
39	70	Current MTZA_P when unpowered		AIFR085I
				MT pZ Curr - off

3. Mutation Probes

Mutation probes are manually integrated into the source code of function *ObcRecvBlockCb*. Figure 3 shows an example of how we integrate mutation probes. All the probes are integrated following the same pattern; more precisely, for each data generation function we manually insert two invocations to the FAQAS mutation probe API, one to perform mutation of the nominal response message (Line 154, in Figure 3) the other one to mutate an error response message (Line 149). The choice of the data model to pass to the FAQAS mutation probe API is based on the value of *cr*, the variable that captures the return status of the specific data generation function invoked (function *GetIfHk* in Figure 3).

The function _FAQAS_mutate takes as input the fault model to be used to drive the mutation. Fault models are automatically generated from template files matching to the tables reported in Section 2.

```
144:
          case 0:
145:
146:
            cr = GetIfStatus(newBlock);
             if (cr == CR Failure){
147:
148:
                 FaultModel *dm = FAQAS GetIfStatus FM Error ()
149:
                  FAQAS mutate( newBlock, dm );
150:
                 FAQAS delete DM(dm)
             } else {
151:
152:
                  FaultModel *dm = FAQAS GetIfStatus FM ()
153:
                   FAQAS mutate( newBlock, dm);
154:
                 FAQAS delete DM(dm)
155:
             }
156:
          }
```

Figure 3: Mutation probe for GetIfStatus