

Getting started with the X-CUBE-ISPU software package for STM32Cube

Introduction

The [X-CUBE-ISPU](#) expansion software package for [STM32Cube](#) runs on the STM32. It includes drivers that recognize the sensors and collect temperature, humidity, pressure, motion, and ISPU data.

The expansion is built on [STM32Cube](#) software technology to ease portability across different STM32 microcontrollers.

The software comes with a sample implementation of the drivers running on the [X-NUCLEO-IKS01A3/X-NUCLEO-IKS02A1](#) expansion boards connected to a featured [STM32 Nucleo](#) development board.

The software is also available on GitHub, where the users can signal bugs and propose new ideas through [[Issues](#)] and [[Pull requests](#)] tabs.

The software provides sample applications for communication with the PC [Unicleo-GUI](#) graphical user interface.

The software also provides template and example code for the ISPU, and binary libraries with sample code for integration in the ISPU.

Related links

[Visit the STM32Cube ecosystem web page on www.st.com for further information](#)

1 License


The software provided in this package is licensed under [Software License Agreement SLA0095](#).

2 Installing the X-CUBE-ISPU pack in STM32CubeMX

After downloading (from www.st.com), installing and launching the STM32CubeMX, the X-CUBE-ISPU pack can be installed in a few steps.


Step 1. From the menu, select [Help]>[Manage embedded software packages].

Figure 1. Managing embedded software packs in STM32CubeMX



Step 2. From the [Embedded Software Packages Manager] window, press the [Refresh] button to get an updated list of the add-on packs. Go to the [STMicroelectronics] tab to find the X-CUBE-ISPU pack.

Figure 2. Installing the X-CUBE-ISPU pack in STM32CubeMX



Step 3. Select it by checking the corresponding box and install it by pressing the [Install Now] button. Once the installation is completed, the corresponding box becomes green, the [Close] button can be pressed, and the configuration of a new project can start.

3 Sample applications

The [X-CUBE-ISPU](#) contains sample applications, which:

- are ready-to-use projects that can be generated through the [STM32CubeMX](#) for any STM32 Nucleo development board, using the [X-NUCLEO-IKS01A3](#) or the [X-NUCLEO-IKS02A1](#) expansion board
- are ready-to-use projects that can be generated through the [STM32CubeMX](#) for any board equipped with an STM32 MCU, using supported MEMS components and MEMS devices with an ISPU core
- show the users how to use the APIs to initialize and use correctly the ST MEMS components and MEMS devices with an ISPU core

3.1 ISPU_DataLogExtended sample application

This application shows how to use the [X-NUCLEO-IKS01A3](#), [X-NUCLEO-IKS02A1](#), or a custom expansion board with MEMS devices and MEMS components with an ISPU core to send sensor data from an [STM32 Nucleo](#) development board, using a UART to a connected PC and displaying it in the [Unicleo-GUI](#) application.

The user can view the data from all on-board environmental sensors (temperature, humidity, and pressure sensors on the [X-NUCLEO-IKS01A3](#)) and from the on-board inertial sensors (magnetometer on the [X-NUCLEO-IKS01A3](#) and the [X-NUCLEO-IKS02A1](#)), as well as data from one of the supported MEMS devices with an ISPU core (accelerometer and gyroscope), connected to the DIL24 socket or on the custom board.

The data can be displayed as text or in graphical plots and can be stored as a CSV file. The ISPU can be programmed with any algorithm stored in a UCF file.

4 Hardware configuration

The [X-NUCLEO-IKS01A3](#) or the [X-NUCLEO-IKS02A1](#) interfaces with the STM32 microcontroller via the I²C bus. Therefore, no particular hardware modification is needed to interface the [X-NUCLEO-IKS01A3](#) or [X-NUCLEO-IKS02A1](#) expansion board with a 64-pin STM32 Nucleo (for example, a NUCLEO-F401RETx) or a 144-pin STM32 Nucleo (for example, a NUCLEO-F429ZITx).

Figure 3. 64-pin STM32 Nucleo and X-NUCLEO-IKS02A1




Figure 4. 144-pin STM32 Nucleo and X-NUCLEO-IKS01A3




Figure 5. X-NUCLEO-IKS01A3 pinout




Figure 6. X-NUCLEO-IKS01A3 pinout with alternate pins





Figure 7. X-NUCLEO-IKS02A1 pinout



Specific configuration for ISPU_DataLogExtended:

- **X-NUCLEO-IKS01A3**

Ensure that the JP6 jumper is connected to the position #7 on the X-NUCLEO-IKS01A3 expansion board in order to connect the USER_INT pin that you selected on your MCU (in our example PA10) to the INT2 pin of the ISPU device.

- **X-NUCLEO-IKS02A1**

Ensure that the JP6 jumper is connected to the position #3 on the X-NUCLEO-IKS02A1 expansion board in order to connect the USER_INT pin that you selected on your MCU (in our example PA10) to the INT2 pin of the ISPU device.

- **Custom board**


Ensure that the USER_INT pin that you selected on your MCU (in our example PA10) is connected to the INT2 pin of the ISPU device.

5 Project generation

5.1 MCU/board selection


After launching the STM32CubeMX, you can choose whether to start a [New Project] from the [MCU Selector] or from the [Board Selector].

Figure 8. STM32CubeMX main page



The [MCU/Board selector] window pops up. From this window, you can select the STM32 MCU or platform.

Figure 9. STM32CubeMX MCU/board selector window



After selecting the MCU or the board, the selected STM32 pinout appears. From this window, you can set up the project, by adding one or more software packs, and configure the peripherals and the clock.


5.2 Pin configuration

The typical pin configuration for the STM32 Nucleo-64 development boards is:

- PB8 (SDA) and PB9 (SCL) - I²C bus for MEMS components
- PA10 - EXTI input for the user interrupt (renamed to USER_INT)
- PA3 (Rx), PA2 (Tx) - USART2 for the communication with a PC
- PA5 - GPIO output for the LED pin
- PC13 - EXTI input for the user button

From the [Pinout & Configuration] tab, click on the [System Core] category and then on the GPIO item to set up the GPIO pins.

Figure 10. GPIO configuration




5.3

NVIC configuration

From the [Pinout & Configuration] tab, click on the [System Core] category and then on the NVIC item to enable the EXTI line interrupts on the pin which is connected to the INT2 of the ISPU device.


Figure 11. NVIC configuration



I²C configuration

From the [Pinout & Configuration] tab, click on the [Connectivity] category and then on the I2C1 item to set the I²C speed at 400 KHz (fast mode).

Figure 12. I²C configuration




5.5 USART configuration

From the [Pinout & Configuration] tab, click on the [Connectivity] category and then on the USART2 button. Check that the configuration is set as shown in the table below.

Table 1. USART configuration parameters


Parameter	Value
Baud rate	921600 bits/s
Word length	8 bits (including parity)
Parity	None
Stop bits	1

Figure 13. USART configuration



From the [Pinout & Configuration] tab, click on the [System Core] category and then on the DMA item. Then, set up the DMA for the USART2_RX in circular mode, incrementing the memory address as shown below.

Figure 14. DMA configuration




5.6

Adding software components

To add software components from the X-CUBE-ISPU software pack to the project, click on the [Software Packs] button. Then, click on the [Select Components] item.

From the [Software Packs Component Selector] window, you can add the drivers for individual MEMS components only, as well as the BSP abstraction layer, or the fully functional applications.

Figure 15. [Software Packs Component Selector] window




5.6.1

Software components for X-NUCLEO-IKS01A3

This section outlines how to configure the STM32CubeMX with an X-NUCLEO-IKS01A3 expansion board that mounts environmental and motion MEMS sensors from the X-CUBE-MEMS1 pack and MEMS component with an ISPU core in a DIL24 socket from the X-CUBE-ISPU pack.

In this case, you can configure the MEMS with an ISPU device to be used via I²C bus (default for the expansion board) or via SPI bus (only four wires).

Figure 16. [Software Packs Component Selector] window for X-NUCLEO-IKS01A3




5.6.2

Software components for X-NUCLEO-IKS02A1

This section outlines how to configure the STM32CubeMX with an [X-NUCLEO-IKS02A1](#) expansion board that mounts environmental and motion MEMS sensors from the [X-CUBE-MEMS1](#) pack and MEMS component with an ISPU core in a DIL24 socket from the [X-CUBE-ISPU](#) pack.

In this case, you can configure the MEMS with an ISPU device to be used via I²C bus (default for the expansion board) or via SPI bus (only four wires).

Figure 17. [Software Packs Component Selector] window for X-NUCLEO-IKS02A1




5.6.3

Software components for a custom board

This section outlines how to configure the STM32CubeMX with a custom board that mounts a MEMS device with an ISPU core.

In this case, you can configure the MEMS with an ISPU device to be used via I²C bus or via SPI bus (only four wires).

Figure 18. [Software Packs Component Selector] window for a custom board




5.7

Configuration of the software components

From the [Pinout and Configuration] tab, click on the [Software Packs] category. Then, press the [STMicroelectronics.X-CUBE-ISPU.1.0.0] item. Enable all the [Board Part] elements, the [Board Support Custom], and the [Device ISPU Applications] checkboxes from the [Mode] view. Set the following platform settings from the [Configuration] view, according to the board used. The figure below shows a configuration example.

Figure 19. Software packs settings for ISPU_DataLogExtended




5.7.1

Configuration for X-NUCLEO-IKS01A3

The figure below shows the software pack settings for the ISPU_DataLogExtended application, when using the X-NUCLEO-IKS01A3 (MEMS1).

Figure 20. Software packs settings - X-NUCLEO-IKS01A3 (MEMS1)



From the [Parameter Settings] tab, you can change some parameters of the MEMS devices. For example, you can decide if the SA0 pin is connected to VDD or GND, in order to associate the correct I²C address to the MEMS device.

You can select the output data rate and the full scale of the MEMS sensors for the ISPU_DataLogExtended application. You can also change some parameters for the routing of the interrupt signals.

The figures below show examples of the parameter settings of the ISPU_DataLogExtended application for the X-NUCLEO-IKS01A3.

Figure 21. Parameter settings - X-NUCLEO-IKS01A3 (ISPU)






Figure 22. Parameter settings - X-NUCLEO-IKS01A3 (MEMS1)



5.7.2 Configuration for X-NUCLEO-IKS02A1

The figure below shows the software pack settings for the ISPU_DataLogExtended application, when using the X-NUCLEO-IKS02A1 (MEMS1).

Figure 23. Software packs settings - X-NUCLEO-IKS02A1 (MEMS1)




From the [Parameter Settings] tab, you can change some parameters of the MEMS devices. For example, you can decide if the SA0 pin is connected to VDD or GND, in order to associate the correct I^C address to the MEMS device.

You can select the output data rate and the full scale of the MEMS sensors for the ISPU_DataLogExtended application. You can also change some parameters for the routing of the interrupt signals.

The figure below shows an example of the parameter settings of the ISPU_DataLogExtended application for the X-NUCLEO-IKS02A1.

Figure 24. Parameter settings - X-NUCLEO-IKS02A1




5.7.3 Configuration for the custom board

From the **[Parameter Settings]** tab, you can change some parameters of the MEMS devices. For example, you can decide if the SA0 pin is connected to VDD or GND, in order to associate the correct I²C address to the MEMS device.

You can select the output data rate and the full scale of the MEMS sensors for the ISPU_DataLogExtended application. You can also change some parameters for the routing of the interrupt signals.

The figures below shows of the parameter settings of the ISPU_DataLogExtended application for a custom board.


Figure 25. Parameter settings - custom board



5.8 Project generation

Once all the above-described steps have been performed, in the **Project Manager** tab increase the Minimum Stack Size to 0x8000, select the preferred Toolchain and the sample application using the **X-CUBE-ISPU** software can be generated clicking the “GENERATE CODE” button.

Figure 26. Project manager configuration



6 Generated folder structure


When generating a project, you can adopt two models of folder structure if you are using a high-level firmware component (a middleware in the STM32CubeMX MCU package):

- **Basic structure**, which is often used with the HAL examples and single package projects. This structure consists in having the IDE configuration folder at the same level of the sources (organized in the *Inc* and *Src* subfolders).
- **Advanced structure**, which provides a more efficient and organized folder model that allows an easy middleware application integration when several packages are used.

In the advanced mode, *Src* and *Inc* are generated under the *Core* folder.

For each package, the list of the generated files is under *<ModuleName>* (*ISPU* for the **X-CUBE-ISPU** pack). They are at the same level of the *Core* and contain the *App* and the *Target* subfolders.

Figure 27. STM32CubeMX application structure configuration



7

Known limitations and workarounds

The [X-CUBE-ISPU](#) pack V1.0.0 is fully compatible with the [STM32CubeMX](#) V6.6.0 and higher. It is not fully compatible with the previous versions of [STM32CubeMX](#).

On the dual-core STM32 series, this expansion software can be used on both cores but exclusively.

The projects for the MDK-ARM toolchain can be generated by default with the MicroLIB disabled for some STM32 families. In this case, the MEMS application, which sends data to the VCOM, does not work properly. To avoid this issue, check that the [**Use MicroLIB**] option is always enabled in the MDK-ARM project options.

Revision history

Table 2. Document revision history

Date	Revision	Changes
01-Aug-2022	1	Initial release.

Contents

1	License	2
2	Installing the X-CUBE-ISPU pack in STM32CubeMX	3
3	Sample applications	4
3.1	ISPU_DataLogExtended sample application	4
4	Hardware configuration	5
5	Project generation	9
5.1	MCU/board selection	9
5.2	Pin configuration	10
5.3	NVIC configuration	11
5.4	I ² C configuration	12
5.5	USART configuration	13
5.6	Adding software components	14
5.6.1	Software components for X-NUCLEO-IKS01A3	14
5.6.2	Software components for X-NUCLEO-IKS02A1	16
5.6.3	Software components for a custom board	17
5.7	Configuration of the software components	18
5.7.1	Configuration for X-NUCLEO-IKS01A3	18
5.7.2	Configuration for X-NUCLEO-IKS02A1	20
5.7.3	Configuration for the custom board	21
5.8	Project generation	22
6	Generated folder structure	23
7	Known limitations and workarounds	24
Revision history		25
List of tables		27
List of figures		28

List of tables

Table 1.	USART configuration parameters	13
Table 2.	Document revision history	25

List of figures

Figure 1.	Managing embedded software packs in STM32CubeMX	3
Figure 2.	Installing the X-CUBE-ISPU pack in STM32CubeMX	3
Figure 3.	64-pin STM32 Nucleo and X-NUCLEO-IKS02A1	5
Figure 4.	144-pin STM32 Nucleo and X-NUCLEO-IKS01A3	6
Figure 5.	X-NUCLEO-IKS01A3 pinout	7
Figure 6.	X-NUCLEO-IKS01A3 pinout with alternate pins	7
Figure 7.	X-NUCLEO-IKS02A1 pinout	8
Figure 8.	STM32CubeMX main page	9
Figure 9.	STM32CubeMX MCU/board selector window	9
Figure 10.	GPIO configuration	10
Figure 11.	NVIC configuration	11
Figure 12.	I ² C configuration	12
Figure 13.	USART configuration	13
Figure 14.	DMA configuration	13
Figure 15.	[Software Packs Component Selector] window	14
Figure 16.	[Software Packs Component Selector] window for X-NUCLEO-IKS01A3	15
Figure 17.	[Software Packs Component Selector] window for X-NUCLEO-IKS02A1	16
Figure 18.	[Software Packs Component Selector] window for a custom board	17
Figure 19.	Software packs settings for ISPU_DataLogExtended	18
Figure 20.	Software packs settings - X-NUCLEO-IKS01A3 (MEMS1)	18
Figure 21.	Parameter settings - X-NUCLEO-IKS01A3 (ISPU)	19
Figure 22.	Parameter settings - X-NUCLEO-IKS01A3 (MEMS1)	19
Figure 23.	Software packs settings - X-NUCLEO-IKS02A1 (MEMS1)	20
Figure 24.	Parameter settings - X-NUCLEO-IKS02A1	20
Figure 25.	Parameter settings - custom board	21
Figure 26.	Project manager configuration	22
Figure 27.	STM32CubeMX application structure configuration	23

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2022 STMicroelectronics – All rights reserved