

### **Sensors and Actuators**

#### Sections:


- 1. Sensors
- 2. Actuators
- 3. Analog-to-Digital Conversion
- 4. Digital-to-Analog Conversion
- 5. Input/Output Devices for Discrete Data


1



## Computer-Process Interface

- To implement process control, the computer must collect data from and transmit signals to the production process
- Components required to implement the interface:
  - Sensors to measure continuous and discrete process variables
  - Actuators to drive continuous and discrete process parameters
  - Devices for ADC and DAC
  - I/O devices for discrete data





Δ



## **Transfer Function**

$$S = f(s)$$

where S = output signal; s = stimulus; and f(s) = functional relationship For binary sensors: S = 1 if s > 0 and S = 0 if  $s \le 0$ .

The ideal functional form for an analogue measuring device is a simple proportional relationship, such as:

$$S = C + ms$$

where C = output value at a stimulus value of zero and m = constant of proportionality (sensitivity)

5



### Example

The output voltage of a particular thermocouple sensor is registered to be 42.3 mV at temperature 105°C. It had previously been set to emit a zero voltage at 0°C. Since an output/input relationship exists between the two temperatures, determine (1) the transfer function of the thermocouple, and (2) the temperature corresponding to a voltage output of 15.8 mV.



## Solution

$$S = C + ms$$

42.3 mV = 0 + 
$$m(105^{\circ}C) = m(105^{\circ}C)$$
  
or  $m = 0.4028571429$ 

$$S = 0.4 (s)$$

$$15.8 \text{ mV} = 0.4 \text{ (s)}$$
  
 $15.8 / 0.4 = \text{s}$   
 $\text{s} = 39.22^{\circ}\text{C}$ 

7



### Sensors

A sensor is a transducer that converts a physical stimulus from one form into a more useful form to measure the stimulus

- Two basic categories:
  - 1. Analog
  - 2. Discrete
    - Binary
    - Digital (e.g., pulse counter)



Sound (db pressure)



Touch



Ultrasonic (distance)



Light (light intensity)



## Other Sensors

- Temperature
- RFID
- Barcode
- Proximity
- Vision
- Gyroscope
- Compass
- Tilt/Acceleration
- Etc.







Q





### **Actuators**





Hardware devices that convert a controller command signal into a change in a physical parameter


- The change is usually mechanical (e.g., position or velocity)
- An actuator is also a transducer because it changes one type of physical quantity into some alternative form
- An actuator is usually activated by a low-level command signal, so an amplifier may be required to provide sufficient power to drive the actuator















## **Motor Controllers**


The POSYS® 3004 (Designed & Made in Germany) is a PC/104 form factor board dedicated to high performance motion control applications with extensive interpolation functionality. The POSYS® 3004 is designed to control up to 4 axes of servo and stepper motors and provides hardware linear, circular, Bit Pattern and continuous interpolation which allow to perform the most complex motion profiles. Update rates per axis do not exist as each axis runs in absolute real-time mode simultaneously which makes these boards to one of the best performing motion controllers for up to 4 axes in the market.



17



## **Stepper Motors**



Step angle is given by: : 
$$\alpha = \frac{360}{n_s}$$

where  $n_s$  is the number of steps for the stepper motor (integer)

**Total angle** through which the motor rotates  $(A_m)$  is given by:  $A_m = n_p \alpha$  where  $n_p$  = number of pulses received by the motor.

**Angular velocity** is given by: 
$$\omega = \frac{2\pi f_p}{n_s}$$
 where  $f_p$  = pulse frequency

**Speed of rotation** is given by: 
$$N = \frac{60 f_p}{n_s}$$



## Example

A stepper motor has a step angle = 3.6°. (1) How many pulses are required for the motor to rotate through ten complete revolutions? (2) What pulse frequency is required for the motor to rotate at a speed of 100 rev/min?

19



## Solution

$$\alpha = \frac{360}{n_s}$$

(1)  $3.6^{\circ} = 360 / n_s$ ;  $3.6^{\circ} (n_s) = 360$ ;  $n_s = 360 / 3.6 = 100$  step angles

$$A_m = n_n \alpha$$

(2) Ten complete revolutions:  $10(360^\circ) = 3600^\circ = A_m$ Therefore  $n_\rho = 3600$  / 3.6 = 1000 pulses

$$N = \frac{60f_p}{n_s}$$

Where N = 100 rev/min:  $100 = 60 f_p / 100$   $10,000 = 60 f_p$  $f_p = 10,000 / 60 = 166.667 = 167$  Hz




## Analog-to-Digital Conversion


Sampling – converts the continuous signal into a series of discrete analog signals at periodic intervals

Quantization – each discrete analog is converted into one of a finite number of (previously defined) discrete amplitude levels

Encoding – discrete amplitude levels are converted into digital code



21





## Features of an ADC

- Sampling rate rate at which continuous analog signal is polled e.g. 1000 samples/sec
- Quantization divide analog signal into discrete levels
- Resolution depends on number of quantization levels
- Conversion time how long it takes to convert the sampled signal to digital code
- Conversion method means by which analog signal is encoded into digital equivalent
  - Example Successive approximation method

23




## Successive Approximation Method

- A series of trial voltages are successively compared to the input signal whose value is unknown
- Number of trial voltages = number of bits used to encode the signal
- First trial voltage is 1/2 the full scale range of the ADC
- If the remainder of the input voltage exceeds the trial voltage, then a bit value of 1 is entered, if less than trial voltage then a bit value of zero is entered
- The successive bit values, multiplied by their respective trial voltages and added, becomes the encoded value of the input signal



## Example

Analogue signal is 6.8 volts. Encode, using SAM, the signal for a 6 bit register with a full scale range of 10 volts.



25



### Resolution

**Quantisation levels** is defined as:  $N_q=2^n$  where  $N_q$  = quantisation levels; and n is the number of bits. Quantisation levels is defined as:

 $R_{ADC} = \frac{L}{N_a - 1} = \frac{L}{2^n - 1}$ Resolution is defined as:

where  $R_{ADC}$  is the resolution of the ADC; L is the full-scale range of the ADC

Quantisation generates an error, because the digitised signal is only sampled from the original analogue signal. The maximum possible error occurs when the true value of the analogue signal is on the borderline between two adjacent quantisation levels, in which case the error is half the quantisationlevel spacing; this gives us the following for quantisation error (Quanerr):

$$Quanerr = \pm \frac{1}{2} R_{ADC}$$

where  $R_{ADC}$  is the resolution of the ADC.



## Example

Using an analogue-to-digital converter, a continuous voltage signal is to be converted into its digital counterpart. The maximum voltage range is  $\pm 25$  V. The ADC has a 16bit capacity, and full scale range of 60 V. Determine (1) number of quantization levels, (2) resolution, (3) the spacing of each quantisation level, and the quantisation error for this ADC.

27



## Solution

$$N_q = 2^n$$

(1) Number of quantization levels:  $= 2^{16} = 65,536$ 

$$R_{ADC} = \frac{L}{N_q - 1} = \frac{L}{2^n - 1}$$
 (2) Resolution:  
 $R_{ADC} = 60 / 65,536 - 1 = \pm 0.0009155 \text{ volts}$ 

(2) Resolution:

$$R_{ADC}$$
 = 60 / 65,536 -1 =  $\pm$  0.0009155 volts

 $Quanerr = \pm \frac{1}{2} R_{ADC}$ 

(3) Quantisation error:

=  $\pm (0.0009155)/2 = \pm 0.00045778$  volts



# Digital-to-Analog Conversion

- Convert digital values into continuous analogue signal
  - Decoding digital value to an analogue value at discrete moments in time based on value within register

$$E_0 = E_{ref} \left\{ 0.5B_1 + 0.25B_2 + \dots + \left(2^n\right)^{-1} B_n \right\}$$

Where  $E_0$  is output voltage;  $E_{\text{ref}}$  is reference voltage;  $B_n$  is status of successive bits in the binary register

 Data Holding that changes series of discrete analogue signals into one continuous signal

29



### Example

- A DAC has a reference voltage of 100 V and has 6-bit precision. Three successive sampling instances 0.5 sec apart have the following data in the data register:
- Output Values:

 $E_{01} = 100\{0.5(1)+0.25(0)+0.125(1)+0.0625(0)+0.03125(0)+0.015625(0)\}$ 

 $E_{01} = 62.50V$ 

 $\mathsf{E}_{02} = 100\{0.5(1) + 0.25(0) + 0.125(1) + 0.0625(0) + 0.03125(0) + 0.015625(0)\}$ 

 $E_{02} = 65.63V$ 

 $E_{03} = 100\{0.5(1)+0.25(0)+0.125(1)+0.0625(0)+0.03125(0)+0.015625(0)\}$ 

 $E_{03} = 70.31V$ 



# Input/Output Devices

#### Binary data:

- Contact input interface input data to computer
- Contact output interface output data from computer
   Discrete data other than binary:
- Contact input interface input data to computer
- Contact output interface output data from computer Pulse data:
- Pulse counters input data to computer
- Pulse generators output data from comp

