

# **Packet Tracer - Troubleshoot Connectivity Issues**

### **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/0	172.16.1.1	255.255.255.0	N/A
	G0/1	172.16.2.1	255.255.255.0	N/A
	S0/0/0	209.165.200.226	255.255.255.252	N/A
R2	G0/0	209.165.201.1	255.255.255.224	N/A
	S0/0/0 (DCE)	209.165.200.225	255.255.255.252	N/A
PC-01	NIC	172.16.1.3	255.255.255.0	172.16.1.1
PC-02	NIC	172.16.1.4	255.255.255.0	172.16.1.1
PC-A	NIC	172.16.2.3	255.255.255.0	172.16.2.1
PC-B	NIC	172.16.2.4	255.255.255.0	172.16.2.1
Web	NIC	209.165.201.2	255.255.255.224	209.165.201.1
DNS1	NIC	209.165.201.3	255.255.255.224	209.165.201.1
DNS2	NIC	209.165.201.4	255.255.255.224	209.165.201.1

## **Objectives**

In this Packet Tracer activity, you will troubleshoot and resolve connectivity issues, if possible. Otherwise, the issues should be clearly documented so they can be escalated.

# Background / Scenario

Users are reporting that they cannot access the web server, www.cisco.pka after a recent upgrade that included adding a second DNS server. You must determine the cause and attempt to resolve the issues for the users. Clearly document the issues and any solution(s). You do not have access to the devices in the cloud or the server www.cisco.pka. Escalate the problem if necessary.

**Note:** Router R1 can only be accessed using SSH with the username **Admin01** and password **cisco12345**. Router R2 is in the ISP cloud and is not accessible by you.

#### Instructions

#### Step 1: Determine connectivity issues from PC-01.

- a. On PC-01, open the command prompt. Enter the command **ipconfig** to verify what IP address and default gateway have been assigned to PC-01. Correct as necessary according to the Addressing Table.
- b. After verifying/correcting the IP addressing issues on PC-01, the issue pings to the default gateway, web server, and other PCs. Were the pings successful? Record the results.

Ping to the default gateway (172.16.1.1)?

To web server (209.165.201.2)? Yes.  Ping to PC-02? Yes.  To PC-A? No  To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka? Yes.  Using the web server IP address?	Ping to PC-02? Yes.  To PC-A? No  To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka? Yes.	Yes.
Ping to PC-02? Yes.  To PC-A? No  To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka? Yes.  Using the web server IP address?	Ping to PC-02? Yes.  To PC-A? No  To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka? Yes. Using the web server IP address?	To web server (209.165.201.2)?
Yes.  To PC-A?  No  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	Yes.  To PC-A?  No  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	Yes.
Yes.  To PC-A?  No  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	Yes.  To PC-A?  No  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	Ping to PC-02?
No To PC-B? No. Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results. Can PC-01 access www.cisco.pka? Yes. Using the web server IP address?	No.  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	
No To PC-B? No. Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results. Can PC-01 access www.cisco.pka? Yes. Using the web server IP address?	No.  To PC-B?  No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	
To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	To PC-B? No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	To PC-A?
No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	No
No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	No.  Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	
Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	Use the web browser to access the web server on PC-01. Access the web server by first entering the URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	To PC-B?
URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	No.
URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	URL http://www.cisco.pka and then by using the IP address 209.165.201.2. Record the results.  Can PC-01 access www.cisco.pka?  Yes.  Using the web server IP address?	
Yes. Using the web server IP address?	Yes. Using the web server IP address?	
Using the web server IP address?	Using the web server IP address?	Can PC-01 access www.cisco.pka?
		Yes.
	Yes.	Using the web server IP address?
Yes.		Yes.

d. Document the issues and provide the solution(s). Correct the issues if possible.

IP address of PC-1 was configured incorrectly. To solve it we updated the IP address 172.168.1.3 to 172.16.1.3.

Also, PC-A and PC-B could not be reached.

### Step 2: Determine connectivity issues from PC-02.

- a. On PC-02, open the command prompt. Enter the command **ipconfig** to verify the configuration for the IP address and default gateway. Correct as necessary.
- b. After verifying/correcting the IP addressing issues on PC-02, the issue pings to the default gateway, web server, and other PCs. Were the pings successful? Record the results.

Ping to the default gateway (172.16.1.1)?

Yes.

C.

To web server (209.165.201.2)?

Yes.

Ping to PC-01?

No.

To PC-A?

No.

To PC-B?

No.

c. Navigate to www.cisco.pka using the web browser on PC-02. Record the results.

Questions:

Can PC-02 access www.cisco.pka?

Yes

Using the web server IP address?

Yes.

d. Document the issues and provide the solution(s). Correct the issues if possible.

The default gateway of PC-2 was configured incorrectly. To solve it we updated the default gateway from 172.16.1.11 to 172.16.1.1

Also, PC-A and PC-B could not be reached.

#### Step 3: Determine connectivity issues from PC-A.

- a. On PC-A, open the command prompt. Enter the command **ipconfig** to verify the configuration for the IP address and default gateway. Correct as necessary.
- b. After correcting the IP addressing issues on PC-A, issue the pings to the web server, default gateway, and other PCs. Were the pings successful? Record the results.

To web server (209.165.201.2)?

No.

Ping to the default gateway (172.16.2.1)?

No.

Ping to PC-B?

Yes.

To PC-01?

No.

To PC-02?

No.

c. Navigate to www.cisco.pka using the web browser on PC-A. Record the results.

Can PC-A access www.cisco.pka?

No.

Using the web server IP address?

No.

d. Document the issues and provide the solution(s). Correct the issues if possible.

Communication with R1 is problematic.

Need to remotely configure the router (as it can not be accessed directly). Discrepancies that will be found with the address table have to be reconfigured using the ip, subnet mask and default gateway given in the address table.

#### Step 4: Determine connectivity issues from PC-B.

- a. On PC-B, open the command prompt. Enter the command **ipconfig** to verify the configuration for the IP address and default gateway. Correct as necessary.
- b. After correcting the IP addressing issues on PC-B, issue the pings to the web server, default gateway, and other PCs. Were the pings successful? Record the results.

To web server (209.165.201.2)?

Yes.

Ping to the default gateway (172.16.2.1)?

Yes

Ping to PC-A?

Yes.

To PC-01?

Yes.

To PC-02?

Yes.

c. Navigate to www.cisco.pka using the web browser. Record the results.

Can PC-B access www.cisco.pka?

No.

Using the web server IP address

Yes

d. Document the issues and provide the solution(s). Correct the issues if possible.

PC-B is unable to map the domain name to the IP address.

e. Could all the issues be resolved on PC-B and still make use of DNS2? If not, what would you need to do?

The issue can not be resolved as the DNS part is locked. So, we can not access it to solve it.

But there can be a temporary solution. That is, DNS1 is working perfectly fine and is being used by the rest of the end devices. So, we can just simply change the DNS of PC-B from DNS2 to DNS1.

### Step 5: Verify connectivity.

Verify that all the PCs can access the web server www.cisco.pka.

Your completion percentage should be 100%. If not, verify that the IP configuration information is correct on all devices and that it matches what is shown in the addressing table.