
Chroma

Programmable AC Source 61611/61612 User's Manual





Get more product & global distributor information in the Chroma ATE APP









Programmable AC Source 61611/61612 User's Manual



Version 1.9 January 2021 P/N A11 001241

Legal Notices

The information in this document is subject to change without notice.

Chroma ATE INC. makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Chroma ATE INC. shall not be held liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance, or use of this material.

CHROMA ATE INC.

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

Copyright Notices. Copyright 2008 Chroma ATE INC., all rights reserved. Reproduction, adaptation, or translation of this document without prior written permission is prohibited, except as allowed under the copyright laws.

Warranty

All of Chroma's instruments are warranted against defects in material and workmanship for a period of one year from date of shipment. Chroma agrees to repair or replace any assembly or component found to be defective, under normal use during this period. Chroma's obligation under this warranty is limited solely to repairing any such instrument, which in Chroma's sole opinion proves to be defective within the scope of the warranty when returned to the factory or to an authorized service center. Purchaser is responsible for the shipping and cost of the service item to Chroma factory or service center. Shipment should not be made without prior authorization by Chroma.

This warranty does not apply to any products repaired or altered by persons not authorized by Chroma, or not in accordance with instructions furnished by Chroma. If the instrument is defective as a result of misuse, improper repair, or abnormal conditions or operations, repairs will be billed at cost.

Chroma assumes no responsibility for its product being used in a hazardous or dangerous manner either alone or in conjunction with other equipment. High voltage used in some instruments may be dangerous if misused. Special disclaimers apply to these instruments. Chroma assumes no liability for secondary charges or consequential damages and in any event, Chroma's liability for breach of warranty under any contract or otherwise, shall not exceed the purchase price of the specific instrument shipped and against which a claim is made.

Any recommendations made by Chroma regarding the use of its products are based upon tests believed to be reliable; Chroma makes no warranty of the results to be obtained. This warranty is in lieu of all other warranties, expressed or implied, and no representative or person is authorized to represent or assume for Chroma any liability in connection with the sale of our products other than set forth herein.

CHROMA ATE INC.

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

Tel: 886-3-327-9999 Fax: 886-3-327-8898

e-mail: info@chromaate.com

www.chromaate.com

Material Contents Declaration

The recycling label shown on the product indicates the Hazardous Substances contained in the product as the table listed below.





: See **<Table 1>**.





See <Table 2>.

<Table 1>

Hazar					us Substances		
Part Name	Lead	Mercury	Cadmium	Hexavalent Chromium		Selected Phthalates Group	
	Pb	Hg	Cd	Cr ⁶⁺	PBB/PBDE	DEHP/BBP/DBP/DIBP	
PCBA	0	0	0	0	0	0	
CHASSIS	0	0	0	0	0	0	
ACCESSORY	0	0	0	0	0	0	
PACKAGE	0	0	0	0	0	0	

[&]quot;O" indicates that the level of the specified chemical substance is less than the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

Remarks:

- 1. The CE marking on product is a declaration of product compliance with EU Directive 2011/65/EU and 2015/863/EU.
- 2. This product is complied with EU REACH regulation and no SVHC in use.

Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and wellbeing. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliances for disposal at least for free of charge.





[&]quot;×" indicates that the level of the specified chemical substance exceeds the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

<Table 2>

	Hazardous Substances					
Part Name	Lead	Mercury	Cadmium	Hexavalent Chromium		Selected Phthalates Group
	Pb	Hg	Cd	Cr ⁶⁺	PBB/PBDE	DEHP/BBP/DBP/DIBP
PCBA	×	0	0	0	0	0
CHASSIS	×	0	0	0	0	0
ACCESSORY	×	0	0	0	0	0
PACKAGE	0	0	0	0	0	0

[&]quot;O" indicates that the level of the specified chemical substance is less than the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.

- 1. Chroma is not fully transitioned to lead-free solder assembly at this moment; however, most of the components used are RoHS compliant.
- 2. The environment-friendly usage period of the product is assumed under the operating environment specified in each product's specification.
- 3. This product is complied with EU REACH regulation and no SVHC in use.

Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and wellbeing. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliances for disposal at least for free of charge.



[&]quot;×" indicates that the level of the specified chemical substance exceeds the threshold level specified in the standards of SJ/T-11363-2006, EU Directive 2011/65/EU, and 2015/863/EU.





Declaration of Conformity

For the following equipment:

Programmable AC Source

(Product Name/ Trade Name)

61511, 61512, 61611, 61612, A615103 (for 200-240V/380-400V input)

(Model Designation)

CHROMA ATE INC.

(Manufacturer Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Manufacturer Address)

Is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU) and Low Voltage Directive (2014/35/EU). For the evaluation regarding the Directives, the following standards were applied:

EN 61326-1:2013 Class A

EN 61326-1:2013(industrial locations)

EN 61000-4-2:2009, EN 61000-4-3:2006+A1:2008+A2:2010, EN 61000-4-4:2012,

EN 61000-4-5:2006, EN 61000-4-6:2014, EN 61000-4-8:2010, EN 61000-4-11:2004

EN 61010-1:2010

The equipment describe above is in conformity with Directive 2011/65/EU and 2015/863/EU of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

The following importer/manufacturer or authorized representative established within the EUT is responsible for this declaration :

CHROMA ATE INC.

(Company Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Company Address)

Person responsible for this declaration:

Mr. Vincent Wu

(Name, Surname)

T&M BU Vice President

(Position/Title)





Declaration of Conformity

For the following equipment:

Programmable AC Source

(Product Name/ Trade Name)

61511, 61512, 61611, 61612, A615103 (for 440-480V input)

(Model Designation)

CHROMA ATE INC.

(Manufacturer Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Manufacturer Address)

Is herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU) and Low Voltage Directive (2014/35/EU). For the evaluation regarding the Directives, the following standards were applied:

EN 61326-1:2013 Class A

EN 61326-1:2013(industrial locations)

EN 61000-4-2:2009, EN 61000-4-3:2006+A1:2008+A2:2010, EN 61000-4-4:2012,

EN 61000-4-6:2006, EN 61000-4-8:2010

EN 61010-1:2010

The equipment describe above is in conformity with Directive 2011/65/EU and 2015/863/EU of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

The following importer/manufacturer or authorized representative established within the EUT is responsible for this declaration :

CHROMA ATE INC.

(Company Name)

88 Wenmao Rd., Guishan Dist., Taoyuan City 333001, Taiwan

(Company Address)

Person responsible for this declaration:

Mr. Vincent Wu

(Name, Surname)

T&M BU Vice President

(Position/Title)

Taiwan 2020.12.23 V / V V (Place) (Date) (Legal Signature)

(anglin origination of

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or specific WARNINGS given elsewhere in this manual will violate safety standards of design, manufacture, and intended use of the instrument. *Chroma* assumes no liability for the customer's failure to comply with these requirements.



BEFORE APPLYING POWER

Verify that the power is set to match the rated input of this power supply.



PROTECTIVE GROUNDING

Make sure to connect the protective grounding to prevent an electric shock before turning on the power.



NECESSITY OF PROTECTIVE GROUNDING

Never cut off the internal or external protective grounding wire, or disconnect the wiring of protective grounding terminal. Doing so will cause a potential shock hazard that may bring injury to a person.



FUSES

Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired fuses or short-circuited fuse holders. To do so could cause a shock or fire hazard.



DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Do not operate the instrument in the presence of flammable gases or fumes. The instrument should be used in an environment of good ventilation.



DO NOT REMOVE THE COVER OF THE INSTRUMENT

Operating personnel must not remove the cover of the instrument. Component replacement and internal adjustment can be done only by qualified service personnel.



- 1. Lethal voltage. AC source may output 426 V peak voltage.
- 2. Touching the connected circuit or output terminal on the front or rear panel when power is on may result in death.
- 3. Before placing the device, be sure the floor is smooth and can withstand the maximum weight. The installation should close to the main structure (beam) of the building
- 4. Be noted that the L1/L2/L3 and NEU may generate maximum current when the configuration is Y connection. Thus, the wire diameter should meet the maximum current requirement.

Safety Symbols

Â	DANGER – High voltage.
<u> </u>	Explanation: To avoid injury, death of personnel, or damage to the instrument, the operator must refer to the explanation in the instruction manual.
	High temperature: This symbol indicates the temperature is hazardous to human beings. Do not touch it to avoid any personal injury.
	Protective grounding terminal: This symbol indicates that the terminal must be connected to ground before operation of the equipment to protect against electrical shock in case of a fault.
<u></u>	Functional grounding: To identify an earth (ground) terminal in cases where the protective ground is not explicitly stated. This symbol indicates the power connector does not provide grounding.
7	Frame or chassis: To identify a frame or chassis terminal.
\sim	Alternating Current (AC)
$\overline{\sim}$	Direct Current (DC) / Alternating Current (AC)
===	Direct Current (DC)
Д 。	Push-on/Push-off power switch
∆WARNING	The WARNING sign highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in injury to, or death of, personnel or long term health hazards.
CAUTION	The CAUTION sign highlights an essential operating or maintenance procedure, practice, condition, statement, etc., which if not strictly observed, could result in damage to, or destruction of, equipment.
Notice	The Notice sign highlights an essential operating or maintenance procedure, condition, or statement.

Revision History

The following lists the additions, deletions and modifications in this manual at each revision.

Date	Version	Revised Sections
Dec. 2008	1.0	Complete this manual.
Apr. 2009	1.1	Modify the chapter "Remote Operation."
Aug.2009	1.2	Add the chapter "Parallel Operation."
Jan. 2012	1.3	Reformat the manual layout and add "Verification of Compliance" Add 3-phase voltage input 440Vac /480Vac (Y: L-L) support
May 2013	1.4	Replace the "CE Declaration of Conformity"
Jun. 2014	1.5	Update the following:
		 Icons of keys described in "Front Panel" section. Pin description in Appendix A "TTL Signal Pin Assignments".
Jun. 2015	1.6	Add warning items in Safety Summary. Modify the following section:
		 "Key Features", "Specifications", "Front Panel" and "Rear Panel" in "General Information" chapter.
		 "Preparation for Use" and "Input Connection" in "Installation" chapter.
		 "External Vref" and "Protection" in "Local Operation" chapter.
Oct. 2016	1.7	Update CE "Declaration of Conformity".
Mar. 2017	1.8	Update "Material Contents Declaration". Update CE "Declaration of Conformity".
Jan. 2021	1.1	Update address.

Table of Contents

1.		General Information	. 1-1
	1.1	Introduction	. 1-1
	1.2	Key Features	
	1.3	Specifications	
	1.4	Names of Parts	. 1-5
	1.4	4.1 Front Panel	. 1-5
	1.4	4.2 Rear Panel	. 1-7
2.		Installation	2-1
	2.1	Initial Inspection	
	2.2	Preparation for Use	
	2.3	Requirements for Input Power	
		3.1 Ratings	
		3.2 Input Connection	
	2.4	Output Connection	
	2.5	Remote Sense Connection	
	2.6	Power On Procedure	2-6
	2.7	Maintenance & Cleaning	. 2-7
	2.8	Common Environment Conditions	. 2-7
3.		Local Operation	. 3-1
-	3.1	Introduction	
	3.2	Using Keyboard & RPG	
	3.3	MAIN PAGE (Output Setting & Measurement)	
	3.3	3.1 OUTPUT: More Setting	. 3-5
		3.3.1.1 Coupling Output Mode (AC+DC, AC, DC)	3-5
		3.3.1.2 Range	. 3-7
		3.3.1.3 Setting 3-phase Output	
		3.3.1.4 Output Degree	
		3.3.1.5 Slew Rate of Output Transient	
		3.3.1.6 Output Degree of 3-phase Voltage Output	
	3.3	3.2 Measurement Setting	
		3.3.2.1 Current Range	
		3.3.2.2 Average Times	
		3.3.2.3 Isurge Delay, Isurge Interval	
		3.3 Waveform Viewer	
	3.3	3.4 Limitation	
		3.3.4.1 Vac Limit	
	2.4	3.3.4.2 Vdc Limit (+), Vdc Limit (-)	3-20 3-20
	3.4	CONFIG Function Key	
	3.4	3.4.1.1 GPIB Address, RS-232C Parity/Baudrate	
		3.4.1.2 Remote Inhibit, EXT. ON/OFF	
		3.4.1.3 Ethernet Setting	
	3 /	4.2 External Vref	
	_	4.3 Display	
		4.4 Power ON Status	
	_	4.5 Protection	
		4.6 Others	
		4.7 Calibration	
		4.8 System Information	
		4.9 Factory Default	
	3.5	PHASE Function Key	

	3 1	5.1	3 Phase Mode	3_33
		5.2	1 Phase Mode	
	3.6	_	OR Function Key	
	3.7		Function Key	
	3.8		UT Function Key	
	3.9		L/REMOTE Function Key	
	3.10		/E/RECALL Function Key	
		10.1	Save/Recall Output Setting.	
		10.1	Save/Recall System Data	
	3.11		ection	
4.	0.11			
4.	4.4		ation	
	4.1		uction	
	4.2		Al Calibration	
	4.2	2.1 2.2	Output Voltage and Measurement Calibration	
		2.2 2.3	Current Measurement Calibration	
	4.2	_	External Vref Calibration	
5.			el Operation	
	5.1		el Connection of AC Source	
	5.2		el Connection	
	5.3		ј Up	
		3.1	Setting the AC Source to Slave	
		3.2	Setting the Slave of Mixed AC Source and A615103	
		3.3	Setting the AC Source to Master	
			eshooting	
	5.4		When the Connecting Cable Falls	
	5.4	4.2	Parallel Setting Error	5-6
6.		Theor	y of Operation	6-1
	6.1	Overvi	ew	6-1
	6.2	Descri	ption of Overall System	6-1
7.		Self To	est & Troubleshooting	7-1
	7.1	Overvi	ew	7-1
	7.2		est	
	7.3		eshooting	
8.			te Operation	
Ο.	8.1		uction	
	0. i 8. ´		USB Interface	
		1.2	GPIB Interface	
	_	1.3	RS-232C Interface	
	_	1.4	Ethernet Interface	
	8.2		uction to Programming	
	8.2		Conventions	
	• • • •	2.2	Numerical Data Formats	
	_	2.3	Boolean Data Format	
		2.4	Character Data Format	
	_	2.5	Basic Definition	
	8.3	-	sal of the Command Tree	
	8.4		tion Order	
	8.5			
	0.0	Comm	lands of AC Source	8-5
			ands of AC Source	
	8.5	5.1	Common Command Dictionary	8-5
	8.5	5.1 5.2	Common Command DictionaryInstrument Command Dictionary	8-5 8-7
	8.5	5.1 5.2 8.5.2.1	Common Command DictionaryInstrument Command Dictionary	8-5 8-7 8-7

Append	lix A TTI	L Signal Pin Assignments	A-1
8.6	Comma	nd Summary	8-21
		STATUS Sub-system	
	8.5.2.7	PHASE Sub-System	8-18
	8.5.2.6	CONFIGURE Sub-System	8-17
	8.5.2.5	SOURCE Sub-System	8-14
	8.5.2.4	OUTPUT Sub-System	8-13
	8.5.2.3	FETCH & MEASURE Sub-System	8-9

1. General Information

1.1 Introduction

The Chroma 61611/61612 Series is a highly efficient programmable AC Source which provides a low distortion sine wave output for power accuracy. The DSP microprocessor generates an accurate, stable output voltage and frequency. The PWM designed power stage allows apparent power into loads. The front panel has a RPG (Rotary Pulse Generator) and keypad control for setting the output voltage and frequency. The LCD gives users a complete operating status. Remote programming is accomplished by the GPIB bus or RS-232C serial port.

1.2 Key Features

A. Configuration

- Local operation by the keypad on the front panel
- Remote operation via GPIB or RS-232C interface
- Protection against over power, over current, over temperature and fan failure
- Thermostatically controlled fan speed
- Built-in output isolation relays

B. Input/Output

- Selectable output voltage with full scale of 150V/300V/Auto (3 ranges)
- Analog (simulation) reference voltage for remote control
- V, I, P, CF, PF, Idc, Vdc, Ipk, Is, VA and VAR measurement
- Remote inhibited control
- AC ON/OFF output signal

1.3 Specifications

Following lists the specifications of model 61611/61612. All specifications are tested by Chroma's standard test procedures, and follow remote sense for connection under the condition of $25 \pm 1^{\circ}$ C and resistive load unless specified otherwise.

Model	61611	61612			
	AC OUTP	UT RATING			
Single Phase	12KW	18KW			
Power					
3-Phase Power	12KW	18KW			
Power per Phase	4KW	6KW			
	VOLT				
Range		B00V/Auto			
Output Voltage		/ / 0~300V			
Accuracy		0.2% F.S.			
Resolution		0.1 V			
Distortion *1		215- 1KHz, 1.5%@>1KHz			
Line Regulation		0.1%			
Load Regulation *2		0.2%			
Temp. Coefficient		egree from 25°C			
0 1 10 1	MAXIMUM CURREN	NI (single phase)			
Output Current (RMS)	96A / 48A	144A / 72A			
Output Current (Peak)	384A / 192A	576A / 288A			
	MAXIMUM CURREN	T (each of 3-phase)			
Output Current (RMS)	32A / 16A	48A / 24A			
Output Current (Peak)	128A / 64A	192A / 96A			
	FREQU	ENCY			
Range	DC, 1	5-1.5KHz			
Accuracy		.01%			
	PHASE	ANGLE			
Range		- 360°			
Resolution		0.3°			
Accuracy		250/60Hz			
	DC OUTPUT RATIN	, , ,			
Power	6KW	9KW			
Voltage	212V / 424V	212V / 424V			
Current	48A / 24A	72A / 36A			
Dawar	DC OUTPUT RATIN				
Power	2KW	3KW			
Voltage	212V / 424V	212V / 424V			
Current	16A / 8A	24A / 12A			
Dower Type		ATING (per phase) a or Y connection			
Power Type					
Voltage Range	3Ф 254-277V±1	3Ф 200-240V±10% V _{LN} (Delta: L-L, Y: L-N) *4 3Ф 254-277V±10% V _{LN} (Y: L-N) *5			
Frequency Range		-63 Hz			
Max. Current	Delta: 80A Y: 70A	Delta: 120A Y: 90A			
	MEASUREMENT				
	VOLT				
Range		7/300V			
Accuracy 0.1%+0.2% F.S.					
Resolution 0.1 V		.1 V			

CURRENT (per phase)				
Range	8A/32A/128Apeak 12A/48A/192Apeak			
Peak per Phase	128A	192A		
Accuracy (RMS)	0.4%+().3% F.S.		
Accuracy (Peak)	0.4%+().6% F.S.		
Resolution	0.006A / 0	.025A / 0.1A		
	POW	/ER		
Accuracy	0.4%+0).4% F.S.		
Resolution	0.	1 W		
	OTHERS			
Efficiency *3	0.75 (Typical)			
Size (H×W×D)	1163×546×700 mm	1163×546×700 mm		
SIZE (LIXVVXD)	45.78×21.5×27.56 inch	45.78×21.5×27.56 inch		
Weight	Weight 220 kg / 505.29 lbs 240 kg / 533.92 lbs			
Protection		P, OTP, FANFAIL		
Remote Interface	·	2, USB, Ethernet		
	TEMPERATURE RANGE			
Operation	0 °C to 40 °C			
Storage	-40 °C to 85 °C			
Humidity	30 % to 90 %			
Safety & EMC		CE		

Notes

- *1: Maximum distortion is tested under output 125VAC (150V RANGE) and 250VAC (300V RANGE) with maximum current to linear load.
 - *2: Load regulation is tested by sine wave and remote sense.
- *3: Efficiency is tested on input voltage: 230V ac or 277Vac.

 *4: 3-phase voltage input 380Vac/400Vac (Y: L-L); 208Vac/220Vac (Delta: L-L)
- *5: 3-phase voltage input 440Vac/480Vac (Y: L-L)

1.4 Names of Parts

1.4.1 Front Panel




Figure 1-1 Front Panel


Item	Icon	Description
1		Display: The 6.5" LCD displays the configuration, output setup, and measurement results.
2		Indicator LED: The Power On indicator surrounds the rotary knob showing the activation status.
3		RPG Rotary : Users can turn the RPG rotary to adjust the voltage, frequency and input programmed data or options.
4	⊕ №	Cursor Movement Keys: These four keys move the cursor in different directions respectively. In normal mode, pressing any of these four keys will change the cursor position.
5	SAVE / RECALL	SAVE or RECALL: Press this on MAIN PAGE can save the output setting, see 3.10.1. By pressing this key on CHOICE PAGE users can save the system data, see 3.10.2.
6	OUT / QUIT	OUT/QUIT: Press this key to Enable/Disable the output voltage of the AC source.
7	LOCAL/ REMOTE	LOCAL/REMOTE: It switches the control mode from "Remote" to "LOCAL" for front panel input.
8	OUTPUT SETTING	OUTPUT SETTING: Changes the screen to "Output: More Setting" for additional settings.
9	CURSOR	CURSOR: It is used to set or adjust the value.

		LOCK:
10	LOCK	Press it for 1 second can lock up "all keys" and the "rotary".
		Press it for 3 seconds to unlock them.
11	PHASE	PHASE:
''	PHASE	It sets single/3-phase.
		CONFIG:
12	CONFIG	It changes the screen to "config choose page" for various
		settings.
	<u> </u>	Numeric and Decimal:
13	to [©] and	Users can use "numeric keys" and "decimal key" to input
		digital data.
4.4		Backward and Decreasing: Press this key to delete the
14	(• /-)	inputted number. It shows " - " if no number exists.
		EXIT:
15	and 🗇	Press it to return to previous screen.
	and S	
		Main Power Switch: It turns on or shut off the power.
16	Ф	
,_		Indicator: It refers to the description on screen for
17		parameter and function setting.
18	ENTER	ENTER: It confirms the setting of parameter.
10	241.11	ENTER. It committes the setting of parameter.
		Remote Control Terminal: No supported. This functiond is
19	ISMA L. CALTON	invalid.
		inivalia.


Table 1-1 Front Panel Description



To extend the product life of output relay, it will delay 50ms for release after pressing **QUIT**. When inductive load is connected, a discharge path will be provided for the inductive current within the period of time delayed due the feature of continuous flow.



1.4.2 Rear Panel






Figure 1-2 Rear Panel

Item	Symbol	Description
1	Rear Panel Output Interface	It includes Ext.V/TTL, Remote Sense, GPIB and USBetc.
2	I/O Terminal Case	It has the input/output terminal. The connector inputs power source from the mains (3-phase power) and outputs power source to the UUT.
3	Ext. Vref./TTL I/O	It inputs the control waveform amplitude from external analog (simulated) signal with TTL transmission control signal (Fault_out, Remote inhibit and AC_ON.)
4	SYSTEM BUS	It is applicable for signal transmission in between 2 AC Sources connected in parallel.
5	Ethernet	It is the terminal that can be controlled by network (LAN).
6	USB	It is used to connect the remote controller to computer for remote operation.
7	RS-232C	It is a 9-pin D type male connector that transmits control commands among distant PCs for remote operation.
8	GPIB Connector	Remote controller uses GPIB bus to connect the PC via the connector for remote operation.
9	INPUT WIRING SELECTION	Select the mapping cable connector for different input cable (Δ-Y). (Note: Not valid for 3-phase voltage input 440Vac/480Vac (Y: L-L).)
10	Remote Sense	It is the terminal that senses the load directly to avoid any voltage drop when connecting cable. Ensure the "SL" terminal of Remote Sense connector is connected to the "L" terminal of Load, and the "SN" is connected to the "N" of Load. Reverse polarity cannot be connected.
11	Input Connecting Terminal	It connects the mains to AC Source as input.

Item	Symbol	Description
12	•	It connects to UUT for output.
l '-	Terminal	
13	I/O Cable Secure Strip	It secures the input/output connection cable.

2. Installation

2.1 Initial Inspection

Before shipment, this instrument was inspected and found to be free of mechanical and electrical defects. As soon as the instrument is unpacked, inspect for any damage that may have occurred in transit. Save all packing materials in case the instrument has to be returned. If damage is found, please file claim with carrier immediately. Do not return the instrument to Chroma without prior approval.

2.2 Preparation for Use

First the instrument must be connected to an appropriate AC line input. Since the instrument is cooling by fans, it must be installed in a place with good circulation of air. It should be in an area where the ambient temperature does not exceed 40°C. The L1/L2/L3 and NEU may generate maximum current when it is Y connection. Thus, the wire diameter should meet the maximum current requirement.

2.3 Requirements for Input Power

2.3.1 Ratings

Input Voltage Range : 3Φ 200-240V±10% V_{LN} (Delta: L-L, Y: L-N)

3Ф 254-277V±10% V_{LN} (Y: L-N)

Input Frequency : 47-63 Hz

Maximum Current : 61611 Δ: 80A, Y: 70A 61612 Δ: 120A, Y: 90A

∆WARNING

The AC Source may be damaged if the input voltage exceeds the configured range.

2.3.2 Input Connection

The input terminal block is located beneath the device's rear panel. The power cord should be rated at least 85°C and the current rating of power line input must be greater than or equal to the maximum current rating of AC Source. The input selector is located on the rear panel (see **Error! Reference source not found.**.) Adjust the selector according to the p ower input (Delta or Y) method.

∆WARNING

Select the model in accord with the local voltage specification. The 200-240V $_{LL}$ 3-phase 4-wire (Delta) and 380-400V $_{LL}$ 3-phase 5-wire (Y) can be selected using input wiring selection before power-on. The range cannot be changed during power-on or it may cause the AC Source to be damaged. The 440-480V $_{LL}$ 3-phase 5-wire (Y) is the sole range without selection.

See Figure 2-3 and perform the steps below accordingly:

- 1. Remove the safety cover from the back of the AC Source.
- 2. Connect the wire to the AC Source terminal blocks (see Figure 2-3)
- Slide the safety cover over the AC input terminal strip.
- Secure it with the I/O cable trim strip and screws.
- 5. Assemble the safety cover back to the AC Source.

CAUTION To protect the operators, the wire connected to GND terminal must be connected to the earth. Under no circumstances shall this AC Source connected to the earth. Under no circumsta be operated without grounding adequately.

Voltage Range	Wire Spec.	Terminal Spec.	
3Ø 200-240V±10%V _{LN-} (Delta:L-L,Y:L-N)	38mm ² (L1/L2/L3/NEU/GND)	38-8(L1/L2/L3/NEU/GND)	
3Ø 254-277V±10%V _{LN} (Y:L-L)	38mm²(L1/L2/L3/NEU/GND)	38-8(L1/L2/L3/NEU/GND)	



Figure 2-1 Input Selector




Figure 2-2 No Input Wiring Selection



- 1. If users turn the Δ -Y switch to Δ , but the actual input wiring is Y, the AC Source will beep to warn the error. Users need to power it off first and turn the Δ -Y switch to Y to resolve the problem.
- 2. The 480V model has Y connection only; therefore there is no input selector.



- 1. Installation of the wire must be conducted by professional personnel complying with local electrical codes.
- 2. If the input wiring selection is 220V 3~ (△ type) max. 120A/phase, the specification of circuit breaker configured for △ type needs to be 220Vac/80A (61511) and 120A (61512) at least.
- 3. If the input wiring selection is 380V 3~ (Y type) max. 70A/phase, the specification of circuit breaker configured for Y type needs to be 380Vac/70A (61511) and 90A (61512) at least.
- 4. If the input wiring selection is 480V 3~ (Y type) max. 90A/phase, the specification of circuit breaker configured for Y type needs to be 480Vac/70A (61611) and 90A (61612) at least.




Figure 2-3 3-Phase Power Input Connection (Y Connection)




Figure 2-4 3-Phase Power Input Connection (Delta Connection)



Please be aware of the color distinction of insulation tube or the wire before connecting the power wire. The black insulation tube or power wire is used for L1, L2 and L3, the blue insulation tube or power wire is used for NEU while the green insulation tube or power wire is used for GROUND.

2.4 Output Connection

The output terminal block is located at the rear of AC Source. The Load is connected to the output terminals. To meet the safety requirements, the I/O input/output wires need to be tied up by a safety strip and the cover must be secured. The wire diameter should be large enough to connect to the load so that it will not overheat when outputting current, see Figure 2-6.



The output terminal labeled "L" is the "+" terminal and the output terminal labeled "COM/N" is the "-" terminal when output voltage contains DC composition.



For propoer ventilation, the hardware should be placed at least 1 meter distance from the device front and rear panel. Do not place the hardware against the wall or other objects.

2.5 Remote Sense Connection

The remote sense function of AC Source monitors the voltage at the load and performs automatic compensation to ensure the voltage delivered to load is the one programmed.

Remove the connecting wires " ψ 1", " ψ 2", " ψ 3" and "COM" from Remote Sense terminal, and connect remote sense to load as Figure 2-5 shows. As the sensing leads transmit only a few milliamperes, the sensing wires are much thinner than the load leads. The sensing leads are part of the feedback circuit of AC Source, so they must be low resistance for the best performance. Connect the sensing leads carefully so that they will not be open-circuited. If the sensing leads are disconnected or become open-circuited during operation, the AC Source may unable to output. The sensing leads must be a twisted pair to minimize the interference from external voltage. The sensing leads need to be connected to the load as close as possible.




Figure 2-5 Output & Remote Sense Connection





Figure 2-6 Input/Output Wire Securing Diagram


2.6 **Power On Procedure**



CAUTION Before turning on the instrument, all protective earth terminals, extension cords and devices connected to the instrument must be connected to a protective earth ground. Any interruption of the protective earth grounding may cause potential electric shock hazard protective earth grounding may calthat could result in personal injury.

Connect the power line and turn on the power switch on the front panel. The AC Source will begin a series of self tests. The LCD on the front panel will be on and displaying the following.





In the mean time the AC Source executes memory, data and communication self tests. The display shows the Model Number and AC Source's Serial No. when executing the self test routines and each test item will show "OK" on the right if no error is found. It needs about 10 seconds for self test to finish the routines and then the software version will show on the display.

"ERROR CODE" will appear on the right if one of the test items is failed. See Section 7.2 Self Test for detail information.

When the self tests of memory, data and communication are done, the AC Source will conduct a power output self test. The output relay is OFF during the procedure to ensure the load connected to the output terminal won't be damaged. The AC Source sets the output to 300Vac for measurement and if the measured voltage exceeds 300V±100V, the power self test fails and the display shows "NG". The display shows as below if it OK and the screen changes to MAIN PAGE automatically.



- Users can run self diagnosis during power on self test to see if there are any errors or NG (No Good) conditions, see section 7.2 Self Test for detail information.
- 2. The AC Source needs about 20 seconds to finish the self test.

2.7 Maintenance & Cleaning

Remove all connected wires and cables on the instrument before cleaning. Use a brush to clean the dust on it and if there are stains on the chassis that cannot be removed by brush, wipe it with a volatile liquid. Do not use any corrosive liquid to avoid damaging the chassis. Use a damp cloth with soap and water or a soft detergent to clean the LCD front panel. Please send it back to the distributors or agents of Chroma for internal cleaning. Do not open the chassis cover arbitrarily

2.8 Common Environment Conditions

- 1. In door use.
- 2. Altitude up to 2000m.
- 3. Temperature 0°C to 40°C.
- 4. Transient over voltage is impulse withstand CAT II.
- 5. Pollution degree 2.

3. Local Operation


3.1 Introduction

The AC Source can be configured to operate in local or remote mode. The remote mode operation is through a remote GPIB or RS-232C interface as described in Chapter 8. This section describes the operation in local mode using the keypad on the front panel for data entry and test. Local operation can be used directly when the AC Source is turned on.

3.2 Using Keyboard & RPG

The AC Source is equipped with a user friendly programmable interface containing a keypad and a RPG (Rotary Pulse Generator) on the front panel. The LCD on AC Source displays the operation menu.

Figure 3-1 shows the command tree. The following describes how to use both the keypad and the RPG to set the commands before explaining each menu. When the power-on procedure is completed (see 2.6), the display will show the MAIN PAGE (3_Phase Mode/1_Phase Mode) as below.



Press , , , keys to move the cursor for item selection. Use numeric and decimal keys or RPG to set the values and press **ENTER** to confirm them. Users can use the indicators located at the bottom or lower right of the LCD to set the parameters or functions following the description at the bottom or lower right of the screen, or press to return to MAIN PAGE.

In MAIN PAGE, users can press the indicators located at the bottom or lower right of the LCD to select the function list. Use ▲, ▼, ◄, ▶ to move the cursor after entering each list. For digital setting, users can use the numeric and decimal keys or the RPG to set the value and then press ENTER for confirmation. For text setting, users can turn the RPG for selection and press ENTER for confirmation.







Figure 3-1




3.3 MAIN PAGE (Output Setting & Measurement)

When the AC Source is turned on and finished the self test, the screen displays the MAIN PAGE (3_Phase Mode/1_Phase Mode). A line on the screen shows the output setting. The default output setting can be set by the Power ON Status (see 3.4.4) under the CONFIG function key. The MEASUREMENT on the screen shows the items measured by the AC Source and each of them has 12 types totaling 3 pages as shown below.







On top of the screen, the range displayed 300V is the Range status (see 3.3.1.2). There are 3 ranges:

- 1. 150V Range
- 2. 300V Range
- 3. AUTO Range

The definition of output parameters:

Vac : AC output voltage in Volts.F : Output frequency in Hertz.Vdc : DC output voltage in Volts.

Press **OUT/QUIT** enables the AC Source outputs the voltage with the setting of Vac, F and Vdc. Press it again the AC Source output is disabled.



When Coupling = AC+DC the output is the sum of Vac and Vdc. However, the combination of peak voltage cannot exceed the limit of each range (range 150V: 212.1V and range 300V: 424.2V.) The output voltage will skip to 0V automatically and trigger protection if it exceeds the voltage limit (OVP).

Following lists the definition of measurement parameters:

V: It is the voltage measurement in Volts. (True RMS measurement)

F: It is the output frequency in Hertz.

I : It is the current measurement in Amps. (True RMS measurement)

P: It is the real power measurement in Volts.

PF: It is Power Factor and the calculation formula = Real Power / (Vrms × Irms)

CF: It is Crest Factor and the calculation formula = Ipeak/Irms

Vdc : It is the DC voltage measurement in Volts.

Idc: It is the DC current measurement in Amps.

Ip : It is the peak current measurement in Amps. The Ipeak display is the Ip (+) or Ip(-) whichever is larger.

Is : It is I surge that is only measured when output changes as defined in section 3.3.2.3.

VA : It is the apparent power in Volt-Ampere and the calculation formula = Vrms×Irms.

VAR : The calculation formula = $\sqrt{VA^2 - P^2}$

3.3.1 OUTPUT: More Setting

Press OUTPUT: More Setting in the MAIN PAGE (3_Phase Mode/1_Phase Mode) (see section 3.3), a line of output functions will appear at the bottom of the screen as described below.





3.3.1.1 Coupling Output Mode (AC+DC, AC, DC)

There are 3 types of AC Source output: AC+DC, AC and DC. The coupling can be set to meet a variety of applications.

The setting procedure from AC to AC+DC is described as below:

- 1. Press Coupling at the bottom.
- 2. Turn the RPG to change the selection from AC to AC+DC and press **ENTER**.








Since the AC Source does not have as many capacitors as the common DC Power Supply, some voltage fluctuations and transient load characters are not the same. This AC Source is able to provide positive and negative voltage without changing the output connector. The output capacitance cannot exceed 20uF as it may cause the device to be damaged due to unstable output.

Though the AC Source has AC/DC/AC+DC output mode, the features are still different from the common DC Power Supply when in pure DC mode as explained below.

- 1. The output voltage ripple is bigger because there is no output capacitor.
- When the output current reaches the current limit set point, the output voltage will be cut
 off and in protection mode. It will not stay in constant current mode with a voltage drop
 like common DC sources.
- 3. It is necessary to connect the fixture as shown below if more than 20uF is to be used.




 The output has DC bias that is smaller than 15mV@150V range (temperature coefficient is 2.5mV/°C typical) or smaller than 30mV@300V range (temperature coefficient is 5mV/°C typical.)


3.3.1.2 Range

The AC Source has full scale voltage of output voltage in 150 V, 300 V and AUTO 3 selections. Users can set Range by the function of OUTPUT: More Setting. This parameter controls the power stage relay for parallel (range 150V) or series (range 300V) for more current or higher voltage. AUTO range indicates the output range will change between 150V and 300V automatically as need.

Set the output voltage range to 150V as instructed below.

- 1. Press Range at the bottom.
- 2. Turn the RPG to change "300V" to "150V" and press **ENTER**.








The output voltage will set to 0V before the range changes to eliminate the peak voltage; and then set the output voltage. Please note that it may cause the UUT to be suspended and/or damaged when changing the range.

3.3.1.3 Setting 3-phase Output

Press Three Phase Setting to enter into the function as shown below.


Edit: All, Each.

Press Edit to set "Each" or "All" for 3-phase output voltage limit.




Sequence: Positive, Negative.


For example, the phase difference degree of 3-phase in positive balance is 120 degrees as shown below.



Press Sequence to set the Positive/Negative sequence for AC Source's 3-phase voltage output. The following lists the procedure to set the 3-phase output voltage sequence to Negative.

- 1. Press Sequence on the right.
- 2. Use RPG to select "Negative" and press **ENTER**.






Three Phases: Independ, Same Freq, Balance.


Press Three Phases to set the relationship among the AC Source 3-phase output voltage, which are Independ, Same Freq and Balance.

Following lists the procedure to set the same frequency for 3-phase voltage output.

1. Press Three Phases on the right.


Use RPG to select "Same freq" and press ENTER.





When 3-phase balance is in use, the user may set the output voltage to be Phase Volt. or Line Volt. Below is the procedure for setting the 3-phase voltage output to 3-phase balance.


- 1. Press Three Phases on the right.
- Use RPG to select "Balance" and press ENTER.
- 3. Press Voltage set on the right.
- 4. Use RPG to select "Line" and press **ENTER**.



Phase re-lock: Enable, Disable.

Phase re-lock is used to lock the phase again. Since the output voltage and frequency are set separately when the AC Source is in 3-phase mode, users can set the 3-phase for different frequency output. Assuming the 3-phase output frequencies are varied and users set them to the same when the phase re-lock function is disabled, the phase difference of the 3-phase output does not return to default (each phase difference is 120°) as Figure 3-3 shows. The phase difference of 3-phase output will return to default (each phase difference is 120°) as Figure 3-4 shows when the phase re-lock function is enabled.

Press Phase re-lock on the right to enable or disable the function.






Figure 3-3 Phase Re-lock Disabled




Figure 3-4 Phase Re-lock Enabled


3.3.1.4 Output Degree

The AC Source can control the degree of the waveform during output or when stopping the output. In MAIN PAGE (3_Phase Mode/1_Phase Mode) (see 3.3) press OUTPUT: More Setting on the right to set ON Degree and OFF Degree.

Following lists the procedure for setting the output phase degree to ON Degree = 90 and OFF Degree=180 in 1_Phase/3_Phase Mode.

- 1. Press OUTPUT: More Setting on the right.
- 2. Move the cursor to "ON Degree= " command position.

- 3. Press **9**, **0**, and **ENTER** to change the value to "90.0".
- 4. The cursor moves to "OFF Degree=" command position automatically.
- 5. Press 1, 8, 0, and ENTER to change the value to "180.0".







If "OFF Degree=IMMED" when **QUIT** is pressed, the output voltage jumps off immediately. If a degree is already set, it will output voltage till it reaches the set degree. Input "OFF Degree= 360" will turn into "OFF Degree= IMMED".

3.3.1.5 Slew Rate of Output Transient

The AC Source has the ability to set the slew rate of the voltage waveform. This id done through 3 commands in OUTPUT: More Setting, which are Vac S/R, F S/R and Vdc S/R which control the change speed of voltage waveform change.

Vac S/R: It the slew rate of Vac output.


F S/R: It is the slew rate of frequency output.


Vdc S/R: It is the slew rate of Vdc output.

Change the output setting in MAIN PAGE when the AC Source is in OUT mode, the output voltage and frequency will change to follow the setting of Vac S/R, F S/R and Vdc S/R.

The procedure of setting Vac S/R =0.2, F S/R =0.1 and Vdc S/R =1 in 1_Phase/3_Phase Mode is described below.

- 1. Move the cursor to "Vac S/R =" command line.
- 2. Press | 0 |, ., 2 and ENTER to change the value to "0.2".
- 3. The cursor moves to "F S/R =" command automatically, press $\boxed{\mathbf{0}}$, $\boxed{\mathbf{1}}$ and $\boxed{\mathbf{ENTER}}$.
- 4. The cursor moves to "Vdc S/R =" command automatically, press 1 and ENTER.








- 1. When setting Vac S/R = 0, F S/R = 0, Vdc S/R = 0, the output transient outputs in the highest speed.
- 2. Though the input range of Vac S/R, F S/R, Vdc S/R is quite large when using the software editor, the output voltage may not apply the slew rate properly due to the hardware limit when the Vac S/R, F S/R and Vdc S/R are too large. The maximum of Vac S/R and Vdc S/R is 1200V/ms and the minimum is 0.001V/ms. The maximum of F S/R is 1600Hz/ms and the minimum is 0.001Hz/ms.
- 3. When executing **OUT** on the AC Source the output will reach the final state as set. Once QUIT is executed, the output turns to 0V immediately. If users wish to output the set slew rate to 0V, it is necessary to key in 0V and press **ENTER** instead of pressing **QUIT** directly.


3.3.1.6 Output Degree of 3-phase Voltage Output

On the other hand the AC Source is able to set the phase difference degree for 3-phase output voltage. For instance the phase difference among the 3 phases is 120 degree for the output voltage with 3-phase balance positive sequence as the figure shown below.



Following lists the procedure for setting the output voltage to 3-phase balance with 120 degree phase difference among the 3 phases.

- 1. Move the cursor to "Phase angle 1-2 =" command line.
- 2. Press 1, 2, 0 and ENTER.
- 3. Move the cursor to "Phase angle 1-3 =" command line.
- 4. Press **2**, **4**, **0** and **ENTER**.






Since the 3-phase voltage output of the AC Source is running independently, it is able to set the phase difference of 3-phase output to unbalance, such as Phase angle 1-2 = 100, Phase angle 1-3 = 200.


3.3.2 Measurement Setting


Press Measurement Setting on the right in MAIN PAGE (3_Phase Mode/1_Phase Mode) to set the measurement as the figure shown below. There are 12 measurement items in the setting screen such as voltage, current, output power and etc. The setting is done by moving the cursor to each item and use the RPG to select the required test item and press **ENTER**.

Below is procedure to change the 3rd measurement item from Po to VA in 3-phase mode.

- 1. Press Measurement Setting on the right in MAIN PAGE (3_Phase Mode).
- 2. Move the cursor to "Po".
- 3. Use the RPG to select "VA" and press **ENTER**.
- Press to return to MAIN PAGE.









Below is the procedure to the 2nd measurement item from I to lac in 1 phase mode.

- 1. Press Measurement Setting on the right in MAIN PAGE (1_Phase Mode).
- 2. Move the cursor to "I".
- 3. Use the RPG to select "lac" and press **ENTER**.
- Press to return to MAIN PAGE.







١.	Pha	s e	3 (00V	LOCAL		QUI	T	
Т				OUTPU					Main
	Vac	=	0	. 0V	F =	60.	0Hz		OUTPUT: More Betting
				5000					Measurement Setting
					SUMEHENT				entresa.
	٧	=	0	.00	Po	=		0.0	Waveform
	lac	=	0 .	000	PF	=	0.	000	Viewer
	Vac	=	0	.00	Vdc	=	0	.00	
	lac	=	0.	000	ldc	=	0.	000	Limitation
	Vpk	=	0	.00	VA	=		0.0	
	lpk	=	0.	000	CF	=	0.	000	-
			_		and		-1111/7		
7000	CH1	Rec		Recall CH3	Recell CH4		ecell HS	More 1 of 2	2008/10/13 19:05:35

3.3.2.1 Current Range

Press Current Range at the bottom can set the current detection range. Setting appropriate current range will result in a more accurate current measurement. The current value of each range is the maximum value it can detect. If the output current is larger than the maximum current the range can detect, the screen will show I = OVRange. The current detection ranges are listed below.

61612:


Φ1 Range: 12A, 48A, 192A, Auto. Φ2 Range: 12A, 48A, 192A, Auto. Φ3 Range: 12A, 48A, 192A, Auto.

61611:


Φ1 Range: 8A, 32A, 128A, Auto. Φ2 Range: 8A, 32A, 128A, Auto. Φ3 Range: 8A, 32A, 128A, Auto.

The procedure for setting the current detection range of the 1st phase to 12A is described below:

- 1. Press Current Range at the bottom.
- 2. Press Φ1 Range on the right.
- 3. Turn the RPG to change to "12A" and press **ENTER**.







3	Pha	se	300V	LOCAL	QUI	T	
т			OUTPUT	SETTING			Setting
#1	Vac		0.0V	F =	60.0	Hz	#1 Range
#2	Vac	-	0.0V	E =	60.0	Hz	12A
# 3	Vac	=	0.0V	F =	60.0	Hz	
			HEASUREHE	INT SETTING			
d	V	_ VA	Vac	Vdc	Vpk	VA	#2 Range
#1	1	PF	lac	ldc	lpk	CF	192A
	V	Po	Vac	Vdc	Vpk	VA	
₩2	1	PF	lac	ldc	lpk	CF	
33	٧	Po	Vac	Vdc	Vpk	VA	#3 Range
8 2	T	PF	lac	Idc	lpk	CF	192A
gi	V 12	V 31	V 12	V 31	17		
I	V22	Po	V23	VA			
	Corrent Range	Average Times	Isurge Delay 10es	isurge interval tims	Edit Each		2008/10/13 19:06:52

3.3.2.2 Average Times

Average Times is the sampling average of voltage/current RMS and voltage/current peak. The AC Source uses moving windows for sampling. When "4" is selected for Average Times it indicates it will be sampling 4 times in moving windows.

Press Average Times at the bottom to set the average times for sampling. When the measurement is fluctuated severely, higher sampling average times can be set to improve the measurement accuracy. The average times for sampling to be set are listed below.

Average Times: 1, 2, 4, 8, 16, 32.

The steps for setting the sampling average times to 1 are described below.

1. Press Average Times at the bottom.

2. Turn the RPG to switch to "1" and press **ENTER**.




3.3.2.3 Isurge Delay, Isurge Interval

The Isurge in Measurement Setting is the surge peak current output by the AC Source. Isurge measurement starts after Isurge Delay when the voltage output changes. The measurement time is set by Isurge Interval. These two functions can be set by Measurement Setting.

The procedure for setting Isurge Delay = 10 ms, Isurge Interval = 10 ms is described below.

- 1. Move the cursor to "Isurge Delay =" command line.
- 2. Press | 1 |, | 0 | and |ENTER | to change the value to "10.0".
- 3. Move the cursor to "Isurge Interval =" command line.
- 4. Press 1, 0 and ENTER to change the value "10.0".





3.3.3 Waveform Viewer

Waveform View can be used to see the real time output voltage/current waveform. There are a total of 3 CH available. Voltage, current and time can be adjusted by the Scale command. The figure below shows the Waveform View.


Ch1: Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I. **Ch2:** Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I. **Ch3:** Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I.

V Scale: 10, 20, 40, 80, 120V/div. **I Scale:** 5, 10, 20, 40, 60A/div.

Time Scale: 0.2, 0.5, 1, 2, 5, 10, 50, 100, 200ms/div.

The procedure for setting CH1 = Φ 1V, CH2 = Φ 2V, CH3 = Φ 3V, V Scale = 10 V/div, I Scale = 5A/div, Time Scale =2 ms/div in 1_Phase/3_Phase Mode is described as below.

- 1. Press CH1 at the bottom.
- 2. Turn the RPG to change to "Φ1V" and press **ENTER**
- Press CH2 at the bottom.
- 4. Turn the RPG to change to "Φ2V" and press **ENTER**.
- 5. Press CH3 at the bottom.
- 6. Turn the RPG to change to "Φ3V" and press **ENTER**.
- 7. Press V Scale at the bottom.
- 8. Turn the RPG to change to "10" and press **ENTER**.
- 9. Press I Scale at the bottom.
- 10. Turn the RPG to change to "5" and press **ENTER**.
- 11. Press Time Scale at the bottom.
- 12. Turn the RPG to change to "2" and press **ENTER**.



3.3.4 Limitation

The Limit of AC Source 1-phase/3-phase output mode is set separately. For instance, the Vac Limit setting will apply the settings of the 1-phase mode when changing it from the 3-phase mode without applying the Limit settings of any one phase.


3.3.4.1 Vac Limit

Vac Limit sets the Vac value in MAIN PAGE (3_Phase Mode/1_Phase Mode). Press Limitation on the right in MAIN PAGE (3_Phase Mode/1_Phase Mode) to set the Vac Limit. This command protects the planned program instead of the hardware.

Press Edit at the bottom to set the limitation of the 3-phase voltage output for "Each" or "All".

The procedure to set Vac Limit = 300V in 1_Phase/3_Phase Mode is described below.

- 1. Move the cursor to "Vac =" command line.
- 2. Press 3, 0, 0 and ENTER to change the value to "300.0".



Notice


The setting of Vac Limit is not restricted by range; however, the Vac in MAIN PAGE is restricted by the range. For example, assuming the range is 150V, though Vac Limit = 300V the maximum Vac setting is 150V.

3.3.4.2 Vdc Limit (+), Vdc Limit (-)

Vdc Limit (+) and Vdc Limit (-) restrict the Vdc setting in MAIN PAGE (3_Phase Mode/1_Phase Mode). These two items can be set in the Limitation function (see 3.3.4). The Vdc setting can exceed Vdc Limit (+) but cannot be under Vdc Limit (-).

The procedure for setting Vdc (+) = 424.2V, Vdc (-) = 0V in 1_Phase/3_Phase Mode is described below.

- 1. Move the cursor to "Vdc (+) = " command line.
- 2. Press 4, 2, 4, ., 2 and ENTER to change the value to "424.2".
- 3. Move the cursor to "Vdc (-) =" command line.
- 4. Press **0** and **ENTER** to change the value to "0.0".





- 1. The setting of Vdc Limit is not restricted by range; however, the Vdc in MAIN PAGE is restricted by the range. For example, assuming the range is 150V, though Vdc Limit=424.2V the maximum Vdc setting is 212.1V.
- It is better to restrict the Vdc value when the output contains it. It
 may cause damage if the output polarity is reversed especially the
 load polarity.

3.4 CONFIG Function Key

Press **CONFIG** in the **FUNCTION** keys shown below to enter into CONFIG function. (3 Phase Mode/1 Phase Mode).





Figure 3-5 FUNCTION Keys






3.4.1 Interface

3.4.1.1 GPIB Address, RS-232C Parity/Baudrate

The AC Source also has remote operation mode that can be activated by the CONFIG function (3_Phase Mode/1_Phase Mode). It is necessary to set GPIB Address to 30 before conducting remote operation in 1_Phase/3_Phase Mode.

- 1. Press GPIB Address at the bottom.
- 2. Turn the RPG to change the Address and press **ENTER** to set Address 30.






Notice

The address range is from 1 to 30.


The AC Source uses the RS-232C bus to provide remote operation. Follow the steps below to set the communication protocol.


Set Parity=None and Baudrate =115200 in 1 Phase/3 Phase Mode as described below:

- Press RS232 Parity at the bottom.
- 2. Turn the RPG to select None and press **ENTER**.
- Press RS232 Baudrate at the bottom.
- Turn the RPG to "115200" and press ENTER.



3	Pha	se	3	00V	LOC	AL	(ו טב	T	
				OUTPUT	SETTI	VC.				Config
*1	Vac	=	- (0.0V	F	=	60	0.0	Hz	
82	Vac	=	(0.0V	F	Ŧ	60	0.0	Hz	Interface
# 3	Vac	=	- (0.00	F	=	60	0.0	Hz	External
				HEAS	UNEMENT					Vief
	٧	=	- (0.00	V	4 :			0.0	1 9005
#1	1	=	0	000	PI			0 .	000	Display
	٧	=	. (0.00	Po	:	=		0.0	PowerON
₩2	1	=	0	000	PI		=	0 .	000	Status
	٧	=	- (0.00	Po				0.0	September 1
8 3	1	=	0	000	PI		=	0.	000	Protection
gi	V 12	=	(0.00	V ₂			0	.00	Hore
Ŧ	V22		_ (00.0	Po				0.0	1 of 2
	SPIB ddress 30	Par No	ity	RB232 Baudrate 115200	Rem Inhi Di sa	bit	ON/O	OFF	Ethernal Setting	2008/10/13 19:18:19







The baudrate selections are 9600/19200/38400/57600/115200 and the selections for parity are EVEN/ODD/NON.

3.4.1.2 Remote Inhibit, EXT. ON/OFF


The output of AC Source can be inhibited by external control or manual trigger. The output signal of the remote inhibit (remote control) is received from the TTL terminal on the rear panel (see *Appendix A*.) Remote Inhibit and EXT. ON/OFF are set by the CONFIG function (3_Phase Mode/1_Phase Mode). There are two remote inhibit output states: Enable and Disable.

Remote Inhibit: When the Remote Inhibit is enabled on the AC Source and the Remote Inhibit signal is LOW the AC Source will disable the output. The AC Source holds the output disabled even when the Remote Inhibit signal turns to HIGH. In order to re-enable the output, the user must press **OUT/QUIT** to restart output.


EXT. ON/OFF: When the EXT. ON/OFF is enabled on the AC Source and the EXT. ON/OFF signal is LOW the AC Source will disable the output. The AC Source will re-enable the output when the EXT. ON/OFF signal turns to HIGH.


The procedure for setting Remote Inhibit/EXT. ON/OFF to disable in 1_Phase/3_Phase Mode is described below.

- 1. Press Remote Inhibit/EXT. ON/OFF at the bottom.
- 2. Turn the RPG to change to "Disable" and press **ENTER**.











The output of the Remote Inhibit (Remote Control) transmits the TTL signals via a special I/O connector. See *Appendix A* for the detail TTL signal pin assignments.

3.4.1.3 Ethernet Setting

The AC Source can be operated remotely through a network once the Ethernet Settings are complete.


Network Setting: Auto, Manual


The procedure for setting Network Setting s manually in 1_Phase/3_Phase Mode is described below.

- 1. Press Ethernet setting at the bottom.
- 2. Move the cursor to "Network Setting:"
- 3. Turn the RPG to change to Manual and press **ENTER**.
- 4. Set the IP Address, Net Mask and Gateway.




3	Pha	se	300V	LOCAL	QUI	T	
			OUTPO	T SETTING			Config
*1	Vac	=	0.0V	F =	60.0	Hz	
e 2	Vac	=	0.0V	F =	60.0	Hz	Set
# 3	Vac	=	0.0V	F =	60.0	Hz	
			Name of Street, Square, Street,	RK SETTING			
	Networ	a Sett	ing:Manual				
	IP Add	ress :	255 . 265 .	255 . 255			
	Not Me	sk :	255 , 255 ,	255 . 255			
	Gatema	y :	255 . 255 .	255 . 255			
	LAN St	etus =	SETTING	41			
	SPIB	RS2		Remote	EXT.	Ethernet	2008/10/13
٨	ddress 30	Pari Non	**************************************	7	Disable	Setting	19:21:59









3.4.2 External Vref

The AC Source has the capability of using an analog control signal (simulated) from an external device to set its output (optional card is required.) The External Vref terminal socket at the rear panel allows users to apply signals to the AC Source for output voltage setting. The External Vref and the Control Method can be set by the CONFIG function (3_Phase Mode/1_Phase Mode). External Vref has two coupled modes to indicate the output of AC Source: Amplifier and Level. When the user is using single phase Ext. Vref, the signal inputted by terminal pin Ext-V Φ 2 is the main control signal. Refer to *Appendix A TTL Signal Pin Assignments* for detail information.

Amplifier: The output voltage (Vout) is the composition of the voltage set in MAIN PAGE and the supplemental programmed voltage inputted externally. The external V reference voltage range is from -10 V to 10V. When Vac=0 and Vdc=0 in MAIN PAGE, the following formula can be used to calculate Vout.

```
Vout (dc) = Vref (dc) / 10 Vdc \times 424.2 Vdc (range 300V) Vout (dc) = Vref (dc) / 10 Vdc \times 212.1 Vdc (range 150V) or Vout (ac) = Vref (ac) / 7.072 Vac \times 300 Vac (range 300V) Vout (ac) = Vref (ac) / 7.072 Vac \times 150 Vac (range150V)
```

Ex. (1): Set Vout to 100Vdc:

- 1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is V= 2.357Vdc, Vout = 100Vdc.
- 2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is V= 4.715Vdc, Vout = 100Vdc.

Ex. (2): Set Vout to 100Vac:

- 1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is V= 2.357Vac, Vout = 100Vac.
- 2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is V= 4.715Vac, Vout = 100Vac.

Level: It is the linear proportional output of output voltage (Vout (ac)) RMS programmed by the DC V reference. The Vreference range is from -10V to 10V. The following formula can be used to calculate Vout:

```
Vout (ac) = | \text{Vref (dc)} | / 10 \text{ Vdc} \times 300 \text{Vac (range 300V)}
Vout (ac) = | \text{Vref (dc)} | / 10 \text{ Vdc} \times 150 \text{Vac (range 150V)}
```


Ex. (1): Set Vout to 100Vac:

- 1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is V= 3.333Vdc (or -3.333Vdc), Vout = 100Vac.
- 2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is V= 6.667Vdc (or -6.667Vdc), Vout = 100Vac.


The procedure for setting Ext. Vref Control = OFF, Control Method = Amplifier is described below.

- 1. Press Ext. Vref Control at the bottom.
- 2. Turn the RPG to change ON to OFF and press **ENTER**.
- 3. Press Control Method at the bottom.

4. Turn the RPG to select Amplifier and press **ENTER**.



3	Pha	se	300V	LOCAL	QUIT	
т			OUTPL	IT SETTING		Config
#1	Vac	=	0.0V	F =	60.0Hz	1000100
#2	Vac	=	0.0V	F =	60.0Hz	Interface
# 3	Vac	=	0.0V	F =	60.0Hz	External
			HEA	SUMEMENT		Visit
3	٧	=	0.00	VA	= 0.0	2003
#1	1	=	0.000	PF	= 0.000	Display
	٧	=	0.00	Po	= 0.0	PowerON
₩2	1	=	0.000	PF	= 0.000	Status
33	٧	=	0.00	Po	= 0.0	1000000000
8 2	1	=	0.000	PF	= 0.000	Protection
gi	V 12	=	0.00	V 31	= 0.00	More
I	V22		0.00	Po	= 0.0	1 of 2
	xt.Vref Control	Cont Medi Amp I i	bod			2008/10/13 19:23:58



5. Press Exit to return to the Main screen. The output parameter F for measurement frequency should be the same as the Ext.V input frequency.



When Ext. Vref Control =ON, Control Method =Level, the output voltage (Vout) can only be controlled by the level of the external DC programming voltage. It is unable to control the Vout amplitude from the front panel keys until Ext. Vref Control=OFF is set.

⚠WARNING

- When Control Method = Amplifier and the Vref frequency exceeds 1500Hz, it could damage the AC Source. This formula should be followed exactly – Vref (pk-pk, V) × F (Vref, Hz) < 10000 VHz.
- The output may be distorted due to the bandwidth restriction of AC Source, especially when the external V reference has too many high frequency components.
- When the input voltage range is over ±10V (it could damge the AC Source if the input signal voltage exceeds ±12V), the AC Source will trigger Over Voltage Protection (OVP).

3.4.3 Display

The brightness of the backlight and power save mode settings of the LCD can be set in the CONFIG function. (3_Phase Mode/1_Phase Mode).

Style: Default.

Backlight: Low, Medium, High.

Backlight OFF after: Never, 1 min, 3 mins, 5 mins, 10 mins, 30 mins, 1 hour, 3 hours.

The procedure for setting Backlight = Medium, Backlight OFF after = Never in 1_Phase/3_Phase Mode is listed below.

1. Press Backlight at the bottom.

2. Turn the RPG to Medium and press **ENTER**.

3. Press Backlight OFF after at the bottom.

4. Turn the RPG to select Never and press **ENTER**.

3	Pha	se	3	00V	LOC	AL		QUIT	
т				OUTPUT	SETTI	VC.			Config
	Vac	=	- 31	0.0V	F	=	6	0.0Hz	
e 2	Vac	=	- 3	0.0V	F	=	6	0.0Hz	Interface
83	Vac	=	- 31	0.0V	F	=	6	0.0Hz	External
				HEAS	UNEMENT				Vief
	٧	=	- 81	0.00	V	A	=	0.0	200
#1	1	=	0	.000	PI	Ē.	=	0.000	Display
	٧	=		0.00	Po		=	0.0	PowerON
62	1	=	0	.000	PI	Ē	=	0.000	Status
	٧	=		0.00	Po		=	0.0	99505W897
B2	T	=	0	.000	PI	F	=	0.000	Protection
	V 12	=		0.00	V	t.	=	0.00	More
Σ	V22		_3	0.00	Po		=	0.0	1 of 2
	Style lotsult	Back Med		Backlight OFF after Never					2008/10/13 19:25:03


	Pha	se	3	00V	LOCAL		QUIT	
Ī				OUTPU				Config
	Vac		(0.0V	F =	60.	0Hz	Interface
								External Vief
				HEAD	DUREMENT			- Villa
	٧	=	- (0.00	Po	=	0.0	2000
	lac	=	0	.000	PF	=	0.000	Display
	Vac	=		0.00	Vdc	=	0.00	PowerON
	lac	=	0	.000	ldc	=	0.000	Status
	Vpk	=	- (0.00	VA	=	0.0	Section 1
	lpk	=	0	.000	CF	=	0.000	Protection
								More 1 of 2
	Style lotsult	Back Med		Backligh OFF afte Never				2008/10/13 19:24:39

3.4.4 Power ON Status

Users can set the output state of AC Source during power on using the Power ON Status in the CONFIG function (3_Phase Mode/1_Phase Mode). Once it is set users should save the data before power off. With the output sets to Off, it indicates the AC Source will not enable the output voltage after it is powered on. With it sets to On the AC Source will enable the output by default after powered on.

3	Pha	se	300V	LOCAL	QUIT	
Т			OUTPU	T SETTING		Config
*1	Vac	=	0.0V	F =	60.0Hz	Interface
82	Vac	=	0.0V	F =	60.0Hz	Miteriace
B 3	Vac	=	0.0V	F =	60.0Hz	External
			POWER ON S	TATUS SETTI	на	Vief
	Vac		0.0V	F =	60.0Hz	Display
•1	Vdc	=	0.07			2000 200
	Vac	=	0.0V	F =	60.0Hz	PewerON Status
12	Vdc	=	0.0V			Protection
	Vac	=	0.0V	F =	60.0Hz	10/2000000
13	Vdc	=	0.00			More 1 of 2
	Output Of f	Edit				2008/10/13 19:25:31

3	Pha	se	300V	LOCAL	QUIT	
			OUTPO	T SETTING		Config
#1	Vac	=	0.0V	F =	60.0Hz	4.0004.000
82	Vac	=	0.0V	F =	60.0Hz	Interface
# 3	Vac	=	0.0V	F =	60.0Hz	External
			POWER ON	STATUS SETT	на	Vief
	Vac	=	0.00	F =	60.0Hz	Display
*1	Vdc	=	0.00			
	Vac	=	0.00	F =	60.0Hz	PowerON Status
₩2	Vdc	=	0.0V			Protection
	Vac	=	0.0V	F =	60.0Hz	100000000
₩3	Vdc	=	0.00	37		More 1 of 2
	Output O11	Edit Each				2008/10/13 19:25:52




3.4.5 Protection

The AC Source's Protection for 1-phase/3-phase output mode is set separately. For instance, the Protection will apply the settings of 1-phase when switching from 3-phase to 1-phase mode rather than the Protection settings of any phase under 3-phase mode.

The Protection in the CONFIG function (3_Phase Mode/1_Phase Mode) is able to set the limit of the output RMS current (OCP), output power (OPP) and the Delay Time for triggering the current protection. The limit in this command is to protect the program instead of the hardware.

Following shows the procedure of setting the current limit = 48A (32A for 61611), power limit = 6000W (4000W for 61611), delay time = 3 sec. for 61612 in 3_Phase Mode.

- 1. Move the cursor to "OCP =" command line.
- 2. Press 4, 8 and ENTER to change the value to "48.0".
- 3. Move the cursor to "OPP =" command line.
- 4. Press | **6** | **0** | **0** | **0** | **0** | **ENTER** to change the value to "6000.0".
- 5. Move the cursor to "Delay time =" command line.
- 6. Press | 3 | ENTER to change the value to "3.0".



Following shows the procedure of setting the current limit = 144A (96A for 61611), power limit = 18000W (12000W for 61611), delay time = 3 sec. for 61612 in 1 Phase Mode.

- 1. Move the cursor to "OCP =" command line.
- 2. Press 1, 4, 4 and ENTER to change the value to "144.0".
- 3. Move the cursor to "OPP =" command line.
- 4. Press 1,8,0,0,0, ENTER to change the value to "18000.0".
- 5. The cursor moves to "Delay time =" command line automatically."
- 6. Press **3**, **ENTER** to change the value to "3.0".

1	Phase	300V	LOCAL	QUI	T	
т			T SETTING			Config
	Vac =	0.0V	F = 6	0.0Hz		Interface
			n pomilo de la comp			External
	900	The second second second second	ION SETTING			
	OCP =_ OPP =1	<u>144.0</u> A 8000.0V	V			Display
	Delay	time =	3.0s	ec		PowerON Status
						Protection
						More 1 of 2
				Set to Maximum	Set to Hinimum	2000/10/13 19:28:00



- 1. When "OCP = 0.0 A", it means the limit of output current equals to the specification limit.
- 2. The setting of the delay time for trigger current protection is only valid when the current is within the specification. When the output is over the specification, the time delay set between 0.1 and 1s for triggering current protection is valid. However, if the current is over the output specification and the protection delay time is set more than 1s, the 1s will be the maximum delay protection time. The resolution is 0.1s.



The protection point varies by the measurement error, thus it may act before reaching the protection point set.

3.4.6 Others

Press MORE on the right in CONFIG function (3_Phase Mode/1_Phase Mode) to go to the second page and press Others on the right to set Output Relay, Buzzer and Date/Time.

Output Relay: Depend, Always ON.

Buzzer: on, off.

Date/Time: Year, Month, Day, Hour, Minute, Second.







The output circuit on the AC Source has a relay to connect to the load. When the output relay is "Always ON", it indicates the output relay is closed (connected) even if the AC Source output state is in QUIT mode. When the output relay is "Depend." the output relay is closed (connected) only when the output state is in OUT mode. If the output state is in QUIT mode, the output relay will be opened (disconnected.)

The procedure for setting the output relay to Always ON in 1_Phase/3_Phase Mode is described below.

- 1. Press Output Relay at the bottom.
- 2. Turn the RPG to set the output relay to Always ON and press **ENTER**. When the output relay is working, the AC Source will click once.








Check if the AC Source has voltage output before powering it off. To ensure the safety of hardware, it is prohibited to power off the AC Source in Output state.

Next, the AC Source buzzer beeps when the panel keys are pressed or the RPG rotary is turned. If the user does not want the buzzer active, it may be turned off.

Following procedure describes the procedure for turning off the buzzer in 1_Phase/3_Phase Mode.

- 1. Press Buzzer at the bottom.
- 2. Turn the RPG to change ON to OFF and press **ENTER**.




At last, set the time and date of AC Source.

Date/Time: Year, Month, Day, Hour, Minute, Second.

Follow the procedure below to set the time and date in 1_Phase/3_Phase Mode.

- 1. Press Date/Time at the bottom.
- 2. Select the item (Year/Month/Day/Hour/Minute/Second) to be set and press the button on the right.
- 3. Use the RPG to change the selected item and press **ENTER**.




3.4.7 Calibration

For detail calibration procedure please refer to the description in Chapter 4.


3.4.8 System Information

Press MORE on the right in the CONFIG function (3_Phase Mode/1_Phase Mode) to go to next page. Press System Information on the right to see the system information of the AC Source.



3.4.9 Factory Default

Press MORE on the right in the CONFIG function (3_Phase Mode/1_Phase Mode) to go to next page. Press Factory Default on the right and Yes at the bottom to return to the factory default.



3.5 PHASE Function Key


Press **PHASE** function key in Figure 3-5 to go to the switch 3_Phase Mode/1_Phase Mode.

3.5.1 3 Phase Mode

The AC Source can be set to 3-phase AC power by pressing the **PHASE** function key to switch to 3_Phase Mode when it is required.

The procedure for setting the AC Source to 3-phase mode is described below.

- 1. Press **PHASE** function key.
- 2. Press Three 3_PHASE on the right.
- 3. Press Yes on the right to confirm the change.




3.5.2 1 Phase Mode

When the 3-phase power of the AC Source is not enough to drive the load, the 3-phase output can be parallelled to one of the phases. Pressing the **PHASE** function key can change the AC Source setting from 3-phase to 1-phase.

The procedure for setting the AC Source to 1-phase mode is described below.

- 1. Press **PHASE** function key.
- Press Single 1_PHASE on the right.
- 3. Press Yes on the right to confirm the change.





When switching between 1-phase and 3-phase mode, the set output value will be reset to zero to avoid damaging the Unit Under Test (UUT).


3.6 CURSOR Function Key


Press **CURSOR** function key in Figure 3-5 to set the value of a single digit.

The RPG can be used to set the digit of hundred, decade, figure and 1st place after the decimal point for voltage or frequency to save time in inputting the values.

The procedure for setting the 1st place after the decimal point for output voltage Vac in 1 Phase/3 Phase Mode is described below.

- 1. Move the cursor to "Vac =" command line.
- 2. Press **CURSOR** function key.
- 3. The cursor will shorten to one digit range.
- 4. Move the cursor to the 1st digit after decimal point and use the RPG to change the value.
- 5. Press **CURSOR** function key again to exit it.







3.7 LOCK Function Key

Press **LOCK** function key in Figure 3-5 to lock the function.

Press this key to lock all functions on the panel and making all keys invalid. Press **LOCK** for 3 seconds to unlock it.






3.8 OUTPUT Function Key

Please refer to 3.3.1 for the detail description of OUTPUT function key.

3.9 LOCAL/REMOTE Function Key

Press **LOCAL/REMOTE** function key in Figure 3-5 to switch to remote control.

When the AC Source is in REMOTE state and controlled by an external device, press this key to release the REMOTE state and return to LOCAL control.




3.10 SAVE/RECALL Function Key


The AC Source has two modes for users to save and recall the output setting or system information as described in section 3.10.1 and 3.10.2. Press **SAVE/RECALL** function key in Figure 3-5 to access the save and recall functions.

3.10.1 Save/Recall Output Setting

The AC Source has 10 channels for users to save the frequently used Vac, F and Vdc for recall. For example, enter the setting and save it to CH1 memory in MAIN PAGE (3_Phase Mode) (see 3.3.)



٠.	Pha	5 e	301	UV	LUC	AL.	- 3	ųυ		
т				OUTF	UT SETTI	NO				Baye/Rocal
*1	Vac	=	0	. 0 V	F	=	6	0 .	0Hz	Save
e 2	Vac	=	0	. 0 V	F	=	6	0 .	0Hz	Output Setting
# 3	Vac	=	0	. 0 V	F	=	6	0.	0Hz	Saye
				CHA	INNEL DAT	A				Bystem Date
	Vac =	0.0V	E		60.0Hz	Vdc		0.00	1	
1	Vac .	0.07			60.0Hz	Vdc		a, av		
	Vac +	0.07	F		60.0Hz	Véc		0.04	1	
	Vec =	0.09	F.		60.0Hz	Vde		0.09	r .	Recall
2	Vac .	0.07	F .		60.0Hz	Vác		0.04	1	Output
	Vec #	0.04	E.		60.0Hz	V4c		0.04	t.	Setting
	Vac =	0.09	F		60.0Hz	Vée		0.0	f	
3	Vec .	0.0V	F.		60.0Hz	Vác		a.av	1	Recall
	Vec *	0.07	F.		60.0Hz	Véc		0.04	6	System Data
	Vec *	0.0V	F		60.0Hz	Vée	#	0.00	<i>l</i> .	
4	Vac +	0.0V	F		60.0Hz	Vdc		a.av	č.	
	Vac *	0.0V	_ F		60.0Hz	Vác		0.QV		_
S	eve to CRH	Save 1	la	Save	12.	e to			More	2008/10/13








- 1. Only the save and recall settings are set in MAIN PAGE. Other parameters are ignored.
- In different output coupling modes (see 3.3.1.1) the missing settings will be adjusted to Vac=0V, F=60Hz, Vdc=0V automatically. For example, when executing save in DC output mode Vac=0V, F=60Hz, Vdc is the setting in MAIN PAGE.

3.10.2 Save/Recall System Data

The AC Source has 10 groups of memory for users to save and recall system data. System data contains all parameters in the function keys such as MAIN PAGE (see 3.3) and CONFIG (see3.4). Press **SAVE/RECALL** in MAIN PAGE (3_Phase Mode) (see 3.3) and press the LCD at the bottom to save the system data as shown below.











The AC Source has 11 groups of memory: GROUP 0, GROUP1~10. GROUP 0 will save the power-on default. The data saved in GROUP 0 will be recalled automatically and loaded when the AC Source powers on again. As to the data saved in GROUP 1~10 memory groups, they need to be called manually for loading.

3.11 Protection

The AC Source has both software and hardware protection. When protection occurs the AC Source will stop the output and disconnect the output relay. The display shows that the source is in protection mode. To return to normal output after the protection is triggered, please address any issues and press **ENTER** to release protection for normal operation.

The table below lists the software protection:

Protection	Description
OCP	It occurs when output current exceeds the limit or specification.
OPP	It occurs when output power exceeds specification.
OVP	It occurs when output voltage exceeds the limit of each range.
Remote - Inhibit	It executes remote inhibit.

The table below lists the hardware protection:

Protection	Description
FAN - FAIL	It occurs when the cooling fan is out of order.
INT - AD	It is the internal AD power stage protection indicating the output voltage is over or under the specification.
INT - DD	It is the internal DD power stage protection indicating the output voltage is over or under the specification.
INT - LINE	It occurs when the line input voltage is over or under specification.
SHORT	It is the short circuit protection.
OTP	It occurs when the AC Source's internal temperature is too high.





The protection point varies by the measurement error, thus it may act before reaching the protection point set.

4. Calibration

4.1 Introduction

The AC Source has a simple procedure built in to calibrate the output and measure the accuracy without opening the chassis. Users simply need to follow the procedure step by step for operation. A voltage meter, current meter and an adequate load with a +5V DC power supply are required to perform the calibration. For the connections of these instruments please refer to Figure 4-1. There are 3 items required for calibration: output voltage, output current and external reference voltage. However, they don't need to be calibrated at the same time. Select one of them for calibration is needed.





Figure 4-1



When in the ambient temperature 25°C, it needs to warm up for 20 minutes before calibration to allow the device internal to reach the normal operation temperature and ensure the calibration is correct.

4.2 Manual Calibration


Select "Calibration" in CONFIG function (3_Phase Mode/1_Phase Mode) to input the calibration procedure. Before any calibration items appear, users have to input a password to eliminate accidental input. The password is included in the manual to ensure users read this manual before executing the calibration procedure.






- 1. The password for calibration procedure is "3621", press **ENTER** to confirm it.
- 2. Users should read the procedure clearly before calibrating the AC Source, or partial memory data could be lost due to incorrect operation.

Once the correct password is entered, the LCD shows that the calibration procedure can only be running in 3-phase mode and is prohibited in 1-phase mode. Press **ENTER** to continue the calibration procedure.



Next users can select the voltage, current and external reference voltage for calibration.




Voltage setting & Measure: This is the calibration for output voltage and measurement accuracy.

Current Measure: This is the calibration for current measurement accuracy.


External Vref.: This is the calibration of external Vref.

4.2.1 Output Voltage and Measurement Calibration

CALIBRATION CHOICE can be input after you enter the password, see section 4.2. Press Voltage setting & Measure at the bottom to calibrate the output voltage and measurement.




When in Voltage Setting & Measurement Calibration, the screen will ask the user if conducting the 150V Range Offset voltage calibration. Press **ENTER** to continue the offset voltage calibration and press **EXIT** to skip it to go into 150V Range Voltage Setting & Meas. calibration procedure.




For step A in 150V Range Offset voltage calibration procedure, users should use a Digital Voltage Meter (DVM) to measure the AC Source's output DC voltage with the unit of mV and key in the measured value to LCD. Keep monitoring the DVM readings and input/output of the DC voltage repeatedly until the DC output is lower than ±10 mV.




- 1. The Vdc offset can be positive or negative. Connect the positive terminal of DVM to the AC Source's Line output and the negative terminal to the AC Source's Neutral output as shown in Figure 4-1.
- 2. The load must be off for all of the steps in ACCURACY CALI under Voltage setting & Measure.



For step B in 150V Range Offset voltage calibration procedure, the display shows the difference between Vac and Vdc measured by the AC Source. It is generated by an internal component. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vac and Vdc calculated by the AC Source at present.




For step C in 150V Range Offset voltage calibration procedure, the display shows the 150V range offset voltage calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 150V range voltage setting and measurement calibration procedure.




In step C, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.




The AC Source calibration procedure can be executed separately; however, it is better to follow the calibration sequence step by step (step A, step B ...) or it may cause an output and measurement error.




Once the 150V Range Offset voltage calibration is done, the screen will ask the user if conducting the 150V Range Setting & Meas. calibration. Press **ENTER** to continue the Setting & Meas. calibration and press **EXIT** to skip it to go into 300V Range Offset voltage calibration procedure.




For step A in the 150V Range Setting & Meas. calibration procedure, the user should remove the load. Check if the output AC voltage measured by the DVM is about 15Vac. This is to confirm the connection is correct, and press **ENTER**.




For step B in the 150V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 120VAC. Input the correct value measured by the DVM and press **ENTER**.




For step C in the 150V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 150VAC. Input the correct value measured by the DVM and press **ENTER**.




For step D in 150V Range Setting & Meas. calibration procedure, the display shows the 150V Range Setting & Meas. calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 300V Range offset voltage calibration.




In step D, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.



Once the 150V Range Setting & Meas. calibration is done, the screen will ask the user if conducting the 300V Range Offset voltage calibration. Press **ENTER** to continue the Offset voltage calibration and press **EXIT** to skip it to go into 300V Range Setting & Meas. calibration.




For step A in the 300V range Offset voltage calibration procedure, users should use a Digital Voltage Meter (DVM) to measure the AC Source's output DC voltage with the unit of mV and key in the measured value to the LCD. Keep monitoring the DVM readings, and the input/output and the DC voltage repeatedly until the DC output is lower than ±10 mV.




For step B in the 300V range Offset voltage calibration procedure, the display shows the difference between Vac and Vdc measured by the AC Source. It is generated by an internal


component. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vac and Vdc calculated by the AC Source at present.




For step C in 300V range Offset voltage calibration procedure, the display shows the 300V range offset voltage calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 300V range voltage setting and measurement calibration procedure.




In step C, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.




Once the 300V Range Offset voltage calibration is done, the screen will ask the user if conducting the 300V Range Setting & Meas. calibration. Press **ENTER** to continue the Setting & Meas. calibration and press **EXIT** to skip it to go into the calibration main screen.




For step A in the 300V Range Setting & Meas. calibration procedure, the user should remove the load. Check if the output AC voltage measured by the DVM is about 30Vac. This is to confirm the connection is correct, and press **ENTER**.




For step B in the 300V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 240VAC. Input the correct value measured by the DVM and press **ENTER**.



For step C in the 300V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 300VAC. Input the correct value measured by the DVM and press **ENTER**.



For step D in 300V Range Setting & Meas. calibration procedure, the display shows the 300V Range Setting & Meas. calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue voltage calibration for other phases.




In step D, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.




- 1. Users can press **ENTER** at the last step to continue calibrating the 2nd and 3rd phase.
- 2. If **EXIT** is pressed without saving the result, the calibration result is kept till power-off.


4.2.2 Current Measurement Calibration

CALIBRATION CHOICE can be inputted after the password is entered, see section 4.2. Press Current Measure at the bottom to calibrate the current measurement.







For step A of ACCURACY CALI in Current Measure the display shows the difference of lac and ldc measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press **ENTER** the lac = 0.00A and ldc = 0.00A.




For step B users adjust the load to 2.5Ω for output and press **ENTER**, the AC Source will output 20Vac.




Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.




Press **ENTER** to continue the calibration procedure. The load will be disconnected at this time.




In step A the display shows the difference of lac and ldc measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press $\boxed{\textbf{ENTER}}$ the lac = 0.00A and ldc = 0.00A.




For step B users adjust the load to 2.5Ω for output and press **ENTER**, the AC Source will output 75Vac.




Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.




Press **ENTER** to continue the calibration procedure. The load will be disconnected at this time.




In step A the display shows the difference of lac and ldc measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press $\boxed{\text{ENTER}}$ the lac = 0.00A and ldc = 0.00A.




For step B users adjust the load to 2.5Ω for output and press **ENTER**, the AC Source will output 120Vac.



Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.



Step C is the last step of ACCURACY CALI in Current Measure. Press **ENTER** to continue calibrating the 2nd and 3rd phase or press **EXIT** to leave this page. The display shows the following. Press Yes on the right to save the calibration results.






- The resistance of the external load has to be constant; therefore the load current and output voltage should be proportional or step B of CURRENT MEAS. ACCURACY will be meaningless. Only when the current complies with step C (output voltage is 125VAC) can this be used for calibration.
- 2. Protection is removed temporary when the calibration procedure is running. It may cause the AC Source to be damaged if the incorrect load is applied.


4.2.3 External Vref Calibration

CALIBRATION CHOICE can be inputted after the password is entered, see 4.2. Press External Vref at the bottom to conduct the external Vref calibration as shown below.





Step A: Short circuiting the pin 1 and pin 4 of the Ext. Vref input terminal and press **ENTER**.




Step B: After short circuited the external Vref input terminal, make the input 0V and the display will show the AC Source's measured Vdc. The offset voltage is generated by internal components. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vdc calculated the AC Source at present.




Step C: Disconnect the pin 1 and pin 4 of the Ext. Vref input terminal, then input a DC voltage of 10Vdc between pin 1 and pin 4 and press **ENTER**.



Step D: Use a DVM to measure the voltage between pin 1 and pin 4 of Ext. Vref input terminal, then input a DC voltage and press **ENTER**.



Step E: It is the last step of External Vref CALI. Press **EXIT** to go into the save screen as shown below, or press **ENTER** to continue the voltage calibration of other phases.



In step E, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.

5. Parallel Operation

5.1 Parallel Connection of AC Source

When two AC Sources or one AC Source with one Power Stage Unit are applied in parallel mode, it can use an Input/Output Terminal Box for Parallel Connection (2 Units) (A615104) to connect the AC Source and Power Stage Unit (A615103) or another AC Source as the figure shown below. Use the Input/Output Terminal Box for Parallel Connection (3 Units) (A615105) when connecting 3 devices in parallel.




Figure 5-1 Master/Slave Connecting Diagram

5.2 Parallel Connection

When the AC Source and the Power Stage Unit are applied in parallel mode, it needs to use the System Bus and DVI communication cable to transmit parallel data. The following figure shows the parallel connencting diagram when connecting the AC Source and Power Stage Unit. If more AC Sources (61511/61512/61611/61612) or A615103 Power Stage Units are required for parallel connection, just follow the way shown below to connect them.



When the parallel mode is in use, it is necessary to connect the System Bus and DVI cables correctly or it will cause the system conntection error.




Figure 5-2 Parallel Connection of AC Source and Power Stage Unit

5.3 Setting Up


5.3.1 Setting the AC Source to Slave

To set an AC Source to Slave, press **CONFIG** in the **FUNCTION** keys to enter into the CONFIG function and select Master/Slave Function for parallel connection setting. The procedures are listed below.

- Press Master/Slave Function.
- 2. Press Position at the bottom.
- 3. Turn the RPG to change the Position to Slave and press **ENTER** to set it to Slave.
- 4. If the AC Source to be set is located between two terminals, press Terminator and turn the RPG to change the Terminator to Enable and then press **ENTER** to set it.




At least one device needs to be set as Slave when applying the parallel connection.




3	Pha	se	300V	LOCAL	QUIT	
т			OUTPU	T SETTING		Config
#1	Vac	=	0.0V	F =	60.0Hz	Others
82	Vac		0.0V	F =	60.0Hz	Others
#3	Vac	=	0.00	F =	60.0Hz	Calibration
			HEAD	SUREMENT		Campracon
	٧	=	0.00	VA	= 0.0	System
#1	1	=	0.000	PF	= 0.000	Information
	٧	=	0.00	Po	= 0.0	Factory
₩2	1	=	0.000	PF	= 0.000	Default
	٧	=	0.00	Po	= 0.0	Hantse Slave
83	1	=	0.000	PF	= 0.000	Function
3	V 12	=	0.00	V 21	= 0.00	Hore
I	V23	=	0.00	Po	= 0.0	2 af 2
	esition larred	Termir Disc				2008/10/13 19:28:34

5.3.2 Setting the Slave of Mixed AC Source and A615103


When the parallel connection is mixed with A615103 and AC Source as the Slave, the terminator of these two terminal devices must be enabled as the figure shown below. The maximum AC Sources to be connected in parallel is N = 5. Please refer to the User's Manual of latest version for any changes.



Example 1: if the system has a Slave AC Source and an A615103 parallelable power stage unit, the connection is shown in the figure below. Set the terminator of Master to "Enable" and the "Position" of Slave AC Source to "Slave1". Also set the Slave ID of A615103 to Slave2 with terminator enabled.



Example 2: if the system has a Slave AC Source and an A615103 parallelable power stage unit, the connection is shown in the figure below. Set the terminator of Master to "Enable" and the "Position" of the Slave AC Source to "Slave2". Also set the Slave ID of A615103 to Slave1 with terminator enabled.



5.3.3 Setting the AC Source to Master

Press **CONFIG** in the **FUNCTION** keys to enter into the CONFIG function and select Master/Slave Function for parallel connection setting. The procedures are listed below.

- 1. Press Master/Slave Function.
- 2. Press Position at the bottom.
- 3. Turn the RPG to change the Position to Master and press **ENTER** to set it to Master.
- 4. Press Number of Slave.
- 5. Turn the RPG to select the quantity of Slaves to connect in parallel and press **ENTER** to set it.
- 6. If the AC Source to be set is located between two terminals, press Terminator and turn the RPG to change the Terminator to Enable and then press **ENTER** to set it.
- 7. Press Function bottom.
- 8. Turn the RPG to change the Function to Enable and press **ENTER** to set it.
- 9. Now, the device set to Master will retrun to the main menu and the one set to Slave will show Slave on the screen.

3	Pha	se	3	00V	LOC	AL		QU	T		
т			_	OUTPUT	SETTI	WG.				Config	
*1	Vac	=	- (0.0V	F	=	6	0.0	Hz	240000	
e 2	Vac	=	- (0.0V	F	5 5	6	0.0	Hz	Others	
#3	Vac	=	- (0.0V	F	=	6	0.0	Hz	Calibration	
				HEASU	MEMENT					Campramon	
	٧	=	- (0.00	V	A	=		0.0	System	
#1	1	=	0	.000	P	ŧ	=	0.	000	Internation	
	٧	=	. (0.00	Po	ē	=		0.0	Factory	
₩2	1	=	0	.000	PF	÷	=	0 .	000	Default	
	٧		(0.00	Po		=		0.0	Master/Slave	
•3	1	=	0	.000	PI	÷	=	0.	000	Function	
ď	V 12	=	(0.00	V ₂	t .	=	0	.00	Hore	
ž	V22		- (0.00	Po		=		0.0	2 of 2	
	osition faster	Numb Star		Terminator Disable					Function Disable	2008/10/13	

3	Pha	se	30	OV	LOC	AL		QU	T	
				OUTPUT	SETTI	NC.				Config
#1	Vac	=	0	. 0 V	F	=	6	0.0)Hz	********
-2	Vac	=	0	. 0 V	F	悪	6	0.0)Hz	Others
#3	Vac	=	0	.07	F	=	6	0.0)Hz	Calibration
				HEASI	MEHENT					Campramon
	٧	=	0	.00	V	A	=		0.0	System
#1	1	=	0 .	000	P	F	=	0	000	Internation
	٧	=	0	.00	Po		=		0.0	Factory
₩2	1	=	0 .	000	P	F	=	0	000	Default
38	٧		0	.00	Po		=		0.0	Master/Slave
83	1	=	0 .	000	PI	F	=	0 .	000	Function
8	V 12	=	0	.00	V	31	=	(0.00	Hore
Ŧ	V22	=	0	.00	Po		=		0.0	2 af 2
	osition Aaster	Numb Star	/0	Terminato Disable	-				Function Enable	2008/10/13 19:28:34






At least one device needs to be set as Slave when in parallel application, or it will show "System Connection Fail!" when setting the Master Enable. See the section below for the detail description of troubleshooting.

5.4 Troubleshooting

When multiple devices are conneted in parallel for use, each standalone device has to have a System bus and a DVI cable to transmit the signal, or the quantity of the Slave set for connection does not match the one in actual. If the connection is busy or errors occurred during connection, follow the troubleshooting procedure to resolve the problem and redo the parallel connection.

5.4.1 When the Connecting Cable Falls

If "System Connection Fail!" occurs when initiating Master connection, check if the System Bus cable is connected firmly and if the Power Stage Unit or another AC Source is set to Slave. When confirmed, press Retry on Master to redo the connection.




If "SYSTEM SHUTDOWN" occurs during connection, power it off first and check if the DVI cable is connected firmly. If yes, reboot it and redo the connection.



5.4.2 Parallel Setting Error

If "System Connection Fail!" occurred when connecting Master, it could be the connection setting error. First check if the Master connected amount (Number of slave) is the same as the actual slave amount. Next, check if the parallel slave position is duplicated. The position set for slave cannot be duplicated. When confirmed, press Retry on the Master to do the connection again.



6. Theory of Operation

6.1 Overview

The 61611/61612 AC source consists of several Printed Circuit Boards (PCB) and other components. Each of the PCBs has specific functions that are described in the following sections.

6.2 Description of Overall System

Figure 6-1 is an overall system diagram that is composed of the following portions:

- Input Stage I Board:
 It converts the AC power to DC power with passive PFC function.
- Isolation Converter G/GD Board:
 The isolation DC/DC converter isolates the I board output with regulation function. It can also provide the inverter a stable input DC source.
- Output Stage HB/HT/O/A board:
 The above boards are composed of an inverter that draws power from G/GD board to provide 61611/61612 to output DC or AC power.
- Auxiliary Power J/Z board:
 The J board converts the mains to a 16-17V DC power for the ICs and fans of entire device use. The Z board is an isolation DC/DC converter that converts the J board output to ±12V and +5V power to drive the IC of various PCB and other components.
- Fan Control Circuit R Board:
 The R board detects the temperature of each power stage and adjusts the fan speed automatically to control the temperature of entire device. This circuit has Over Temperature Protection (OTP) and FAN- FAIL protection.
- Digital Signal Processor B board:
 The B board contains DSP, FPGA and CPLD control elements that are responsible for the actions and measurements of 61611/61612's entire device.
- Communication Interface E board:
 The E board connects all of the 61611/61612 communication interfaces such as GPIB, RS-232, USB......and sends the signals back to B board to accomplish the remote control function.
- Signal Transmission C Board:
 The C board is responsible for transmitting the signals from B board and other PCBs.
- Key input KA/KC/KR/KS board:
 It is the front panel key controls for the above PCBs that send the inputted signals to B board.

- 1-phase Output Connecting Device L Board:
 When L board is in 1-phase output, short circuit L1~L3 3 outputs for user wiring.
- Input Wire Selection Switch (Δ -Y wiring selection switch): Users can follow the actual power system to change the 61611/61612 internal input connection that enables 61611/61612 to accept the input from Δ or Y.




Figure 6-1 Overall System Diagram

7. Self Test & Troubleshooting

7.1 Overview

This chapter describes the procedures of self test and suggestions for troubleshooting when the AC Source is unable to operate normally. If the information provided here is unable to resolve the problem, please contact the local Chroma distributor.

7.2 Self Test

The AC Source runs a series of self tests during power-on. First, it executes the memory, data and communication self tests for the items of DISPLAY, WAVEFORM, and REMOTE. If any failure is detected on a certain item, an "error code" will show on the right of the item. The following table lists all of the error messages.

Error Code	Description	Remark
Bit 0	Memory error	0 – OK, 1 - ERROR
Bit 1	Waveform Generator error	0 – OK, 1 – ERROR
Bit 2	DATA error	0 – OK, 1 – ERROR
Bit 3	Communication error	0 – OK, 1 - ERROR
Bit 4	Output test result	0 – OK, 1 – ERROR
Bit 5	Reserved	
Bit 6	Reserved	
Bit 7	Reserved	

Example: If an error code shows " ERROR = 05 ", it is " 00000101" in binary. The bit 0 and bit 2 are "1". So "ERROR = 05" means memory error and DATA error occurs.

Error Message	Description	Resolution
Memory error	Memory tested fail.	Consult your dealer for further support
Waveform Generator error	Waveform generator tested fail.	Consult your dealer for further support.
DATA error	The data in Flash or EEPROM tested fail.	Consult your dealer for further support.
Communication error	Unable to send.	 Power off the AC Source and wait for three seconds to power it on again. Consult your dealer for further support.

After the self test of memory, data and communication, the AC Source executes the power output self test. In this procedure, the output relays are OFF to prevent the load connected to the output terminal from damage. An error message will appear on the panel if abnormal is encountered during self test.

7.3 Troubleshooting

The following table lists the operating problems and suggested corrective actions:

Problem	Cause	Resolution
Poor measurement	Aged components result in deviation	Periodic calibration is required.
of V, I.	of characteristics.	Refer to Chapter 4 Calibration.
Output distortion	1. The output voltage of AC Source	
	is too low.	voltage.
	2. The rectified load is too large	Reduce the load or output
	during high frequency.	frequency.
Over Temperature	The ambient temperature is too	1. Operate the unit in 0 ~ 40°C.
Protection (OTP)	high.	Unblock the airway.
	2. The airway is obstructed.	
Over Power	The output power exceeds	Remove the output power or
Protection (OPP)	specification.	output voltage.
Over Current	The output current exceeds	Remove the overload or expand
Protection (OCP)	specification or I LIMIT.	the I LIMIT.
Output Short	1. The output is shorted.	Remove the short state.
Protection (Short)	2. External current reversed.	2. Remove the load.
Input error protection	The line input voltage of AC Source	Measure the input voltage and
(INT_LINE)	is too low or too high.	regulate it if over specification.
AUX output error	The internal auxiliary power outputs	If it is unable to reset the
protection (INT_OFF)	abnormally.	protection, consult the dealer for
INIT AD must set is a	4. The evel of deposit for the circuit	assistance.
INT _ AD protection	The cycle dropout for line input	Check the stability of input
	voltage.	voltage. 2. Remove the load.
	Instant over current during output.	3. If it is unable to reset the
	3. The AD power stage is	protection, consult the dealer
	damaged.	for assistance.
INT _ DD protection	The cycle dropout for line input	Check the stability of input
Titt _ bb protection	voltage.	voltage.
	Instant over current during	2. Remove the load.
	output.	3. If it is unable to reset the
	3. The DD power stage is	protection, consult the dealer
	damaged.	for assistance.
OUTPUT OVP	Remote Sense is open.	Connect the output to
protection	2. Output voltage peak exceeds the	
ľ	range.	2. Check the settings of Vac
		and Vdc on MAIN PAGE.
Cooling fan	The fan stops operation due	Clear the fan.
protection (FANFAIL)	obstruction.	2. If it is unable to reset the
	2. The fan is not inserted.	protection, consult the dealer
		for assistance.
Unable to control AC	The address of AC Source is	Update the address.
Source via GPIB	incorrect.	Check the connection and
	2. GPIB cable is loose at rear.	tighten the screws.

8. Remote Operation

8.1 Introduction

The AC Source is able to do remote control via USB, GPIB, RS-232 or Ethernet. The USB interface supports USB 2.0/USB 1.1. The GPIB interface is an 8-bit parallel data bus that is synchronized by the bus command from the host. RS-232C interface is a serial bus with less powerful functions; however, the user can do basic remote control via simple programs.

8.1.1 USB Interface

(1) Hardware Support: USB 2.0 and USB 1.1

(2) Software Support: USBTMC class and USB488 subclass

(3) OS Support: Windows 98/2000/XP/Vista

(4) Installing Driver: 62000P Series USB Interface supports USBTMC, so if the PC

OS supports USBTMC (installed NI-VISA runtime version 3.00 or above) it is no need to install other drivers. The OS will search for the standard USBTMC driver installation program

automatically.

If the PC OS does not support USBTMC, it is suggested to install the NI-VISA runtime version 3.00 or above first. When the installation of NI-VISA runtime is done, the USBTMC driver program is stored in OS. The PC can communicate with 62000P Series via NI-VISA after using the USB cable to connect them.

Related Documents:

- USB Test and Measurement Class (USBTMC) specification, Revision 1.0, http://www.usb.org
- USB Test and Measurement Class USB488 subclass specification, Revision 1.0, http://www.usb.org

8.1.2 GPIB Interface

The default of GPIB address is 30 and it can only be changed from the "CONFIG" function menu (see Figure 3-1.)


GPIB Capability	Description	Interface Function
Talker/Listener	and received via the GPIB bus. Status information	AH1, SH1, T6, L4
	can be retrieved by serial query.	
Service Request	The AC Source sets the SRQ to be true if there is	SR1
1	a service request.	
Remote/Local	When the AC Source is powered on in local mode,	RL1
	it can operate the front panel. In remote mode, all	
	Press LOCAL/REMOTE can return to local mode.	

8.1.3 RS-232C Interface

The baud rate of the AC Source is set to **115200** with parity set to None. For the RS-232C parameters such as baudrate and parity can be set via "CONFIG" function menu (see section 3.4.) Only TxD and RxD signals are used for data transmission. The connector is a 9-pin D-subminiature male connector. The following table describes the pins and signals of RS-232C connector.

Pin No.	Input/Output	Description
1		No Connection
2	INPUT	RxD
3	OUTPUT	TxD
4		No Connection
5	GND	GND
6		No Connection
7		No Connection
8		No Connection
9		No Connection

Interconnection between the computer (compatible with IBM PC) and the AC Source is illustrated below:



8.1.4 Ethernet Interface

To remote program an AC Power Supply via a PC with Ethernet interface, it needs to confirm the IP address, Gateway address and Subnet mask in advance. See 3.4.1.3 for detail settings. To ensure reliable data transmission, TCP is used for data transmission and the communication port is 2101.

8.2 Introduction to Programming

All commands and response messages are transmitted in ASCII code. The response messages must be read completely before sending a new command; otherwise the remaining response messages will be lost and a query interrupt error will occur.

8.2.1 Conventions

Angle brackets	<	>	Items in angle brackets are parameter abbreviations.
Vertical bar			Vertical bar separates alternative parameters.
Square brackets	[]	Items in square brackets are optional. For example,
			OUTP [: STATe] means that : STATe may be omitted.
Braces	{	}	Braces indicate the parameters that may be repeated.
		-	The notation <a> {<, B>} means that parameter "A" must
			be entered while parameter "B" may be omitted or entered
			once or many times.

8.2.2 Numerical Data Formats

All data programmed to or returned from the AC Source are ASCII. The data can be numerical or character string.

Symbol	Description	Example
NR1	It is a digit with no decimal point. The decimal is	123, 0123
	assumed to be on the right of the least significant digit.	
NR2	It is a digit with a decimal point.	12.3, .123
NR3	It is a digit with a decimal point and an exponent.	1.23E+2

8.2.3 Boolean Data Format

Boolean parameter <Boolean> applies ON|OFF format only.

8.2.4 Character Data Format

The character strings returned by query command may in either of the following forms:

<CRD> Character Response Data: character string with maximum length of 12. <SRD> String Response Data: character string.

8.2.5 Basic Definition

Command Tree Table:

The commands of the AC Source are structured hierarchically, which is called tree system. Full path must be specified to obtain a particular command. This path is represented in the table by placing the highest node in the farthest left position of the hierarchy. Lower nodes in the hierarchy are indented in the position to the right under the parent node.

Program Header:

Program header is the key word to identify the command according to the IEEE 488.2 syntax described in section 8.5. The AC Source accepts characters in both upper and lower cases without any distinction. Program header consists of two unique types, the common command header and the instrument-controlled header.

Common Command and Query Header:

The syntax of common commands and query headers are described in IEEE 488.2. They are used along with the IEEE 488.2 defined common commands and queries. The commands with leading "*" are common commands.

Instrument-Controlled Header:

Instrument-controlled header can be applied to all instrument commands. Each header has a long form and a short form. The AC Source only accepts the exact short and long forms. A special notation is used to distinguish the short form header from the long one of the same in this section. The short form of header is shown by upper case characters while the rest of the headers are shown in lower case.

Program Header Separator (:):

If a command has more than one header, a colon must be used to separate them (FETC: CURR?, VOLT:DC 10). At least one space is required to separate the data and program header.

Program Message:

The program message consists of many elements including zero sequence or message components that are separated by the separator (semicolon.)

Program Message Component:

A program component is a single command, programming data, or query.

Example: FREQ?, OUTPut ON.

Program Message Component Separator (;):

The separator (semicolon;) separates the program message components from another in a program message.

Example: VOLT:AC 110; FREQ 120<PMT>

Program Message Terminator (<PMT>):

A program message terminator can end the program message. Three permitted terminators are:

- (1) <END>: end or identify (EOI)
- (2) <NL>: new line which is a single ASCII encoded byte 0A (10 decimals).
- (3) <NL> <END>: new line with EOI.



The response message is terminated by <NL> <END> for GPIB, and <NL> for RS-232C.




Figure 8-1 Structure of Command Message

8.3 Traversal of the Command Tree

Multiple program message units can be sent in one program message. The first command usually refers to the root node. Subsequent commands refer to the tree level same as the previous command in a program message. When the colon is ahead of the program message component it changes the header path to root level.

Example:

OUTPut : PROTection : CLEar All colons are header separators.

OUTPut : PROTection : CLEar; : VOLT : AC 100 Only the third colon is a specified root.

8.4 Execution Order

The AC Source executes program messages by the order received. Problems may occur if the sequence is not followed.

For example, assuming the current output voltage range is LOW, the output voltage range desired for new state is HIGH with amplified 220 Volt. If the commands

VOLTage : AC 220<PMT> VOLTage : RANGeHIGH<PMT>

are sent out, the error of out of range will appear.

8.5 Commands of AC Source

This section talks about the syntax and parameters of all commands for the AC Source. The examples of each command can be used in common.

Syntax Form Syntax definition is in long format header; however, only short

format header appears in the examples.

Parameter Most commands require a parameter.

Return Parameter All queries return a parameter.

Model If a command is merely applied to specific models, these models will be

listed in the Model only entry. If there is no Model only entry, the

command will be applied to all models.

8.5.1 Common Command Dictionary

The common commands begin with a " * " and consist of three letters and/or one "?" (query). Common commands and queries are listed alphabetically. The command commands and queries are listed in alphabetic order.

*CLS Clear status

This command clears the following registers

- (1) Questionable Status Event
- (2) Status Byte
- (3) Error Queue

*ESE<n> Standard event status enabled

This command programs the Standard Event register bits. If one or more enabled events of Standard Event registers are set, the ESB of Status Byte Register is set as well.

Bit Configuration of Standard Event Status Enabled Register

Bit Position	7	6	5	4	3	2	1	0
Bit Name	PON		CME	EXE	DDE	QYE	-	OPC
CME = Comn	nmand Error DDE = Device-dependent error							
EXE = Execu	tion Erro	•						
PON = Power	·							

*ESE? Return standard event status enabled

*ESR? The query reads the Standard Event readings of Event register and clears it.

The bits of configuration are the same as Standard Event Status Enabled Register.

*IDN? Return the AC Source identification string.

Return Parameter Chroma ATE,61600,123456,1.00

Chroma ATE : Company name
61600 : Model name
123456 : Serial number
1.00 : Firmware version

*RCL<n> Restore the values of specified group that stored in memory previously.

Parameter 1 - 3

*SAV<n> Save the values to a specified group in memory.

Parameter 1 - 3

* RST It resets the AC Source to the initial states. It's better to wait for 3 seconds to

send the next command.

*SRE It sets conditions of Service Request Enabled Register. If one or more of the

enabled events of the Status Byte Register is set, the MSS and RQS of Status

Byte Register are set too.

*SRE? This guery returns the Service Request Enabled Register.

*STB? This query returns the Status Byte Register.

Bit Configuration of Status Byte Register

Bit Position	7	6	5	4	3	2	1	0
Condition		MSS	ESB	MAV	QUES			
		RQS						

ESB = Event Status Byte Summary

QUS = Questionable Status Summary

RQS = Request for Service

MSS = Master Status Summary

MAV = Message Available

* TST? It queries the self-test result of the AC Source.

8.5.2 Instrument Command Dictionary

The commands are listed in alphabetical order. Commands followed by question marks (?) are in query forms. When a command has both command and query forms, it is noted in the description of query syntax.

8.5.2.1 SYSTEM Sub-System

SYSTem

:ERRor? :VERSion? :LOCal :REMote :DATE :TIME

SYSTem: ERRor?

Description : This command queries the error string of the command parser.

Query Syntax : SYSTem:ERRor?

Parameter : None

Return Parameter: Error string response: No Error

Data Format Error Data Range Error Too Many Errors Execution Error

SYSTem: VERSion?

Description : This query requests the AC Source to identify itself.

Query Syntax : SYSTem: VERSion?

Parameter : None

Return Parameter: Current version (XX.XX)

SYSTem:LOCal

Description : This command can only be used under the control of RS-232C. If

SYST: LOC is programmed, the AC source will be set in the LOCAL

state, and the front panel will work.

Query Syntax : None Parameter : None Return Parameter : None

SYSTem:REMote

Description : This command can only be used under the control of RS-232C. If

SYST: REM is programmed, the AC source will be set in the REMOTE state, and the front panel will be disabled except the

"<PAGE/EXIT> key.

Query Syntax : None

Parameter : None Return Parameter : None

SYSTem:DATE

Description : This command sets the date of the AC Source real time clock.

Query Syntax : SYSTem:DATE?

Parameter : <year>,<month>,<day>

Return Parameter: 2008,01,01

SYSTem:TIME

Description : This command sets the time (24H) of the AC Source real time clock.

Query Syntax : SYSTem:TIME?

Parameter : <hour>,<minute>,<second>

Return Parameter: 20,30,01

8.5.2.2 INSTRUMENT Sub-System

INSTrument

:EDIT

:Couple

:NSELect

:SELect

:PHASe

INSTrument:EDIT

Description : It is very convenient to use a programmed command to set all

phases at the same time for an AC Source that equipped with multiple phases. If INST:EDIT ALL has been programmed, it will be sent to all phases. INST:EDIT EACH command disables EDIT ALL

command.

Query Syntax : INSTrument:EDIT?

Parameter : EACH | ALL

Return Parameter: None

INSTrument: COUPle

Description : It is easy to use a command to program all phases in an AC Source

with multiple phases. If INST: COUP ALL is programmed, the command will be sent to all phases. INST: COUP NONE command

will cancel COUP ALL command.

Query Syntax : INSTrument : COUPle?

Parameter : NONE | ALL

Return Parameter: None

INSTrument: NSELect

Description : This command sets individual output for subsequent commands or

queries in the multi-phase model. If INST: COUP NONE has been programmed, the phase selection command will send to a specific output phase set by INSTrument: NSELect. If INST: COUP ALL has been programmed, all remote operation commands will send to all output phases. This command only affects the set voltage and

queries the measurement data. For instance, if "INST: COUP ALL", "INST: NSEL 2" and "Meas: VOLT?" are programmed, the AC Source will return Φ 2 measurement voltage. INST: NSEL follows

the number to select phase.

Query Syntax : INSTrument : NSELect?

Parameter : 1 | 2 | 3 Return Parameter : 1 | 2 | 3

INSTrument: SELect

Description : This command sets individual output for subsequent commands or

queries in the multi-phase model. If INST: COUP NONE has been programmed, the phase selection command will send to a specific output phase set by INSTrument: SELect. If INST: COUP ALL has been programmed, all remote operation commands will send to all output phases. This command only affects the set voltage and queries the measurement data. For instance, if "INST: COUP ALL", "INST: SEL OUTPUT2" and "Meas: VOLT?" are programmed, the AC Source will return Φ 2 measurement voltage. INST: SELect

follows the number to select phase.

Query Syntax : None

Parameter : OUTPUT1 | OUTPUT2 | OUTPUT3

Return Parameter: None

INSTrument: PHASe

Description : It switches between single phase and three-phase mode.

Query Syntax : INSTrument : PHASe?
Parameter : THREE | SINGLE
Return Parameter : THREE | SINGLE

8.5.2.3 FETCH & MEASURE Sub-System

FETCh | MEASure

[: SCALar]

: CURRent

: AC? It queries the rms current of AC component.

: DC? It queries the DC current level. : ACDC? It queries the current (AC+DC) rms.

: AMPLitude : MAXimum? It queries the peak current.
: CREStfactor? It queries the current crest factor.
: INRush? It queries the inrush current.
: FREQuency? It queries the frequency.

: POWer : AC

[: REAL]? It queries the real power.
: APParent? It queries the apparent power.
: REACtive? It queries the reactive power.
: PFACtor? It queries the power factor.
: TOTal? It queries the total power.

: TOTal : APParent? It queries the total apparent power.

:VOLTage

: AC? It queries the rms voltage of AC component.

: DC?: ACDC?: AMPLitude : MAXimum?It queries the DC voltage.It queries the rms voltageIt queries the peak voltage.

:LINE

:V12? It queries the voltage difference of phase 1 & 2. :V23? It queries the voltage difference of phase 2 & 3. :V31? It queries the voltage difference of phase 3 & 1.

This command enables users to get measurement data from the AC Source via MEASure and FETCh. MEASure triggers the acquisition to get new data before returning data, while FETCh returns the previously acquired data from measurement buffer.

FETCh [: SCALar]: CURRent: AC? MEASure [: SCALar]: CURRent: AC?

Description : These queries return the rms current of AC component that is output

from the output terminal.

Query Syntax : FETCh : CURRent : AC?, MEASure : CURRent : AC?

Return Parameter: <NR2>

FETCh [: SCALar]: CURRent: DC? MEASure [: SCALar]: CURRent: DC?

Description : These queries return the DC current that is output from the output

terminal.

Query Syntax : FETCh : CURRent : DC?, MEASure : CURRent : DC?

Return Parameter: <NR2>

FETCh [: SCALar]: CURRent: ACDC? MEASure [: SCALar]: CURRent: ACDC?

Description : These queries return the rms current that is output from the output

terminal.

Query Syntax : FETCh : CURRent : ACDC?, MEASure : CURRent : ACDC?

Return Parameter: <NR2>

FETCh [: SCALar]: CURRent: AMPLitude: MAXimum? MEASure [: SCALar]: CURRent: AMPLitude: MAXimum?

Description : These gueries return the absolute value of peak current.

Query Syntax : FETCh : CURRent : AMPLitude : MAXimum?,

MEASure: CURRent: AMPLitude: MAXimum?

Return Parameter: <NR2>

FETCh [: SCALar]: CURRent: CREStfactor?
MEASure [: SCALar]: CURRent: CREStfactor?

Description : These queries return the output current crest factor. It is the ratio of

peak output current to rms output current.

Query Syntax : FETCh : CURRent : CREStfactor?

MEASure: CURRent: CREStfactor?

Return Parameter: <NR2>

FETCh [: SCALar]: CURRent: INRush? MEASure [: SCALar]: CURRent: INRush?

Description : These queries return the inrush current that is output from the output

terminal.

Query Syntax : FETCh:CURRent: INRush?, MEASure: CURRent : INRush?

Return Parameter: <NR2>

FETCh [: SCALar]: FREQuency? MEASure [: SCALar]: FREQuency?

Description : These queries return the output frequency in Hertz.

Query Syntax : FETCh : FREQuency?

MEASure: FREQuency?

Return Parameter: <NR2>

FETCh [: SCALar]: POWer: AC [: REAL]?
MEASure [: SCALar]: POWer: AC [: REAL]?

Description : These gueries return the real power that is output from the output

terminals in watt.

Query Syntax : FETCh : POWer : AC?

MEASure: POWer: AC?

Return Parameter: <NR2>

FETCh [: SCALar]: POWer: AC: APParent? MEASure [: SCALar]: POWer: AC: APParent?

Description : These queries return the apparent power that is output from the

output terminals in volt-ampere.

Query Syntax : FETCh : POWer : AC : APParent?

MEASure: POWer: AC: APParent?

Return Parameter: <NR2>

FETCh [: SCALar]: POWer: AC: REACtive? MEASure [: SCALar]: POWer: AC: REACtive?

Description : These queries return the reactive power that is output from the

output terminals in volt-ampere. Reactive power is calculated by

the following formula:

 $VAR = \sqrt{APPARENTPOWER^2 - REALPOWER^2}$

Query Syntax : FETCh : POWer : AC : REACtive?

MEASure: POWer: AC: REACtive?

Return Parameter: <NR2>

FETCh [: SCALar]: POWer: AC: PFACtor? MEASure [: SCALar]: POWer: AC: PFACtor?

Description : These queries return the power factor that is output from the

output terminals. Power factor is computed by: PF = TRUE POWER / APPARENT POWER

Query Syntax : FETCh : POWer : AC : PFACtor?

MEASure: POWer: AC: PFACtor?

Return Parameter: <NR2>

FETCh [: SCALar]: POWer: AC: TOTal? MEASure [: SCALar]: POWer: AC: TOTal?

Description : These queries return the total of real power that is output from 3-

phase output terminal in watt.

Query Syntax : FETCh : POWer : AC : TOTal?

MEASure: POWer: AC: TOTal?

Return Parameter: <NR2>

FETCh [:SCALar]:POWer:AC:TOTal:APParent? MEASure [:SCALar]:POWer:AC:TOTal:APParent?

Description : These queries return the total apparent power that is output from

3-phase output terminal in volt-ampere.

Query Syntax : FETCh:POWer:AC:TOTal:**APParent**?

MEASure:POWer:AC:TOTal:APParent?

Return Parameter: <NR2>

FETCh [: SCALar]: VOLTage: AC? MEASure [: SCALar]: VOLTage: AC?

Description : These queries return the rms of AC component that is output from

the output terminal.

Query Syntax : FETCh [: SCALar] : VOLTage : AC?

MEASure [: SCALar] : VOLTage : AC?

Return Parameter: <NR2>

FETCh [: SCALar]: VOLTage: DC? MEASure [: SCALar]: VOLTage: DC?

Description : These queries return the DC composite voltage that is output from

the output terminal.

Query Syntax : FETCh [: SCALar] : VOLTage : DC?

MEASure [: SCALar]: VOLTage: DC?

Return Parameter: <NR2>

FETCh [: SCALar]: VOLTage: ACDC? MEASure [: SCALar]: VOLTage: ACDC?

Description : These queries return the rms that is output from the output

terminal.

Query Syntax : FETCh [: SCALar] : VOLTage : ACDC?

MEASure [: SCALar]: VOLTage: ACDC?

Return Parameter: <NR2>

FETCh [: SCALar]: VOLTage: AMPLitude: MAXimum? MEASure [: SCALar]: VOLTage: AMPLitude: MAXimum?

Description : These queries return the absolute value of peak voltage.

Query Syntax : FETCh : **VOLTage**: AMPLitude : MAXimum?,

MEASure: **VOLTage**: AMPLitude: MAXimum?

Return Parameter: <NR2>

FETCh [: SCALar]: LINE: V12? MEASure [: SCALar]: LINE: V12?

Description : These queries return the line voltage between phase 1 and 2.

Query Syntax : FETCh [: SCALar]: LINE: V12?

MEASure [: SCALar]: LINE: V12?

Return Parameter: <NR2>

FETCh [: SCALar]: LINE: V23? MEASure [: SCALar]: LINE: V23?

Description : These queries return the line voltage between phase 2 and 3.

Query Syntax : FETCh [: SCALar] : LINE : V23?

MEASure [: SCALar]: LINE: V23?

Return Parameter: <NR2>

FETCh [: SCALar]: LINE: V31? MEASure [: SCALar]: LINE: V31?

Description : These queries return the line voltage between phase 3 and 1.

Query Syntax : FETCh [: SCALar]: LINE: V31?

MEASure [: SCALar]: LINE: V31?

Return Parameter: <NR2>

8.5.2.4 OUTPUT Sub-System

OUTPut

[: STATe] : RELay : SLEW

> : VOLTage : AC : DC :FREQency

: COUPling : PROTection :CLEar

OUTPut [: STATe]

Description : This command enables or disables the output of the AC Source.

Disabled output is to set the output voltage amplitude to 0 Volt.

Query Syntax : OUTPut [: STATe]?

Parameter : OFF | ON Return Parameter : OFF | ON

OUTPut: RELay

Description : This command sets output relay on or off.

Query Syntax : OUTPut : RELay?

Parameter : OFF | ON, ON sets the output relay of the AC Source on (close),

OFF sets the output relay of the AC source off (open).

Return Parameter: OFF | ON

OUTPut: SLEW: VOLTage: AC

Description : This command sets the slew rate of the AC output voltage.

Query Syntax : OUTPut : SLEW : VOLTage : AC?

Parameter : <NR2>, valid range is 0.000V/ms ~ 1200.000V/ms.

Return Parameter: <NR2>

OUTPut : SLEW : VOLTage : DC

Description : This command sets the slew rate of the DC composite voltage.

Query Syntax : OUTPut : SLEW : VOLTage : DC?

Parameter : <NR2>, valid range is 0.000V/ms ~ 1200.000V/ms.

Return Parameter: <NR2>

OUTPut: SLEW: FREQuency

Description : This command sets the slew rate of the output frequency.

Query Syntax : OUTPut : SLEW : FREQuency?

Parameter : <NR2>, valid range is 0.000 Hz/ms ~ 1600.000Hz/ms

Return Parameter: <NR2>

OUTPut: COUPling

Description : This command selects the coupling of the output signals.

Query Syntax : OUTPut : COUPling?
Parameter : AC | DC | ACDC
Return Parameter : AC | DC | ACDC

OUTPut: PROTection: CLEar

Description : This command clears the latch that disables the output when over

current (OCP), over temperature (OTP), over power (OPP) or

remote inhibit (RI) is detected. All conditions that generate the faults

must be resolved before the latch is cleared.

Query Syntax : None Parameter : None Return Parameter : None

8.5.2.5 SOURCE Sub-System

```
[SOURce:]
```

CURRent

: LIMit : DELay

: INRush

: STARt

: INTerval

: RANGe

FREQency

[: {CW | IMMediate}]

: LIMit

VOLTage

[: LEVel][: IMMediate][:AMPLitude]

: AC : DC

: LIMit

: AC

: DC

: PLUS

: MINus

: RANGe POWer

: PROTection

[SOURce:] CURRent: LIMit

Description : This command sets the rms current limit of the AC Source for

protection.

Query Syntax : [SOURce :] CURRent : LIMit?

Parameter : <NR2>, valid range is 0.00 ~ maximum current spec. of the specific

model (unit: A.)

Return Parameter: <NR2>

[SOURce :] CURRent : DELay

Description : This command sets the time delayed for triggering over current

protection.

Query Syntax : [SOURce :] CURRent : DELay?

Parameter : <NR2>, valid range is 0.0 ~ 5.0 (unit: 0.1 second.)

Return Parameter: <NR2>

[SOURce :] CURRent : INRush : STARt

Description : This command sets the time to start the inrush current

measurement.

Query Syntax : [SOURce :] CURRent : INRush : STARt? Parameter : <NR2>, valid range is 0 ~ 9999 (unit: ms.)

Return Parameter: <NR2>

[SOURce :] CURRent : INRush : INTerval

Description : This command sets the measuring interval for inrush current

measurement.

Query Syntax : [SOURce :] CURRent : INRush : INTerval? Parameter : <NR2>, valid range is 0 ~ 9999 (unit: ms.)

Return Parameter: <NR2>

[SOURce:]CURRent:RANGe

Description : This command sets the current measurement range for output 此命

Query Syntax : [SOURce:]CURRent:RANGe?

Parameter :

Para. Model	1	2	3	AUTO
61512	12A	48A	192A	Auto
61511	8A	32A	128A	Auto
61612	12A	48A	192A	Auto
61611	8A	32A	128A	Auto

Return Parameter: 1 | 2 | 3 | Auto

[SOURce :] FREQuency [: {CW | IMMediate}]

Description : This command sets the output waveform frequency for the AC

Source in Hz.

: [SOURce :] FREQuency [: {CW | IMMediate}]? Query Syntax Parameter : <NR2>, valid range is 15.00 ~ 1500.0 (unit: Hz.)

Return Parameter: <NR2>

[SOURce :] FREQuency : LIMit

: This command sets the output frequency limit for the AC Source. Description

Query Syntax : [SOURce:] FREQuency: LIMit?

Parameter : <NR2>, valid range is 15.00 ~ 1500.00 (unit: Hz)

Return Parameter: <NR2>

[SOURce:] POWer:PROTection

Description : This command sets the OPP (Over Power Protection) for AC

Source.

Query Syntax : [SOURce :] POWer:PROTection?

: <NR2>, valid range is 0.0 ~ maximum power of specific model Parameter

(unit: W.)

Return Parameter: <NR2>

[SOURce:] VOLTage [: LEVel][: IMMediate][: AMPLitude]: AC

: This command sets the AC composite output voltage in Volts. Description Query Syntax : [SOURce :] VOLTage [: LEVel][: IMMediate][: AMPLitude] : AC? Parameter : <NR2>, valid range is 0.0 ~ 150.0 (low range), 0.0 ~ 300.0 (high

range.)

Return Parameter: <NR2>

[SOURce :] VOLTage [: LEVel][: IMMediate][: AMPLitude] : DC

: This command sets the DC composite output voltage in Volts. Description : [SOURce :] VOLTage [: LEVel][: IMMediate][: AMPLitude] : DC? Query Syntax : <NR2>, valid range is -212.1 ~ 212.1 (low range), -424.2 ~ 424.2 Parameter

(high range.)

Return Parameter: <NR2>

[SOURce :] VOLTage : LIMit : AC

Description : This command sets the Vac LIMIT to restrict the value of Vac.

: [SOURce :] VOLTage : LIMit : AC? Query Syntax

: <NR2>, valid range is 0.0 ~ 300.0 (unit: V.) Parameter

Return Parameter: <NR2>

[SOURce :] VOLTage : LIMit : DC : PLUS

Description : This command sets the Vdc Limit(+).

: [SOURce:] VOLTage: LIMit: DC: PLUS? Query Syntax Parameter : <NR2>, valid range is -424.2 ~ 424.2 (unit: V)

PS: The lower limit cannot exceed Vdc Limit(-).

Return Parameter: <NR2>

[SOURce :] VOLTage : LIMit : DC : MINus

Description : This command sets the Vdc Limit(-).

Query Syntax : [SOURce :] VOLTage : LIMit : DC : MINus? Parameter : <NR2>, valid range is -424.2 ~ -424.2 (unit: V)

PS: The upper limit cannot exceed Vdc Limit(+).

Return Parameter: <NR2>

[SOURce:] VOLTage: RANGe

Description : This command sets the output voltage range to LOW (150 V) or

HIGH (300 V) or AUTO 3 selections.

Query Syntax : [SOURce :] VOLTage : RANGe?

Parameter : LOW | HIGH Return Parameter : LOW | HIGH

8.5.2.6 CONFIGURE Sub-System

[SOURce:]

CONFigure

: INHibit : EXTernal : COUPling : EXTON

[SOURce:] CONFigure: INHibit

Description : This command sets the Remote Inhibit function.

Query Syntax : [SOURce :] CONFigure : INHibit?

Parameter : DISABLE | ENABLE Return Parameter : DISABLE | ENABLE

[SOURce :] CONFigure : EXTernal

Description : This command sets if enabling the External-V Reference function.

Query Syntax : [SOURce :] CONFigure : EXTernal?

Parameter : OFF | ON Return Parameter : OFF | ON

[SOURce :] CONFigure : COUPling?

Description : This command sets the External-V Reference to be

AC_AMPLIFIER or DC_LEVEL to control the AC Source output.

Query Syntax : [SOURce :] CONFigure : COUPling?

Parameter : AC | DC Return Parameter : AC | DC

[SOURce:] CONFigure: EXTON

Description : This command sets the External ON/OFF control.

Query Syntax : [SOURce :] CONFigure : EXTON?

Parameter : DISABLE | ENABLE | Return Parameter : DISABLE | ENABLE |

8.5.2.7 PHASE Sub-System

[SOURce:]

PHASe

:ON

:OFF

:P12

:P13

:SEQuence

:THREE

:RELOCK

[SOURce:] PHASe: ON

Description : This command sets the transition angle when the waveform shifts.

The default is ON meaning 0 degree.

Query Syntax : [SOURce :] PHASe : ON?

Parameter : $\langle NR2 \rangle$, valid range is 0.0 ~ 359.9.

Return Parameter: <NR2>

[SOURce:] PHASe: OFF

Description : This command sets the transition angle when the waveform ends.

Query Syntax : [SOURce :] PHASe : OFF?

Parameter : <NR2>, valid range is 0.0 ~ 360.0, 360.0: means IMMED.

Return Parameter: <NR2>

[SOURce:]PHASe:P12

Description : This command sets the phase difference of Φ 1 and Φ 2.

Query Syntax : [SOURce :]PHASe:P12?

Parameter : <NR2>, valid range is 0.0 ~ 359.9.

Return Parameter: <NR2>

[SOURce:]PHASe:P13

Description : This command sets the phase difference of Φ 1 and Φ 3.

Query Syntax : [SOURce :]PHASe:P13?

Parameter : <NR2>, valid range is 0.0 ~ 359.9.

Return Parameter: <NR2>

[SOURce:]PHASe:SEQuence

Description : This command sets the phase sequence in 3-phase mode.

Query Syntax : [SOURce :]PHASe:SEQuence?

Parameter : POS | NEG

Return Parameter: POSITIVE | NEGATIVE

[SOURce:]PHASe:RELOCK

Description : This command sets the relock function in 3-phase mode.

Query Syntax : [SOURce :]PHASe:RELOCK?

Parameter : ENABLE | DISABLE Return Parameter : ENABLE | DISABLE

[SOURce:]PHASe:THREE

Description : This command set the operation mode in 3-phase mode.

Query Syntax : [SOURce :]PHASe:THREE?

Parameter : INDEPEND | SAMEFREQ | BALANCE Return Parameter : INDEPEND | SAMEFREQ | BALANCE

8.5.2.8 STATUS Sub-system

STATus

: OPERation [: EVENt]? : ENABle : QUEStionable

> : CONDition [: EVENt]? : ENABle : NTRansition

STATus : OPERation [: EVENt]?

: PTRansition

Description : This command queries the Operation Status register.

Query Syntax : STATus : OPERation [: EVENt]?

Parameter : None Return Parameter : Always 0.

STATus: OPERation: ENABle

Description : This command sets the Operation Status Enable register. The

register is the shield when specific bit is enabled from Operation

Status register.

Query Syntax : STATus : OPERation : ENABle? Parameter : <NR1>, valid range is 0 ~ 255.

Return Parameter: Always 0.

STATus: QUEStionable: CONDition?

Description : This query command returns the value of Questionable Condition

register. It is a read only register that saves the questionable

condition of AC Source in real time.

Query Syntax : STATus : QUEStionable : CONDition?

Parameter : NONE

Return Parameter: <NR1>, valid range is 0 ~ 511.

STATus: QUEStionable [: EVENt]?

Description : This query command returns the value of Questionable Event

register. It is a read only register that saves all items that passed Questionable NTR and/or PTR filter. If the QUES bit in Service Request Enabled register has been set and Questionable Event register > 0, the QUES of Status Byte register will be set too.

Query Syntax : STATus : QUEStionable [: EVENt]?

Parameter : NONE

Return Parameter: <NR1>, valid range is 0 ~ 511.

STATus: QUEStionable: ENABle

Description : The command sets or reads the value of Questionable Enable

register. The register is the shield when specific bit is enabled to set the QUES bit of Status Byte register from Operation Status register.

Query Syntax : STATus : QUEStionable : ENABle? Parameter : <NR1>, valid range is 0 ~ 511.

Return Parameter: <NR1>

STATus: QUEStionable: NTRansition

Description : These commands set or read the value of register.

The operation of these registers is the same as polarity filter of Questionable Enable and Questionable Event registers that lead the following actions:

- * When a bit of the Questionable NTR register is set to 1, a 1-to-0 transition of the corresponding bit in the Questionable Condition register will make that bit in the Questionable Event register to be set.
- * When a bit of the Questionable PTR register is set to 1, a 0-to-1 transition of the corresponding bit in the Questionable Condition register will make that bit in the Questionable Event register to be set.
- If the two same bits in both NTR and PTR registers are set to 0, none transition of that bit in the Questionable Condition register can set the corresponding bit in the Questionable Event register.

Bit Configuration of Questionable Status Register

			9						- 3	
Bit	15-9	8	7	6	5	4	3	2	1	0
Position										
Condition		OVP	INP	OCP	FAN	SHT	OTP	OPP	INT-DD	INT-AD

OVP : Output voltage protection INP : Line input protection. OCP : Over current protection.

FAN : Fan failure.

SHT : Output short protection.
OTP : Over temperature protection.

OPP : Over power protection.

INT-DD : Inner DD power stage protection INT-AD : Inner AD power stage protection

Query Syntax : STATus : QUEStionable : NTRansition?

Parameter : <NR1>, valid range is 0 ~ 511.

Return Parameter: <NR1>

STATus: QUEStionable: PTRansition

Description : These commands set or read the values of Questionable PTR

register. Please refer to the description of previous command.

Query Syntax : STATus : QUEStionable : PTRansition?

Parameter : <NR1>, valid range is 0 ~ 511.

Return Parameter: <NR1>

8.6 **Command Summary**

Common Commands

* CLS Clear status * ESE<n> Enable standard event status * ESE? Return enabled standard event status Return the AC Source ID * IDN? Recall the AC Source file * RCL<n> * RST Reset the AC Source to initial states

* SAV<n> Save the AC Source status * SRE Set request enable register

Return status byte * STB?

Return the self-test result of AC Source * TST?

Instrument Commands

SYSTem

: ERRor? : VERSion? : LOCal : REMote : DATE : TIME

INSTrument

: EDIT : Couple : NSELect : SELect : PHASe

FETCh | MEASure

```
[: SCALar]
    : CURRent
        : AC?
        : DC?
        : ACDC?
        : AMPLitude:MAXimum?
         : CREStfactor?
        : INRush?
    : FREQuency?
    : POWer
        : AC
             [: REAL]?
             : APParent?
             : REACtive?
             : PFACtor?
             : TOTal?
             : TOTal:APParent?
```

:VOLTage : AC?

```
: DC?
             : ACDC?
             : AMPLitude:MAXimum?
        :LINE
             :V12?
             :V23?
             :V31?
OUTPut
    [: STATe]
    : RELay
    : SLEW
        : VOLTage
             : AC
             : DC
        :FREQency
    : COUPling
    : PROTection
        :CLEar
[SOURce:]
     CURRent
        : LIMit
        : DELay
        : INRush
             : STARt
             : INTerval
        :RANGe
     FREQency
        [: {CW | IMMediate}]
         : LIMit
     VOLTage
        [: LEVel][: IMMediate][:AMPLitude]
             : AC
             : DC
        : LIMit
             : AC
             : DC
                 : PLUS
                 : MINus
        : RANGe
    POWer
        : PROTection
 [SOURce:]
     PHASe
        : ON
        : OFF
[SOURce:]
     CONFigure
        : INHibit
```

STATus

: OPERation

[: EVENt]?

: ENABle

: QUEStionable

: CONDition

[: EVENt]?

: ENABle

: NTRansition

: PTRansition

Appendix A TTL Signal Pin Assignments

Green terminal with female connector:

Pin No.	Signal	Description
1	Ext-V Ф1	Φ1 External-V Reference signal input (-10V~10V)
2	Ext-V Ф2	Φ2 External-V Reference signal input (-10V~10V)
		It is the input pin of external voltage signal when applied in
		single phase.
3	Ext-V Ф3	Φ3 External-V Reference signal input (-10V~10V)
4	AGND	External-V Reference signal grounding
5	+12V	12V voltage output (providing current 1A)
6	Reserved	
7	DGND	Digital signal grounding
8	DGND	Digital signal grounding
9	AC-ON	This pin turns to HIGH when the AC Source outputs voltage
		and turns to LOW when quits output.
10	/ FAULT-OUT	The voltage level of this pin is HIGH when the AC Source is
		in normal mode, it will turn to LOW when the AC Source is
		in protection mode.
11	/ Ext-ONOFF	When EXT-ONOFF is enabled and the voltage level of this
		pin turns to LOW, the AC Source output will be open and it
	/ 5	will close on the contrary.
12	/ Remote-Inhibit	When the voltage level of this pin turns to LOW, it can
10	/D , E :	inhibit the AC Source output or trigger mode.
13	/Remote-Excite	When this pin receives a negative edge signal (from High to
4.4	/Tue ve e i e ve t	Low), it can trigger the transient output of AC Source.
14	/Transient	When the output of AC Source changes, this pin will send
15	/INV_E	out a low level 64us or remain at high level.
15	/IINV_ _	It is for the signal terminal of Reverse Current Protection Unit A615106 use.
16	/CON	It is for the signal terminal of Reverse Current Protection
10	/CON	Unit A615106 use.
17	Reserved	OTIIL AUTOTOU USE.
18	Reserved	
10	1/6961/60	



CHROMA ATE INC. info@chromaate.com www.chromaate.com