

Title: Daily Maintenance Report

Doc Number :

GMJV-KeNHA-BRW-WOM039FM008

Revision:

Doc Type:

Form

Reviewed by: Maurice Ademba

Author/Owner: Wellingtone Odali

Effective Date: January 2022

Review Date: January 2023

Number Pages: Page 1 of 3

Approved by: Godfrey Walala

BUSIA Site Name Dates/Duration MOGAKA **Technician Name** System Check X Comments/issues/observations **Systems VOLTAGE** LINE VOLTAGE Electrical Systems L1-L2 L1-L3 L2-L3 PHASE Within range **VOLTAGE** L1-N L2-N L3-N PHASE & EARTH L1-E L2-E L3-E OTHER APPLIANCES Isolators **MCCBs** Oka Contactors **MCBs** Photocells Scales systems Check the following:-Scale Accuracy Indicator Functionality Okav System Grounding Remote Display Unit



Title: Daily Maintenance Report

Doc Number: GMJV-KeNHA-BRW-WOM039FM008

Revision:

Doc Type:

Form Author/Owner: Wellingtone Odali

Reviewed by: Maurice Ademba

Effective Date: January 2022

Review Date: January 2023

Number Pages: Page 2 of 3

Approved by: Godfrey Walala

Traffic control system		
Check the following:-	Booms functionality	V
	Traffic lights	lovay
1		V Ceay
(4)	Clean cameras	
90	Network equipment	
Generator		
Check the following:-		
	Battery Voltage	V 13.7V DC
N 21	Took was sonest	VOVAN
	Test run genset	
	 Fuel level	3/14 Full
	Voltages on test run(vac)	V L-L1415V; L-N240V
,		
	Run hours to service	76.3hr
n		VOCAU
5 " " 0 0 1	Emergency button	COCAY
Buildings & General Maintenance		
Check the following:-		
*	Power to Buildings	V
		L GORACI
ii	Power to Switches	
· ·	Dower to applied outlete	
n	Power to socket outlets	
ж	Power to Bulbs	
	Fower to buins	
	Power to Floodlights	
	J 2 4450	COPS AR is faulty
	Air Conditioners	
	Leaking Roof	* NONE
		Vokay
	Drainage	



Doc Number: GMJV-KeNHA-BRW-WOM039FM008

Revision:

11

Doc Type:

Form

Author/Owner: Wellingtone Odali
Reviewed by: Maurice Ademba
Effective Date: January 2022
Review Date: January 2023

Number Pages: Page 3 of 3

Approved by: Godfrey Walala

Title: Daily Maintenance Report

1				
3				
Others		X		None
Health, Safety & Environment				
Check the following:	Adherence to safety procedures by staff		V	7 Adhered to
	Adheres to min PPE		V	
	Potential hazards	1		None

Prepared By: (Technician)	BILLY	MOGAKA		Sign_Rth
Checked By: (Duty Manager	Sammy	Chira	Sign _	6





Site Name

JV Management System

Title: Generator Start-Up Form

BUSIA

Doc Number: GMJV-KeNHA-BRW-WOM0 39FM002

Revision:

01

Doc Type :

Form

Author/Owner: Wellingtone Odali Reviewed by: Maurice Ademba

Effective Date: January 2022

Review Date : January 2023

Number Pages : Page 1 of 2

Approved by: GodfreyWalala

Name of Technician	BILLY	MOGALLA	 	
Date or Duration valid	07/09/	2022	 	

GENERATOR START UP PROCEDURE-14KV	/A 3PHASE	TEKSA	AN GENERATOR
	√	Х	COMMENTS
1. Ensure the emergency (RED) buttons are NOT pressed in. If pressed-in twist clockwise and the button will pop out.	V		7
2. Press the STOP soft key for 2 seconds to clear any old emergency status	V		4 Done 3
3. Press the AUTO soft key till the GREEN LED appears to show the generator is on automatic standby.	V		Working
4. Incase the generator is switched off using the emergency button, follow the steps 1 to 3 again	V		Working
5. Whenever the generator does not start automatically and its on AUTO standby, press the OFF soft key button then press either AUTO or MANUAL soft key button	V		
6. When generators comes ON afrer procedure 5. above press the AUTO soft key button	V		
7. To stop the generator whenever the automatic change over does not switch it OFF use the STOP soft key not the EMERGENCY button	V		
8. Always ensure before locking the generator shelter that you inspect it for leakages. Follow steps 1 and finally inspect the cables	V		



Title: Generator Start-Up Form

Doc Number: GMJV-KeNHA-BRW-WOM@39FM002

Revision:

01

Doc Type:

Form

Author/Owner: Wellingtone Odali Reviewed by: Maurice Ademba Effective Date: January 2022

Review Date: January 2023

Number Pages: Page 2 of 2

Approved by:

Godfrey Walala

RESETTING THE GENERATOR AFTER SERVICE ALARMS COME ON

1. Use the programme (PGM) arrow < > soft keys to select the function on the controller screen.	V	
2. Select COUNTERS screen, the first screen will show engine total hours of running, after pressing the arrow key again, the second COUNTERS screen will show Engine hours to service request	/	4 Done 3
3. If the hours (100hrs) to service request have already been achieved and the alarm lamp for service request and the hazard lamp are ON, call the service provider immediately	V	Correctly
4. To enable the generator to run before the service provider is on site, clear the alarms by pressing the test lamp ☼ and the alarm ∃ ◀ soft key buttons together for 2secs till alarm! Clears then press the STOP soft key button to clear the alarm for service request.	V	
5. Press the AUTO button soft key button.		

Prepared By: (Technician) BILLY MOGALA Sign_

Checked By: (Duty Manager) Sammy Clin



Title: HSWIM Check List

Doc Number: GMJV-KeNHA-BRW-WOM039FM004

Revision:

Doc Type :

Form

Author/Owner: Wellingtone Odali Reviewed by: Maurice Ademba

Effective Date: January 2022 Review Date: January 2023 Number Pages: Page 1 of 1

Approved by : Godfrey Walala

HSWIM CHECK LIST

Name	of	TAC	hni	cian

Date or Duration valid

Site Name

PHYSICAL & SYSTEM CHECKS	FREQ	√	Х	COMMENTS
Check on the functionality of Weighing Sensors	D	V		7
Check on the functionality of Loops	D	1		yokay.
Check on the functionality of MSI Position Sensors	D	V		9
4. Check on the functionality of ANPR cameras	D			
5. Check on the functionality of Overview Cameras	D	<u></u>		
6. Check on the alignment of ANPR and Overview Cameras	D	1		
7. Check on the functionality of gantry floodlights	D	V	89	Additional light needs.
8. Check whether HSWIM parameters are transmitted and viewed at the Directing Office.	D	v		7
Check on the state of Grounding and Lightening Arrestors	D	V		
10. Check on the Physical State of HSWIM Equipment	D	V		Okay
i) Check cables are intact and well terminated and not exposed	D			
ii) Check on the grouting status of the sensors	M	1		
iii) Check on the physical state of the gantry (ensure it is not knocked/damaged)	D	レ		
iv) Check on the state of gantry protection (bollards)	D			3 bollarde are broken
v) Check cable routing (pipes, sleeves and ducts) are secure and not flooded with water	D	~		7
vi) Check whether silt/soil has accumulated at the sensor area	D	~		YOKay
vii) Check drainage around the sensor area to ensure it is not flooded.	D	V		
11. Check on the white box components	D	~		
 i) Check on the functionality and physical state of Breakers, Connectors, PLCs, Network Switches, Power Supply and cable termination. 	D	V		
*Gantry Cameras to be cleaned and aligned monthly	M	V		\cup

NB: APPlies	to KMPL	BND HSW	IM.	Like Mildel
KSM BA	A HSWIM A	twaiting C	lean trione	V HIGHWAYS AUTHO
Prepared By: (Technician)	ISILLY MOGA	Sign		
Checked By: (Duty Manager)	Sammy Chira	Sign	0.7	SEP 2022
6			San	GE SIANO
*			. Box 49	NEIGHBRIDO, HAIR



CHECK LIST

JV Management System

Title: SCALE ANPR, SCALE SIDE VIEW & CCTV CAMERAS

Doc Number: GMJV-KeNHA-BRW-WO M039FM007

Revision:

01

Doc Type:

Form

Author/Owner: Wellingtone Odali Reviewed by: Maurice Ademba

Effective Date: January 2022

Review Date: January 2023

Number Pages: Page 1 of 1

Approved by: Godfrey Walala

SCALE ANPR. SCALE SIDE VIEW & CCTV CAMERAS CHECKLIST

Name	of	Technician	

Date or Duration valid

Site Name

BILL	4	MOGA
OT	09	2022
BUS	A	

CAMERAS CHEKLIST	FREQ	√	Х	Comments
NPR & Side View photos				
. Check with the system administrators at the image server all cameras				
10 (PEC 1995) (1	D			
o ensure they are all ON 2. If all cameras are OFF check the single phase consumer unit at the	D	-		1
	D			VOKay.
veighing room for any tripped MCB	D	+		
s. If the cameras are OFF randomly, check the yellow boxes at the		1		
amera pole for a tripped MCB or a faulty blue ginger PSU (check LED)	D			
I. If blue ginger and/or circuit breaker are faulty after testing the input and	<u> </u>			
butput ensure they are replaced (AC circuit breaker input & output=240V				
hile Blue ginger input AC 240V & output DC 12V)	D			
i. If 4 above is true test the camera functionality from the server with the	D	-		
system admin	D	V		
is, Inspect cameras' 4 port IP switches in the outdoor housing-Check that	U	- /		
s powered, ports LED blinking, cables connected securely	w			
s powered, ports LED blinking, cables connected securely	VV	-		
t to a controlling and a second for why wind domains or mindignment	D			
'. Inspect all cameras for physical damage or misalignment	D	- V		
the section of the se	D	1/		
Inspect cameras view relative to master alignment photo. If camera is misaligned after 7 above, realign the camera as required.	D			
	D	V		
nd test the view from the image server again 0. Wipe all camera view window with a clean damp cloth followed by a	D			
ry lint free cloth till the window is clean	w			
Inspect the lanes next to the cameras for probable danger of	VV			
nocking the poles and advise accordingly	D			
Check floodlights for proper functionality-ON/OFF status as required-	<u> </u>			
Night inspection)	w	i/		
Night Inspection)	**			
3. Check floodlights for proper alignment	w			Additional lights need
S. Cricek hooding its for proper disgriftering				The comment of the co
CCTV				at KMPL RAJ ANPR
. Check at the LED monitor for ON or OFF status for all CCTV				
ameras	D	-		
. If any camera is OFF check the single phase consumer unit at the				
veigh room for any tripped MCB	D	1		
L Check BNC connectors for proper connections at the back of the DVR	-	_		
n case 2 above is ON and cameras are still OFF	D			Jokay
. Check for proper focus of each CCTV camera	W	V		
i. If any camera is off focus, have a person (system admin) at the				
creen and yourself at the camera to adjust the focus knobs under the		4		
Redi view cameras till focus is restored.	W			
. Check the playback of the CCTV cameras at the DVR at different		+		
	W	-		
atto erre mil				
. Inspect the CCTV cameras for physical damage and misalignment	W	1		
Inspect the CCTV cameras for physical damage and misalignment. If misaligned after 6 above ensure they are correctly aligned as the per		,		THE HOLD WAY
ne master alignment photo	W			FUONAL HIGHWAYS AME
. Wipe all camera view window with a clean damp cloth followed by a	* *			O 7 SEP 2022
	W			

NOTES

- 1. Use a lint free cloth to clean Camera lenses and windows
- 2. Use a properly functioning multimeter to measure voltage
- 3. Ensure you have all minimum personal protective safety gear while working at heights

O. BOX 49712 - 00100. NAIROS