# How do I configure Remote Management for my TP-Link Wireless Router?

User Application Requirement

Updated 04-18-2019 07:10:55 AM

**1**229502

This Article Applies to: ♥

#### Step 1

Open the web browser and in the address bar type in:

http://192.168.1.1 or http://192.168.0.1 or http://tplinklogin.net

Then press Enter.



#### Note:

The LAN IP is vary by model. Please find it on the bottom label of the product.

#### Step 2

Type the username and password in the login page. They are both admin by default.




#### 5 ac. 3

Security->Remote Management on the left side.

#### Step 4

With the default setting (Port 80 and IP address 0.0.0.0), the **Remote Management** function is disabled. To enable this function, please change the **Remote Management IP address** from 0.0.0.0 to a specific authorized remote IP address.

You can also change the **Web Management port** to another one if necessary, this is also a security enhancement.



#### Step 5

Click **Save** to save the settings.

To access the Router, you should enter your Router's WAN IP address into your browser's address (in IE) or location (in Netscape) box and the custom port number. For example, if your Router's WAN address is 202.96.12.8 and you use port number 8080, enter http://202.96.12.8:8080 in your browser. You will be asked for the Router's password. After successfully entering the password, you will be able to access the Router's web-based utility.

#### Note:

- 1. Type a specific Public IP address for the Remote Management IP Address means that you can only connect to this device remotely from a computer which is using this specific IP address.
- 2. Type **0.0.0.0** Remote Management IP Address means that you cannot connect to this device remotely.
- 3. Type **255.255.255**.Remote Management IP Address means that you can connect to the router remotely from anywhere via Internet, this is not recommended and please use it with caution.
- 4. We suggest changing the default log in Username and Password if the Remote Management feature is enabled, especially if you typed 255.255.255.255 as the Remote Management IP address. Please click <u>How do I change the Administrative username and Password</u> to view how to change them.

to know more details of each function and configuration please go the manual of your product.

### Is this faq useful?

Your feedback helps improve this site.

Yes

No

## **Recommend Products**





TL-WR841N

300Mbps Wireless N Router

TL-WR940N

450Mbps Wireless N Router



# **TP-Link Community**

Still need help? Search for answers, ask questions, and get help from TP-Link experts and other users around the world.

<u>Visit the Community ></u>

**Subscribe** 

**Let's Connect** 

Be The First To Get Exclusive Deals & News

**Email Address** 

Subscribe

#### 4/19/25, 8:01 PM

#### How do I configure Remote Management for my TP-Link Wireless Router?

About Press Partners Learning Center

About Us News Partner Program Technology Trends

Corporate Information Blog Partner Deal Registration Training & Certification

Contact Us Security Advisory MAP Policy

Careers at TP-Link Awards

Privacy Policy

Do Not Sell My Info

Accessibility

**Promotions** 

©2025 TP-Link Systems Inc. and its affiliated companies. All rights reserved.

United States / English

TP-Link, Tapo, Kasa, Omada, VIGI, Aginet, HomeShield, and Tapo Care branded products are products of TP-Link Systems Inc. or its affiliates.

Note: Some services and materials may require you to accept additional terms and conditions before access or use.

References to "TP-Link" may include TP-Link Systems Inc., its subsidiaries, or business units within the TP-Link corporate structure, as applicable.

The materials provided, including but not limited to press releases, presentations, blog posts, and webcasts, are current as of the date of publication and may be superseded by subsequent updates.