Setting up Raspberry Pi for Tensile Tester operation

OS version: raspios bullseye

- 1. Follow the usual steps to create a RPi image and boot
 - 1. It is easiest to use the dedicated application, *Raspberry Pi Imager*, that creates the SD card for your RPi
 - 2. Choose to customize the installed image
 - 3. Set the hostname to tensilepi
 - 4. Set the username to tensile and the password to t3ns1le
 - 5. You can try to set the wireless nework to UWS and your password, but usually this doesn't work because UWS is, well, UWS :-(
 - 6. Set the wireless LAN country to CA
 - 7. Set the locale to Edmonton and leave the keyboard a US
 - 8. Change to the Services section and enable SSH. Select "Use password authentication"
 - 9. Save and say yes to using the custom settings, then yes to start formating the image
- 2. When the Imager is finished, pop the SD card into the RPi and boot
- 3. The very first boot will take some time as the OS configures itself.
- 4. Connect to Wifi
 - 1. It appears that UWS at the UofA will not work
 - 2. An option is to tether to a cellphone, which does work well.
- 5. Update the system via the terminal; sudo apt update, then sudo apt upgrade
 - 1. This may take a while
- 6. Enable VNC
 - sudo raspi-config
 - 2. Navigate to Interface Option and hit enter
 - 3. Navigate to VNC and hit enter
 - 4. Set the VNC server to be yes, hit enter
 - 5. exit raspi-config

- 6. reboot
- 7. Test the VNC connection using your laptop
 - 1. On a Mac, install tigervnc-viewer, for example
 - 2. Get the RPi IP address
 - 3. Connect using the VNC viewer
- 8. Install and configure node-red using this guide
 - 1. Execute in a terminal the following

```
bash <(curl -sL https://raw.githubusercontent.com/node-red/linux-
installers/master/deb/update-nodejs-and-nodered)</pre>
```

- Install the RPi specific nodes
- Don't set up user security
- Don't set up the Projects feature
- Name the flows file flows_tensilepi.json
- Use t3ns1le for the catchphrase
- · Choose the default colour scheme
- · Select the default font, monaco
- Allow Function nodes to load external modules
- 2. Enable node-red to start at boot

```
sudo systemctl enable nodered.service
```

3. Check if it's running by ps ax | grep node and if not, start using

```
sudo systemctl start nodered.service
```

- 4. Now you can bring up the node-red flow editor on a computer on the same network as the tensilepi by connecting to http://tensilepi.local:1880 in a browser
- 9. Install the node-red dashboard and git packages

```
cd ~/.node-red
npm i node-red-dashboard
npm i npm install node-red-contrib-git-nodes
```

10. Install and configure pigpio

sudo systemctl enable pigpiod

11. Restart node-red on the RPi

node-red-restart

- 12. Once restarted, you can bring up the node-red dashboard on a computer on the same network as the tensilepi by connecting to http://tensilepi.local:1880/ui in a browser.
 - changes made in the flow editor will be reflected in the UI once they are "deployed"
- 13. The flow editor can be accessed by connecting to http://tensilepi.local:1880