WARNING

SERVICES AND ENVIRONMENT THAT GUARANTEES THE PROPER FUNCTIONNING OF THE PRODUCTS FROM THIS COMPANY. THE PURCHASER, AND THE PURCHARSER'S INSTALLERS SHALL PROVIDE THE SUPPLY LINES NECESSARY FOR EACH PRODUCT IN ACCORDANCE WITH ESTABLISHED APPLICABLE NORMS AND REGULATIONS. THE COMPANY DECLINES ALL RESPONSABILITY FOR FAILURE TO COMPLY WITH SUCH LAWS AND REGULATIONS.

NOTE

THIS COMPANY RESERVES THE RIGHT TO MODIFY THIS DRAWING ACCORDING TO THE TECHNICAL DEVELOPMENT OF THE EQUIPMENT.

This equipment has been designed for use in accordance with the International EMC(Electromagnetic Compatibility) Standards. In view of different environments, please follow the instructions given below to eliminate interference, if necessary.

- Move the equipment or rotate its direction;
- Enlarge the space between the equipment and other machines:
- Put the plug into other outlets;
- Please consult with the local distributor or qualified electrician.

Installation:

- 1. It will require at least Four(4) or more people to carry the sterilizer to avoid dropping it off by mistake.
- 2. Located position the sterilizer on a stable bench or work surface.
- 3. Position the sterilizer on a stable laboratory bench or work surface, ensuring at least 100~200 mm clearance between the wall or other pieces of equipment and the sides of the unit for free circulation of air.
- 4. Make sure that the door can be opened freely after installation.
- 5. Do not install or operate the sterilizer in areas where flammable items or volatile substances are used or stored. An explosion could occur, causing personal injury, An installation site with good air circulation is required.
- 6. A separate (dedicated) socket is required for the sterilizer. Make sure the socket is earthed and can offer the capacity of 20 A / 230V AC/ 3000 W.

ENVIRONMENT CONDITIONS IN THE STERILE AREA:

- Indoor use;
- Under 1,000m (altitude);
- Temperature 5°C to 40°C:
- Relative Humidity 80%RH@31°C to Relative Humidity 50%RH@40°C;
- Voltage fluctuation ±10 %;
- Transient overvoltages category II);
- (Pollution degree 2)


Important Safety Instructions:

- 1. Connect the external water supplier to the water inlet with presure greather than 2~ 8 bar,15~30°C.
- 2. Refer to the table for the requirements of water quality.
- 3. Connect the drainage pipe to exhaust the used water according to the local authority's law.
- 4. Do not obstruct the drainage system.
- 5. Consult technicians for the correct connections.
- 6.Drainage pipe ♥≥1" metallic pipe, corrosion resistance 2"G. and a temperature of 100°C above.

ATTENTION:

- CHAMBER DIMENSIONS: Ø300 mmx710 mm.
- DEVICE OUTSIDE DIMENSIONS:600(W)mmx980(h)mmx450(D)mm.
- ALL THE OUTLETS MUST BE INSTALLED ACCORDING TO LOCAL APPLICABLE NORMS.
- THE INSTALLATION UP TO THE MACHINE AS WELL AS THE SUPPLY OF ACCESSIBLE KEY ACCORDING TO THE SPECIFICATIONS INDICATED IN THE DRAWING, ARE CHARGEABLE TO THE PURCHASERS.
- THE MEASUREMENTS OF THIS DRAWING ARE CONSIDERING FINISHED WALLS.
- THE SPACES OF MAINTENANCE MUST BE SUFFICIENTLY ILLUMINATED.





MARK REVISION RECORD 參更內容

MANE 名 SA-300VMA INSTALLATION PLAN

SA-300VMA-HE-001-01

UNIT 單位 mm

MODEL NO. 代表機種 SA-300VMA

表面處理

DRAWN修改

DATE日期

Table: Suggested maximum limits of contaminants in

and specification for water for steam sterilization

Evaporate residue

feed water

≤10 mg/l