TES-1500 Capacitance Meter





0.5% Accuracy.
Overload Fuse protection.
Test Clips/Direct insert jack for easy measurement.





SPECIFICATION

Range	Resolution	Accuracy	Max. In- range Display	Test Frequency	Overload Protection
200pF	0.1pF	+/- (0.5%+1+0.5pF)	199.9pF	800Hz	0.25A/250 Fuse Protection
2nF	1pF	+/- (0.5%+1)	1.999nF	800Hz	0.25A/250 Fuse Protection
20nF	10pF	+/- (0.5%+1)	19.99nF	800Hz	0.25A/250 Fuse Protection
200nF	100pF	+/- (0.5%+1)	199.9nF	800Hz	0.25A/250 Fuse Protection
2 m F	1nF	+/- (0.5%+1)	1.999 m F	800Hz	0.25A/250 Fuse Protection
20 m F	10nF	+/- (0.5%+1)	19.99 m F	80Hz	0.25A/250 Fuse Protection
200 m F	100nF	+/- (0.5%+1)	199.9 m F	8Hz	0.25A/250 Fuse Protection
2000 m F	1 m F	+/- (1%+1)	1999 m F	8Hz	0.25A/250 Fuse Protection
20mF (20000 m F)	10 m F	+/- (2%+1)	19.99mF	8Hz	0.25A/250 Fuse Protection

Operating Principle	Dual Slop Integration		
Display Rate	Approx. 2 times per second		
Zero Adjustment	+ - 20pF Approx.		
Operating/Storage Condition	0°C to 40°C < 80% R.H. -10°C to 60°C < 70% R.H.		
Power Source	006P DC 9V 1pc		
Size & Weigh	135mm(L) x 72mm(W) x 33mm(H) & 207g		
Accessories	Test Clips, Spare Fuse, Battery & Instruction Manual		

pF = 10^{-12} F, nF = 10^{-9} F, μ F= 10^{-6} F