
TensegritySim Documentation

Release 1.0.0

Austin Brown

Mar 09, 2025

CONTENTS:

1	2D Tensegrity Sim	1
1.1	About	1
1.2	Getting started	1
1.3	Definitions and Conventions (as used in this project)	1
1.4	Organization	1
2	Simulation Setup	3
2.1	Parser	3
2.2	Visualizer	3
2.3	TensegritySolver	3
3	YAML Reference	5
3.1	Nodes	5
3.2	Connections	5
3.3	Builders	6
3.4	Pins	6
3.5	Control	7
3.6	Surface	7
4	Data Structures	9
4.1	Node	9
4.2	Connection	9
4.3	Surface	11
4.4	Tensegrity	11
5	YamlParser	13
6	TensegritySolver	15
7	Visualization	19
	Index	21

2D TENSEGRITY SIM

1.1 About

This repo contains code to create a simulation for Tensegrity structures specifically tailored to the needs of the Elbow Brace Project.

1.2 Getting started

I recommend using a venv to keep the libraries for this project separate from the main python interpreter. To create a venv, from the project's main directory run `python3 -m venv ./venv`. Now everytime you want to use this venv run `source venv/bin/activate`. To deactivate simply use the `deactivate` command. If running on WSL, tkinter may not be installed by default. If the visualization doesn't open when you run the project you can install tkinter with `sudo apt install python3-tk`

This project uses Python3, in order to run it you will need some dependencies. To get them you can run `pip install -r requirements.txt` (with the venv active)

To run the project:

```
python3 main.py <path/to/yaml/config>
```

Sample yaml config files are provided in the `yaml` directory. To understand how to change the simulation to your needs, see the *simulation setup* documentation.

1.3 Definitions and Conventions (as used in this project)

Strings - Strings are connection types that only carry tension, they lengthen as force is applied

Bar - A bar can carry either tension or compression, but does not change length

Forces - Tensions are positive values and compression forces in connections are negative.

1.4 Organization

`main.py` is the primary file to run the project. It take as an input a yaml file an allows the user to change the length of control strings

1.4.1 TensegritySim Module

The TensegritySim directory contains all the code TensegritySim python module.

- `data_structures.py` contains the `Node`, `Connection`, `Control`, and `Tensegrity` classes

- `yaml_parser.py` reads the yaml file and returns the Tensegrity object. See *YAML Reference* for how to format the yaml file
- `visualization.py` shows the tensegrity structure using matplotlib
- `tensegrity_solver.py` uses an optimizer to solve for an updated structure

1.4.2 yaml

The `yaml` directory contains sample yaml files for running the sim

SIMULATION SETUP

The `main()` function in `main.py` can be changed to run the simulation as desired.

The primary parts to the simulations are:

- The `YamlParser`
- The Visualization
- The `TensegritySolver`

2.1 Parser

This should be the first step to running the simulation. It takes the input yaml file from the commandline and creates the `Tensegrity` object.

```
from TensegritySim import YamlParser

# Load the tensegrity system from the YAML file
tensegrity_system = YamlParser.parse(file)
```

2.2 Visualizer

The `Visualization` class takes in a `Tensegrity` object and can then be used to plot the tensegrity system using the `plot()` method.

```
from TensegritySim import Visualization as Viz

# Create the visualization object
viz = Viz(tensegrity_system)

viz.plot(label_nodes=True, label_connections=True)
```

2.3 TensegritySolver

The `TensegritySolver` class takes in a `Tensegrity` object and can then be used to solve the system using the `solve()` method.

A tensegrity object with a surface defined should use the `TensegritySolver` with the `dimension` parameter set to 2.

```
from TensegritySim import TensegritySolver

# Create the TensegritySolver object
solver = TensegritySolver(tensegrity_system, dim=2)

# Manipulate the tensegrity system
tensegrity_system.change_control_lengths(-0.5)

solver.solve()
```


YAML REFERENCE

The config file is a YAML file defining:

- *Nodes*
- *Connections*
- *Builders*
- *Pins*
- *Control*
- *Surface*
 - *Type*
 - *Linked Nodes*

These sections can be defined in any order in the YAML file, but it is easiest to logically go through them in the order defined above.

There are sample config files in the `yaml` directory.

3.1 Nodes

Nodes are the points that bars and strings connect at.

Nodes have a name and initial x, y, z positions.

A node named `Node1` with `x = 1`, `y = 2`, and `z = 0`, it would look like:

```
nodes:  
  Node1: [1, 2, 0]
```

3.2 Connections

Connections are how the nodes are connected to each other. There can be unlimited connection types, with each connection type having different properties as defined in the *Builders* section.

A connection type named `strings` with a connection between `Node1` and `Node2` looks like:

```
connections:  
  strings:  
    - [Node1, Node2]
```

Connections can also optionally be named (for later specifying connections to control).

```
connections:
  strings:
    - string1: [Node1, Node2] # Named connection
    - [Node2, Node3] # Unnamed connection
```

String connections (as defined in the builders section) can pass through multiple nodes. They are assumed to frictionlessly pass through nodes and therefore always have the same tension along it's entire length.

```
connections:
  strings:
    - string1: [Node1, Node2, Node5, Node6]
```

3.3 Builders

Builders are the connection properties that define the strings or bars that hold the nodes together. A builder must have a name matching a connection type in the Connections section.

For the `string` connection type with a stiffness (k) of 100N/m (it is actually unitless, but it helps me to think of everything in terms of metric units) and the unstretched length of the string 95% of the currently defined length between nodes:

```
builders:
  strings:
    stiffness: 100
    type: string
    initial_length_ratio: 0.95
```

If the unstretched length of the string is unknown but the tension is known, Hooke's Law can be used to calculate the initial length: $F = k * (l_s - l)$ where l_s is the stretched length of the string (distance between it's nodes) and l is the unstretched length.

Bars are defined in the builder's sections just like strings. The `initial_length_ratio` is normally left out because bars are usually significantly stiff enough it is assumed to be 1

```
builders:
  bars:
    stiffness: 10000
    type: bar
```

Important: The name of each builder can be what ever the user desires (bars, strings, high_tension_strings, blue_string, red_springs, etc), but the defined type in each must be exactly `bar` or `string`

3.4 Pins

In 2D space the solved structure can float anywhere in the XY plane with any rotation unless we pin nodes (to define a place in XY space the structure is fixed to)

A pin needs a node name and a list of True/False values, with True indicating that the node is translationally pinned in that direction. To pin Node1 in the x and y directions:

```
pin:
  Node1: [True, True, False]
```

3.5 Control

The `control` section defines which strings are able to be controlled (change length).

To define a control string the name of the connections need to be defined. For instance if the connection `String1` is being controlled:

```
control:
- String1
```

3.6 Surface

3.6.1 Type

The only type of surface currently implemented is a cylinder. A radius must be specified for the radius of the cylinder to wrap the tensegrity around.

The structure is wrapped around a $\hat{k}$ axis. In other words the x-axis wraps the circumference of the cylinder with a set radius, r . In the future I hope we can define the radius to change as a function of the z height, either with an equation, or reading in points from a file and using interpolation.

3.6.2 Linked Nodes

The linked nodes section takes pairs of nodes to be connected to each other on opposite sides of the cylinder.

```
surface:
  cylinder:
    radius: 3.5

  linked_nodes:
    - [Node1, Node7]
    - [Node4, Node8]
    - [Node9, Node12]
```

The only currently defined surface for linking nodes around is a cylinder.

DATA STRUCTURES

4.1 Node

class TensegritySim.**Node**(*name: str, position: list*)

Represents a node in a 2D tensegrity structure.

name

The name of the node.

Type

str

position

The position of the node in 3D space as a numpy array.

Type

numpy.ndarray

copy()

4.2 Connection

class TensegritySim.**Connection**(*nodes: List[Node], connection_type: ConnectionType, stiffness: float = 0, initial_length: float | None = None, name: str | None = None*)

Represents a connection between nodes in a tensegrity structure.

nodes

A list of nodes that are part of the connection.

Type

List[Node]

nodes_original

A list of the original positions of the nodes.

Type

List[Node]

connection_type

The type of connection.

Type

ConnectionType

stiffness

The stiffness of the connection.

Type
float

initial_length

The initial length of the connection.

Type
float

force

The force in the connection.

Type
float

name

The name of the connection.

Type
str, optional

initial_length_ratio

The initial length ratio of the connection.

Type
float, optional

class ConnectionType(*value*)

An enumeration.

BAR = 2

STRING = 1

current_length(*linked_nodes: List[Tuple[Node, Node]] | None = None*)

Calculates the current length of the connection, considering linked nodes if provided.

Parameters

linked_nodes (*List[Tuple[Node, Node]]*, *optional*) – A list of tuples representing linked nodes. Defaults to None.

Returns

The current length of the connection.

Return type

float

update_force(*current_length: float*)

Updates the force in the connection using the provided current length.

Parameters

current_length (*float*) – The current length of the connection.

4.3 Surface

class TensegritySim.**Surface**(*shape: Dict, linked_nodes: List[Tuple[Node, Node]]*)

Represents a surface in the simulation.

shape

The shape of the surface. Contains ‘surface_type’ and ‘properties’.

Type

dict

linked_nodes

A list of tuples representing the linked nodes that form the seam on the surface.

Type

List[Tuple[Node, Node]]

4.4 Tensegrity

class TensegritySim.**Tensegrity**(*nodes: List[Node], connections: List[Connection], pins: Dict[str, List[bool]] | None = None, controls: List[Connection] | None = None, surface: Surface | None = None*)

Represents a tensegrity structure.

nodes

A list of nodes in the tensegrity structure.

Type

List[Node]

connections

A list of connections between the nodes.

Type

List[Connection]

pins

A dictionary representing the pinned nodes. Defaults to an empty dictionary.

Type

Dict[str, List[bool]], optional

controls

A list of control connections. Defaults to an empty list.

Type

List[Connection], optional

surface

The surface on which the tensegrity structure is placed. Defaults to None.

Type

Surface, optional

update_forces()

Updates the forces in all connections. Call after updating the positions of the nodes.

get_control_order()

Returns a comma-separated string of the names of the control connections.

Returns

A comma-separated string of the names of the control connections.

Return type

str

change_control_lengths(*delta_lengths)

Changes the lengths of the control connections by the given delta lengths.

Parameters

***delta_lengths** (*float*) – Variable number of arguments representing the changes in lengths for each control connection.

Raises

ValueError – If the number of delta lengths provided does not match the number of control connections.

reset_control_lengths()

Resets the lengths of the control connections to their original lengths.

YAMLPARSER

class TensegritySim.YamlParser

A class for parsing YAML files and creating a Tensegrity object.

parse(file

str) -> Tensegrity: Parses the YAML file and returns a Tensegrity object.

static parse(file: str) → *Tensegrity*

Parses the YAML file and returns a Tensegrity object.

Parameters

file (str) – The path to the YAML file.

Returns

The tensegrity system containing Nodes and Connections.

Return type

Tensegrity

Raises

- **FileNotFoundError** – If the specified file does not exist.
- **yaml.YAMLError** – If the YAML file is invalid.
- **KeyError** – If a builder type does not have a builder.
- **ValueError** – If a connection type is not recognized.

TENSEGRITYSOLVER

class TensegritySim.**TensegritySolver**(*tensegrity*: Tensegrity, *dim*: int = 2)

TensegritySolver class for solving the positions of nodes in a tensegrity structure. This class provides methods to initialize the solver, set forces on nodes, and solve the positions of nodes using optimization techniques. It also includes internal functions to compute the objective function, spring connection energy, and its derivatives.

tensegrity

The tensegrity object containing nodes and connections.

Type

Tensegrity

dim

The dimension of the optimization problem (default is 2).

Type

int

set_forces(*forces*: Dict[str, ndarray]) → None

Sets the forces on the nodes in the tensegrity structure.

Parameters

forces (Dict[str, np.ndarray]) – A dictionary containing the forces on each node.

Raises

ValueError – If the force vector does not have the same dimension as the optimization problem.

solve(*method*: str = 'lm') → None

Solves the position of nodes in the tensegrity structure.

This method uses the root function from the scipy.optimize module to find the positions of the nodes in the tensegrity structure with Virtual Work.

Parameters

method (str) – The method to use for the root function (default is “lm”).

Returns

None. Changes are made internally to the Tensegrity object.

_objective(*x*: ndarray) → ndarray

Computes the objective function for the optimization problem. This function calculates the virtual work from potential energy and external forces, and optionally includes surface constraints if a surface is defined.

Parameters

x (np.ndarray) – Input array representing the generalized coordinates.

Returns

The objective function value, which is the virtual work with optional surface constraints.

Return type

np.ndarray

_spring_connection_energy(*connection*: [Connection](#), *N*: ndarray) → float

Calculates the energy stored in a spring connection.

Parameters

- **connection** ([Connection](#)) – The spring connection object.
- **N** (np.ndarray) – The current positions of all nodes.

Returns

The energy stored in the spring connection.

Return type

float

_spring_connection_energy_derivative(*connection*: [Connection](#), *N*: ndarray) → ndarray

Calculates the derivative of the spring connection energy with respect to node positions.

The energy of a spring connection is given by:

$$V = 0.5 * k * (l - l_0)^2$$

where k is the stiffness, l is the current length of the connection, and l_0 is the rest length.

The derivative of the energy with respect to the position of node i is:

$$\begin{aligned} dV/dq_i &= -k * (l - l_0) * dl/dq_i \\ &= C * dl/dq_i \end{aligned}$$

where C is a constant factor.

Parameters

- **connection** ([Connection](#)) – The connection object representing the spring.
- **N** (np.ndarray) – The array of node positions.

Returns

The derivative of the spring connection energy with respect to the node positions.

Return type

np.ndarray

_length_derivative(*connection*: [Connection](#), *N*: ndarray) → ndarray

Calculates the derivative of the length of a connection with respect to the node positions.

Parameters

- **connection** ([Connection](#)) – The connection object containing the nodes.
- **N** (np.ndarray) – The array of node positions.

Returns

The derivative of the length with respect to the node positions.

Return type

np.ndarray

_connection_length(*connection*: [Connection](#), *N*: *ndarray*) → float

Calculates the current length of a connection based on the node positions.

Parameters

- **connection** ([Connection](#)) – The connection object.
- **N** (*np.ndarray*) – The current positions of all nodes.

Returns

The current length of the connection.

Return type

float

_node_distance(*node1*: *str*, *node2*: *str*, *N*: *ndarray*) → float

Calculates the distance between two nodes based on their positions.

Parameters

- **node1** (*str*) – The name of the first node.
- **node2** (*str*) – The name of the second node.
- **N** (*np.ndarray*) – The current positions of all nodes.

Returns

The distance between the two nodes.

Return type

float

_surface_constraints(*x*: *ndarray*) → *ndarray*

Computes the surface constraints for the optimization problem.

Parameters

x (*np.ndarray*) – The input array representing the current state of the nodes.

Returns

An array of constraints that must be satisfied. For a cylindrical surface,
the constraints ensure that: - The y-coordinates of linked nodes are equal. - The x-coordinates of linked nodes are exactly the circumference of the cylinder apart.

Return type

np.ndarray

_create_initial_guess() → *ndarray*

Creates the input vector *x0* for the optimization problem (node positions - pinned nodes).

Returns

The input vector *x0*.

length = *d**len(nodes) - pins, Elements are the node positions (except those that are pinned)

Return type

np.ndarray

_get_nodes_from_input(*x*: *ndarray*) → *ndarray*

Extracts node positions input vector (adding the pinned nodes back in).

Parameters

x (*np.ndarray*) – The input vector containing node positions.

Returns

The extracted node positions including those removed from the input because they were pinned.

Return type

`np.ndarray`

VISUALIZATION

class TensegritySim.**Visualization**(*tensegrity*: Tensegrity, *dim*: int = 2)

Visualization class for tensegrity structures.

This class provides methods to visualize 2D and 3D tensegrity structures using matplotlib.

tensegrity

The tensegrity structure to visualize.

Type

Tensegrity

dim

Dimension of the visualization (2 or 3).

Type

int

fig

Matplotlib figure object.

Type

Figure

ax

Matplotlib axes object.

Type

Axes

plot(*label_nodes*: bool = False, *label_connections*: bool = False, *label_forces*: bool = False)

Plots the visualization of the tensegrity structure.

Parameters

- **label_nodes** (*bool*) – Whether to label the node names in the plot. Default is False.
- **label_connections** (*bool*) – Whether to label the connection names in the plot. Default is False.
- **label_forces** (*bool*) – Whether to label the forces on the connections. Default is False.

_plot_2d(*label_nodes*: bool = False, *label_connections*: bool = False, *label_forces*: bool = False)

Plots the 2D visualization of the tensegrity structure.

Parameters

- **label_nodes** (*bool*) – Whether to label the node names in the plot. Default is False.

- **label_connections** (*bool*) – Whether to label the connection names in the plot. Default is False.
- **label_forces** (*bool*) – Whether to label the forces on the connections. Default is False.

_plot_3d(*label_nodes: bool = False, label_connections: bool = False, label_forces: bool = False*)

Plots the 3D visualization of the tensegrity structure.

Parameters

- **label_nodes** (*bool*) – Whether to label the node names in the plot. Default is False.
- **label_connections** (*bool*) – Whether to label the connection names in the plot. Default is False.
- **label_forces** (*bool*) – Whether to label the forces on the connections. Default is False.

set_3d_equal_scaling(*ax*)

Sets equal scaling for the 3D plot.

Parameters

ax (*Axes3D*) – The 3D axes object.

INDEX

Symbols

`_connection_length()` (*TensegritySim.TensegritySolver method*), 16
`_create_initial_guess()` (*TensegritySim.TensegritySolver method*), 17
`_get_nodes_from_input()` (*TensegritySim.TensegritySolver method*), 17
`_length_derivative()` (*TensegritySim.TensegritySolver method*), 16
`_node_distance()` (*TensegritySim.TensegritySolver method*), 17
`_objective()` (*TensegritySim.TensegritySolver method*), 15
`_plot_2d()` (*TensegritySim.Visualization method*), 19
`_plot_3d()` (*TensegritySim.Visualization method*), 20
`_spring_connection_energy()` (*TensegritySim.TensegritySolver method*), 16
`_spring_connection_energy_derivative()` (*TensegritySim.TensegritySolver method*), 16
`_surface_constraints()` (*TensegritySim.TensegritySolver method*), 17

A

`ax` (*TensegritySim.Visualization attribute*), 19

B

`BAR` (*TensegritySim.Connection.ConnectionType attribute*), 10

C

`change_control_lengths()` (*TensegritySim.Tensegrity method*), 12
`Connection` (*class in TensegritySim*), 9
`Connection.ConnectionType` (*class in TensegritySim*), 10
`connection_type` (*TensegritySim.Connection attribute*), 9
`connections` (*TensegritySim.Tensegrity attribute*), 11
`controls` (*TensegritySim.Tensegrity attribute*), 11
`copy()` (*TensegritySim.Node method*), 9

`current_length()` (*TensegritySim.Connection method*), 10

D

`dim` (*TensegritySim.TensegritySolver attribute*), 15
`dim` (*TensegritySim.Visualization attribute*), 19

F

`fig` (*TensegritySim.Visualization attribute*), 19
`force` (*TensegritySim.Connection attribute*), 10

G

`get_control_order()` (*TensegritySim.Tensegrity method*), 11

I

`initial_length` (*TensegritySim.Connection attribute*), 10
`initial_length_ratio` (*TensegritySim.Connection attribute*), 10

L

`linked_nodes` (*TensegritySim.Surface attribute*), 11

N

`name` (*TensegritySim.Connection attribute*), 10
`name` (*TensegritySim.Node attribute*), 9
`Node` (*class in TensegritySim*), 9
`nodes` (*TensegritySim.Connection attribute*), 9
`nodes` (*TensegritySim.Tensegrity attribute*), 11
`nodes_original` (*TensegritySim.Connection attribute*), 9

P

`parse()` (*TensegritySim.YamlParser static method*), 13
`pins` (*TensegritySim.Tensegrity attribute*), 11
`plot()` (*TensegritySim.Visualization method*), 19
`position` (*TensegritySim.Node attribute*), 9

R

`reset_control_lengths()` (*TensegritySim.Tensegrity method*), 12

S

`set_3d_equal_scaling()` (*TensegritySim.Visualization method*), 20
`set_forces()` (*TensegritySim.TensegritySolver method*), 15
`shape` (*TensegritySim.Surface attribute*), 11
`solve()` (*TensegritySim.TensegritySolver method*), 15
`stiffness` (*TensegritySim.Connection attribute*), 9
`STRING` (*TensegritySim.Connection.ConnectionType attribute*), 10
`Surface` (*class in TensegritySim*), 11
`surface` (*TensegritySim.Tensegrity attribute*), 11

T

`Tensegrity` (*class in TensegritySim*), 11
`tensegrity` (*TensegritySim.TensegritySolver attribute*), 15
`tensegrity` (*TensegritySim.Visualization attribute*), 19
`TensegritySolver` (*class in TensegritySim*), 15

U

`update_force()` (*TensegritySim.Connection method*), 10
`update_forces()` (*TensegritySim.Tensegrity method*), 11

V

`Visualization` (*class in TensegritySim*), 19

Y

`YamlParser` (*class in TensegritySim*), 13