# **Cinemate**

**User & Builder Guide** 

None

None

## Table of contents

1.	Cinemate	Docs	6
2.	Quick sta	rt	7
	2.1	Quick start	7
		2.1.1 Hardware requirements	7
		2.1.2 Installation	7
3.	Using the	camera	8
	3.1 5	Simple GUI	9
	3.2	Compatible sensors	10
	3.3 <i>A</i>	Audio recording (experimental)	12
	3.4 5	Speed ramping	15
		3.4.1 Speed ramping in Cinemate	15
		3.4.2 Shutter angle synchronisation	16
	3.5 [	Dual sensors	17
4.	Customis	ing your build	18
	4.1 5	Settings file	18
		4.1.1 welcome message	18
		4.1.2 system	19
		4.1.3 geometry	19
		4.1.4 output	20
		4.1.5 preview	20
		4.1.6 anamorphic_preview	20
		4.1.7 gpio_output	21
		4.1.8 arrays	21
		4.1.9 settings	22
		4.1.10 analog_controls	22
		4.1.11 free_mode	23
		4.1.12 buttons	23

	4.1.13 two_way_switches	24
	4.1.14 rotary_encoders	24
	4.1.15 quad_rotary_controller	25
	4.1.16 i2c_oled	26
4.2	CLI user guide	27
	4.2.1 Checking available options	27
	4.2.2 Camera modes	27
	4.2.3 Low-resolution (lores) stream	27
	4.2.4 Preview window	28
	4.2.5 Tuning files	28
	4.2.6 Post processing	28
	4.2.7 Cinemate-specific flags	29
	4.2.8 Example commands	29
4.3	Commands reference	31
	4.3.1 Available Commands	32
4.4	Connecting to the Pi with SSH	37
4.5	Configuring the Wi-Fi hotspot	38
System	management	39
5.1	System services	39
	5.1.1 cinemate-autostart.service	39
	5.1.2 storage-automount.service	39
	5.1.3 wifi-hotspot.service	40
5.2		
0.2	Modifying config.txt	41
0.2	Modifying config.txt  5.2.1 Adjusting config.txt for different sensors:	41 41
5.3	5.2.1 Adjusting config.txt for different sensors:	41
5.3	5.2.1 Adjusting config.txt for different sensors:  Recompiling cinepi-raw	41 42
5.3 5.4 5.5	5.2.1 Adjusting config.txt for different sensors:  Recompiling cinepi-raw  Overclocking the Pi	41 42 43
5.3 5.4 5.5 Referer	5.2.1 Adjusting config.txt for different sensors:  Recompiling cinepi-raw  Overclocking the Pi  Backing up the SD card	41 42 43 44
	4.3 4.4 4.5 System	4.1.15 quad_rotary_controller 4.1.16 i2c_oled  4.2 CLI user guide  4.2.1 Checking available options  4.2.2 Camera modes  4.2.3 Low-resolution (lores) stream  4.2.4 Preview window  4.2.5 Tuning files  4.2.6 Post processing  4.2.7 Cinemate-specific flags  4.2.8 Example commands  4.3 Commands reference  4.3.1 Available Commands  4.4 Connecting to the Pi with SSH  4.5 Configuring the Wi-Fi hotspot  System management  5.1 System services  5.1.1 cinemate-autostart.service  5.1.2 storage-automount.service

		6.1.2 cp_controls	45
		6.1.3 cp_stats	46
		6.1.4 Controlling the camera from your own script	47
	6.2	Redis key reference	48
	6.3	Hardware overview	55
7.	Cinemat	te builds	58
8.	Develop	ment & contributing	60
	8.1	Installation	60
		8.1.1 Camera stack	60
		8.1.2 Cinemate	68
		8.1.3 Todo	75

## 1. Cinemate Docs

Welcome to the **Cinemate** project - an open-source boiler plate for building your own digital cinema camera using a Raspberry Pi 5. It combines a lightweight Python interface with the CinePi-raw recorder by Csaba Nagy for capturing 1 2 -bit CinemaDNG footage.

To begin, follow the steps in Quick start. Later chapters explain how to customise the system to tailor Cinemate to your needs.

For sharing your build with others, inspiration and discussion, make sure to join the CinePi Discord.

Download this documentation in pdf format for easy offline reference.

#### 2. Quick start

## 2.1 Quick start

#### 2.1.1 Hardware requirements

- Raspberry Pi
- Official HQ or Global Shutter camera
- HDMI monitor or a phone/tablet for monitoring

#### 2.1.2 Installation

- 1 . **Burn the Cinemate image** to an SD card ( 8 GB or larger).
- 2. Connect the Pi and the camera sensor board.

**Important:** Ensure the Pi is powered off before attaching the camera ribbon cable. Hot-swapping the cable is not advised.

- 3. Boot the Pi. CineMate should start automatically.
- 4 . Previewing the image
- 5 . Plug in an HDMI monitor **or** connect your phone/tablet to the Wi-Fi network CinePi (password 11111111).
- **6** . Open a browser and go to <a href="cinepi.local:5000">cinepi.local:5000</a> to see the interface. A clean video feed without the GUI is available at <a href="cinepi.local:8000/stream">cinepi.local:8000/stream</a>.
- 7. Recording footage
- 8 . Attach a high-speed drive: an **SSD** (Samsung T 7 recommended), an **NVMe drive**, or the **CFE Hat**.
- 9 . Format the drive as ext4 and give it the label RAW.
- 1 0 . Connect a button between GPIO 5 and GND (or briefly short these pins with a paper clip). When using the phone preview, you can also start/stop recording by tapping the preview.

That's it—your bare-bones CineMate build is ready!

Remember to power everything down before disconnecting hardware!

## 3. Using the camera

TBA

## 3.1 Simple GUI

Simple GUI is available via browser and/or attached HDMI monitor.

- Red color means camera is recording.
- Purple color means camera detected a drop frame
- Green color means camera is writing buffered frames to disk. You can still start recording at this stage, but any buffered frames from the last recording will be lost.

Buffer meter in the lower left indicates number of frames in buffer. Useful when testing storage media.

When a compatible USB microphone is connected, VU meters appear on the right side of the GUI so you can monitor audio levels.

## **3.2 Compatible sensors**

Sensor	Cinemate sensor mode	Resolution	Aspect Ratio	Bit Depth	Max FPS ★	Fil Si:
IMX 2 8 3	0	2 7 3 6 x 1 5 3 8	1.80	1 2	4 0	7
	1	2 7 3 6 x 1 8 2 4	1.53	1 2	3 4	8
IMX 2 9 6	0	1 4 5 6 x 1 0 8 8	1.33	1 2	6 0	2
IMX 4 7 7	0	2 0 2 8 x 1 0 8 0	1.87	1 2	5 0	4
	1	2 0 2 8 x 1 5 2 0	1.33	1 2	4 0	5
	2	1 3 3 2 x 9 9 0	1.34	1 0	1 2 0	2
IMX 5 8 5	0	1 9 2 8 x 1 0 9 0	1.77	1 2	8 7	4
	1	3 8 4 0 x 2 1 6 0	1.77	1 2	3 4	4

Note that maximum fps will vary according to disk write speed. For the specific fps values for your setup, make test recordings and monitor the output. Purple background in the monitor/web browser indicates drop frames. You can cap Cinemates max fps values for your specific build by editing the file

cinemate/src/module/sensor\_detect.py

## 3.3 Audio recording (experimental)

Cinemate records audio alongside the image sequence. Support is currently limited to a few USB microphones with hard coded configurations: - **RØDE VideoMic NTG** – recorded in stereo at 2 4 -bit/ 4 8 kHz. - **USB PnP microphones** – recorded in mono at 1 6 -bit/ 4 8 kHz.

Audio is written as .wav files into the same folder as the .dng frames. The implementation is still experimental and audio/video synchronization needs further investigation.

#### .asoundrc Setup

For dsnoop support, create a ~/.asoundrc in home directory:

nano ~/.asoundrc

#### Paste this into the file:

```
pcm.dsnoop_24bit {
    type dsnoop
    ipc_key 2048
    slave {
        pcm "hw:Device,0"
        channels 2
        rate 48000
        format S24_3LE
        period_size 1024
        buffer_size 4096
    }
}
pcm.dsnoop_16bit {
    type dsnoop
    ipc_key 2049
    slave {
        pcm "hw:Device,0"
        channels 1
        rate 48000
        format S16_LE
        period_size 1024
        buffer_size 4096
    }
}
pcm.mic_24bit {
    type plug
    slave.pcm "dsnoop_24bit"
}
pcm.mic_16bit {
    type plug
    slave.pcm "dsnoop_16bit"
}
```

Exit nano editor using ctrl+x.

## 3.4 Speed ramping

Speed ramping is the process of changing the camera's frame rate during a shot so that playback speed varies once the footage is conformed to a constant frame rate in post production. Ramping up the frame rate produces slow motion while ramping down speeds up the action.

#### 3.4.1 Speed ramping in Cinemate

Cinemate exposes frame rate control through the CinePiController class. The simplest way to change speed on the fly is the CLI command:

```
set fps <value>
```

For quick 2 × changes Cinemate also implements set\_fps\_double which toggles between the current FPS and twice that value. This can be used for designing a slow-motion button. Here is how you would to it in the settings file, button section:

```
{
  "pin": 18,
  "pull_up": true,
  "debounce_time": 0.1,
  "press_action": {"method": "set_fps_double"}
}
```

No argument is needed here. For methods such as <code>set\_fps\_double</code>, calling the method without an argument will simply toggle the control, in tis caseturning the slow motion on and off. If the user provides an argument, the control will be set explicitly to that value.

The controller contains an experimental <u>\_ramp\_fps</u> helper that gradually steps the frame rate up or down using <u>ramp\_up\_speed</u> and <u>ramp\_down\_speed</u> delays. This can be adapted if smoother transitions are desired.

#### 3.4.2 Shutter angle synchronisation

When frame rate changes the shutter angle can either remain fixed (preserving motion blur) or adjust to keep the exposure time constant. This behaviour is controlled by <a href="mailto:shutter\_a\_sync\_mode">shutter\_a\_sync\_mode</a>.

Mode o keeps the **motion blur consistent** because the physical shutter angle does not change. As the FPS increases the exposure time gets shorter, resulting in a darker image.

Mode 1 stores the current exposure time and recalculates the shutter angle whenever the FPS is adjusted so that **exposure time** stays the same.

Cinemate updates the nominal exposure time when the user sets a new angle. FPS is recalculated from the stored exposure time:

## 3.5 Dual sensors

CineMate automatically detects each camera connected to the Raspberry Pi and spawns a separate cinepi-raw process per sensor. By default:

- **Primary camera** (first detected) displays its preview on HDMI port 0.
- Secondary cameras run with --nopreview and map to subsequent HDMI outputs (cam 1 → HDMI 1, cam 2 → HDMI 2, etc.).
- Preview windows are centered and sized according to your geometry settings.

Cameras are synchronized with cam 0 being the server and cam 1 being the client.

You can override default HDMI mappings in <a href="mailto:settings.json">settings.json</a> under the <a href="mailto:output">output</a> section.

#### 4. Customising your build

## 4.1 Settings file

This file controls how the camera behaves and how your buttons, switches and displays are mapped. It lives in <a href="https://cinemate/src/settings.json">(cinemate/src/settings.json</a> on the Raspberry Pi. You can edit it with any text editor; the settings take effect the next time you start CineMate.

The configuration is structured as JSON. Each top-level key describes a feature area of the system. Below is a tour of every section and what the options do.

#### 4.1.1 welcome message

Text or image displayed briefly when Cinemate starts.

```
"welcome_image": null
"welcome_message": "THIS IS A COOL MACHINE",
```

Set welcome\_image to the path of a bitmap file to show a logo instead of text.

Example path: /home/pi/welcome\_image.bmp.

If welcome image path is set, this will override the text message.

### **4.1.2** system

```
"system": {
    "wifi_hotspot": {
        "name": "CinePi",
        "password": "11111111",
        "enabled": false
    }
}
```

- name the Wi-Fi network name (SSID) broadcast by the Pi when hotspot mode is enabled.
- password password for joining the hotspot.
- enabled set to true to start the hotspot automatically on boot. If set to false, CineMate will still start its web ui but stream it on whatever network the Pi is connected to.

Use the hotspot when you need a direct connection in the field. Disable it during development so the Pi can join your regular Wi-Fi and reach the internet. If you are connected to the Pi via Ethernet you can keep the hotspot on.

#### 4.1.3 geometry

Controls image orientation for each camera port (camo, cam1, etc.). These settings let you mount cameras in any orientation and still get an upright preview and recording. Example:

```
"geometry": {
   "cam0": { "rotate_180": false, "horizontal_flip": false, "vertical_f
lip": false },
   "cam1": { "rotate_180": false, "horizontal_flip": false, "vertical_f
lip": false }
}
```

- rotate\_ 1 8 0 flip the image upside-down.
- horizontal\_flip mirror the image left/right.
- **vertical\_flip** mirror the image top/bottom.

#### **4.1.4 output**

Maps each camera to an HDMI connector. Use -1 for automatic selection.

```
"output": {
   "cam0": { "hdmi_port": 0 },
   "cam1": { "hdmi_port": 1 }
}
```

#### 4.1.5 preview

Adjusts zoom levels for the HDMI/browser preview.

```
"preview": {
    "default_zoom": 1.0,
    "zoom_steps": [1.0, 1.5, 2.0]
}
```

- **default\_zoom** magnification factor used at startup.
- **zoom\_steps** list of zoom factors you can cycle through with the set\_zoom\_step command.

### 4.1.6 anamorphic\_preview

For stretching the preview when using anamorphic lenses.

```
"anamorphic_preview": {
   "default_anamorphic_factor": 1,
   "anamorphic_steps": [1, 1.33, 2.0]
}
```

- default\_anamorphic\_factor factor loaded when Cinemate starts.
- anamorphic\_steps selectable squeeze factors; values above 1.0 widen the image.

#### 4.1.7 gpio\_output

Defines pins used for visual feedback or sync signals.

```
"gpio_output": {
    "pwm_pin": 19,
    "rec_out_pin": [6, 21]
}
```

4.1.7 gpio output

- pwm\_pin outputs a strobe for shutter sync or external devices.
- rec\_out\_pin list of pins pulled high while recording (useful for tally LEDs).

#### **4.1.8** arrays

Preset lists for exposure and frame-rate settings. Cinemate will step through these values unless you enable free mode, either in the settings file or during runtime.

```
"arrays": {
   "iso_steps": [100, 200, 400, 640, 800, 1200, 1600, 2500, 3200],
   "shutter_a_steps": [1, 45, 90, 135, 172.8, 180, 225, 270, 315,
346.6, 360],
   "fps_steps": [1, 2, 4, 8, 12, 16, 18, 24, 25, 33, 40, 50],
   "wb_steps": [3200, 4400, 5600]
}
```

#### 4.1.9 settings

General options for runtime behaviour.

```
"settings": {
  "light_hz": [50, 60],
  "conform_frame_rate": 24
}
```

- light\_hz list of mains frequencies used to calculate flicker-free shutter angles. These are added to the shutter angle array and also dynamically calculated upon each fps change. This way, there is always a flicker free shutter angle value close by, when toggling through shutter angles, either via the cli or using buttons/pots/rotary encoder.
- **conform\_frame\_rate** frame rate intendend for project conforming in post. This setting is not really used by CineMate except for calculating the recording timecode tracker in redis but might be used in future updates.

#### 4.1.10 analog\_controls

Maps Grove Base HAT ADC channels to analogue dials (potentiometers). Use null to disable a dial.

```
"analog_controls": {
    "iso_pot": 0,
    "shutter_a_pot": 2,
    "fps_pot": 4,
    "wb_pot": 6
}
```

**Note** that even if you are using a Grove Base Hat, it might be useful to disable the dials not connected to pots, since noise from these connectors might trigger false readings.

#### **4.1.11** free\_mode

When enabled, ignores the preset arrays and exposes the full range supported by the sensor.

```
"free_mode": {
   "iso_free": false,
   "shutter_a_free": false,
   "fps_free": true,
   "wb_free": false
}
```

#### **4.1.12** buttons

Defines GPIO push buttons. Each entry describes one button and the actions it triggers.

```
{
  "pin": 5,
  "pull_up": true,
  "debounce_time": 0.1,
  "press_action": {"method": "rec"}
}
```

- pin BCM pin number the button is connected to.
- pull\_up set true if the pin idles high (internal pull-up). Use false for pull-down wiring.
- debounce\_time ignore additional presses within this time window (seconds).
- press\_action, single\_click\_action, double\_click\_action,
   triple\_click\_action, hold\_action actions to perform for each type of interaction. Actions call Cinemate CLI commands with optional args.

Automatic detection of inverse push buttons

Some push-buttons are wired closed = logic 1 and open = 0. At start-up, CineMate automatically detects buttons in state true and reverses them. This way the user can use any type of push buttons, both 1 - 0 - 1 and 0 - 1 - 0 types.

### 4.1.13 two\_way\_switches

Latching on/off switches. Cinemate triggers an action whenever the state changes.

```
{
  "pin": 27,
  "state_on_action": {"method": "set_all_lock", "args": [1]},
  "state_off_action": {"method": "set_all_lock", "args": [0]}
}
```

#### 4.1.14 rotary\_encoders

Rotary encoders used for fine adjustment of settings. These can be wired straight to the GPIO pins of the Pi.

```
{
  "clk_pin": 9,
  "dt_pin": 11,
  "encoder_actions": {
      "rotate_clockwise": {"method": "inc_iso"},
      "rotate_counterclockwise": {"method": "dec_iso"}
}
}
```

- clk\_pin and dt\_pin the two pins of the encoder.
- encoder\_actions commands to run when turning the dial.

#### **4.1.15** quad\_rotary\_controller

Support for the Adafruit Neopixel Quad I 2 C rotary encoder breakout. Each entry maps one of the four dials to a setting and defines the push button actions similar to the buttons section.

```
"quad_rotary_controller": {
  "enabled": true,
  "encoders": {
    "0": {"setting_name": "iso", "button": {"press_action":
{"method": "rec"}}},
    "1": {"setting_name": "shutter_a", "button": {"press_action": {"me
thod": "set_fps_double"}}},
    "2": {
      "setting_name": "fps",
      "button": {
        "press_action": "None",
        "single_click_action": {"method": "set_resolution"},
        "double_click_action": {"method": "restart_cinemate"},
        "triple_click_action": {"method": "reboot"},
        "hold_action": {"method": "toggle_mount"}
      }
    "3": {"setting_name": "wb", "button": {"press_action": {"method":
"rec"}}}
  }
}
```

- enabled turn the quad rotary controller on or off.
- encoders mapping of each dial to a setting and button actions.

#### 4.1.16 i2c\_oled

Configuration for the optional OLED status screen. This can be useful for presenting extra information appart from the HDMI/web display.

```
"i2c_oled": {
    "enabled": true,
    "width": 128,
    "height": 64,
    "font_size": 30,
    "values": ["write_speed_to_drive"]
}
```

- enabled turn the OLED display on or off.
- width / height pixel dimensions of your screen.
- font\_size size of the displayed text.
- values list of Redis keys or pseudo-keys to show (for example cpu\_temp).

Available keys come from src/module/i2c/i2c\_oled.py. Here are some examples:

- iso, fps basic camera settings.
- shutter\_a shown as **SHUTTER** with a suffix.
- wb\_user shown as **WB** with a trailing K.
- space\_left displayed as SPACE in gigabytes.
- write\_speed\_to\_drive write speed in MB/s.
- resolution prints width\*height@bit\_depth on the first line.
- is\_recording draws a bullet when recording.
- cpu\_load , cpu\_temp , memory\_usage Pi system statistics.

Other keys will display their name in uppercase and the raw value from Redis.

## 4.2 CLI user guide

Here is how you can operate **CinePi-raw** from the command line.

#### 4.2.1 Checking available options

Before running the program you can view all command-line flags with:

```
cinepi-raw -h
```

This prints a long list of options supported by the application. It includes the standard parameters from <a href="rpicam-apps">rpicam-apps</a> (such as resolution and exposure settings) plus additional flags specific to the Cinemate.

#### 4.2.2 Camera modes

CinePi-raw uses **Libcamera** to talk to your Raspberry Pi camera module. Each sensor supports one or more *modes*, which define the resolution and bit depth of the RAW images that the sensor can produce. A mode is written as:

```
--mode 2028:1080:12:U
```

- width and height select the active pixel area of the sensor.
- bit-depth is usually 1 2 or 1 6 bits per pixel.
- packing can be P for packed or U for unpacked data.

The mode must match the sensor you are using. For example, an IMX 4 7 7 camera can run at 4056:3040:12 (full sensor) or at smaller cropped resolutions. When specifying a mode you typically also set the output --width and --height which control the size of the image written to disk. These can be equal to the mode values or smaller when scaling is applied.

## 4.2.3 Low-resolution (lores) stream

```
--lores-width 1280 --lores-height 720
```

CinePi-raw can produce a secondary low-resolution stream alongside the full-resolution RAW frames.

#### 4.2.4 Preview window

By default the program opens an HDMI preview so you can see what the camera captures. The size and position of this window are controlled with:

```
-p 0,30,1920,1020
```

This positions the preview  $3\ 0$  pixels from the top of the screen with a  $1\ 9\ 2\ 0 \times 1\ 0\ 2\ 0$  window.

#### 4.2.5 Tuning files

```
--tuning-file /home/pi/cinemate/resources/tuning_files/imx477.json
```

Describes the camera's colour and lens characteristics. Point to a file supplied with Libcamera (for example imx477.json for the HQ camera)

### 4.2.6 Post processing

--post-process-file /home/pi/post-processing.json

For cinepi-raw, this file defines the port used by cpp-mjpeg-streamer (default cinepi.local:  $8\ 0\ 0\ 0$ )

If you have more than one camera connected to the Pi, and activated in boot/firmware/config.txt, the camera commected to physical cam 0 will use /home/pi/post-processing 0 .json and the camera connected to cam 1 will use /home/pi/post-processing 1 .json

#### 4.2.7 Cinemate-specific flags

The CineMate fork introduces several extra options:

Flag	Argument	Description
cam-port	cam0   cam1	Select which CSI camera port to use.
hdmi-port	0   1	Choose the HDMI connector for the preview  (0 = HDMI- 0, 1 = HDMI- 1, -1 = autodetect).
same-hdmi	(none)	Force both capture and controller GUI to share the same HDMI output.
keep16	true   false	Save full 1 6 -bit DNGs instead of 1 2 -bit packed files.

At this moment though, Cinemate is 1 2 bit only. The flag is for future updates of the IMX 5 8 5 1 6 bit clear HDR modes.

## 4.2.8 Example commands

Below are sample commands for different sensors and modes.

#### IMX477 (12-bit, full width)

#### IMX585 (12-bit unpacked)

Now, with an SSH shell running redis-cli you should be able to capture RAW footage from the command line!

```
redis-cli
> set is_recording 1
> publish cp_controls is_recording
```

## 4.3 Commands reference

Cinemate doesn't use a real shell parser. Instead, a background thread reads simple text commands from SSH or the serial port and calls the corresponding controller methods.

## **4.3.1 Available Commands**

Command	Input type	Example
rec / stop	none	rec
set iso <value></value>	int	set iso 800
inc iso / dec iso	none	inc iso
set shutter a <angle></angle>	float	set shutter a 180
inc shutter a $I$ dec shutter a	none	inc shutter a
set shutter a nom <angle></angle>	float	set shutter a nom 180
inc shutter a nom / dec shutter a nom	none	inc shutter a nom
set fps <value></value>	float	set fps 24
inc fps / dec fps	none	inc fps

Command	Input type	Example
set wb [ <kelvin>]</kelvin>	int or none	set wb 5600
inc wb / dec wb	none	inc wb
<pre>set resolution [<mode>]</mode></pre>	int or none	set resolution 2
set anamorphic factor [ <float>]</float>	float or none	set anamorphic factor 1.33
<pre>set zoom [<float>]</float></pre>	float or none	set zoom 2
inc zoom / dec zoom	none	inc zoom
mount / unmount	none	mount
toggle mount	none	toggle mount
time	none	time
set rtc time	none	set rtc time

Command	Input type	Example
space	none	space
get	none	get
set shutter a sync [0/1]	0 / 1 or none	set shutter a sync 1
set iso lock [0/1]	0 / 1 or none	set iso lock
set shutter a nom lock [0/1]	0 / 1 or none	set shutter a nom lock
set shutter a nom fps lock [0/1]	0 / 1 or none	set shutter a nom fps lock
set fps lock [0/1]	0 / 1 or none	set fps lock 1
set all lock [0/1]	0 / 1 or none	set all lock 0
set fps double [0/1]	0 / 1 or none	set fps double

Command	Input type	Example
reboot / shutdown	none	reboot
restart camera	none	restart camera
restart cinemate	none	restart cinemate
set iso free [0/1]	0 / 1 or none	set iso free 1
set shutter a free [0/1]	0 / 1 or none	set shutter a free 0
set fps free [0/1]	0 / 1 or none	set fps free 1
set wb free [0/1]	0 / 1 or none	set wb free
set filter <0/1>	0 / 1	set filter 1

Commands without an explicit argument will toggle the current state when possible (e.g. set fps lock flips the lock; set fps lock 1 forces it on).

## 4.4 Connecting to the Pi with SSH

Connect your computer and the Pi to the same network. If you are using the preinstalled image file, the system automatically starts a built-in hotspot: join the **CinePi** Wi-Fi with password 11111111.

You can change this behaviour later in the settings file.

Open a terminal (on Windows you can use PowerShell).

Try the hostname first:

```
ssh pi@cinepi.local
```

If this fails you can list devices on the network:

```
arp -a
```

Look for an entry labelled cinepi or note the new IP address that appears.

Use the hostname or IP address with SSH:

```
ssh pi@cinepi.local
# or
ssh pi@<ip-address>
```

When asked about the host key, type yes. Enter the default password when prompted.

You will now see the pi@cinepi prompt, meaning you are logged in.

If you are installing Cinemate manually, the hostname has not yet been set to cinepi. Then you will have to identify which ip address on the network is actually the Raspberry Pi and use that ip address.

From here you can run cinemate to start the interface or use make commands to manage the service. For security you should change the password with passwd after the first login.

## 4.5 Configuring the Wi-Fi hotspot

The built-in hotspot ensures you can always reach Cinemate even when there is no other network available. When <a href="wifi\_hotspot">wifi\_hotspot</a> in <a href="settings.json">settings.json</a> is set to <a href="true">true</a> and no hotspot is active, Cinemate runs <a href="mailto:nmcli device wifi hotspot">nmcli device wifi hotspot</a> using your chosen SSID and password.

This is handy when shooting in the field. Connect your phone or laptop directly to the hotspot and browse to the GUI to control the camera. If the Pi was previously connected to a Wi-Fi network, that connection is replaced by the hotspot.

During development you may want the Pi to join your normal Wi-Fi so it has internet access. Set <a href="mailto:system.wifi\_hotspot.enabled">system.wifi\_hotspot.enabled</a> to <a href="false">false</a> and configure Wi-Fi through <a href="mailto:raspi-config">raspi-config</a> or the desktop tools. The web interface will appear on the Pi's regular network address, letting you stay connected to both the Pi and the internet.

If you plug an Ethernet cable into the Pi, you can keep the hotspot running while also having a wired connection for internet and local networking.

Note that Cinemate still streams its web gui on whatever network the Pi is connected to, with GUI at: 5 0 0 0 and clean preview without GUI on: 8 0 0 0 /stream

## 5. System management

## 5.1 System services

### 5.1.1 cinemate-autostart.service

```
make install # copy service file
make enable # start on boot
make start # launch now
make stop # stop it
make status # check status
make disable # disable autostart
make clean # remove the service
```

Note that in order for the web ui to work properly you have to run <a href="make install">make install</a> once in the <a href="https://home/pi/cinemate">/home/pi/cinemate</a> folder, even if you are not using the autostart service.

## 5.1.2 storage-automount.service

storage-automount is a systemd service that watches for removable drives and mounts them automatically. The accompanying Python script reacts to udev events and the CFE-HAT eject button so drives can be attached or detached safely.

It understands <code>ext4</code>, <code>ntfs</code> and <code>exfat</code> filesystems. Partitions labelled <code>RAW</code> are mounted at <code>/media/RAW</code>; any other label is mounted under <code>/media/<LABEL></code> after sanitising the name. This applies to USB SSDs, NVMe drives and the CFE-HAT slot.

To manually install and enable the service:

```
cd cinemate/services/storage-automount
sudo make install
sudo make enable
```

You can stop or disable it later with:

```
sudo make stop
sudo make disable
```

## 5.1.3 wifi-hotspot.service

wifi-hotspot keeps a small access point running with the help of NetworkManager so you can always reach the web interface. The SSID and password are read from <a href="https://home/pi/cinemate/src/settings.json">home/pi/cinemate/src/settings.json</a> under <a href="mailto:system.wifi\_hotspot">system.wifi\_hotspot</a>.

Install and enable it with:

```
cd cinemate/services/wifi-hotspot
sudo make install
sudo make enable
```

As with storage-automount, you can stop or disable the hotspot with make stop and make disable.

## **5.2 Modifying config.txt**

## 5.2.1 Adjusting config.txt for different sensors:

sudo nano /boot/firmware/config.txt

Uncomment the section for the sensor being used, and make sure to comment out the others. Reboot the Pi for changes to take effect.

Exit the editor by pressing Ctrl+C

## 5.3 Recompiling cinepi-raw

## Compiling cinepi-raw

For easy later rebuilding and installation of cinepi-raw you can create the file compile-raw.sh.

nano compile-raw.sh

#### Paste this into the file

sudo meson install -C build

## Exit by pressing Ctrl+C

#### Make it exectutable:

sudo chmod +x compile-raw.sh

Now, from the same folder, to build and install cinepi-raw:

./compile-raw.sh

# **5.4 Overclocking the Pi**

## 5.5 Backing up the SD card

## Create a compressed image:

```
sudo dd if=/dev/mmcblk0 bs=4M conv=sparse,noerror status=progress | \
gzip -c > /media/RAW/Cinemate_$(date +"%Y%m%d_%H%M%S").img.gz
```

#### Or use PiShrink for a smaller file:

```
sudo bash -euo pipefail -c '
   ts=$(date +%Y%m%d_%H%M%S)
   raw="/media/RAW/Cinemate_${ts}.img"
   final="/media/RAW/Cinemate_${ts}.img.gz"
   dd if=/dev/mmcblk0 of="$raw" bs=4M conv=sparse,noerror
   status=progress
   pishrink.sh -v -z "$raw" "$final"
   rm -f "$raw"
'
```

## 6. Reference & troubleshooting

## 6.1 Redis API quick start

### 6.1.1 Redis-cli

```
# List all keys
redis-cli KEYS '*'
# Read the current ISO value
redis-cli GET iso
# Start a recording (same as pressing the Rec button)
redis-cli SET is_recording 1
redis-cli PUBLISH cp_controls is_recording
```

### You can also type:

```
redis-cli
```

This will open the redis cli.

## 6.1.2 cp\_controls

Both CinePi-raw and Cinemate writes values and immediately publish the key name. The recorder only reacts when it receives that publish event.

Any key may be sent this way. For example, to adjust the preview zoom:

```
# Set preview zoom level

redis-cli SET zoom 1.5

redis-cli PUBLISH cp_controls zoom
```

Note that for the **is\_recording** key Cinemate stops recording upon edge detection (the variable changes from 0 to 1 or vice versa). The reason for this exception has to do with how the CinePi-raw fork handles recording with multiple cameras

```
# Start recording
redis-cli SET is_recording 1  # triggers 0 → 1 edge

# Stop recording
redis-cli SET is_recording 0  # triggers 1 → 0 edge
```

## **6.1.3** cp\_stats

Every frame, cinepi-raw sends a small JSON object containing live statistics.

```
Json::Value data;
Json::Value histo;
data["framerate"] = completed_request->framerate;
data["colorTemp"] = info.colorTemp;
data["focus"] = info.focus;
data["frameCount"] = app_->GetEncoder()->getFrameCount();
data["bufferSize"] = app_->GetEncoder()->bufferSize();
redis_->publish(CHANNEL_STATS, data.toStyledString());
```

CineMate's RedisListener parses these messages and updates Redis keys like framecount, BUFFER and fps\_actual.

## 6.1.4 Controlling the camera from your own script

Below is a very small example using redis-py.

```
import redis
r = redis.Redis(host='localhost', port=6379, db=0)

# toggle recording
current = r.get('is_recording')
new_value = b'0' if current == b'1' else b'1'
r.set('is_recording', new_value)
r.publish('cp_controls', 'is_recording')
```

Note that in this example, the publishing of the is\_recording key is not strictly needed for recording to start/stop, but for formality's sake I think we should keep the publish command.

Info

This is basically what Cinemate does: it keeps track of variables being set by cinepiraw, and also sets variables itself.

# **6.2** Redis key reference

This page lists all Redis keys used by Cinemate and CinePi-raw. Values are simple strings so you can read or write them with redis-cli.

Each entry explains which component normally writes the key and what happens when you change it manually.

Key	Written by	Description	Safe to change manually?
anamorphic_factor	Cinemate	Preview squeeze for anamorphic lenses	Yes (publish key to apply)
iso	Cinemate → CinePi- raw	Sensor gain in ISO	Yes
shutter_a	Cinemate → CinePi- raw	Actual shutter angle in degrees	Yes
shutter_angle_nom	Cinemate	Desired shutter angle before sync/free adjustments	Yes
shutter_a_sync_mode	Cinemate	Keep exposure constant when changing FPS	Yes
fps	Cinemate → CinePi- raw	Target frames per second	Yes
sensor_mode	Cinemate  → CinePi- raw startup	Active sensor resolution/mode	Yes (causes pipeline restart)
wb	Cinemate → CinePi- raw	White-balance temperature (Kelvin)	Yes
zoom	Cinemate	Digital zoom for preview streams	Yes

Key	Written by	Description	Safe to change manually?
ir_filter	Cinemate → CinePi- raw	Toggle IR-cut filter (IMX 5 8 5 only)	Yes
rec / is_recording	Cinemate  → CinePi- raw	Start/stop recording when toggled	Yes (edge-triggered)
bit_depth	Cinemate  → CinePi- raw startup	Sensor bit depth ( 1 0 or 1 2)	No (set at startup)
height / width	Cinemate  → CinePi- raw startup	Active sensor resolution	No
lores_width / lores_height	CinePi-raw startup	Preview stream resolution	No
cg_rb	Cinemate  → CinePi- raw	White-balance gain pair " 1 /R, 1 /B"	Yes (advanced)
fps_user	Cinemate	Temporary storage for the UI slider	No
fps_last	Cinemate	Previous stable fps from stats	No
fps_actual	CinePi-raw  → Cinemate	Measured FPS from pipeline	No
framecount	CinePi-raw  → Cinemate	Total frames recorded	No

Key	Written by	Description	Safe to change manually?
buffer	CinePi-raw → Cinemate	Raw frames currently in RAM	No
buffer_size	CinePi-raw → Cinemate	Size of RAM buffer in frames	No
is_buffering	CinePi-raw → Cinemate	1 while buffer pre-fills	No
is_writing	CinePi-raw → Cinemate	1 while frames are flushing to disk	No
is_writing_buf	Cinemate	Internal countdown after recording stops	No
is_mounted	Cinemate (SSD monitor)	1 when storage is mounted	No
storage_type	Cinemate (SSD monitor)	Drive type (NVME/USB/SD)	No
space_left	Cinemate (SSD monitor)	Remaining space in GB	No
write_speed_to_drive	Cinemate (SSD monitor)	Current write speed MB/s	No
file_size	Cinemate	Bytes per frame for current mode	No

Key	Written by	Description	Safe to change manually?
last_dng_cam 0 / 1	CinePi-raw → Cinemate	Path to last written DNG frame	No
recording_time	Cinemate	HH:MM:SS:FF timer while recording	No
memory_alert	Cinemate	1 if RAM usage high	No
cam_init	CinePi-raw	Internal flag during startup	No
cameras	CinePi-raw	JSON list of detected cameras	No
gui_layout	Cinemate	Path to GUI layout preset	No
pi_model	Cinemate	Raspberry Pi model string	No
sensor	CinePi-raw	Active camera model	No
tc_cam 0 /tc_cam 1	CinePi-raw → Cinemate	SMPTE time code per camera	No
shutter_angle_actual	Cinemate	Calculated shutter angle applied after clamping or sync	No
shutter_angle_transient	Cinemate	Temporary value during ramping	No

Key	Written by	Description	Safe to change manually?
exposure_time	Cinemate	Current exposure time in seconds	No
wb_user	Cinemate	Kelvin value set before converting to cg_rb	No

## **6.3 Hardware overview**

CineMate image file comes pre-installed with: - StarlightEye - CFE Hat - Grove Base HAT

## 7. Cinemate builds

TBA

## 8. Development & contributing

## 8.1 Installation

Here is how you can manually install libcamera, cinepi-raw, cinemate and accompanying software on the Raspberry Pi.

Stack is confirmed to work on Raspberry pi 4 and 5 models.

This guide assumes fresh Raspbery Pi Bookworm installation running kernel 6 . 1 2 . 3 4 .

If you run Raspberry Pi OS Lite, begin by installing the following packages:

```
sudo apt-get install python3-jinja2 python3-ply python3-yaml
```

#### 8.1.1 Camera stack

### **Tools & dependencies**

```
sudo apt update -y
sudo apt upgrade -y
```

sudo apt install -y git cmake libepoxy-dev libavdevice-dev build-essential cmake libboost-program-options-dev libdrm-dev libexif-dev libcamera-dev libjpeg-dev libtiff5-dev libpng-dev redis-server libhiredis-dev libasound2-dev libjsoncpp-dev libpng-dev meson ninja-build libavcodec-dev libavdevice-dev libavformat-dev libswresample-dev && sudo apt-get install libjsoncpp-dev && cd ~ && git clone https://github.com/sewenew/redis-plus-plus.git && cd redis-plus-plus && mkdir build && cd build && cmake .. && make && sudo make install && cd ~

#### libcamera 1.7.0 raspberry pi fork

sudo apt install -y python3-pip python3-jinja2 libboost-dev libgnutls28-dev openssl pybind11-dev qtbase5-dev libqt5core5a meson cm ake python3-yaml python3-ply libglib2.0-dev libgstreamer-plugins-base1.0-dev libgstreamer1.0-dev libavdevice59

sudo apt-get install --reinstall libtiff5-dev && sudo ln -sf \$(find /
usr/lib -name "libtiff.so" | head -n 1) /usr/lib/aarch64-linux-gnu/
libtiff.so.5 && export LD\_LIBRARY\_PATH=/usr/lib/aarch64-linux-gnu:\$LD\_
LIBRARY\_PATH && sudo ldconfig

```
git clone https://github.com/raspberrypi/libcamera.git && \
sudo find ~/libcamera -type f \( -name '*.py' -o -name '*.sh' \) -
exec chmod +x \{ \} \  \; && \
cd libcamera && \
sudo meson setup build --buildtype=release \
  -Dpipelines=rpi/vc4,rpi/pisp \
  -Dipas=rpi/vc4,rpi/pisp \
  -Dv4l2=true \
  -Dastreamer=enabled \
  -Dtest=false \
  -Dlc-compliance=disabled \
  -Dcam=disabled \
  -Dqcam=disabled \
  -Ddocumentation=disabled \
  -Dpycamera=enabled && \
sudo ninja -C build install
```

cd  $\sim$ /libcamera/utils && sudo chmod +x \*.py \*.sh && sudo chmod +x  $\sim$ /libcamera/src/ipa/ipa-sign.sh && cd  $\sim$ /libcamera && sudo ninja -C build install

#### cpp-mjpeg-streamer

sudo apt install -y libspdlog-dev libjsoncpp-dev && cd /home/pi && git clone https://github.com/nadjieb/cpp-mjpeg-streamer.git && cd cpp-mjpeg-streamer && mkdir build && cd build && cmake .. && make && sudo make install && cd

#### CinePi-raw cinemate fork

```
git clone https://github.com/Tiramisioux/cinepi-raw.git --branch rpicam-apps_1.7_custom_encoder cd cinepi-raw sudo rm -rf build sudo meson setup build sudo ninja -C build sudo meson install -C build cd sudo ldconfig
```

### Seed Redis with white balance default keys

```
redis-cli <<EOF
SET cg_rb 2.5,2.2
PUBLISH cp_controls cg_rb
EOF
```

#### **Additional drivers**

```
sudo apt install linux-headers dkms -y
```

#### imx585 driver

```
git clone https://github.com/will127534/imx585-v4l2-driver.git --
branch 6.12.y
cd imx585-v4l2-driver/
./setup.sh
cd
```

The imx 5 8 5 is written by Will Whang. For original drivers and startup guides, visit https://github.com/will 1 2 7 5 3 4 /StarlightEye

#### Add IMX585 tuning files

```
curl -L -o /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585.json \
  https://raw.githubusercontent.com/will127534/libcamera/master/src/
ipa/rpi/pisp/data/imx585.json
sed -i '8s/"black_level": *[0-9]\+/"black_level": 0/' /home/pi/
libcamera/src/ipa/rpi/pisp/data/imx585.json
cp /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585.json /usr/local/
share/libcamera/ipa/rpi/pisp/
```

curl -L -o /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585\_mono.json https://raw.githubusercontent.com/will127534/libcamera/master/src/ipa/rpi/pisp/data/imx585\_mono.json && sudo cp /home/pi/libcamera/src/ipa/rpi/pisp/data/imx585\_mono.json /usr/local/share/libcamera/ipa/rpi/pisp/

#### IR filter switch script

sudo wget https://raw.githubusercontent.com/will127534/StarlightEye/
master/software/IRFilter -0 /usr/local/bin/IRFilter
sudo chmod +x /usr/local/bin/IRFilter

Cinemate has its own way of handling the IR switch but the installation above can be convenient for use outside of Cinemate

#### imx283 driver cinemate fork

```
git clone https://github.com/will127534/imx283-v4l2-driver.git
cd imx283-v4l2-driver/
./setup.sh
cd
```

The imx 2 8 3 is written by Will Whang. For original drivers and startup guides, visit https://github.com/will 1 2 7 5 3 4 /imx 2 8 3 -v 4 I 2 -driver

### **Enabling I<sup>2</sup>C**

sudo raspi-config nonint do\_i2c 0

Enabling I 2 C is needed for using the camera modules.

### **Setting hostname**

sudo hostnamectl set-hostname cinepi

You will find the pi as <a href="cinepi.local">cinepi.local</a> on the local network, or at the hotspot Cinemate creates

### Add camera modules to config.txt

sudo nano /boot/firmware/config.txt

Paste this into your file, and uncomment the sensor you are using.

Also specify which physical camera port you have connected your sensor to (example shows imx 4 7 7 activated)

```
# Raspberry Pi HQ camera
camera_auto_detect=1
dtoverlay=imx477,cam0
# Raspberry Pi GS camera
#camera_auto_detect=1
#dtoverlay=imx296,cam0
# OneInchEye
#camera_auto_detect=0
#dtoverlay=imx283,cam0
# StarlightEye
#camera_auto_detect=0
#dtoverlay=imx585,cam0
# StarlightEye Mono
#camera_auto_detect=0
#dtoverlay=imx585, cam1, mono
# CFE Hat (pi 5 only)
dtparam=pciex1
dtparam=pciex1_gen=3
dtoverlay=disable-bt
```

#### And at the very bottom of the file:

```
[all]
avoid_warnings=1
disable_splash=1
```

Exit with Ctrl+x. System will ask you to save the file. Press "y" and then enter.

## **Change the console font (optional)**

```
sudo apt install console-setup kbd
sudo dpkg-reconfigure console-setup

# choose: UTF-8
# Guess optimal character set
# Terminus
# 16x32 (framebuffer only)
```

#### Enable the service:

```
sudo systemctl enable console-setup.service sudo systemctl start console-setup.service
```

This can be useful if running the Pi on a small HD field monitor

#### **Create post-processing configs**

Paste this into the terminal and hit enter:

```
sudo bash -c 'cat > post-processing.json << EOF</pre>
{
    "sharedContext": {},
    "mjpegPreview": {
        "port": 8000
    }
}
EOF' && \
sudo chmod +x post-processing.json && \
sudo bash -c 'cat > post-processing0.json << EOF</pre>
{
    "sharedContext": {},
    "mjpegPreview": {
        "port": 8000
    }
}
EOF' && \
sudo chmod +x post-processing0.json && \
sudo bash -c 'cat > post-processing1.json << EOF</pre>
{
    "sharedContext": {},
    "mjpegPreview": {
        "port": 8001
    }
}
EOF' && \
sudo chmod +x post-processing1.json
```

#### **Install PiShrink**

```
wget https://raw.githubusercontent.com/Drewsif/PiShrink/master/pishrink.sh
sudo install -m755 pishrink.sh /usr/local/bin/pishrink
```

PiShrink is a great tool for compressing SD image file backups of the SD card. See here for instructions

#### Reboot:

```
sudo reboot
```

### Trying out CinePi from the terminal

You should now have a working install of cinepi-raw. To see if your camera is recognized by the system:

```
cinepi-raw --list-cameras
```

Try it out with a simple cli command:

```
cinepi-raw --mode 2028:1080:12:U --width 2028 --height 1080 --lores-
width 1280 --lores-height 720
```

For more details on running CinePi-raw from the command line, see this section.

### 8.1.2 Cinemate

#### System wide packages

```
sudo apt update
sudo apt install -y \
    git build-essential python3-dev python3-pip python3-venv \
    i2c-tools python3-smbus python3-pyudev \
    libgpiod-dev libgpiod2 python3-libgpiod gpiod \
    portaudio19-dev python3-systemd \
    e2fsprogs ntfs-3g exfatprogs \
    console-terminus
```

#### Create a Python virtual environment

```
python3 -m venv ~/.cinemate-env
source /home/pi/.cinemate-env/bin/activate
echo "source /home/pi/.cinemate-env/bin/activate" >> ~/.bashrc
```

#### Grant sudo privileges and enable I2C

```
echo "pi ALL=(ALL) NOPASSWD: /home/pi/.cinemate-env/bin/*" | sudo tee /etc/sudoers.d/cinemate-env sudo chown -R pi:pi /home/pi/.cinemate-env sudo chown -R pi:pi /media && chmod 755 /media sudo usermod -aG i2c pi sudo modprobe i2c-dev && echo i2c-dev | sudo tee -a /etc/modules echo "pi ALL=(ALL) NOPASSWD: /home/pi/run_cinemate.sh" | sudo tee -a / etc/sudoers.d/pi_cinemate
```

#### Reboot so the group changes take effect:

```
sudo reboot
```

## **Python packages**

```
If you previously installed the board Python package, remove it with pip3 uninstall board.
```

```
pip install \
    pyudev gpiozero \
    adafruit-blinka adafruit-circuitpython-ssd1306 adafruit-
circuitpython-seesaw \
    luma.oled grove.py pigpio-encoder smbus2 rpi_hardware_pwm \
    watchdog psutil pillow redis keyboard pyudev numpy termcolor sound
device \
    evdev inotify_simple sysv_ipc flask_socketio sugarpie
```

#### **Alternative GPIO back-end**

```
sudo apt install -y swig python3-dev build-essential git git clone https://github.com/joan2937/lg cd lg && make sudo make install cd .. && pip install lgpio
```

### **Clone the Cinemate repo**

```
git clone https://github.com/Tiramisioux/cinemate.git --branch
cinemate-3.1
```

#### Allow Cinemate to run with sudo

Edit the sudoers file:

```
sudo visudo
```

add this to the end of the file:

```
pi ALL=(ALL) NOPASSWD: /home/pi/cinemate/src/main.py
pi ALL=(ALL) NOPASSWD: /bin/mount, /bin/umount, /usr/bin/ntfs-3g
pi ALL=(ALL) NOPASSWD: /home/pi/cinemate/src/logs/system.log
pi ALL=(ALL) NOPASSWD: /sbin/mount.ext4
```

Exit with Ctrl+x. System will ask you to save the file. Press "y" and then enter.

#### **Enable NetworkManager**

```
sudo systemctl enable NetworkManager --now
```

#### **Rotate logs**

Paste this into the terminal and hit enter:

```
sudo tee /etc/logrotate.d/general_logs <<'EOP'
/var/log/*.log {
    size 100M
    rotate 5
    compress
    missingok
    notifempty
}</pre>
```

#### Seed Redis with default keys

```
redis-cli MSET \
anamorphic_factor 0 bit_depth 0 buffer 0 buffer_size 0 cam_init 0 came
ras 0 cg_rb 3.5,1.5 \
file_size 0 fps 24 fps_actual 24 fps_last 24 fps_max 1 fps_user 24 fra
mecount 0 \
gui_layout 0 height 0 ir_filter 0 is_buffering 0 is_mounted 0 is_recor
ding 0 \
is_writing 0 is_writing_buf 0 tc_cam0 0 tc_cam1 0 iso 100
lores_height 0 lores_width 0 \
pi_model 0 rec 0 sensor 0 sensor_mode 0 shutter_a 0 space_left 0 stora
ge_type 0 \
wb 5600 wb_user 5600 width 0 memory_alert 0 \
shutter_a_sync_mode 0 shutter_angle_nom 0 shutter_angle_actual 0 shutt
er_angle_transient 0 \
exposure_time 0 last_dng_cam1 0 last_dng_cam0 0 \
zoom 0 write_speed_to_drive 0 recording_time 0
```

(See the settings guide for the full list.)

#### Add alias

```
nano ~/.bashrc
```

#### Add to the end of the file:

```
alias cinemate='python3 /home/pi/cinemate/src/main.py'
```

Exit with Ctrl+x. System will ask you to save the file. Press "y" and then enter.

#### Reload .bashrc

```
source ~/.bashrc
```

#### **Cinemate services**

#### storage-automount

Mounts and unmounts removable drives such as SSDs, NVMe enclosures and the CFE HAT.

#### wifi-hotspot

Keeps a simple Wi-Fi hotspot running via NetworkManager so you can reach the web UI while in the field. The SSID and password come from the <a href="mailto:system.wifi\_hotspot">system.wifi\_hotspot</a> section of <a href="mailto:section.se

Install and enable both services with:

```
cd /home/pi/cinemate/services
sudo make install
sudo make start # starts the service
sudo make enable # makes the service start on boot
```

You can also start and enable the service individually, by entering their respective folders and issuing the <a href="sudo make">sudo make</a> command

Note that if you were connected to the Pi via wifi, this connection is now broken due to the Pi setting up its own hotspot.

To connect again, check your available wifi networks. There should now be a network available named CinePi. Connect to it using password 11111111

Now you shuld be able to ssh to the Pi this command:

```
ssh pi@cinepi.local
```

You should also be able to find the Pi by opening a terminal and typing:

```
arp -a
```

#### You will see something like

```
> arp -a
? (10.42.0.1) at e4:5f:1:a9:72:a7 on en0 ifscope [ethernet]
...
```

During development/building your rig you might prefer the Pi to use your normal Wi-Fi instead of its own hotspot so you remain online while tinkering.

To stop the hotspot from starting on boot, type

```
sudo systemctl disable wifi-hotspot.
```

If you plug in an Ethernet cable you can keep the hotspot active while the wired connection provides internet access. See Hotspot logic for more details on how the hotspot works.

### Connect to the Pi (if not already connected):

```
ssh pi@10.42.0.1
# password: 1
```

#### **Starting Cinemate**

Now, back on the Pi, anywhere in the terminal, type:

```
cinemate
```

Make sure things are running smoothly and then you can move on to enabling the cinemate-autostart service:

## cinemate-autostart.service

```
cd /home/pi/cinemate/

sudo make install # copy service file
sudo make enable # start on boot
make start # launch now
```

After enabling the service, Cinemate should autostart on boot.

You now have a 1 2 bit RAW image capturing system on your Raspberry Pi!

### 8.1.3 Todo

- simple\_gui.py adaptive layout for non 1 9 2 0 x 1 0 8 0 screens
- 1 6 bit modes for imx 5 8 5
- support for imx 2 9 4
- overclocking of ISP
- optional auto-exposure
- hardware sync of sensor frame capture, perhaps via a pico
- rendering mode, for creating proxy files in camera (using https://github.com/ mrjulesfletcher/dng\_to\_video)
- automatic detection of attached sensor and dynamic dtoverlay