

Revision: 1.0.0 Date: 03/09/2019

# **Command Handbook**

For the HuskySat-1 Mission



#### **Table of Contents**

Table of Contents	2
Commands	3
CMD IGNORE FSW	3
CMD_PPT_SINGLE_FIRE	3
CMD_PPT_TIME_UPD	3
CMD_ROLLCALL	4
GCMD_AUTOSEQ_ADD_1	4
GCMD AUTOSEQ ADD 2	4
GCMD AUTOSEQ ENABLE	4
GCMD AUTOSEQ GET INDICES	4
GCMD_AUTOSEQ_GET_MET	5
GCMD AUTOSEQ REMOVE CAN ID	5
GCMD AUTOSEQ RM AT INDEX	5
GCMD_BATT_SET_HEATER_CHECK	5
GCMD_BDOT_CONTROL	5
GCMD BDOT MAG CONTROL	6
GCMD BDOT MAX TUMBLE	6
GCMD_BDOT_POLE_OVERRIDE	6
GCMD BDOT SPAM	7
GCMD COM1 MODE CAMERA	7
GCMD_COM1_MODE_HEALTH	8
GCMD_COM1_MODE_REALTIME	8
GCMD_COM1_MODE_SAFE	8
GCMD_COM1_TRANSPONDER_OFF	8
GCMD_COM1_TRANSPONDER_ON	8
GCMD_COM2_RUN	8
GCMD_DIST_AUTOSHUTOFF	8
GCMD_DIST_RESET_MISSION	10
GCMD_DIST_SELF_RESTART	10
GCMD_DIST_SET_PD_OVC_BDOT	10
GCMD_DIST_SET_PD_OVC_COM2	10
GCMD_DIST_SET_PD_OVC_EPS	10
GCMD_DIST_SET_PD_OVC_ESTIM	10
GCMD_DIST_SET_PD_OVC_PPT	10
GCMD_DIST_SET_PD_OVC_RAHS	10
GCMD_DIST_SET_PD_STATE	11
GCMD_EPS_BATT_FULLDEF	12
GCMD_GEN_SET_PT_STATE	12
GCMD_MTQ_PMS	13
GCMD_MTQ_POP	13
GCMD_MTQ_PWM_TIME	14
GCMD_PPT_HALT	14
GCMD_PPT_MULTIPLE_FIRE	14
GCMD_RESET_MINMAX	14
GRND_EPOCH	15
TLE_1	15
TLE_2	15
TLE_3	15
TLE_4	15
TLE_5	16



# Commands

# CMD\_IGNORE\_FSW

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_IGNORE_FSW_IGNORE	ignore the bdot commands from fsw		0	1	0	224	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							

# CMD\_PPT\_SINGLE\_FIRE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_PPT_SINGLE_FIRE_WITH_PULSE	Do we fire or just	charge?	0	1	0	224	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
CMD_PPT_SINGLE_FIRE_OVERRIDE	Do we fire or just	charge?	0	1	0	225	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
CMD_PPT_SINGLE_FIRE_OVERRIDE_SMT	Whether the Sch checked	midt Trigger is	0	1	0	226	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							

# CMD\_PPT\_TIME\_UPD

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_PPT_TIME_UPD_CHARGE	PPT Main Capacitor Charge Time	0	65535	0	224	16	UINT	2^-15s
CMD_PPT_TIME_UPD_IGN_DELAY	PPT Main Igniter Delay	0	65535	0	240	16	UINT	2^-15s
CMD_PPT_TIME_UPD_IGN_CHARGE	PPT Igniter Charge Time	0	65535	0	256	16	UINT	2^-15s



CMD\_PPT\_TIME\_UPD\_COOLDOWN PPT Cooldown Time 65535 0 272 16 **UINT** 2^-15s

## CMD\_ROLLCALL

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
CMD_ROLLCALL_MSP		0	255	0	224	8	UINT	
CMD_ROLLCALL_MET	Mission Elapsed Time	0	1099511627775	0	232	40	UINT	2^-8 s
CMD_ROLLCALL_TYPE	Rollcall Type (Unused for now)	0	255	0	272	8	UINT	

### GCMD\_AUTOSEQ\_ADD\_1

propertires of autosequencer entry

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ADD_1_CAN_ID	the CAN Id of the message to add	0	536870911	0	224	29	UINT	
GCMD_AUTOSEQ_ADD_1_MET	the MET of the entry to add	0	4294967295	0	253	32	UINT	2^- 15s
GCMD_AUTOSEQ_ADD_1_SENDFLG	whether the CAN packet should send	0	1	0	285	1	UINT	

## GCMD\_AUTOSEQ\_ADD\_2

data of CAN packet to be added to the autosequencer

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ADD_2_DATA	the data of the CAN packet to be added to the autosequencer	0	18446744073709600768	0	224	64	UINT	

## GCMD\_AUTOSEQ\_ENABLE

Item Name	Descript	ion	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_ENABLE_ENABLE State Value		0	255	0	224	8	UINT		
	FALSE	0							
	TRUE	1							
	NULL	2							

## GCMD\_AUTOSEQ\_GET\_INDICES

get indices of the specified packet in the autosequencer

**Item Name** Description Min Max **Default Bit Offset Bit Size Data Type** Units



ky · ky · killing tab

Date: 03/09/2019

GCMD\_AUTOSEQ\_GET\_INDICES\_ID the CAN Id 0 536870911 0 224 29 UINT

### GCMD\_AUTOSEQ\_GET\_MET

get MET of the item at the specified index of the autosequencer

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_GET_MET_INDEX	the index	0	255	0	224	8	UINT	

## GCMD\_AUTOSEQ\_REMOVE\_CAN\_ID

remove all occurrence of the specified CAN Id in the autosequencer

Item Name	Description	Min	Max	Default	Offset		Type	Units
GCMD_AUTOSEQ_REMOVE_CAN_ID_ID	remove all occurrences of the specified CAN Id in the autosequencer	0	536870911	0	224	29	UINT	

#### GCMD\_AUTOSEQ\_RM\_AT\_INDEX

remove the autosequencer entry at the specified index

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_AUTOSEQ_RM_AT_INDEX_INDEX	the index	0	255	0	224	8	UINT	

### GCMD\_BATT\_SET\_HEATER\_CHECK

enables/disables battery heater automation

Item Name	Description the state of heater automation State Value		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BATT_SET_HEATER_CHECK_STATE			0	3	0	224	2	UINT	
	the state of heater automation  State Value  FALSE 0  TRUE 1								
	FALSE	0							
	TRUE	1							
	NULL	2							

## GCMD\_BDOT\_CONTROL

Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
Chooses mode that bdot is in: 0 = NORM = SLEEP_MODE	AL_MODE,1	0	3	0	224	2	UINT	
State	Value							
NORMAL_MODE	0							
	Chooses mode that bdot is in: 0 = NORM = SLEEP_MODE  State	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 3 = SLEEP_MODE  State  Value	Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 0 3 0 = SLEEP_MODE  State  Value	Description     Min     Max     Default     Offset       Chooses mode that bdot is in: 0 = NORMAL_MODE, 1 = SLEEP_MODE     0     3     0     224       State     Value	Description     Min     Max     Default     Offset     Size       Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE     0 3 0 224 2       State     Value	Description     Min     Max     Default     Offset     Size     Type       Chooses mode that bdot is in: 0 = NORMAL_MODE , 1 = SLEEP_MODE     0     3     0     224     2     UINT       State     Value



UINT

SLEEP_MODE	1
SPAM_MAG_SELF_TEST	2
SPAM	3

## GCMD\_BDOT\_MAG\_CONTROL

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BDOT_MAG_CONTROL_MODE	•	Choose the best fit magnetometer from ground. 0 = Auto, 1 = BDOT, 2 = SP1, 3 = SP2			0	224	2	UINT	
	State	Value							
	AUTO_MODE	0							
	BDOT_MODE	1							
	SP1_MODE	2							
	SP2_MODE	3							

## GCMD\_BDOT\_MAX\_TUMBLE

Item Name	Description	Min	Max	Default	Bit Offset		Data Type	Units
GCMD_BDOT_MAX_TUMBLE_TIME	Chooses the maximum time bdot is tumbling continuously. If bdot tumbles for longer than this time, will automatically go into sleep mode. Units: Minutes	0	65535	0	224	16	UINT	minutes

# GCMD\_BDOT\_POLE\_OVERRIDE

GCMD\_BDOT\_POLE\_OVERRIDE\_Y

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BDOT_POLE_OVERRIDE_GAIN_X	Percentage dipole gain o	Percentage dipole gain on x axis		255	0	224	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_GAIN_Y	Percentage dipole gain o	Percentage dipole gain on y axis		255	0	232	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_GAIN_Z	Percentage dipole gain o	rcentage dipole gain on z axis		255	0	240	8	UINT	pct
GCMD_BDOT_POLE_OVERRIDE_X		Flips the dipole signs on bdot x axis before sending command to mtq		2	0	248	2	UINT	
	State	s the dipole signs on bdot x axis before ading command to mtq							
	FALSE	0							
	TRUE	1							
	NULL	NULL 2							

Flips the dipole signs on bdot y axis before



sending command to mtq

State	Value
FALSE	0
TRUE	1
NULL	2

GCMD\_BDOT\_POLE\_OVERRIDE\_Z

Flips the dipole signs on bdot  $\boldsymbol{z}$  axis before sending command to  $\boldsymbol{mtq}$ 

State	Value
FALSE	0
TRUE	1
NULL	2

0 2 0 252 2 UINT

# GCMD\_BDOT\_SPAM

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_BDOT_SPAM_TIME_ON	Chooses the amount of minutes in between SPAM	0	65535	0	224	16	UINT	minutes
GCMD_BDOT_SPAM_TIME_OFF	Chooses the amount of time SPAM should be on for	0	65535	0	240	16	UINT	minutes
GCMD_BDOT_SPAM_MAGNITUDE_X	What magnitude the magnetorquer should spam on x axis	-100	100	0	256	8	INT	
GCMD_BDOT_SPAM_MAGNITUDE_Y	What magnitude the magnetorquer should spam on y axis	-100	100	0	264	8	INT	
GCMD_BDOT_SPAM_MAGNITUDE_Z	What magnitude the magnetorquer should spam on z axis	-100	100	0	272	8	INT	
GCMD_BDOT_SPAM_CONTROL	Turn spam on or off	0	2	0	280	2	UINT	

State	Value
FALSE	0
TRUE	1
NULL	2

## GCMD\_COM1\_MODE\_CAMERA

Commands COM1 to switch to Camera Mode

Item Name	Description	Min	Max	Default	Offset	Size	Type	Units
GCMD_COM1_MODE_CAMERA_TIME	The timeout for camera mode, in minutes. 0 minutes means use last time.	0	255	0	224	8	UINT	minutes



### GCMD\_COM1\_MODE\_HEALTH

Commands COM1 to switch to Health Mode

### GCMD\_COM1\_MODE\_REALTIME

Commands COM1 to switch to Real-Time Mode

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_COM1_MODE_REALTIME_TIME	The timeout for realtime mode, in minutes. 0 minutes means use last time.	0	255	0	224	8	UINT	minutes

### GCMD\_COM1\_MODE\_SAFE

Commands COM1 to switch to Safe Mode

#### GCMD\_COM1\_TRANSPONDER\_OFF

Commands COM1 to disable the transponder

#### GCMD\_COM1\_TRANSPONDER\_ON

Commands COM1 to enable the transponder

## GCMD\_COM2\_RUN

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_COM2_RUN_FILENO	Which file to run		0	255	0	224	8	UINT	
GCMD_COM2_RUN_JUMP	Do you want to jump	p the queue?	0	1	0	232	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
GCMD_COM2_RUN_CLEAR	Do you want to clear	the gueue and run?	0	1	0	233	1	UINT	
	State	Value		-	· ·	200	-	0211	
	State	value							
	FALSE	0							
	TRUE	1							

## GCMD\_DIST\_AUTOSHUTOFF

Set the status of dist autoshutoff for each power domain



Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_AUTOSHUTOFF_COM2	Whether autoshutoff is enabled on the power domain		0	3	0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_RAHS	Whether autos	hutoff is enabled on the power	0	3	0	226	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_BDOT	Whether autos	hutoff is enabled on the power	0	3	0	228	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_ESTIM	Whether autos	hutoff is enabled on the power	0	3	0	230	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_EPS	Whether autos	hutoff is enabled on the power	0	3	0	232	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_AUTOSHUTOFF_PPT	Whether autos	hutoff is enabled on the power	0	3	0	234	2	UINT	
	State	Value							
	FALSE	0							



TRUE 1
NULL 2

### GCMD\_DIST\_RESET\_MISSION

Resets MET and autosequencer, also sets the autosequencer to be reinitialized on next powerup

## GCMD\_DIST\_SELF\_RESTART

Causes dist to self-restart

### GCMD\_DIST\_SET\_PD\_OVC\_BDOT

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_BDOT_OVC	Set PD overcurrent BDOT	0.0	15.0	0.0	224	32	FLOAT	Α

### GCMD\_DIST\_SET\_PD\_OVC\_COM2

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_COM2_OVC	set PD Overcurrent Com2	0.0	15.0	0.0	224	32	FLOAT	Α

### GCMD\_DIST\_SET\_PD\_OVC\_EPS

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_EPS_OVC	Set PD Overcurrent EPS	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_ESTIM

Item Name	Description	Min	Max Default		Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_ESTIM_OVC	Set PD overcurrent ESTIM	0.0	15.0	0.0	224	32	FLOAT	Α

## GCMD\_DIST\_SET\_PD\_OVC\_PPT

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_OVC_PPT_OVC	Set PD overcurrent PPT	0.0	15.0	0.0	224	32	FLOAT	Α

#### GCMD\_DIST\_SET\_PD\_OVC\_RAHS

Item Name Description Min Max Default Bit Offset Bit Size Data Type Units



GCMD\_DIST\_SET\_PD\_OVC\_RAHS\_OVC

Set PD overcurrent RAHS

0.0 15.0

0.0

224

32

FLOAT

Α

# GCMD\_DIST\_SET\_PD\_STATE

Item Name	Description	Description		Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_DIST_SET_PD_STATE_COM1	Enables or disable power domain	Enables or disables the power switch to com1 power domain			0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_SET_PD_STATE_COM2	Enables or disable	es the power switch to com2	0	3	0	226	2	UINT	
	State	State Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_SET_PD_STATE_RAHS	Enables or disable power domain	Enables or disables the power switch to rahs power domain		3	0	228	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_SET_PD_STATE_BDOT	Enables or disables the power switch to BDOT power domain		0	3	0	230	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_DIST_SET_PD_STATE_ESTIM	Enables or disables the power switch to the estimator power domain		0	3	0	232	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							

0

3

0

234



Date: 03/09/2019

UINT

reaction wheels (empty power domain)

State	Value
FALSE	0
TRUE	1
NULL	2

GCMD\_DIST\_SET\_PD\_STATE\_EPS

Enables or disables the power switch to the EPS power domain

State	Value
FALSE	0
TRUE	1
NULL	2

GCMD\_DIST\_SET\_PD\_STATE\_PPT

Enables or disables the power switch to the PPT power domain

State	Value
FALSE	0
TRUE	1
NULL	2

UINT 236

UINT 238

## GCMD\_EPS\_BATT\_FULLDEF

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_EPS_BATT_FULLDEF_CONST_VOLT	Limits for detecting a full state on the battery (voltage must be greater than this value)	0.0	8.0	0.0	224	32	FLOAT	V
GCMD_EPS_BATT_FULLDEF_CHG_CURR	Limits for detecting a full state on the battery (current must be less than this value)	0.0	1.0	0.0	256	32	FLOAT	Amps

## GCMD\_GEN\_SET\_PT\_STATE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_GEN_SET_PT_STATE_1	enables or disables Power Tracker #1		0	3	0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							



UINT

GCMD\_GEN\_SET\_PT\_STATE\_2

enables or disables Power Tracker #2

State FALSE TRUE NULL

Value
0
1

3 0 226

3

0

GCMD\_GEN\_SET\_PT\_STATE\_3

enables or disables Power Tracker #3

State	Value
FALSE	0
TRUE	1
NULL	2

228 2 UINT

2

# GCMD\_MTQ\_PMS

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_PMS_X	Sets permamenent dipole strength	-100	100	0	224	8	INT	
GCMD_MTQ_PMS_Y	Sets permamenent dipole strength	-100	100	0	232	8	INT	
GCMD_MTQ_PMS_Z	Sets permamenent dipole strength	-100	100	0	240	8	INT	
GCMD_MTQ_PMS_ENABLE	turns on permanent magnet setting	0	2	0	248	2	UINT	

State	Value
FALSE	0
TRUE	1
NULL	2

## GCMD\_MTQ\_POP

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_POP_X	flips the polar	ity on mtq x axis	0	2	0	224	2	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							
	NULL	2							
GCMD_MTQ_POP_Y	flips the polar	ity on mtq y axis	0	2	0	226	2	UINT	

	Value
FALSE 0	0

0



TRUE 1 2 NULL

GCMD\_MTQ\_POP\_Z

flips the polarity on mtq z axis

**State** Value **FALSE** TRUE 1 2 NULL

2 0 228

2

UINT

Date: 03/09/2019

# GCMD\_MTQ\_PWM\_TIME

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_MTQ_PWM_TIME_ACTUATION		0	255	0	224	8	UINT	seconds
GCMD_MTQ_PWM_TIME_MEASUREMENT		0	255	0	232	8	UINT	seconds

# GCMD\_PPT\_HALT

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_PPT_HALT_CONFIRM	Are you sure you want to halt the ppt?		0	1	0	224	1	UINT	
	State	Value							
	FALSE	0							
	TRUE	1							

# GCMD\_PPT\_MULTIPLE\_FIRE

Item Name	Description		Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_PPT_MULTIPLE_FIRE_COUNT	How many times to fire		0	255	0	224	8	UINT	
GCMD_PPT_MULTIPLE_FIRE_OVERRIDE	Ppt fire override		0	1	0	232	1	UINT	
	State	State Value							
	FALSE 0								
	TRUE	1							

# GCMD\_RESET\_MINMAX

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GCMD_RESET_MINMAX_BDOT	Whether to reset the subsystem	0	1	0	224	1	UINT	



r to reset the subsystem	0	1	0	225	1	UINT
r to reset the subsystem	0	1	0	226	1	UINT
r to reset the subsystem	0	1	0	227	1	UINT
r to reset the subsystem	0	1	0	228	1	UINT
r to reset the subsystem	0	1	0	229	1	UINT
r to reset the subsystem	0	1	0	230	1	UINT
r to reset the subsystem	0	1	0	231	1	UINT
r to reset the subsystem	0	1	0	232	1	UINT
	er to reset the subsystem	er to reset the subsystem 0	er to reset the subsystem 0 1	er to reset the subsystem 0 1 0	er to reset the subsystem 0 1 0 226 er to reset the subsystem 0 1 0 227 er to reset the subsystem 0 1 0 228 er to reset the subsystem 0 1 0 229 er to reset the subsystem 0 1 0 230 er to reset the subsystem 0 1 0 230 er to reset the subsystem 0 1 0 231	er to reset the subsystem 0 1 0 226 1 er to reset the subsystem 0 1 0 227 1 er to reset the subsystem 0 1 0 228 1 er to reset the subsystem 0 1 0 229 1 er to reset the subsystem 0 1 0 230 1 er to reset the subsystem 0 1 0 231 1

# GRND\_EPOCH

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
GRND_EPOCH_VAL		0	1099511627775	0	224	40	UINT	2^-8 s

# TLE\_1

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_1_BSTAR	TLE BSTAR drag term	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	
TLE_1_MNA	TLE ID and Mean anomaly	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	degrees

# TLE\_2

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_2_DAY	TLE ID and Days since J2000 TT	-1.7e+308	1.7e+308	0.0	224	64	FLOAT	

# TLE\_3

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_3_INC	TLE Orbital inclination	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	degrees
TLE_3_ECC	TLE ID and Eccentricity	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	

# TLE\_4

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_4_RAAN	TLE Rt ascension of the asc. node	-3.4e+38	3.4e+38	0.0	224	32	FLOAT	degrees
TLE_4_AOP	TLE ID and Argument of perigee	-3.4e+38	3.4e+38	0.0	256	32	FLOAT	degrees



# TLE\_5

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
TLE_5_MNM	TLE ID and mean motion	-1.7e+308	1.7e+308	0.0	224	64	FLOAT	revolutions/day