

AWP550B Operation and Maintenance Manual

∠ 1/2" AWP550B





A WARNING

To reduce the risk of injury, read and understand these safety warnings and instructions before using the tool. Keep these instructions with the tool for future reference. If you have any questions, contact your MAC TOOLS representative or distributor.

TABLE OF CONTENTS

Introduction	2
Safety Instructions	3
Specifications	4
Getting Started	5
Tool Components	6
Contact Information	8

INTRODUCTION

The **Mac Tools™ AWP550B** is a precision-built tool, designed for professionals for high torque assembly and disassembly of threaded fasteners. This tool will deliver efficient, dependable service when used correctly and with care. As with any fine power tool, for best performance the manufacturer's instructions must be followed. Please study this manual before operating the tool and understand the safety warnings and instructions. The instructions on installation, operation and maintenance should be read carefully, and the manuals kept for reference. NOTE: Additional safety measures may be required because of your particular application of the tool. Contact your **Mac Tools** representative or distributor with any questions concerning the tool and its use.

Mac Tools 505 North Cleveland Avenue Suite 200 Westerville, Ohio 43082

WARRANTY

We warrant that this tool shall be free from manufacturing defects for a period of ONE YEAR from the original purchase date. Our obligation to the original purchaser shall be limited to repairing or replacing, at our expense (not including shipping charges) a defective tool if returned by the original purchaser within one year from the date of purchase, all incoming shipping charges prepaid. THIS WARRANTY DOES NOT COVER DEFECTS OR DAMAGES TO THE TOOL (i) after the warranty period expires; (ii) resulting from misuse or abnormal operation; (iii) resulting from a failure to properly lubricate, maintain or operate the tool; or (iv) resulting from any repair or maintenance services performed by any party other than Mac Tools.



IMPORTANT SAFETY INFORMATION ENCLOSED. READ THIS MANUAL BEFORE OPERATING THE MACHINE.

FAILURE TO OBSERVE THE FOLLOWING WARNINGS COULD RESULT IN INJURY.



Do not use damaged, frayed or deteriorated air hoses and fittings.



Air powered tools can vibrate in use. Vibration, repetitive motions or uncomfortable positions may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use.



Do not carry the tool by the hose.



Keep body stance balanced and firm. Do not overreach when operating this tool.



Always wear hearing protection when operating this tool.



Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting any accessory on this tool, or before performing any maintenance on this tool.



Always wear eye protection when operating or performing maintenance on this tool.



Operate at 90 psig (6.2 bar / 620 kPa) Maximum air pressure.

GENERAL SAFETY INSTRUCTIONS

⚠ WARNING

- Always wear ANSI Z87.1 eye protection when operating or performing maintenance on this tool. Everyday
 eve glasses are not safety glasses
- Always wear hearing protection when operating this tool
- Keep hands, loose clothing and long hair away from rotating end of tool
- Anticipate and be alert for sudden changes in motion during start up and operation of any power tool
- Keep body stance balanced and firm. Do not overreach when operating this tool
- Do not operate this tool for long periods of time. Vibration caused by tool action may be harmful to your hands and arms. Stop using any tool if discomfort, tingling feeling or pain occurs. Seek medical advice before resuming use
- Use impact rated accessories recommended by Mac Tools only. Inspect accessories before use. Do not
 use cracked or damaged accessories
- Do not operate this tool in the presence of flammable liquids, gasses, dust, or explosive atmospheres
- This tool is not insulated against electric shock
- Always turn off the air supply and disconnect the air supply hose before installing, removing or adjusting
 any accessory on this tool, or before performing any maintenance on this tool
- For safety, top performance, and maximum durability of parts, operate this tool at 90 psig (6.2 bar / 620 kPa) maximum air pressure at the inlet with 3/8" (10mm) inside diameter air supply hose
- Do not use damaged, frayed or deteriorated air hoses and fittings
- Do not lubricate tools with flammable or volatile liquids such as kerosene, diesel or jet fuel
- Do not remove any labels. Replace any damaged label

800.MACTOOLS

Lightweight Composite Housing



			SF	PECIF	ICAT	ONS					
Model#	Square Drive	Blow Rate	Breakaway Torque			Noise	Level				ation evel
	in	bpm	ft-lbs / Nm	Pressu	re dB(A)	Power	r dB(A)	Pressui	re dB(C)	m	n/s²
AWP550B	1/2	1060	800 / 1080	96	3*	107	3*	109	3*	10.2	1.5**

Model#	Free Speed	Average Air Consumption	Working Pressure	Weight	Dimensions
	rpm	cfm / I/min	psi / bar	lbs / kg	in / mm
AWP550B	8000	5.0 / 143	90 / 6.2	4.9 / 2.2	7.1 x 2.7 x 7.2 / 180 x 69 x 184


^{* =} measurement uncertainty in dB(A)



^{** =} measurement uncertainty in m/s2

GETTING STARTED

- Always operate, inspect and maintain this tool in accordance with all regulations (local, state, federal and country) that may apply to hand-held / hand-operated pneumatic tools
- Be sure all hoses and fittings are the correct size and are tightly secured
- Always use clean, dry air at 90 psig maximum air pressure. Dust, corrosive fumes and/or excessive moisture can ruin the motor of an air tool
- The use of a hose whip is recommended. A coupler connected directly to the air inlet increases tool bulk and decreases tool maneuverability
- For maximum performance, the coupler on the wall should be the next size larger than the coupler used on the tool. The coupler closest to the tool should not be less than the proper air supply hose size




PLACING TOOL IN SERVICE

LUBRICATION




Always use an air line lubricator with this tool. After every eight hours of operation, if a lubricator is not used on the compressed air network, inject 1/2 to 1 cc of approved air tool oil (Mac Tools part #PO32) through the tool's inlet connection.

After every forty-eight hours of operation, or as experience indicates, inject about 4 cc of approved pneumatic grease (Mac Tools part #PNG16) into the grease fitting.



800.MACTOOLS



1/2" Impact Wrench		
ANVIL ASSEMBLY 19 31R200098		
ANVIL ASSEMBLY 1 19 31R200091 ANVIL 1 26 31M200023 O-RING 1 27 31M200024 SOCKET RETAINER 1 27 31R200108 IMPACT ASSEMBLY 1 29 31R200108 HAMMER FRAME 1 30 31M200024 HAMMER PIN 2 33 31R200110 HAMMER PIN 2 33 31R200110 HAMMER PIN 2 33 31R200110 HAMMER PIN 2 31R200110 31R200110 HAMMER PIN 1 35 31M200025 ANVIL ASSEMBLY 1 40 31R200112 THROTTLE VALVE PIN 1 2 31R200112 RUBBER SEAL 1 40 31R200112 THROTTLE VALVE PIN 1 2 31R200112 TRIGGER PIN 1 2 31R200112 TRIGGER PIN 1 2 31R200112 TRIGGER PIN 1 2 31	SPRING PIN	1
ANVIL O-RING O-RING O-RING SOCKET RETAINER IMPACT ASSEMBLY 1 27 317200034 IMPACT ASSEMBLY 1 30 31R200107 HAMMER FRAME 1 31 31R200110 HAMMER PIN 2 33 31R200110 HAMMER PIN 1 36 31M200025 HAMMER PIN 1 37 31M200025 HAMMER PIN 1 37 31M200026 HAMMER PIN 1 2 2 31M20004 THROTTLE VALVE PIN 1 2 2 3 31M20004 THROTTLE VALVE PIN 1 2 2 3 31M20004 THROTTLE VALVE PIN 1 2 2 3 31M200110 TRIGGER PIN 1 2 2 3 31M20004 TRIGGER PIN 1 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	SPRING PIN	1
O-RING 1 27 31720034	BACKHEAD	1
SOCKET RETAINER 1 28 31R200107	REVERSE VALVE KNOB	1
IMPACT ASSEMBLY 30 31R200108 HAMMER FRAME	EW	1
IMPACTASSEMBLY 30 31M200024 HAMMER FRAME	EW	4
HAMMER FRAME	REAR END PLATE	1
HAMMER PIN	SPRING PIN	2
HAMMER PIN	RETAINER	1
ANVIL ASSEMBLY 1 36 31M200026	CYLINDER	1
HOUSING ASSEMBLY 40 31R200112	TOR	-1
HOUSING ASSEMBLY 1 40 31R200112	FRONT END PLATE	-1
THROTTLE VALVE ASSEMBLY 1 TK 31M100004 THROTTLE VALVE PIN 1 2 AM100004 RUBBER SEAL 1 3 AM100004 THROTTLE VALVE 1 7 AM1 TRIGGER ASSEMBLY 1 1 23 TRIGGER PIN 23 AM1 LOCKING PLUG 1 25 LOCKING PLUG 1 32 BUSHING 1 39 GREASE FITTING 1 46 RETAINER 1 46 RETAINER 1 48 GUIDE TUBE 1 52 RETAINER 1 52 THROTTLE VALVE SEAT 1 47 EXHAUST DEFLECTOR 1 6 EXHAUST DEFLECTOR 1 6	SHER	1
THROTTLE VALVE ASSEMBLY 1 TK 31M100004 THROTTLE VALVE PIN 1 2 AM100004 RUBBER SEAL 1 3 AM100004 THROTTLE VALVE 1 3 AM100004 TRIGGER PIN 1 22 AM1000 TRIGGER PIN 1 23 AM1000 LOCKING PLUG 1 24 AM1000 LOCKING PLUG 1 32 AM1000 BUSHING 1 39 AM1000 GREASE FITTING 1 46 AM1000 GREASE FITTING 1 46 AM1000 THROTTLE VALVE SEAT 1 52 AM1000 THROTTLE VALVE SEAT 1 52 AM1000 EXTABLECTOR 1 52 AM1000 EXHABITICAL 1 52 AM1000 EXHABITICAL 1 52 AM1000 EXHABITICAL 1 52 AM1000 EXHABITICALOR 1 48 AM1000 </td <td></td> <td></td>		
THROTTLE VALVE PIN 1 2 RUBBER SEAL 1 3 THROTTLE VALVE 1 7 TRIGGER ASSEMBLY 1 11 TRIGGER PIN 1 22 TRIGGER PIN 1 23 I CKING PLUG 1 24 LOCKING PLUG 1 25 BUSHING 1 33 GREASE FITTING 1 38 GREASE FITTING 1 46 GREASE FITTING 1 48 GUIDE TUBE 1 48 GUIDE TUBE 1 52 THROTTLE VALVE SEAT 1 48 THROTTLE VALVE SEAT 1 52 THROTTLE VALVE SEAT 1 52	TUNE UP KIT	
RUBBER SEAL 1 3 THROTTLE VALVE 1 7 TRIGGER ASSEMBLY 1 7 TRIGGER PIN 1 22 TRIGGER PIN 1 23 AREVERSE VALVE ASSEMBLY 1 24 LOCKING PLUG 1 25 BUSHING 1 33 GREASE FITTING 1 38 GREASE FITTING 1 39 GUIDE TUBE 4 44 RETAINER 1 52 THROTTLE VALVE SEAT 1 52 THROTTLE VALVE SEAT 1 52 THROTTLE VALVE SEAT 1 52	ING	1
THROTTLE VALVE	ING	2
TRIGGER ASSEMBLY 1 11 TRIGGER PIN 1 22 REVERSE VALVE ASSEMBLY 1 23 LOCKING PLUG 1 25 LOCKING PLUG 1 25 LOCKING PLUG 1 38 BUSHING GREASE FITTING 1 39 GREATE FITTING 1 39	ING	2
TRIGGER ASSEMBLY 1 11 TRIGGER PIN 22 REVERSE VALVE ASSEMBLY 1 24 LOCKING PLUG 1 25 LOCKING PLUG 1 25 WHAMMER CASE ASSEMBLY 1 38 BUSHING GREASE FITTING 1 39 GREAT 1 39 GREATE 1	ING	1
TRIGGER PIN	ING	1
REVERSE VALVE ASSEMBLY 23 24 24 24 24 25 25 25 25	STEEL BALL	1
REVERSE VALVE ASSEMBLY 1 24 1 25 1 25 1 25 1 25 25 25	ING	1
LOCKING PLUG	ING	1
HAMMER CASE ASSEMBLY 32	SKET	1
HAMMER CASE ASSEMBLY 38	BALL BEARING	1
BUSHING 1 39 GREASE FITTING 1 46 GUIDE TUBE 48 48 GUIDE TUBE 1 52 RETAINER 1 52 THROTTLE VALVE SEAT 1 60 EXAMINIST DEFLECTOR 1 60	ROTOR BLADE	9
GREASE FITTING	BALL BEARING	1
47 48 48 48 49 49 49 49 49	ING	-
48 48 48 48 49 49 49 49	SOCKET RETAINER	-
GUIDE TUBE 1 52 RETAINER 1 1 THROTILE VALVE SEAT 1 1 EXHAUST DEFLECTOR 1 1	SKET	1
RETAINER THROTTLE VALVE SEAT EXHAUST DEFLECTOR	MUFFLER ELEMENT	1
THROTTLE VALVE SEAT EXHAUST DEFLECTOR		
EXHAUST DEFLECTOR		
1		
31Y200033 AIR INLET 1		
31R200087 SPRING PIN 1		



CUSTOMER SERVICE

We at Mac Tools are committed to our customers, please reference the following phone number for a direct contact to one of our customer technicians. They will be more than happy to help with any service or warranty questions you may have about your power tool.

Mac Tools
505 North Cleveland Avenue
Suite 200
Westerville, Ohio 43082
800.MACTOOLS
MACTOOLS.COM

CE DECLARATION OF CONFORMITY

WE, MAC TOOLS, 505 NORTH CLEVELAND AVENUE, SUITE 200 WESTERVILLE, OHIO 43082 DECLARE UNDER OUR OWN RESPONSIBILITY THAT THE PRODUCTS AWP550B 1/2" AIR IMPACT WRENCH - IS IN CONFORMITY WITH THE «MACHINERY» DIRECTIVE 2006/42/EC

- AND IS IN CONFORMITY WITH THE PROVISIONS OF THE FOLLOWING STANDARDS ISO 12100:2010

130 12100:2010

ISO 11148-6:2012

ISO 15744:2002

ISO 28927-2:2009

((

Eric Min QUALITY DIRECTOR 23 12 2013