
- 1 使用前請先完成,需要加入開發板資料於 Arduino IDE 中
 - QuickBLE Nrf51822 Arduino IDE/QuickBLE_EVB_Serial 使用教學.pdf
 https://github.com/VierMTech/QuickBLE_Nrf51822_Arduino_IDE/blob/master/
 QuickBLE_EVB_Serial%E4%BD%BF%E7%94%A8%E6%95%99%E5%AD%
 B8.pdf
- 2 参考範例於
 QuickBLE_Nrf51822_Arduino_IDE\Quickble_Serial_Timer_LedBlink_GY-521_MPU6050 目錄中
- 3 根據如下圖接線



4 GY-521 Example Code reference
https://github.com/janaka/Gy521-Dev-Kit/blob/master/Gy521_send_serial.ino

5 Code Example 参考
QuickBLE_Nrf51822_Arduino_IDE\Quickble_Serial_Timer_LedBlink_GY521_MPU6050\Quickble_Serial_Timer_LedBlink_GY-521_MPU6050.ino