

\$Date: 2019/07/15 \$ Version \$Revision: #2 \$



User Guide

For

QDMA Ethernet Platform

(Linux Kernel Driver)

Project Number: 2000-0158

Author: Pankaj Kumar

The information contained herein is proprietary to Xilinx Inc and may not be divulged to any third party without the express written consent of Xilinx Inc.

Copyright © 2019 Xilinx, Inc. All rights reserved.



\$Date: 2019/07/15 \$

4.2

4.3

4.4 4.5

4.6

User Guide Version \$Revision: #2 \$

CONTENTS

1	Int	roduction	4
	1.1	Document Overview	4
	1.2	Document Reference	4
	1.3	Glossary	4
2	Sy	stem Overview	5
	-	nux Kernel Driver	
	3.1	System Setup	6
	3.2	Environment	
	3.3	Build Kernel Module	7
	3.4	Inserting Kernel Module	7
	3.5	Unloading Kernel Module	8
	3.6	Driver Validation	
	3.7	Driver Usage and Configuration	9
4	De	ebugfs Usage	11
	4.1	CMAC	11

QEP Config12

Document Review History13



\$Date: 2019/07/15 \$ User Guide Version \$Revision: #2 \$

Xilinx QDMA Ethernet Platform Page 3 of 13

LIST OF TABLES

Table 1-1: Document Reference	4 4
Table 3-1: System Configuration	6
Table 3-2: Linux Kernel Software Database Content	7
Table 4-1: Document Review History	13
LIST OF FIGURES	
Figure 1: Software Architecture	5
Figure 2: Lspci Output	6
Figure 3: Ifconfig Output1	8
Figure 4: Ifconfig Output2	8
Figure 5: Ping Test System Setup	
Figure 7: Debugfs Tree Snapshot	

User Guide Version \$Revision: #2 \$

\$Date: 2019/07/15 \$

1 Introduction

1.1 Document Overview

This User Guide provides the setup procedure and software usage instructions of the Linux Kernel driver for Network PF of QDMA Ethernet Platform.

1.2 Document Reference

Document References	Version
[1] QDMA Subsystem for PCI Express (PG302)	3.0
[2] Integrated 100G Ethernet Subsystem (PG203)	2.6

Table 1-1: Document Reference

1.3 Glossary

Acronym / Term	Description
BAR	Base Address Register
BDF	Bus, Device, Function of a PCIe device
C2H	Card to Host
CMAC	100G Media Access Control (Ethernet Layer 2)
DMA	Direct Memory Access
H2C	Host to Card
IP	Intellectual Property
PF	Physical Function
QDMA	Multi Queue Direct Memory Access
QEP	QDMA Ethernet Platform
STM	Streaming Traffic Manager
STM-N	Streaming Traffic Manager for Networking

Table 1-2: Glossary

2 System Overview

This design adds networking support to QDMA based SDAccel platform. The Ethernet Subsystem is added to the static region of the shell. The platform has three physical functions, two physical functions for device management (PF0) and compute acceleration (PF1), and one physical function (PF2) for Network acceleration. The Ethernet subsystem is accessible to the host via PF2.




Figure 1: Software Architecture

User Guide Version \$Revision: #2 \$

\$Date: 2019/07/15 \$

3 Linux Kernel Driver

QEP Linux Kernel Driver configures the underlying PCI device, initializes the QDMA, STM-N and CMAC, setups the queues, and registers the device as network device to the Linux kernel. The Linux Kernel Driver supports

- Standard Network Device Operations
- Ethtool Operations
- Debugfs

The following sections provide a brief set of instructions to build and deploy the Linux Kernel Driver and run a few tests to validate.

Note: All the instructions must be executed with root privilege.

3.1 System Setup

This release was tested with the following system configuration.

Host System Configuration	Description
Operating System	Ubuntu 18.04.1 LTS
Linux Kernel	4.15.0-54-generic
RAM	32GB on local NUMA node

Table 3-1: System Configuration

3.2 Environment

For QEP Linux Kernel driver following system requirements are to be met:

- Host System with at least one Gen3 x16 PCIe slot and minimum 16GB RAM on same CPU node.
- U250 Board
- 3. USB Digilent cables to connect the U250 board to the Host System.
- Xilinx 2019.1 Vivado tools for programming the FPGA.
- 5. SDAccel Platform DSA with networking subsystem

Program the U250 board with QEP platform. Please refer to https://www.xilinx.com/products/boards-and-kits/alveo/u250.html#gettingStarted for bringing up U250 boards. Once the device is programmed with QEP platform, execute the following command on the server:

Ispci -d 10ee:

```
-Following is sample output
```

```
04:00.0 Processing accelerators: Xilinx Corporation Device 7000 04:00.1 Processing accelerators: Xilinx Corporation Device 7001 04:00.2 Ethernet controller: Xilinx Corporation Device 7002
```

Figure 2: Lspci Output

Note: There should be three PFs shown and the PCIe device ID should be shown as 7002 for the device enumerated as Ethernet controller.



3.3 Build Kernel Module

Below Table describes the QEP Linux driver database structure and its contents on the Xilinx Github https://github.com/Xilinx/qep-drivers, subdirectory linux-kernel.

Directory	Description				
qep_drivers/linux-kernel/driver	Linux Kernel Driver Source				
qep_drivers/linux- kernel/ug02_2000_0158.pdf	This document (User guide)				
qep_drivers/linux-kernel/RELEASE.txt	Release Notes				

Table 3-2: Linux Kernel Software Database Content

Steps to build the driver

```
# sudo apt-get install linux-headers-$(uname -r) build-essential
# git clone https://github.com/Xilinx/qep-drivers.git
# cd qep_drivers/linux-kernel/driver
# make clean
```

make

This will generate qep_drv.ko (Kernel Module)

3.4 Inserting Kernel Module

Execute the following command to load kernel module:

Upon successful insertion of the driver, a new network interface is created, that can be used for sending and receiving traffic.

To list all network interfaces, use following command:

1: Enable

User Guide Version \$Revision: #2 \$

\$Date: 2019/07/15 \$

ifconfig -a

Below is sample output for 100G network interface

```
enp4s0 Link encap:Ethernet HWaddr 00:00:00:00:00:00
inet6 addr: fe80::200:ff:fe00:0/64 Scope:Link

UP BROADCAST RUNNING MULTICAST MTU:9600 Metric:1

RX packets:17625026 errors:0 dropped:9738388 overruns:0 frame:0

TX packets:16 errors:0 dropped:0 overruns:0 carrier:0

collisions:0 txqueuelen:1000

RX bytes:8817175776 (8.8 GB) TX bytes:2462 (2.4 KB)
```

3.5 Unloading Kernel Module

Execute the following command to unload kernel module:

```
# sudo rmmod qep drv
```

3.6 Driver Validation

3.6.1 Data Path Test in Loopback

This is a simple test by putting CMAC IP in loopback mode. In loopback mode, CMAC core puts the data coming on TX path onto its RX path. So, the packets sent on TX interface would be received on RX interface. The CMAC core can be put in loopback mode by module parameter loopback_en.

Execute the below commands for this test.

```
# sudo apt install hping3
```

ifconfig -s -a

sample output:

Iface	MTU	RX-OK	RX-ERR	RX-DRP	RX-OVR	TX-OK	TX-ERR	TX-DRP	TX-OVR	Flg
enpOs25	1500	1012365	0	0	0	140785	0	0	0	BMRU
10	65536	11492	0	0	0	11492	0	0	0	LRU

Figure 3: Ifconfig Output1

```
# insmod qep drv.ko nb queues=1 rs fec en=1 loopback en=1
```

sample output:

Iface	MTU	RX-OK	RX-ERR	RX-DRP	RX-OVR	TX-OK	TX-ERR	TX-DRP	TX-OVR	Flg
enpOs25	1500	1013255	0	0	0	140876	0	0	0	BMRU
ens4f2	1500	6	0	0	0	6	0	0	0	BMPRU
10	65536	11500	0	0	0	11500	0	0	0	LRU

Figure 4: Ifconfig Output2

```
# ifconfig ens4f2 -arp
```

[#] ifconfig -s -a

[#] ifconfig ens4f2 192.168.1.10

[#] hping3 192.168.1.20 -I ens4f2 -2 -c 10 -d 64

Note: Verify that difference in number of TX-OK packet and RX-OK packet before and after executing the above hping3 command is same.

3.6.2 Ping test with peer NIC

Ping test ensures connectivity with a peer NIC.




Figure 5: Ping Test System Setup

Following are the steps,

- 1) Set IP address and netmask on Host1 network interface using following command
 - # ifconfig ens4f2 192.168.1.1 netmask 255.255.255.0
- 2) Set IP address and netmask of Host2 network interface using following command
 - # sudo ifconfig enp175s0 192.168.1.2 netmask 255.255.255.0
- 3) From Host1 execute the following commands to check connectivity

```
# ping -I ens4f2 192.168.1.2
64 bytes from 192.168.1.2: icmp_seq=1 ttl=63 time=0.220 ms
64 bytes from 192.168.1.2: icmp_seq=2 ttl=63 time=0.274 ms
64 bytes from 192.168.1.2: icmp_seq=3 ttl=63 time=0.289 ms
```

3.7 Driver Usage and Configuration

To assign an IP address to the network interface

ifconfig <interface> <ip address> netmask <subnet mask>

· To assign MAC address to the network interface

ifconfig <interface> hw ether <MAC Address>

To bring network interface up

ifconfig <interface> up

To bring network interface down

ifconfig <interface> down

To change MTU (Maximum Transmission Unit) size of network interface

ifconfig <interface> mtu <mtu size>



Xilinx



User Guide \$Date: 2019/07/15 \$ Version \$Revision: #2 \$

To check driver and device information of network interface

ethtool -i <interface>

To print statistics of network interface

ethtool -S <interface>

To query ring size values of network interface

ethtool -g <interface>

To modify ring size of network interface

ethtool -G <interface> rx <Rx Ring Size> tx <Tx Ring Size>

To modify channels (Queues) of network interface

ethtool -L <interface> rx <num channel> tx <num channel>

To change the coalescing settings of the specified network device

ethtool -C <interface> rx-usecs <N> rx-frames <N>

To dump all Tx/Rx packets of network interface

tcpdump -XX -i <interface>

For more options please refer man page of standard Linux IP utilities (e.g. ifconfig, ethtool, tcpdump, etc.).

4 Debugfs Usage

The QEP Linux Kernel Driver provides rich debugfs support. Along with configuration, status, and statistics, debug related information is also provided through the read-only interface. Debug information is provided for CMAC, STM-N and QDMA subsystems. The debugfs files are located at /sys/kernel/debug/qep_dev/ filesystem. For every device a filesystem tree is populated with directory name as its BDF.

>sudo tree /sys/kernel/debug/qep dev/ sample output: /sys/kernel/debug/qep_dev/ □ 04:00:2 - cmac qdma info qdma regs qep_config queues c2h cntxt desc info cmpt cntxt desc info h2c cntxt desc info stmn

Figure 6: Debugfs Tree Snapshot

4.1 CMAC

This file contains a snapshot of error, status and statistics registers of CMAC IP. For details refer to CMAC user guide.

Sample Command:

cat /sys/kernel/debug/qep dev/<BDF>/cmac

4.2 QDMA Info

This file provides information about configuration mode of QDMA.

Sample Command:

cat /sys/kernel/debug/qep dev/<BDF>/qdma info

\$Date: 2019/07/15 \$

User Guide Version \$Revision: #2 \$ Xilinx QDMA Ethernet Platform Page 12 of 13

4.3 QDMA Register Dump

This file provides a snapshot of QDMA registers. For details please refer to QDMA IP user guide Sample Command:

cat /sys/kernel/debug/qep dev/<BDF>/qdma regs

4.4 QEP Config

This file provides information on QEP driver configuration modes.

Sample Command:

cat /sys/kernel/debug/qep_dev/<BDF>/qep_config

4.5 Queue

This directory tree is dynamic and populates following files corresponding to C2H, H2C and CMPT queue up to max number of configured queues.

- cntxt: Software and Hardware Context of queue
- desc: Raw descriptor queue
- · info: Queue info

Sample Command:

cat /sys/kernel/debug/qep dev/<BDF>/queues/0/c2h/info

4.6 STM-N

This file prints a snapshot of STM-N error, drops, status and statistics. After every read, the underlying registers get cleared.

Sample Command:

cat /sys/kernel/debug/qep_dev/<BDF>/stmn

5 Document Review History

Version	Date	Review Details	State		
1	12-Jul-19	Initial draft of QEP Linux Kernel Driver User Guide	Not Released		
2	15-Jul-19	Reviewed and approved for Release	Released		

Table 5-1: Document Review History