



Bluetooth remote control use instructions

- 1. You need to download the **PCA9685_Drive_Bluetooth _WIFI_control** program and upload this program to the UNO board of 6WD robot car.
- 2. You need to download and install Bluetooth control APP control APP, and install it to your Android phone.
- 3. Fully charge the 6WD car to ensure it has enough power. Please refer to the place shown below as the charging method.



4. You need to connect the Bluetooth module and unplug the wifi camera module. As shown below.





5. After charging is complete. You need to open the power switch of the 6WD robot car.(the red indicating light of the Bluetooth module is flashing)
Then, open the Bluetooth of your Android phone, and open the already installed Bluetooth remote control APP.


You will see the Bluetooth signal in the upper left corner of your phone interface.




6. Bluetooth will be connected automatically when the phone is near the robot



car, no need the pairing password.





If Bluetooth is not automatically connected, you need to click on the **【CONNECT】** of the APP interface.

7. After Bluetooth is successfully connected, (the red indicating light of the



Bluetooth module is not flashing, is on) you can control the robot car.

8. After successful connection, enter the main control page.

