Model conversion

Model conversion

- 1. Jetson Orin YOLO11 (benchmark)
- 2. Enable optimal performance of the motherboard
 - 2.1. Enable MAX power mode
 - 2.2. Enable Jetson clocks
- 3. Model conversion
 - 3.1. CLI: pt \rightarrow onnx \rightarrow engine
 - 3.2. Python: $pt \rightarrow onnx \rightarrow engine$
- 4. Model prediction

CLI usage

Frequently asked questions

ERROR: onnxslim

References

1. Jetson Orin YOLO11 (benchmark)

YOLO11 benchmark data comes from the Ultralytics team, which tests models in multiple formats (data is for reference only)

2. Enable optimal performance of the motherboard

2.1. Enable MAX power mode

Enabling MAX Power Mode on Jetson will ensure that all CPU and GPU cores are turned on:

sudo nvpmodel -m 2

2.2. Enable Jetson clocks

Enabling Jetson Clocks will ensure that all CPU and GPU cores run at maximum frequency:

sudo jetson_clocks

3. Model conversion

According to the test parameters of different formats provided by the Ultralytics team, we can find that the inference performance is best when using TensorRT!


When using the export mode of YOLO11 for the first time, some dependencies will be automatically installed. Just wait for it to be completed automatically!

3.1. CLI: pt \rightarrow onnx \rightarrow engine

Convert the PyTorch format model to TensorRT: The conversion process will automatically generate an ONNX model

cd /home/jetson/ultralytics/ultralytics

```
yolo export model=yolo11n.pt format=engine
# yolo export model=yolo11n-seg.pt format=engine
# yolo export model=yolo11n-pose.pt format=engine
# yolo export model=yolo11n-cls.pt format=engine
# yolo export model=yolo11n-obb.pt format=engine
```



3.2. Python: $pt \rightarrow onnx \rightarrow engine$

Convert PyTorch format models to TensorRT: The conversion process will automatically generate ONNX models

cd /home/jetson/ultralytics/ultralytics/yahboom_demo

python3 model_pt_onnx_engine.py

```
from ultralytics import YOLO

# Load a YOLO11n PyTorch model

# model = YOLO("/home/jetson/ultralytics/ultralytics/yolo11n.pt")

model = YOLO("/home/jetson/ultralytics/ultralytics/yolo11n-seg.pt")

# model = YOLO("/home/jetson/ultralytics/ultralytics/yolo11n-pose.pt")


# model = YOLO("/home/jetson/ultralytics/ultralytics/yolo11n-cls.pt")

# model = YOLO("/home/jetson/ultralytics/ultralytics/yolo11n-obb.pt")

# Export the model to TensorRT

model.export(format="engine")
```

Note: The model file generated by the conversion is located in the converted model file location




4. Model prediction

CLI usage


CLI currently only supports calling USB cameras. CSI camera users can directly modify the previous python code to call onnx and engine models!

cd /home/jetson/ultralytics/ultralytics

yolo predict model=yolo11n.onnx source=0 save=False show




yolo predict model=yolo11n.engine source=0 save=False show




Frequently asked questions

ERROR: onnxslim



Solution: Enter the onnxslim installation command in the terminal

sudo pip3 install onnxslim



References

https://docs.ultralytics.com/guides/nvidia-jetson/

https://docs.ultralytics.com/integrations/tensorrt/