Robot keyboard control

Note: The virtual machine needs to be in the same LAN as the car, and the ROS_DOMAIN_ID needs to be consistent. You can check [Read me] to set the IP and ROS_DOMAIN_ID on the board.

1. Program function description

After the program is started, the car movement can be controlled through the keyboard.

2. Start and connect to the agent

Taking the supporting virtual machine as an example, enter the following command to start the agent:

```
sudo docker run -it --rm -v /dev:/dev -v /dev/shm:/dev/shm --privileged --net=host
microros/micro-ros-agent:humble udp4 --port 8090 -v4
```

Then, turn on the car switch and wait for the car to connect to the agent. The connection is successful, as shown in the figure below.

```
create_participant
                                                                                                       | client_key: 0x0B62A009, par
cipant_id: 0x000(1)
                                                  | create topic
                                                                             | topic created
                                                                                                      | client_key: 0x0B62A009, topi
_id: 0x000(2), participant_id: 0x000(1)
                                                  | create_publisher
                                                                             publisher created
                                                                                                      | client_key: 0x0B62A009, publ
isher_id: 0x000(3), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, data
                                                  | create datawriter
                                                                             I datawriter created
writer_id: 0x000(5), publisher_id: 0x000(3)
                                                  | create_topic
                                                                                                      | client_key: 0x0B62A009, topi
_id: 0x001(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, publ
                                                  | create_publisher
isher_id: 0x001(3), participant_id: 0x000(1)
                                                  | create_datawriter
                                                                                                      | client_key: 0x0B62A009, data
writer_id: 0x001(5), publisher_id: 0x001(3)
                                                                                                      | client key: 0x0B62A009, topi
                                                  | create topic
 _id: 0x002(2), participant_id: 0x000(1)
                                                  | create_publisher
                                                                                                      | client_key: 0x0B62A009, publ
isher_id: 0x002(3), participant_id: 0x000(1)
                                                  | create_datawriter
                                                                                                      | client_key: 0x0B62A009, data
writer_id: 0x002(5), publisher_id: 0x002(3)
                                                                                                      | client key: 0x0B62A009, topi
                                                  create topic
_id: 0x003(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, subs
criber_id: 0x000(4), participant_id: 0x000(1)
                                                  | create_datareader
                                                                             datareader created
                                                                                                      | client_key: 0x0B62A009, data
reader_id: 0x000(6), subscriber_id: 0x000(4)
                                                                                                      | client_key: 0x0B62A009, topi
                                                  create_topic
c_id: 0x004(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, subs
                                                  | create subscriber
criber_id: 0x001(4), participant_id: 0x000(1)
                                                  | create_datareader
                                                                                                      | client_key: 0x0B62A009, data
reader_id: 0x001(6), subscriber_id: 0x001(4)
                                                                                                      | client_key: 0x0B62A009, topi
                                                  | create topic
                                                                             | topic created
c_id: 0x005(2), participant_id: 0x000(1)
                                                  | create_subscriber
                                                                                                      | client_key: 0x0B62A009, subs
criber_id: 0x002(4), participant_id: 0x000(1)
                                                  I create datareader
                                                                                                      | client_key: 0x0B62A009, data
     _id: 0x002(6), subscriber_id: 0x002(4)
```

3. Start the keyboard control program

Enter the following command in the terminal to start the keyboard control program.

```
ros2 run yahboomcar_ctrl yahboom_keyboard
```

```
yahboom@yahboom-VM:~$ ros2 run yahboomcar_ctrl yahboom_keyboard

Control Your SLAM-Bot!

Moving around:

u i o
j k l
m , .

q/z : increase/decrease max speeds by 10%

w/x : increase/decrease only linear speed by 10%
e/c : increase/decrease only angular speed by 10%
t/T : x and y speed switch
s/S : stop keyboard control
space key, k : force stop
anything else : stop smoothly

CTRL-C to quit

currently: speed 0.2 turn 1.0
```

Keyboard key descriptions are as follows

Directional control.

[i] or [I]	[linear, 0]	[u] or [U]	[linear, angular]
[,]	[-linear, 0]	[o] or [U]	【linear, -angular】

[i] or [I]	[linear, 0]	[u] or [U]	[linear, angular]
[j] or [J]	[0, angular]	[m] or [M]	[-linear, -angular]
[I] or [L]	[0, -angular]	[.]	[-linear, angular]

According to the control table description, you can go forward by pressing the [i] key. Press [,] to go back, Press [l] to rotate to the right, press [j] to rotate to the left, and so on.

speed control table

speed change	speed change	keyboard keys	speed change
[q]	Linear speed and angular speed increased by 10%	[z]	Linear speed and angular speed are reduced by 10%
[w]	Only line speed increases by 10%	[×]	Only line speed is reduced by 10%
[e]	Only the angular velocity is increases by 10%	[c]	Only the angular velocity is reduced by 10%
[t]	Linear speed X-axis/Y-axis direction switching	[s]	Stop keyboard control

Note: Since the car has a four-wheel drive structure with ordinary tires and cannot move sideways, the [t] button has no meaning. Before each use of keyboard control, you need to click on the terminal that starts the program, otherwise the key event cannot be detected.