




## Expand course ---6.Ultrasonic avoid

### 1. Learning goal

In this lesson, we will learn how to achieve ultrasonic obstacle avoidance.

### 2. Preparation


2.1 The position of the ultrasonic port on the expansion board. As shown below.




2.2 The pin of UNO board is connected the pins of motor and ultrasonic module on the expansion board .

### 3. Principle of experimental


The ultrasonic module is a sensor that uses ultrasonic characteristics to detect the distance. It has two ultrasonic probes for transmitting and receiving ultrasonic waves. The range of measurement is 3-450 cm.



- (1) You need to input a high level signal of at least 10us to the Trig pin to trigger the ranging function of the ultrasonic module.



- (2) After the ranging function is triggered, the module will automatically send out 8 ultrasonic pulses with 40 kHz and automatically detect whether there is a signal return. This step is done internally by the module.



- (3) When the module detects an echo signal, the ECHO pin will output a high level. The high level duration is the time from when the ultrasonic wave is sent to when it returns. You can calculate the distance by using the time function to calculate the high level duration.

**Formula: Distance = High level duration \* Speed of sound(340M/S)/2.**  
PCA9685 chip and UNO board adopt I2C communication method. I2C address is 0x40.

connection as shown below.

PCA9685 chip	Right front Motor
10	Forward
11	Reverse

PCA9685 chip	Right rear Motor
8	Forward
9	Reverse

PCA9685 chip	Left front Motor
13	Forward
12	Reverse

PCA9685 chip	Left rear Motor
15	Forward
14	Reverse

Classification	Function	The number of Drive chip PCA9685	Drive Method	Connection with CPU	Uno board
Left Motor	Left front motor forward	LINB(13)	PCA9685	I2C_SDA/I2C_SCL	A4/A5
	Left front motor reverse	LINA(12)			
	Left rear motor forward	RINB(15)			
	Left rear motor reverse	RINA(14)			
Right Motor	Right front motor forward	LED10			
	Right front motor reverse	LED11			
	Right rear motor forward	LED8			
	Right rear motor reverse	LED9			
Servo	Control S1	LED0			A0
	Control S2	LED1			
	Control S3	LED2			
	Control S4	S1 (3)			
LOGO light	Control bluelight	LED7			A1
Tracking sensor	Left tracking sensor				
	Middle tracking sensor				
	Right tracking sensor				
Ultrasonic sensor	Ultrasonic Echo		Uno board drive directly		A2
	Ultrasonic RGB light				
Key	K1				12
IR	IR control				
Bluetooth interface	RX				
	TX				
On board RGB Light	RGB Light on expansion board				11
Buzzer	Control buzzer				

From the hardware interface manual, we can know that ultrasonic module are driven by Pin 12.

From the hardware interface manual, we can know that four motor of the robot car are driven by PWM by PCA9685 chip.

#### 4. About code

For the code of this course, please refer to: [Ultrasonic\\_Avoid.ino](#) in the [Ultrasonic\\_Avoid](#) folder.

```
#include <Wire.h>
#include "Adafruit_PWMServoDriver.h"
Adafruit_PWMServoDriver pwm = Adafruit_PWMServoDriver(0x40);
#define SERVOMIN 150 // this is the 'minimum' pulse length count (out of
4096)
#define SERVOMAX 600 // this is the 'maximum' pulse length count (out of
4096)
const int SingPin = 12;
float distance;

#include "RGBLed.h"
#define RGB_GREEN    0xFF0000    //Define different
color(green,red,blue)
#define RGB_RED     0x00FF00
#define RGB_BLUE    0x0000FF
#define RGB_YELLOW  0xFFFF00
#define RGB_OFF     0
const int RgbPin = 11;      //Define pin of Ultrasonic RGB light
RGBLed mRgb(RgbPin,2);
const int key = 7; //Define key pin

.....
void Servo_180(int num, int degree)
{
    long us = (degree * 1800 / 180 + 600); // 0.6 ~ 2.4
    long pwmvalue = us * 4096 / 20000;    // 50hz: 20,000 us
    pwm.setPWM(num, 0, pwmvalue);
}

.....
void Ultrasonic_avoid()
{
    Distance();
    if (distance > 50)
    {
        mRgb.setColor(0,RGB_GREEN); //There are two RGB light on the
Ultrasonic module No.1 and No.2
        mRgb.show();
        run(80);      //When the distance is far away, run at full speed
    }
}
```

```


else if (distance >= 25 && distance <= 50)
{
    mRgb.setColor(0,RGB_BLUE); //There are two RGB light on the
Ultrasonic module No.1 and No.2
    mRgb.show();
    run(60); //When the distance is near,slow down
}
else if (distance < 25)
{
    brake();
    mRgb.setColor(0,RGB_RED); //There are two RGB light on the
Ultrasonic module No.1 and No.2
    mRgb.show();
    spin_right(70); //When approaching obstacles,turn right at about 90
degrees
    delay(500);
    brake();
    delay(200);
    Distance_test(); //Test again to determine the distance ahead
if (distance >= 25)
{
    mRgb.setColor(0,RGB_YELLOW); //There are two RGB light on the
Ultrasonic module No.1 and No.2
    mRgb.show();
    run(80); //When the distance is greater than 25cm after turning,run
}
else if (distance < 25)
{
    brake();
    mRgb.setColor(0,RGB_RED); //There are two RGB light on the
Ultrasonic module No.1 and No.2
    mRgb.show();
    spin_left(70); //When the distance less than 25cm after turning,turn
left 180 degrees in place
    delay(400);
    brake();
    delay(200);
    Distance_test(); //Test again to determine the distance ahead
if (distance >= 25)
{
    mRgb.setColor(0,RGB_YELLOW); //There are two RGB light on the
Ultrasonic module No.1 and No.2
    mRgb.show();
    run(80); //When the distance is greater than 25cm after turning,run
}

```



```
        }
        else if (distance < 25)
        {
            brake();
            mRgb.setRGB(0,RGB_RED); //There are two RGB light on the
Ultrasonic module No.1 and No.2
            mRgb.show();
            spin_left(70);//When the distance less than 25cm after turning,turn
right 90 degrees in place
            delay(400);
            brake();
            delay(200);
        }
    }
}
```

## 5. Compiling and downloading code

5.1 We need to open the **Ultrasonic\_Avoid.ino** file by Arduino IDE software. Then click “√” under the menu bar to compile the code, and wait for the word **“Done compiling”** in the lower left corner, as shown in the figure below.



5.2 In the menu bar of Arduino IDE, we need to select 【Tools】---【Port】--- selecting the port that the serial number displayed by the device manager just now, as shown in the figure below.



5.3 After the selection is completed, you need to click “→”under the menu bar to upload the code to the UNO board. When the word “**Done uploading**” appears in the lower left corner, the code has been successfully uploaded to the UNO board, as shown in the figure below.

Ultrasonic\_Ranging | Arduino 1.8.5

File Edit Sketch Tools Help

```
#include <Adafruit_PWM_Servo_Driver.h>
Adafruit_PWM_Servo_Driver pwm = Adafruit_PWM_Servo_Driver(0x40);
const int SingPin = 13;
float distance;


/**
 * Function      setup
 * @author        liusen
 * @date          2017.07.25
 * @brief         Initial configuration
 * @param[in]     void
 */

Done uploading.
```

Sketch uses 5924 bytes (18%) of program storage space. Maximum : Global variables use 451 bytes (22%) of dynamic memory, leaving

## 6. Experimental phenomena

After the program is downloaded. We need to wait for servo rotate to 90°(Front), as shown below.



Then, we need to press K1 on the expansion board, the robot car will advance. When there are obstacles in front of it, the car will spin left or spin right to avoid obstacles. And RGB light of ultrasonic module will change different color.

### **Note:**

**It just avoid some obstacles in front. The side is the blind spot of the ultrasonic module.**



If the experiment is not very good, you can modify the program according to the actual situation.