

uart flush input 中的 rx_buffered_len error

问题描述:

- We're based of 4.4.0 https://github.com/espressif/esp-idf/commit/8153bfe4125e6a608abccf1561fd
- We've applied a fix on uart related to the proper restore of `RX interrupts after a flush` (http
- >> 2. how to reproduce the issue? Can it be reproduced with a simple demo code? If so, it would be
- we're evaluating how often the issue happens on the product with the final software.
- we re evaluating now often the issue happens on the product with the final software.
- What we noticed is that if you add more code before the execution enters into the critical region
- -- We suspect concurrency between the uart rx interrupt handler and the task we call flush_input f
- >> 1. 您正在使用的 IDF 的详细版本, IDF commit 将有所帮助。
- 我们基于 4.4.0 https://github.com/espressif/esp-idf/commit/8153bfe4125e6a608abccf1561fd10285016
- 我们已经在 uart 上应用了一个与刷新后正确恢复 "RX 中断 "有关的修复程序 (https://github.com/espressif/e
- >> 2. 如何重现该问题?能否用简单的演示代码重现该问题?如果可以,最好能提供一个。
- 我们正在评估该问题在最终软件产品上的发生频率。
- 我们注意到,如果在执行进入临界区域(下图第 1386 行)之前添加更多代码,问题发生的频率会更高。
- -- 我们怀疑 uart rx 中断处理程序与我们调用 flush_input 的任务之间存在并发性。在我们的案例中,uart 在 cpu

```
1378
               data = (uint8_t*) xRingbufferReceive(p_uart->rx_ring_buf, &size, (portTickType) 0);
1379
                if(data == NULL) {
1380
1381
1382
                   //do anything here to delay the flush execution a little more eg nop() ?
1383
1384
1385
                    bool error = false;
1386
                    UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));
                    if( p_uart_obj[uart_num]->rx_buffered_len != 0 ) {
1388
                        p_uart_obj[uart_num]->rx_buffered_len = 0;
1389
                        error = true;
1390
                    //We also need to clear the `rx_buffer_full_flg` here.
                    p_uart_obj[uart_num]->rx_buffer_full_flg = false;
1393
                    UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
1394
1395
                    if (error) {
1396
                       ESP_LOGE(UART_TAG, "rx_buffered_len error");
1397
1398
1399
1400
                    break;
```

测试过程

测试分支:

```
→ esp-idf git:(v4.4) X gcor 8153bfe
```

分支改动内容:

```
esp_err_t uart_flush_input(uart_port_t uart_num)
   xSemaphoreTake(p_uart->rx_mux, (portTickType)portMAX_DELAY);
   uart_disable_intr_mask_and_return_prev(uart_num, UART_INTR_RXFIFO_FULL | UART_INTR_RXFIFO_TOUT, &prev_mask);
   UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
       if (p_uart->rx_head_ptr) {
           vRingbufferReturnItem(p_uart->rx_ring_buf, p_uart->rx_head_ptr);
            UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));
            p_uart_obj[uart_num]->rx_buffered_len -= p_uart->rx_cur_remain;
            uart_pattern_queue_update(uart_num, p_uart->rx_cur_remain);
            UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
           p_uart->rx_ptr = NULL;
            p_uart->rx_cur_remain = 0;
            p_uart->rx_head_ptr = NULL;
       data = (uint8_t*) xRingbufferReceive(p_uart->rx_ring_buf, &size, (portTickType) 0);
            if( p_uart_obj[uart_num]->rx_buffered_len != 0 ) {
                error = true;
           //We also need to clear the `rx_buffer_full_flg` here.
p_uart_obj[uart_num]->rx_buffer_full_flg = false;
            UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
               // this must be called outside the critical section
ESP_LOGE(UART_TAG, "rx_buffered_len error:%d,remain:%d",p_uart_obj[uart_num]->rx_buffered_len,p_uart->rx_cur_remain);
       UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));
```

测试代码:

```
#include <stdio.h>
#include "freertos/FreeRTOS.h"
#include "freertos/task.h"
#include "driver/uart.h"
#include "driver/gpio.h"
#define BUF SIZE (1024)
static void uart_init_task(void *arg)
    /* Configure parameters of an UART driver,
    * communication pins and install the driver */
    uart_config_t uart_config = {
        .baud_rate = 115200,
        .data_bits = UART_DATA_8_BITS,
        .parity = UART_PARITY_DISABLE,
        .stop_bits = UART_STOP_BITS_1,
        .flow_ctrl = UART_HW_FLOWCTRL_DISABLE,
        .source_clk = UART_SCLK_APB,
    };
    int intr_alloc_flags = 0;
#if CONFIG_UART_ISR_IN_IRAM
    intr_alloc_flags = ESP_INTR_FLAG_IRAM;
#endif
    ESP_ERROR_CHECK(uart_driver_install(UART_NUM_1, BUF_SIZE * 2, 0, 0, NULL, intr_alloc_flags));
    ESP_ERROR_CHECK(uart_param_config(UART_NUM_1, &uart_config));
    ESP_ERROR_CHECK(uart_set_pin(UART_NUM_1, GPIO_NUM_4, GPIO_NUM_5, -1, -1));
    while (1)
    {
        vTaskDelay(10 / portTICK_PERIOD_MS);
    }
}
static void uart_read_task(void *arg)
{
    uint8_t *data = (uint8_t *)malloc(BUF_SIZE);
```

```
while (1)
{
    // Read data from the UART
    uart_flush_input(UART_NUM_1);

    int len = uart_read_bytes(UART_NUM_1, data, BUF_SIZE, 10 / portTICK_PERIOD_MS);


    // Write data back to the UART
    uart_write_bytes(UART_NUM_1, (const char *)data, len);
}

void app_main(void)
{
    xTaskCreatePinnedToCore(uart_init_task, "uart_init_task", 5 * 1024, NULL, 4, NULL, 0);
    xTaskCreatePinnedToCore(uart_read_task, "uart_read_task", 5 * 1024, NULL, 5, NULL, 1);
}
```

1.分配在不同的核上,中断不放在IRAM上:


有效复现问题, 关rx中断已加锁, flush中加空延时

```
w (250) spi_flash: Detected size(16384k) larger than the size in the binary image header(2048k). Using the size in the binary image header. I (263) sleep: Configure to isolate all GPIO pins in sleep state
I (270) sleep: Enable automatic switching of GPIO sleep configuration
I (277) cpu_start: Starting scheduler on PRO CPU.
I (0) cpu_start: Starting scheduler on APP CPU.
E (35110) uart: rx_buffered_len error:68,remain:0
```



2.分配在不同核上,中断放在IRAM上:

有效复现问题, 关rx中断已加锁, flush中加空延时



3.分配在同一个核上,中断放在IRAM上:

关rx中断已加锁, flush中加空延时:

未复现问题

4.分配在同一个核上,中断未放在IRAM上:

关rx中断已加锁, flush中加空延时:

未复现问题

问题分析

核0初始化 UART

uart_driver_install 在核0上初始化,其中 uart_isr_register 注册中断:

```
r = uart_isr_register(uart_num, uart_rx_intr_handler_default, p_uart_obj[uart_num], intr_alloc
```

其中 uart_rx_intr_handler_default 中断函数存在更新rx_buffered_len的操作:

```
p_uart->rx_buffered_len += p_uart->rx_stash_len;
```

如下为 uart_isr_register 函数说明:

从函数申明中可以看到,UART ISR 处理程序将连接到与此函数运行在同一 CPU 内核上。所以,此时的RX接收中断函数运行在核0。

进一步分析 uart_isr_register,中断由 esp_intr_alloc 注册:

```
/**
 * @brief Allocate an interrupt with the given parameters.
 * This finds an interrupt that matches the restrictions as given in the flags
 * parameter, maps the given interrupt source to it and hooks up the given
 * interrupt handler (with optional argument) as well. If needed, it can return
 * a handle for the interrupt as well.
 * The interrupt will always be allocated on the core that runs this function.
 * If ESP INTR_FLAG_IRAM flag is used, and handler address is not in IRAM or
 * RTC_FAST_MEM, then ESP_ERR_INVALID_ARG is returned.
 * @param source The interrupt source. One of the ETS_*_INTR_SOURCE interrupt mux
                 sources, as defined in soc/soc.h, or one of the internal
                 ETS_INTERNAL_*_INTR_SOURCE sources as defined in this header.
  @param flags An ORred mask of the ESP INTR FLAG * defines. These restrict the
                 choice of interrupts that this routine can choose from. If this value
                 is 0, it will default to allocating a non-shared interrupt of level
                 1, 2 or 3. If this is ESP_INTR_FLAG_SHARED, it will allocate a shared
                 interrupt of level 1. Setting ESP_INTR_FLAG_INTRDISABLED will return
                 from this function with the interrupt disabled.
 * @param handler The interrupt handler. Must be NULL when an interrupt of level >3
                is requested, because these types of interrupts aren't C-callable.
                Optional argument for passed to the interrupt handler
 * @param arg
 * @param ret_handle Pointer to an intr_handle_t to store a handle that can later be
                 used to request details or free the interrupt. Can be NULL if no handle
                 is required.
 * @return ESP ERR INVALID ARG if the combination of arguments is invalid.
           ESP_ERR_NOT_FOUND No free interrupt found with the specified flags
           ESP OK otherwise
esp_err_t esp_intr_alloc(int source, int flags, intr_handler_t handler, void *arg, intr_handle_t *
```

The interrupt will always be allocated on the core that runs this function(中断总是分配给运行此函数的内核)。指明了rx的中断函数被注册到核0上。

核1运行flush_input

在核1上的 uart_flush_input 中存在关闭rx接收中断的操作:

```
uart_disable_intr_mask_and_return_prev(uart_num, UART_INTR_RXFIFO_FULL | UART_INTR_RXFIFO_TOUT, &p
```

其与 uart disable rx intr 行为保持一致:

```
esp_err_t uart_disable_rx_intr(uart_port_t uart_num)
{
    return uart_disable_intr_mask(uart_num, UART_INTR_RXFIFO_FULL | UART_INTR_RXFIFO_TOUT);
}
```

此时就存在,在核1上操作和0的中断,而 p_uart->rx_buffered_len 的操作处于核0上,导致存在对 p_uart->rx_buffered_len 的影响,进一步触发 rx_buffered_len error 的问题。

解决方案

参考 IDF Release 4.4 及以后版本中 uart_flush_input 的改动,增加在开启与关闭uart rx中断时加锁,并将 uart_driver_install 与 uart_flush_input 放在同一核上。

```
UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));
uart_disable_intr_mask_and_return_prev(uart_num, UART_INTR_RXFIFO_FULL | UART_INTR_RXFIFO_TOUT, &prev_mask);
UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
while (tnue) {
```

```
uart_hal_rxfifo_rst(&(uart_context[uart_num].hal));

UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));

uart_enable_intr_mask(uart_num, prev_mask);

UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
```

```
UART_ENTER_CRITICAL(&(uart_context[uart_num].spinlock));
uart_enable_intr_mask(uart_num, prev_mask);
UART_EXIT_CRITICAL(&(uart_context[uart_num].spinlock));
```

```
xTaskCreatePinnedToCore(uart_init_task, "uart_init_task", 5 * 1024, NULL, 4, NULL, 0);
xTaskCreatePinnedToCore(uart_read_task, "uart_read_task", 5 * 1024, NULL, 5, NULL, 0);
```