## Requirements before you begin with cloud services

HCI

Ann-Marie Grissino December 17, 2019

This PDF was generated from https://docs.netapp.com/us-en/hci/docs/reference\_requirements\_beforeyoubegin.html on April 25, 2020. Always check docs.netapp.com for the latest.



### **Table of Contents**

R	equirements before you begin with cloud services	. 1
	System requirements.	. 1
	Networking requirements	. 1
	System size requirements.	. 2
	NetApp Kubernetes Service requirements.	. 2
	Requirements for Cloud Volumes on NetApp HCI and NetApp Fabric Orchestrator	. 2
	Browser requirements	2

# Requirements before you begin with cloud services

Before you use cloud services on NetApp HCI, you should have completed networking and other requirements.

#### **System requirements**

- A NetApp HCI 1.6 or later system deployed by the NetApp Deployment Engine (NDE)
- Upgraded NetApp HCI management services. See management services information in the NetApp Element User Guide.
- NetApp Hybrid Cloud Control available on the management node of your system
- NetApp HCI management node 2.2 or later (requires updates from the 2.0 version)
- Your version of VMware vCenter supported by the NetApp HCI Deployment Engine
- All nodes must have IP addresses assigned to them by Dynamic DHCP. A DHCP server must be able to run on all NKS networks.
- The "NetApp-HCI-Datastore-02" datastore must exist in vSphere. It is a requirement for enabling NKS. If the datastore does not exist, the cloud services installation will not be successful. Before enabling cloud services, check vSphere to see that the datastore is there. If you are creating the datastore, it must meet the following conditions: 2 TiB in size, formatted as a VMware Virtual Machine File System (VMFS), shared with all compute hosts, and with the default QoS (or higher).
- Ports must be opened in the firewall as specified in NKS information. https://docs.netapp.com/us-en/kubernetes-service/whitelist-ports-and-ip-addresses.html



Running NKS services through a proxy server is not supported.

#### **Networking requirements**

- You must have already configured the required vSphere distributed switches (VDS). VMware standard switches (VSS) are not supported.
- You must have already configured the recommended vSphere distributed switch (VDS) port groups:
  - NetApp HCI VDS 01-HCI\_Internal\_NKS\_Management
  - NetApp HCI VDS 01-HCI\_Internal\_NKS\_Workload
  - NetApp HCI VDS 01-HCI\_Internal\_NKS\_Data
- Using VDS requires a vSphere Enterprise Plus license. You must have this license.

### System size requirements

- 2x4 systems are not supported for production use. However, you can use these for demo work.
- 3x4 systems are the minimum production system size we support.
- 4x4 systems are the recommended minimum size.

#### **NetApp Kubernetes Service requirements**

- A NetApp Kubernetes Service (NKS) account
- A NetApp Kubernetes Service API token, which authorizes the installer to access the NKS organization. You can create this before or during the process of enabling cloud services on NetApp HCI.

## Requirements for Cloud Volumes on NetApp HCI and NetApp Fabric Orchestrator

- An NKS account. NetApp HCI installs the service cluster on NKS, which in turn installs the Kubernetes pods, which is a set of one or more containers used for Cloud Volumes on NetApp HCI.
- All requirements needed for NKS, such as the NKS API token, which authorizes the installer to access the NKS organization.
- · Access to the NKS storage system
- A Cloud Central account

### **Browser requirements**

· Any modern browser

#### Find more information

- NetApp Cloud Central
- NetApp Cloud Documentation
- NetApp HCI Documentation Center

#### **Copyright Information**

Copyright © 2019–2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval systemwithout prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.