SIGNAL	IN/OUT	DIGITAL/ANALOG
TX	IN	DIGITAL
RX	IN	DIGITAL
BUZZER	OUT	DIGITAL
HEATER	OUT	DIGITAL

PIN	NOTE
3 (PD1)	Always LOW, HIGH when activated
2 (PD0)	Always LOW, HIGH when activated
4 (PD2)	Always LOW, HIGH when activated
5 (PD3)	Always LOW, HIGH when activated