

Engineer's Mini-Notes on a

Schematic Symbols, Device Packages, Design and Testing



Forrest M. Mims III

CIRCUIT SYMBOLS



ENGINEER'S MINI-NOTEBOOK SCHEMATIC SYMBOLS, DEVICE PACKAGES, DESIGN AND TESTING

BY

FORREST M. MIMS, III

CONTRIBUTING EDITOR MODERN ELECTRONICS

FIRST EDITION
SECOND PRINTING - 1990

A SILICONCEPTS THE BOOK

COPYRIGHT @ 1988 BY FORREST M. MIMS, III
ALL RIGHTS RESERVED

PRINTED IN THE UNITED STATES OF AMERICA


THIS BOOK INCLUDES STANDARD APPLICATION CIRCUITS AND CIRCUITS DESIGNED BY THE AUTHOR. EACH CIRCUIT WAS ASSEMBLED AND TESTED BY THE AUTHOR AS THE BOOK WAS DEVELOPED. AFTER THE BOOK WAS COMPLETED, THE AUTHOR REASSEMBLED EACH CIRCUIT TO CHECK FOR ERRORS. WHILE REASONABLE CARE WAS EXERCISED IN THE PREPARATION OF THIS BOOK, VARIATIONS IN COMPONENT TOLERANCES AND CONSTRUCTION METHODS MAY CAUSE THE RESULTS YOU OBTAIN TO DIFFER FROM THOSE GIVEN HERE. THEREFORE THE AUTHOR AND RADIO SHACK ASSUME NO RESPONSIBILITY FOR THE SUITABILITY OF THIS BOOK'S CONTENTS FOR ANY APPLICATION. SINCE WE HAVE NO CONTROL OVER THE USE TO WHICH THE INFORMATION IN THIS BOOK IS PUT, WE ASSUME NO LIABILITY FOR ANY DAMAGES RESULTING FROM ITS USE. OF COURSE IT IS YOUR RESPONSIBILITY TO DETERMINE IF COMMERCIAL USE, SALE OR MANUFACTURE OF ANY DEVICE THAT INCORPORATES INFOR-MATION IN THIS BOOK INFRINGES ANY PATENTS, COPYRIGHTS OR OTHER RIGHTS.

DUE TO THE MANY INQUIRIES RECEIVED BY RADIO SHACK AND THE AUTHOR, IT IS NOT POSSIBLE TO PROVIDE PERSONAL RESPONSES TO REQUESTS FOR ADDITIONAL INFORMATION (CUSTOM CIRCUIT DESIGN, TECHNICAL ADVICE, TROUBLESHOOTING ADVICE, ETC.). IF YOU WISH TO LEARN MORE ABOUT ELECTRONICS, SEE OTHER BOOKS IN THIS SERIES AND RADIO SHACK'S "GETTING STARTED IN ELECTRONICS." ALSO, READ MAGAZINES LIKE MODERN ELECTRONICS. THE AUTHOR WRITES A MONTHLY COLUMN, "ELECTRONICS NOTEBOOK," FOR MODERN ELECTRONICS.

CONTENTS

1. SCHEMATIC SYMBOLS	4
WIRE, GROUND, CHASSIS INDUCTORS, TRANSFORMERS POWER SUPPLIES, FUSES, SHIELDING ELECTRON TUBES	5 6 7 8
MICRO PHONES, SPEAKERS, LAMPS CONNECTORS SWITCHES RELAYS	10-11 12-13
MOTORS, SOLENOIDS, METERS RESISTORS CAPACITORS SEMIC ONDUCTORS	15 16 17 18-21
2. DEVICE PACKAGES RESISTORS, CAPACITORS DIODES TRANSISTORS INTEGRATED CIRCUITS	22 23 24 25
BATTERIES LAMPS	26-27 28-30
3. COMPONENT HANDLING ELECTROSTATIC DISCHARGE	31 32-34
H. COMPONENT TESTING	35
5. CIRCUIT DESIGN TIPS	36
6. CIRCUIT LAYOUT TIPS	37
7. HEATSINKING	38-39
8 SOLDERING	40-43
9. TROUBLESHOOTING	44-47
LO SAFETY PRECAUTIONS	48

1 SCHEMATIC SYMBOLS ANTENNAS EXTERNAL DIPOLE FOLDED DIPOLE UHF LOOP LIHE BOWTIE TELESCOPIC FERRITE CORE LOOP ROTATABLE LOOP MICROWAVE HORN EARTH STATION





INDUCTORS VARIABLE CORE AIR CORE POWDERED IRON CORE IRON CORE TRANSFORMERS AIR CORE IRON CORE VARIABLE CORE AUTO TYPICAL INPUT TYPICAL OUTPUT 11 TRANSFORMER (TAPPED) YPICAL POWER AC LOW VOLTAGE OUT AC VOLTAGE VOLTAGE

OUT

IN

POWER SUPPLIES SINGLE CELL MULTIPLE CELL BATTERY AC CURRENT SOURCES SOLAR CELLS FUSES SHIELDING NOTE: DASHED LINE(S) ALSO USED TO INDICATE MECHANICAL CONNECTION. SHIEL DED ENCLOSURE






PIEZOELECTRIC DEVICES

FREQUENCY PHONO CARTRIDGES BUZZER
CONTROL MONO STEREO


CONNECTORS

TERMINAL TEST POINT TP1 ENGAGED FEMALE MALE PHONO/COAXIAL PLUG PHONO/COAXIAL JACK 2-CONDUCTOR PLUG 3-CONDUCTOR PLUG 2-CONDUCTOR JACKS 3-CONDUCTOR JACKS SPST





SWITCHES SINGLE POLE SINGLE THROW (SPST) SINGLE POLE DOUBLE THROW (SPDT) DOUBLE POLE SINGLE THROW (DPST) USE DASHED LINE TO CONNECT TWO HALVES OF SWITCH SEPARATED IN A CIRCUIT DIAGRAM. DOUBLE POLE DOUBLE THROW (DPDT) MULTIPLE CONTACT ROTARY


NORMALLY OPEN SPST PUSHBUTTON	
NORMALLY CLOSED SPST PUSHBUTTON	\$
TVIV	
NORMALLY OPEN/CLOSED SPDT PUSHBUTTON	Topological Co.
+ 0 1 0 - 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Service of the servic
NORMALLY OPEN DPST PUSHBUTTON	:
MANUAL CIRCUIT BREAKER	
AUTOMATIC CIRCUIT BREAKER	
RESET	
TELEGRAPH KEY REED SWITCH	
T E	
MAGNET	




MOTORS












3-LAYER SWITCHES (DIACS)




H-LAYER SWITCHES




TRANSISTORS












DIGITAL CIRCUITS LOGIC GATES AND OR DUAN NOR INVERTERS EXCLUSIVE NOR EXCLUSIVE OR 3-STATE BUFFERS SCHMITT TRIGGERS C = CONTROL FLIP-FLOPS JK SR I Q. ø ō ۵ COMPUTER FLOWCHART SYMBOLS DECISION OPERATION FLOW BEGIN/IN BEGIN


2 DEVICE PACKAGES











CAPACITORS


































LAMPS






















MIDGET

FLANGE










T-1-3/4



BI-PIN




WIRE






NE-2 WIRE

NE-2 WIRE + RESISTOR





3. COMPONENT HANDLING

1 STORE COMPONENTS AT ROOM TEMPERATURE IN A DRY, DUST-FREE PLACE, PREFERABLY IN THE ORIGINAL PACKAGE.

2. A VOID DROPPING COMPONENTS. A FALL TO THE FLOOR SUBJECTS EVEN THE SMALLEST DEVICE TO MANY TIMES THE FORCE OF GRAVITY. A DROPPED DEVICE MAY APPEAR UNDAMAGED, BUT THE FORCE OF IMPACT

MAY SEPARATE INTERNAL CONNECTIONS AND FORM TIMY MICROCRACKS IN THE FUNCTIONAL PART OF THE DEVICE OR ITS PROTECTIVE COVERING OR COATING.

CRACKS IN THE FUNCTIONAL PART OF THE DEVICE
MAY RENDER IT USELESS, ALTER ITS SPECIFICATIONS
OR DEGRADE ITS PERFORMANCE. CRACKS IN THE
COATING WEAKEN THE DEVICE AND PERMIT THE
ENTRY OF MOISTURE.

3. A VOID OVERHEATING COMPONENTS WHEN SOLDERING

DR DESOLDERING. PROTECT
HEAT SENSITIVE COMPONENTS
WITH A SOLDERING HEAT SINK
DR PLIERS. COOL THESE

COMPONENTS BY BLOWING ON THEM, BUT NOT THE


CONNECTION, AFTER SOLDERING.

4. TO BEND A COMPONENT LEAD, GRASP THE LEAD WITH LONG NOSE PLIERS NEAR THE DEVICE AND

THEN BEND THE LEAD WITH A FINGER. THE RADIUS OF THE BEND SHOULD EXCEED THE

DIAMETER OF THE LEAD.
BENDING LEADS WITHOUT

PLIERS MAY FORM CRACKS
BETWEEN LEAD AND DEVICE.



ELECTROSTATIC DISCHARGE

IT IS WELL KNOWN THAT MOS (METAL - OXIDE SEMICONDUCTOR) COMPONENTS CAN BE DAMAGED
BY ELECTROSTATIC DISCHARGE (ESD). WHAT
IS LESS WELL KNOWN IS THAT MANY OTHER
COMPONENTS CAN ALSO BE DAMAGED BY ESD.
COMPONENTS SUSCEPTABLE TO DAMAGE FROM
ESD ARE SOMETIMES MARKED WITH A WARNING



MPORTANT TO KNOW WHICH KINDS OF COMPO-NENTS ARE SUSCEPTABLE TO POSSIBLE DAMAGE FROM ESD.

ESD DAMAGE THRESHOLD OF CERTAIN COMPONENTS:

EXTREMELY VUL NERABLE	MODERATELY VULNERABLE	SOMEWHAT VULNER ABLE
(1 T-0 1,000 V)	(1,000 TO 5,000V)	(5,000 TO 1 5,000 V)
MOS TRANSISTORS	CMOS ICS	TTL ICS
MOS ICS	LS TTL ICS	SMALL SIGNAL
WAVE TRANSISTORS	SCHOTTKY TTL ICS	DIDDES AND
TUNC TION FETS	SCHOTTKY DIODES	TRANSISTORS
LASE & DIODES	LINEAR ICS	PIEZOELECTRIC
METAL FILM RESISTORS		CRYSTALS

THIS IS ONLY A PARTIAL LISTING. WHEN DOUBT EXISTS, TREAT SUSPECT DEVICES AS ESD SENSITIVE.

LABEL

TYPICAL ESD VOLTAGE GENERATED BY VARIOUS MATERIALS (75° F., 60% RELATIVE HUMIDITY):

MATERIAL	ACTION	VOLTAGE
RUBBER COMB	STROKE DRY HAIR	-2,500
DESK CHAIR	ROLL ACROSS PLASTIC	-2,000
POLY ETHYLENE BAG	CRUMPLE IN HAND	- 300
TO-92 TRANSISTORS IN POLY BAG	SHAKE BAG SEVERAL TIMES	- 200
PENCIL ERASER	RUB ACROSS CIRCUIT	+ 100
PLASTIC PARTS BOX	RUB WITH 100% COTTON FABRIC	+ 100
CLEAN PLASTIC TAPE (2" WIDE)	RAPIDLY UNROLL SEVERAL INCHES	+ 500
ADULT MALE (RUBBER SOLE SHOES)	WALK ACROSS CARPET	1,000

THESE MEASUREMENTS MADE WITH COMMERCIAL STATIC METER. ESD VOLTAGE IS FROM 10 TO SO TIMES HIGHER WHEN RELATIVE HUMIDITY IS 10 TO 20%.

TYPICAL ESD DAMAGE TO GATE OF MOS FET :

		JO WATE	OF MOS F	ET:
GATE .		444/	, , , , ,	// 1
REGION	40	(4)	CRATER	// 1
REG ION			FRAGMEN OF MOLTE	TS/MICRO-
BORDER			METAL	
				Z2

ESD HANDLING PRECAUTIONS

OBSERVE THE FOLLOWING PRECAUTIONS WHEN HANDLENG COMPONENTS SUSCEPTABLE TO DAMAGE FROM ESD:

- 1. STORE COMPONENTS IN ORIGINAL PACKAGES, ELECTRICALLY CONDUCTIVE CONTAINERS OR CONDUCTIVE PLASTIC FOAM.
- 2. DO NOT TOUCH LEADS OR PINS.
- 3. DISCHARGE THE STATIC CHARGE ON YOUR BODY, BEFORE TOUCHING COMPONENTS, BY TOUCHING A GROUNDED METAL SURFACE (CABINET, APPLIANCE, ETC.).
- 4. PLACE COMPONENTS ON AN ALUMINUM FOIL SHEET OR TRAY OR ON CONDUCTIVE FOAM AFTER REMOVING THEM FROM THEIR CONTAINERS PRIOR TO INSTALLING THEM.
- 5. DO NOT SLIDE COMPONENTS ACROSS A WORK BENCH OR OTHER SURFACE.
- 6. KEEP STATIC-GENERATING MATERIALS (C.G. PLASTIC, CELLOPHANE, CANDY WRAPPERS, PAPER, CARDBOARD, ETC.) AWAY FROM WORK AREA.
- 7. NEVER ALLOW CLOTHING TO MAKE CONTACT
- 8. NEVER INSTALL ESD-SENSITIVE COMPONENTS IN A CIRCUIT WHEN POWER IS APPLIED, AND NEVER REMOVE COMPONENTS FROM A CIRCUIT WHEN POWER IS APPLIED.
- Q. WHEN POSSIBLE, USE A BATTERY-POWERED IRON TO MAKE SOLDER CONNECTIONS TO ESD-SENSITIVE COMPONENTS. AN AC-POWERED IRON. MAY BE USED IF THE TIP DOES NOT CARRY STRAY VOLTAGE.

COMPONENT TESTING ALTHOUGH COMPONENTS CONNECTED IN A CIRCUIT CAN BE TESTED, BETTER RESULTS ARE OBTAINED BY TESTING COMPONENTS NOT INSTALLED IN A CIRCUIT. SUGGESTED METHODS INCLUDE: RESISTORS - MEASURE RESISTANCE WITH A MULT IMETER. CAPACITORS - DISCHARGE CAPACITOR BY SHORTING LEADS. THEN CONNECT AN ANALOG MULTIMETER SET TO HIGHEST RESISTANCE RANGE ACROSS CAPACITOR. (BE SURE TO OBSERVE POLARITY OF ELECTROLYTIC CAPACITORS.) METER NEEDLE SHOULD MOVE TO RIGHT AND THEN FALL BACK TO INITIAL POINT NEEDLE WILL MOVE MORE WITH LARGE VALUE CAPACITORS. IT MAY NOT MOVE WHEN VALUE IS BELOW 0.01 MF. IF NEEDLE REMAINS AT OR NEAR RIGHT SIDE OF METER, THE CAPACITOR IS SHORTED. IF NEEDLE FAILS TO MOVE, VALUE OF CAPACITOR IS BELOW D. DI JAF OR CAPACITOR IS OPEN. DIODES - USE A MULTIMETER. RESISTANCE SHOULD BE LOW IN FORWARD DIRECTION AND HIGH IN REVERSE DIRECTION. LOW RESISTANCE HIGH RESISTANCE TRANSISTORS THIS GIRCUIT 4701 PROVIDES A LED "GO/NO-GO TEST FOR SWITC HING TRANSISTORS. RESPECTIVE INSERT LED GLOWS IF TRANSISTOR TRANSI STOR PNPO HERE IS GOOD. ₹ 🗧

5. CIRCUIT DESIGN TIPS


- 1. USE EXISTING CIRCUITS AS BUILDING BLOCKS.
 TO FORM ENTIRELY NEW CIRCUITS.
- 2. ALWAYS REVIEW THE MANUFACTURER'S SPECIFICATIONS FOR ACTIVE DEVICES (TRANSISTORS,
 INTEGRATED CIRCUITS, ETC.) BEFORE USING THEM
 IN A CIRCUIT. PAY PARTICULAR ATTENTION TO
 OPERATING VOLTAGES, INPUT AND OUTPUT REQUIREMENTS AND POTENTIAL PROBLEMS (SUCH AS
 OSCILL ATION, NOISE, LATCHUP, ETC.).
- 3. BYPASS CAPACITORS, WHILE NOT ALWAYS REQUIRED, CAN PREVENT NOISE AND OSCILLATION IN ANALOG CIRCUITS AND FALSE TRIGGERING AND MEMORY LOSS IN DIGITAL CIRCUITS. IN ANALOG CIRCUITS PLACE A 0.1 MF AND 1.0 MF CAPACITOR ACROSS BATTERY LEADS WHERE THEY ENTER THE CIRCUIT BOARD. USE 0.1 MF CAPACITORS FROM POWER SUPPLY PINS OF OPERATIONAL AMPLIFIERS TO GROUND. IN DIGITAL CIRCUITS PLACE A 0.1 MF CAPACITOR ACROSS THE POWER SUPPLY PINS OF EACH CHIP.
- 4. COMPONENT SUBSTITUTION IS GENERALLY.
 OKAY. HERE ARE SOME GENERAL GUIDELINES:
- Q. RESISTORS-USE NEXT CLOSEST VALUE. USE EQUAL OR HIGHER POWER RATING. CIRCUIT PERFORMANCE MAY BE ALTERED. FOR EXAMPLE, A SMALLER THAN SPECIFIED RESISTOR IN SERIES WITH AN LED WILL INCREASE CURRENT THROUGH THE LED.
- b. CAPACITORS USE NEXT CLOSEST VALUE. USE EQUAL OR HIGHER VOLTAGE RATING. CIRCUIT PERFORMANCE MAY BE ALTERED. FOR EXAMPLE, USING A SMALLER THAN SPECIFIED CAPACITOR IN A TIMER CIRCUIT WILL REDUCE THE TIMING CYCLE.
- C. BIPOLAR TRANSISTORS SUBSTITUTE WITHIN SAME FAMILY. OBSERVE POLARITY AND POWER.


6. CIRCUIT LAYOUT TIPS

- 1. CONNECTIONS BETWEEN COMPONENTS SHOULD BE AS SHORT AS POSSIBLE IN HIGH-SPEED DIGITAL CIRCUITS AND HIGH-FREQUENCY ANALOG CIRCUITS.
- 2. THE INPUT AND DUTPUT SECTIONS OF HIGH-GAIN AMPLIFIERS SHOULD BE PHYSICALLY ISOLATED FROM ONE ANOTHER. OTHERWISE INDUCTANCE BETWEEN THE INPUT AND OUTPUT WIRING MAY CAUSE A PORTION OF THE DUTPUT SIGNAL TO BE FED BACK TO THE INPUT. THE RESULT WILL BE SEVERE OSCILLATION.
- 3. POWER TRANSISTORS, ICS AND SOME OTHER COMPONENTS THAT BECOME WARM DURING OPERATION OFTEN PERFORM BETTER WITH A HEAT SINK. THERE FORE, LEAVE SPACE AROUND SUCH COMPONENTS FOR A HEAT SINK. AVOID PLACING HEAT SENSITIVE COMPONENTS NEAR COMPONENTS THAT MAY BECOME HOT.
- 4. USE INSULATED WIRE FOR INTERCONNECTIONS.
 INSULATE EXPOSED COMPONENT LEADS MOUNTED
 CLOSE TO OTHER EXPOSED LEADS OR HARDWARE.
 - 5. ALL LEADS THAT CARRY HOUSEHOLD LINE CURRENT MUST BE INSULATED.
 - 6. CIRCUITS IN WHICH A CURRENT FLOW IS SUDDENLY SWITCHED OFF OR ON MAY EMIT RADIO FREQUENCY RADIATION THAT CAN CAUSE SIGNIFICANT INTERFERENCE IN NEARBY RADIOS AND TELEVISIONS. RADIO FREQUENCY EMISSION CAN BE REDUCED BY ENCLOSING THE ENTIRE CIRCUIT IN A GROUNDED METAL ENCLOSURE. EXTERNAL CONNECTIONS TO OR FROM THE ENCLOSURE SHOULD BE MADE WITH SHIELDED CABLES.
 - 7. USE STRANDED WIRE FOR ALL CONNECTIONS THAT ARE NOT FIXED IN POSITION (BATTERY CLIP LEADS, ETC.). USE SOLID WIRE FOR FIXED CONNECTIONS.

7. HEATSINKING

HEAT IS PRODUCED WHEN AN ELECTRICAL CURRENT FLOWS THROUGH A COMPONENT OR A CONDUCTOR. MOST COMPONENTS ARE SPECIFIED FOR OPERATION WITHIN A GIVEN TEMPERATURE RANGE. A HEATSINK WILL HELP REMOVE EXCESS HEAT FROM A COMPONENT. THERE ARE THREE PRIMARY MEANS BY WHICH HEAT LEAVES A COMPONENT:





RADIATION

HEAT IS CONDUCTED HEAT IS INTO SURROUNDING

HEAT SPACE AS INTO

IS RADIATED

CONDUCTED AIR AND WAFTED AWAY THROUGH ELECTROMAGNETIC AWAY. DEVICE LEADS. RADIATION.

HEATSINKS ARE METAL STRUCTURES THAT IMPROVE THE EFFICIENCY WITH WHICH HEAT A COMPONENT. THE THERMAL CONDUC-TIVITY OF VARIOUS MATERIALS IS COMPARED BELOW:

CONDUCTIVITY (RELATIVE TO SILVER) MATERIAL 5.4 DIA MOND (II)

1.4 WATER ALUMINUM IS THE 1.0 SILVER MOST COMMON HEAT 93 CO PPER 74 SINK MATERIAL. GOLD


NOTE THAT COPPER 56 ALDMINUM IS NEARLY AS GOOD .21 NICKEL

AS SILVER. IRON 16 TIN .0014

MIKA 000085 AIR

A HEATSINK WILL PERMIT A DEVICE SUCH AS A POWER SEMICONDUCTOR TO DISSIPATE AS MUCH AS TEN TIMES OR MORE HEAT THAN OTHERWISE. A HEATSINK WILL ALSO INCREASE A DEVICE'S RELIABILITY AND LIFETIME.

THE INTERFACE BETWEEN A HEATSINK AND A COMPONENT IS NOT PERFECTLY FLAT. THEREFORE A THERMALLY CONDUCTIVE PAD OR FILM OF SILICONE GREASE MUST BE PLACED BETWEEN THE HEATSINK AND THE DEVICE:



8. SOLDERING

FOLLOW THESE STEPS TO PRODUCE SUCCESSFUL SOLDER CONNECTIONS:

- 1. ELECTRONIC COMPONENTS AND CIRCUIT
 BOARDS CAN BE DAMAGED BY EXCESSIVE HEAT.
 THEREFORE, WHEN SOLDERING COMPONENTS
 TO A BOARD, ALWAYS USE A LOW-WATTAGE
 SOLDERING IRON (15 TO 40 WATTS). BE SURE
 TO TIN THE TIP ACCORDING TO THE INSTRUCTIONS
 SUPPLIED WITH THE IRON.
- 2. ALWAYS USE SMALL DIAMETER ROSIN CORE SOLDER WHEN SOLDERING ELECTRONIC PARTS. NEVER USE ACID CORE SOLDER. IT WILL CORRODE SOLDERED LEADS.
- 3. ALWAYS PREPARE THE SURFACES TO BE
 SOLDE RED. SOLDER WILL NOT ADHERE TO PAINT,
 OIL, WAX, GREASE OR MELTED INSULATION.
 REMOVE THESE MATERIALS WITH A SOLVENT,
 STEEL WOOL OR FINE SANDPAPER. ALWAYS
 BUFF THE COPPER FOIL OF A CIRCUIT BOARD
 WITH STEEL WOOL. BE SURE THERE IS A GOOD
 CONNECTION BETWEEN SURFACES BEING SOLDERED.
 - 4. TO SOLDER, HEAT THE CONNECTION FIRST,
 NOT THE SOLDER. AFTER A SECOND OR TWO
 TOUCH THE END OF A LENGTH OF SOLDER TO
 THE CONNECTION.
 - 5. LEAVE THE HOT TIP OF THE IRON IN PLACE UNTIL MOLTEN SOLDER FLOWS THROUGH AND AROUND THE CONNECTION. THEN REMOVE THE IRON. IMPORTANT: DO NOT APPLY TOO MUCH SOLDER OR ALLOW THE CONNECTION TO MOVE BEFORE IT COOLS.
 - 6. KEEP THE TIP OF THE IRON CLEAN AND SHINY. WIPE AWAY EXCESS SOLDER AND DEBRIS WITH A PAMP SPONGE OR CLOTH.

DESOLDERING

A COMPONENT CAN BE REMOVED FROM A BOARD
BY HEATING ITS CONNECTIONS WITH A HOT
SOLDERING IRON UNTIL THE SOLDER MELTS
AND THEN PULLING ON THE LEADS UNTIL THE
COMPONENT IS FREE. UNLESS SPECIALIZED
DE SOLDERING TIPS ARE USED, THIS METHOD
IS SUITABLE ONLY FOR INDIVIDUAL WIRES OR
COMPONENTS WITH TWO LEADS. TO REMOVE
COMPONENTS WITH MULTIPLE LEADS OR PINS,
A DESOLDERING IRON OR TOOL SHOULD BE
USED. FOLLOW THESE STEPS:

1 HEAT THE CONNECTION UNTIL THE SOLDER

2. DESOLDERING IRON - SQUEEZE BULB BEFORE HEATING CONNECTION; RELEASE BULB WHEN SOLDER MELTS.

DESOLDERING TOOL - SQUEEZE BULB OR

ACTUATE PLUNGER. WHEN SOLDER MELTS,
TOUCH TIP OF TOOL TO SOLDER AND RELEASE
BULB OR PLUNGER. REPEAT IF NECESSARY.
DESOLDERING BRAID PLACE BRAID OVER SOLDER


DESOLDERING BRAID PLACE BRAID OVER SOLDER CONNECTION. PRESS BRAID AGAINST CONNECTION WITH TIP OF IRON UNTIL SOLDER MELTS AND FLOWS INTO BRAID.

3. REPAIR BROKEN AND SEPARATED FOIL PATTERN. SPLICE'S CAN BE MADE BY SOLDERING SHORT LENGTHS OF WIRE ACROSS BREAKS.

SOLDERING PRECAUTIONS

- 1. A HOT SOLDERING IRON CAN CAUSE A FIRE OR BURN A FINGER. UNPLUG AN UNUSED SOLDERING IRON!
- 2. AVOID BREATHING SMOKE AND VAPOR FROM HOT SOLDER. SOLDER IN A WELL-VENTILATED AREA.
- 3. SUPERVISE CHILDREN WHO USE SOLDERING IRONS.

HOW TO SOLDER



CLIP SOLDERED CONNECTION EXCESS LEAD*

ALLOW THE JUNCTION TO COOL BEFORE MOVING THE BOARD EYES

DON'T

BREATHEL

SOLDER TO MELT

FLOW OVER ..

REMOVE THE IRON

SOLDER AND

JUNCTION.

AND

AND

AND

THROUGH

42

HOW TO DESOLDER

RON TIP DESOLDERING IRON

DESOLDERING

TOOL

RON

TIP

1. HEAT THE JUNCTION
TO BE DESOLDERED
WITH A HEATED
SOLDERING IRON
UNTIL THE SOLDER
MELTS OR

2. .. HEAT THE
JUNCTION WITH A
HEATED DESOLDERING
IRON UNTIL THE
SOLDER MELTS.

3. SQUEEZE THE BULB
OF A DESOLDERING
TOOL (OR IRON),
PLACE TIP OF TOOL
(OR IRON) AS CLOSE
AS POSSIBLE TO
SOLDER AND RELEASE
BULB. SOLDER WILL
BE SLURPED UP INTO
TOOL. COMPONENT
LEAD CAN NOW BE
REMOVED. NOTE

THAT LEAD CAN BE REMOVED BY PULLING ON IT WHEN SOLDER

4. CLEAN TERMINAL.

IS MOLTEN.

5. REPAIR BROKEN FOIL PATTERN WITH WIRE BRIDGE. SOLDER IN PLACE.

9. TROUBLESHOOTING

TROUBLESHOOTING IS THE PROCESS OF IDENTIFYING THE PROBLEM THAT CAUSES A CIRCUIT TO
MALFUNCTION. WITH THE EXCEPTION OF MINOR
PROBLEMS, TROUBLESHOOTING SOPHISTICATED
SYSTEMS LIKE COMPUTERS AND VCRS IS BEST
LEFT TO QUALIFIED TECHNICIANS. THE PROCEDURES LISTED BELOW CAN BE USED TO TROUBLESHOOT DO-IT-YOURSELF PROJECTS:

- 1. BE SURE YOU FULLY UNDERSTAND THE FUNC-TION OF THE CIRCUIT AS DESCRIBED IN THE IN-STRUCTIONS FOR ITS CONSTRUCTION.
- 2. IF THE CIRCUIT DOES NOT FUNCTION, BE SURE IT IS RECEIVING POWER. ARE THE BATTERIES FRESH AND INSTALLED CORRECTLY?

 ARE THE BATTERY HOLDER'S TERMINALS CLEAN?

 HAS A BATTERY CLIP LEAD BECOME BROKEN


 INSIDE ITS INSULATING TACKET? IS THE POWER

 CORD INSERTED IN AN OUTLET? IS A FUSE

 BLOWN? DOES THE CIRCUIT'S POWER REQUIREMENT

 EXCEED THE AVAILABLE POWER?
 - 3. CAREFULLY COMPARE THE CIRCUIT WITH THE SCHEMATIC. HAS EVERY CONNECTION BEEN MADE? ARE ANY CONNECTIONS INCORRECT? ARE ANY SOLDER CONNECTIONS DEFECTIVE?
 - 4. ARE POLARITY-SENSITIVE COMPONENTS LIKE ELECTROLYTIC CAPACITORS, DIODES AND TRANSISTORS INSTALLED CORRECTLY? ARE INTEGRATED CIRCUITS INSTALLED CORRECTLY?
 - 5. ARE UNUSED INPUTS OF DIGITAL LOGIC CHIPS CONNECTED TO GROUND OR ONE SIDE OF THE POWER SUPPLY?
 - 6. FOR BEST RESULTS FOLLOW AN ORGANIZED, LOGICAL APPROACH TO TROUBLESHOOTING. THE TROUBLESHOOTING TREE ON THE FACING PAGE ILLUSTRATES THIS APPROACH.


TROUBLESHOOTING TREE



DIGITAL TROUBLESHOOTING


THESE SIMPLE CIRCUITS PERMIT DIGITAL LOGIC CIRCUITS TO BE TESTED. BOTH CIRCUITS CAN BE ASSEMBLED USING SAME 4049.

BOUNCELESS SWITCH



CONNECT VD AND GROUND TO, RESPECTIVELY, POSITIVE SUPPLY AND GROUND OF THE CIRCUIT BEING TESTED. TOGGLE SI TO PRODUCE CLEAN, NOISE-FREE PULSE.






CONNECT VD AND GROUND TO, RESPECTIVELY,
POSITIVE SUPPLY AND GROUND OF THE CIRCUIT
BEING TESTED. TOUCH INPUT PROBE TO TERMINAL
OF CIRCUIT BEING TESTED. LEDS INDICATE LOGIC
STATUS (L=LOW; H=HIGH). R1- TABLE GIVES VALUES
FOR ~ 5 MA CURRENT. OKAY TO USE 2.2 K FOR ALL
VALUES OF VDD IF LEDS ARE SUPER-BRIGHT UNITS.
46


ANALOG TROUBLE SHOOTING

THESE CIRCUITS CAN BE USED TO TROUBLESHOOT AUDIO AMPLIFIERS AND TO DETERMINE THE CONTINUITY OF MULTI-CONDUCTOR WIRE AND CABLE. (SEE SAFETY PRECAUTIONS ON FOLLOWING PAGE.)

SIGNAL INJECTOR



*NOT TO EXCEED TESTED CIRCUIT'S SUPPLY VOLTAGE.




47

10. SAFETY PRECAUTIONS

ELECTRONIC CIRCUITS POWERED BY HOUSEHOLD LINE CURRENT AND SOME BATTERY-POWERED CIRCUITS CAN CAUSE DANGEROUS ELECTRICAL SHOCKS. AN ELECTRICAL SHOCK CAN CAUSE HEART FAILURE. A SHOCK CAN ALSO CAUSE A VIOLENT MUSCLE REFLEX THAT MAY INJURE AN ARM OR LEG OR EVEN THROW YOU TO THE FLOOR. DBSERVE THESE PRECAUTIONS:

- 1. HOUSEHOLD LINE CURRENT CAN KILL! ONLY EXPERIENCED TECHNICIANS SHOULD WORK ON A LINE-POWERED CIRCUIT WITH THE POWER ON!
 - 2. EXPERIENCED TECHNICIANS NEVER WORK ALONE AND ALWAYS KEEP ONE HAND IN A POCKET TO HELP PREVENT AN ELECTRICAL DISCHARGE PATH THROUGH THEIR BODY.
 - 3. LARGE FILTER AND ENERGY STORAGE CAPA-CITOR'S CAN STORE A DANGEROUS CHARGE FOR SEVERAL DAYS OR MORE! NEVER TOUCH THE TERMINALS OF SUCH CAPACITORS! CAPACITORS CAN BE DISCHARGED BY CAREFULLY TOUCHING THE METAL TIP OF A SCREWDRIVER WITH AN INSULATED HANDLE ACROSS THEIR TERMINALS SEVERAL TIMES.
 - 4. CHILDREN AND THOSE INEXPERIENCED IN WORKING WITH ELECTRONIC CIRCUITS SHOULD NOT ATTEMPT TO SERVICE LINE-POWERED CIRCUITS!
 - 5. NEVER PLAY WITH ELECTRICITY!
 - 6. A FTER SERVICING LINE-POWERED EQUIP-MENT, REPLACE ALL PANELS AND SCREWS BEFORE APPLYING POWER.
 - 7. WEAR RUBBER-SOLED SHOES AND STAND ON A DRY RUBBER MAT OR WOOD SURFACE WHEN WORKING WITH LINE-POWERED CIRCUITS.

RESISTOR COLOR CODE



BLACK × 1 BROWN × 10 RED 2 × 100 ORANGE 3 3 * 1,000 4 YELLOW 4 × 10,000 5 5 × 100,000 GREEN 6 6 × 1,000,000 7 × 10,000,000 BLUE VIOLET 8 × 100,000,000 GRAY 8 WHATE 9

FOURTH BAND INDICATES TOLERANCE (ACCURACY):
GOLD=±5% SILVER=±10% NONE= ±20%

OHM'S LAW: V=IR R=V/I I=V/R P=VI=I2R

ABBREVIATIONS

A = AMPERE R = RESISTANCE F = FARAD V (OR E) = VOLT I = CURRENT W = WATT P = POWER \(\Omega = OHM \)


M (MEG-) = x 1,000,000 K (KILO-) = x 1,000 M (MILLI-) = .001 M (MICRO-) = .000 001 M (NANO-) = .000 000 001

P (PICO-) = .000 000 000 001

Kadio/haek

A Division of Tandy Corporation Fort Worth, TX 76102

PRINTED IN U.S.A.



276-5017