VFAT2 I2C

This module handles I2C transactions with the VFAT2 hybrids.

Addressing

OptoHybrid Wishbone address: 0b 0000 0000 0000 000X XXXX YYYY YYYYY

Y register	Mode	Function
VFAT2 regis	ters	
0 - 151	Read / Write	Access the Y (8 bit address) on VFAT2 X (5 bit chip identifier)

Threshold & Latency Scans

This module performs a threshold/latency scan on a single VFAT2 by varying its threshold/latency from a minimum value min to a maximum value max by steps of step and by counting the number of events where the SBits/strips are fired in a set of N events.

Addressing

OptoHybrid Wishbone address: 0b 0001 0000 0000 000X XXXX 0000 0YYYY

Mode	Function			
Write only	Start a threshold scan on the VFAT2 addressed using the X parameter			
	(ID of the VFAT2 encoded on 5 bits). This will also empty the FIFO			
	holding the data of the previous scan. The written value is ignored.			
Read / write	mode - 2 bits - {0, 1, 2}			
	<pre>0 = threshold scan</pre>			
	1 = threshold scan by channel			
	2 = latency scan			
Read / write	min - 8 bits - [0x0, max[
Read / write	max - 8 bits -]min, 0xFF]			
Read / write	step - 8 bits - [0x0, 0xFF]			
Read / write	N - 24 bits -]0x0, 0xFFFFFF]			
Read / write	channel - 8 bits - [0x0, 0xFF]			
	Only used for a threshold scan by channel			
Read only	FIFO holding the results of the scan. This register will return the data			
	points collected by the scan using the following data format:			
	8 MSBits hold the threshold/latency value of the point			
	24 LSBits hold the number of events that have fired			
	If no data is present, an error is returned.			
Write only	Local reset of the module			
	Read / write Read / write			

Description

One Scan module is present per sector on the GEB (6 sectors of 4 VFAT2s). This means that 6 scans can be operated in parallel. The configuration registers ARE NOT shared between sectors but ARE shared between VFAT2s of the same sector. For example, setting the parameters for a scan of VFAT2 #0 means that a scan of VFAT2 #1 can be launched immediately afterwards without having to set the parameters in the registers. However, the parameters set for VFAT2 #0 do not propagate to VFAT2 #7 which is in another sector.

Note that the module will store the value of the register before the scan and reapply the latter after the end of the operation.

Errors

Two types of errors can be returned by the module when running the scan: global errors and local errors.

A global error occurs if the VFAT2 is not present or running at the start of the scan. In that case, a single 32 bits word of value 0xFF000000 is stored in the FIFO. No other read operations of the FIFO should occur afterwards.

A local error occurs if one of the I2C operations used to change the value did not succeed. In that case, the value of the 24 LSBits of that particular point is 0xFFFFFF. Other data points will still be saved and be present in the FIFO.

T1 Controller

This module sends T1 commands to the VFAT2s according to different operation modes defined by mode.

Addressing


OptoHybrid Wishbone address: 0b 0011 0000 0000 0000 0000 0000 0YYYY

Y register	Mode	Function	
Control			
0	Read / write	Enable (1) / disable (0) the module.	
1	Read / write	mode - 2 bits - {0, 1, 2}	
Mode 0 & 1 parameters			
2	Read / write	type - 2 bits - {0, 1, 2, 3} 0 = LV1A - 1 = Calpulse - 2 = Resync - 3 = BC0	
3	Read / write	<pre>N - 32 bits - [0, 0xfffffffff] 0 = infinite</pre>	
4	Read / write	interval - 32 bits - [4, 0xFFFFFFFF]	
5	Read / write	delay - 32 bits - [interval + 4, 0xffffffff]	
Mode 2 parameters			
7 & 6	Read / write	lvla_sequence - 64 bits	
9 & 8	Read / write	calpulse_sequence - 64 bits	
11 & 10	Read / write	resync_sequence - 64 bits	
13 & 12	Read / write	bc0_sequence - 64 bits	
Reset			
14	Write only	Local reset of the module	

Operation modes

Mode 0

Send N T1 commands of type type with an interval of interval BXs. Note that interval cannot be smaller than 4 BXs which is the time needed to encode a T1 command on the wire. Example with an interval of 4 BXs:



Mode 1

Send *N* packets composed of a Calpulse followed by an LV1A separated by *interval* BXs. The packets are spaced by *delay* BXs. Note that *interval* cannot be smaller than 4 BXs which is the time needed to encode a T1 command on the wire and that *delay* must be greater or equal to (*interval* + 4) BXs. Example with an *interval* of 4 BXs and a *delay* of 10 BXs:

CLK	_ - - - -	_ - _ - _ -		_ - _ -	_ - _ -	_ - _ -	_ - _
LV1A		-					_ - _
CAL	-				-		

Mode 2

Send T1 commands according to a pattern defined by the sequence registers: $lv1a_sequence$, $calpulse_sequence$, $resync_sequence$, and $bc0_sequence$. Every 4 BXs, the module reads a bit in each of the registers and sets/resets the T1 line according to the asserted bits. This operation mode allows the user to create custom patterns of T1 commands. The module will loop over the registers indefinitely. Example of a generated pattern using the $lv1a_sequence$ and $calpulse_sequence$ registers.

CLK	_ - _ - _ - _	_ - _ - _ - _ - _ - _ - _ - _ -	_ - _ - _
SEQ_LV1A	1		1
SEQ_BC0		11	
LV1A	_1 - 1		_ -
BC0		_1-1	

Notes

In mode 0 and 1 the module needs to be turned off and on again using the enable/disable register in order to send another burst of packets.