

Example Response	<pre>{ "response_code":0 }</pre>
------------------	--------------------------------------

5.18. setClearVoice

For setting Clear Voice in each Zone.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
enable	boolean	yes	Specifies Clear Voice setting

URI	<BaseURL>/v1/<zone>/setClearVoice?enable=<enable>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setClearVoice?enable=false

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	<pre>{ "response_code":0 }</pre>
------------------	--------------------------------------

5.19. setSubwooferVolume

For setting Subwoofer Volume in each Zone.

Request Parameters

name	type	required	description
zone	string	yes	Specifies target zone. Available for zones with this function Values: "main" / "zone2" / "zone3" / "zone4"
volume	integer	yes	Specifies volume value Values: Value range calculated by minimum/maximum/step values gotten via /system/getFeatures

URI	<BaseURL>/v1/<zone>/setSubwooferVolume?volume=<volume>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/main/setSubwooferVolume?volume=3

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details