

FieldTalk™ diagslave

Linux Edition Read Me Notes

Revision 3.4, 2021-03-26

This Read Me file contains last-minute product information for the FieldTalk™ diagslave utility.

diagslave is a command line based Modbus slave simulator and test utility.

Files part of the package

```
README.txt, README.pdf
These Read Me notes.

LICENSE-FREE.txt, LICENSE-FREE.pdf
License containing the Terms & Conditions of use for this free software.

arm-linux-gnueabihf/diagslave
ARMv7 binary for 32-bit ARM Linux systems (Raspberry Pi, BeagleBoard etc)

aarch64-linux-gnu/diagslave
ARMv8 binary for 64-bit AArch64 Linux systems

i686-linux-gnu/diagslave
x86 binary for 32-bit x86 Linux systems

x86_64-linux-gnu/diagslave
x86_64 binary for 64-bit x86 Linux systems
```

Usage

```
Usage: diagslave [OPTIONS] [SERIALPORT]
Arguments:
              Serial port when using Modbus ASCII or Modbus RTU protocol
serialport
              COM1, COM2 ...
                                        on Windows
              /dev/ttyS0, /dev/ttyS1 ...
                                            on Linux
General options:
-m ascii Modbus ASCII protocol

-m rtu Modbus RTU protocol (o

-m tcp MODBUS/TCP protocol
              Modbus RTU protocol (default)
-m udp
              MODBUS UDP
              Encapsulated Modbus RTU over TCP
-m enc
-0 #
              Master activity time-out in seconds (1.0 - 100, 3 s is default)
-a # Slave address (1-255 for RTU/ASCII, 0-255 for TCP)
Options for MODBUS/TCP:
              TCP port number (502 is default)
-p #
              Connection time-out in seconds (1.0 - 3600, 60 s is default)
Options for Modbus ASCII and Modbus RTU:
-b #
       Baudrate (e.g. 9600, 19200, ...) (19200 is default)
-d #
              Databits (7 or 8 for ASCII protocol, 8 for RTU)
-s #
              Stopbits (1 or 2, 1 is default)
            No parity
-p none
```

README 1

Release history

Version 3.4 (2021-03-26)

Added Linux ARMv8 AArch64 (64-bit) platform

Version 3.3 (2020-10-17)

Remove limit of 2000 addressable coils

Version 3.2 (2019-04-01)

Added -f # option to set tolerance for inter-frame gap detection

Version 3.1 (2018-11-28)

Modbus UDP protocol added (-m udp)

Version 3.0 (2018-07-09)

• RTU over TCP protocol added, which is also known as encapsulated RTU (-m enc)

Version 2.13 (2013-05-16)

• Bug fix, slave ID of 255 for Modbus/TCP did not work

Version 2.12 (2012-07-19)

- RTU/ASCII: Added RS-485 mode for Win32, QNX and Linux platforms.
- COMn syntax can now also be used for COM port number >= 10

Version 2.11 (2011-03-05)

• Protocol is now auto-detected as RTU or TCP depending on value of first parameter

Version 2.10 (2010-03-31)

• Added connection time-out, changed -t to -o for activity time-out.

README 2

Version 2.9 (2009-11-16)

• Default baudrate is now 19200 as per Modbus standard.

Version 2.8 (2009-10-26)

• Using the -d and -s command line parameters returned an error message in earlier releases.

Version 2.7 (2009-10-20)

• First release as standalone application.

Copyright (c) 2002-2021 proconX Pty Ltd. All rights reserved.

Please refer to file LICENSE-FREE for license and distribution terms.

THIS SOFTWARE IS PROVIDED BY PROCONX AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PROCONX OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

README 3