Experiment 7

<u>Title</u>: Interfacing ADC with UART Communication

Aim: To integrate ADC with UART communication on an STM32 Microcontroller.

Tool used: Tool used in this assignment is **STM32CubeIDE**.

Procedure:

- 1. Create a new STM32 project with a suitable project name.
- 2. IOC UI will open in that configure desired pins as input/output.
- 3. In system core select SYS.
- 4. In Mode select debug as serial wire.
- 5. In ADC1 mode and configuration select IN10.
- 6. In connectivity select USART1(mode asynchronous) and in parameter settings make baud rate 9600 bits/sec.
- 7. Select PA0 as input(switch) and PG13 as LED.
- 8. Press Ctrl+S to generate the code.
- 9. In the main.c file add the desired code.
- 10. Go to Project-> Build Project
- 11. Connect the discovery Board and go to Run-> Run.

CubeMX Pin Diagram:



Code:

```
/* USER CODE BEGIN Header */
**************************
* @file : main.c
* @brief : Main program body
 * @attention
 * Copyright (c) 2023 STMicroelectronics.
 * All rights reserved.
 * This software is licensed under terms that can be found in the LICENSE file
 * in the root directory of this software component.
 * If no LICENSE file comes with this software, it is provided AS-IS.
******************************
 */
/* USER CODE END Header */
/* Includes -----*/
void HEX2BCDASCII(unsigned int Val,unsigned char *str)
     unsigned int i,BCD;
     i=0:
     BCD=Val/1000;
     str[i++]=BCD+0x30;
     BCD=(Val% 1000)/100;
     str[i++]=BCD+0x30;
     BCD=((Val%1000)%100)/10;
     str[i++]=BCD+0x30;
     BCD=Val%10;
     str[i]=BCD+0x30;
#include "main.h"
/* Private includes -----*/
/* USER CODE BEGIN Includes */
/* USER CODE END Includes */
/* Private typedef -----*/
/* USER CODE BEGIN PTD */
```

```
/* USER CODE END PTD */
/* Private define -----*/
/* USER CODE BEGIN PD */
/* USER CODE END PD */
/* Private macro -----*/
/* USER CODE BEGIN PM */
/* USER CODE END PM */
/* Private variables -----*/
ADC_HandleTypeDef hadc1;
UART_HandleTypeDef huart1;
/* USER CODE BEGIN PV */
/* USER CODE END PV */
/* Private function prototypes -----*/
void SystemClock_Config(void);
static void MX_GPIO_Init(void);
static void MX_ADC1_Init(void);
static void MX_USART1_UART_Init(void);
/* USER CODE BEGIN PFP */
/* USER CODE END PFP */
/* Private user code -----*/
/* USER CODE BEGIN 0 */
unsigned char MSG1[]="ADC Interfacing Sample Program \r\n";
unsigned char MSG2[]="ADC Value in Decimal:0000";
unsigned char MSG3[]="ADC input Voltage:";
unsigned char MSG4[]="V \r\n";
unsigned char MSG5[]="\r\n";
unsigned char ASCIIVAL[4];
unsigned int ADCVAL;
float ADCVTG:
unsigned char ADC_Status;
/* USER CODE END 0 */
/**
 * @brief The application entry point.
 * @retval int
int main(void)
```

```
/* USER CODE BEGIN 1 */
/* USER CODE END 1 */
/* MCU Configuration-----*/
/* Reset of all peripherals, Initializes the Flash interface and the Systick. */
HAL_Init();
/* USER CODE BEGIN Init */
/* USER CODE END Init */
/* Configure the system clock */
SystemClock_Config();
/* USER CODE BEGIN SysInit */
/* USER CODE END SysInit */
/* Initialize all configured peripherals */
MX_GPIO_Init();
MX_ADC1_Init();
MX_USART1_UART_Init();
/* USER CODE BEGIN 2 */
HAL_UART_Transmit(&huart1,MSG1,sizeof(MSG1)-2,100);
/* USER CODE END 2 */
/* Infinite loop */
/* USER CODE BEGIN WHILE */
while (1)
 /* USER CODE END WHILE */
 HAL_ADC_Start(&hadc1);
 ADC_Status=HAL_ADC_PollForConversion(&hadc1,10);
 if(ADC_Status==HAL_OK)
     ADCVAL=HAL_ADC_GetValue(&hadc1);
     HEX2BCDASCII(ADCVAL,MSG2+21);
     HAL UART Transmit(&huart1,MSG2,sizeof(MSG2)-1,100);
     HAL_UART_Transmit(&huart1,MSG5,sizeof(MSG5),100);
     ADCVTG=ADCVAL*(3.3/4095);
     ADCVTG=ADCVTG*1000;
     HEX2BCDASCII(ADCVTG,ASCIIVAL);
     MSG3[18]=ASCIIVAL[0];
     MSG3[20]=ASCIIVAL[1];
     MSG3[21]=ASCIIVAL[2];
     MSG3[22]=ASCIIVAL[3];
     HAL_UART_Transmit(&huart1,MSG3,sizeof(MSG3),100);
```

```
HAL_UART_Transmit(&huart1,MSG4,sizeof(MSG4),100);
  }
  HAL_Delay(1000);
  /* USER CODE BEGIN 3 */
 /* USER CODE END 3 */
/**
 * @brief System Clock Configuration
 * @retval None
void SystemClock_Config(void)
 RCC OscInitTypeDef RCC OscInitStruct = {0};
 RCC_ClkInitTypeDef RCC_ClkInitStruct = {0};
 /** Configure the main internal regulator output voltage
 __HAL_RCC_PWR_CLK_ENABLE();
 HAL PWR VOLTAGESCALING CONFIG(PWR REGULATOR VOLTAGE SCALE
3);
 /** Initializes the RCC Oscillators according to the specified parameters
 * in the RCC_OscInitTypeDef structure.
 RCC_OscInitStruct.OscillatorType = RCC_OSCILLATORTYPE_HSI;
 RCC OscInitStruct.HSIState = RCC HSI ON;
 RCC OscInitStruct.HSICalibrationValue = RCC HSICALIBRATION DEFAULT;
 RCC OscInitStruct.PLL.PLLState = RCC PLL NONE;
 if (HAL_RCC_OscConfig(&RCC_OscInitStruct) != HAL_OK)
 Error Handler();
 /** Initializes the CPU, AHB and APB buses clocks
 */
 RCC_ClkInitStruct.ClockType =
RCC_CLOCKTYPE_HCLK|RCC_CLOCKTYPE_SYSCLK
               |RCC CLOCKTYPE PCLK1|RCC CLOCKTYPE PCLK2;
 RCC_ClkInitStruct.SYSCLKSource = RCC_SYSCLKSOURCE_HSI;
 RCC_ClkInitStruct.AHBCLKDivider = RCC_SYSCLK_DIV1;
 RCC_ClkInitStruct.APB1CLKDivider = RCC_HCLK_DIV1;
 RCC_ClkInitStruct.APB2CLKDivider = RCC_HCLK_DIV1;
 if (HAL_RCC_ClockConfig(&RCC_ClkInitStruct, FLASH_LATENCY_0) != HAL_OK)
 Error_Handler();
```

```
}
/**
 * @brief ADC1 Initialization Function
 * @param None
 * @retval None
static void MX_ADC1_Init(void)
/* USER CODE BEGIN ADC1_Init 0 */
 /* USER CODE END ADC1_Init 0 */
 ADC ChannelConfTypeDef sConfig = {0};
 /* USER CODE BEGIN ADC1_Init 1 */
/* USER CODE END ADC1 Init 1 */
 /** Configure the global features of the ADC (Clock, Resolution, Data Alignment and
number of conversion)
 hadc1.Instance = ADC1;
 hadc1.Init.ClockPrescaler = ADC_CLOCK_SYNC_PCLK_DIV2;
 hadc1.Init.Resolution = ADC_RESOLUTION_12B;
 hadc1.Init.ScanConvMode = DISABLE;
 hadc1.Init.ContinuousConvMode = DISABLE;
 hadc1.Init.DiscontinuousConvMode = DISABLE;
 hadc1.Init.ExternalTrigConvEdge = ADC_EXTERNALTRIGCONVEDGE_NONE;
 hadc1.Init.ExternalTrigConv = ADC_SOFTWARE_START;
 hadc1.Init.DataAlign = ADC_DATAALIGN_RIGHT;
 hadc1.Init.NbrOfConversion = 1;
 hadc1.Init.DMAContinuousRequests = DISABLE;
 hadc1.Init.EOCSelection = ADC_EOC_SINGLE_CONV;
 if (HAL_ADC_Init(&hadc1) != HAL_OK)
  Error_Handler();
 /** Configure for the selected ADC regular channel its corresponding rank in the sequencer
and its sample time.
 */
 sConfig.Channel = ADC_CHANNEL_10;
 sConfig.Rank = 1;
 sConfig.SamplingTime = ADC_SAMPLETIME_3CYCLES;
 if (HAL_ADC_ConfigChannel(&hadc1, &sConfig) != HAL_OK)
  Error_Handler();
```

```
/* USER CODE BEGIN ADC1_Init 2 */
/* USER CODE END ADC1_Init 2 */
}
 * @brief USART1 Initialization Function
 * @param None
 * @retval None
static void MX_USART1_UART_Init(void)
/* USER CODE BEGIN USART1 Init 0 */
/* USER CODE END USART1_Init 0 */
/* USER CODE BEGIN USART1 Init 1 */
 /* USER CODE END USART1_Init 1 */
 huart1.Instance = USART1;
 huart1.Init.BaudRate = 9600;
 huart1.Init.WordLength = UART_WORDLENGTH_8B;
 huart1.Init.StopBits = UART_STOPBITS_1;
 huart1.Init.Parity = UART_PARITY_NONE;
 huart1.Init.Mode = UART_MODE_TX_RX;
 huart1.Init.HwFlowCtl = UART_HWCONTROL_NONE;
 huart1.Init.OverSampling = UART OVERSAMPLING 16;
 if (HAL_UART_Init(&huart1) != HAL_OK)
 Error_Handler();
/* USER CODE BEGIN USART1 Init 2 */
/* USER CODE END USART1_Init 2 */
}
 * @brief GPIO Initialization Function
 * @param None
 * @retval None
static void MX_GPIO_Init(void)
GPIO_InitTypeDef GPIO_InitStruct = {0};
/* USER CODE BEGIN MX_GPIO_Init_1 */
/* USER CODE END MX GPIO Init 1 */
```

```
/* GPIO Ports Clock Enable */
 __HAL_RCC_GPIOC_CLK_ENABLE();
 __HAL_RCC_GPIOA_CLK_ENABLE();
 __HAL_RCC_GPIOG_CLK_ENABLE();
 /*Configure GPIO pin Output Level */
 HAL GPIO WritePin(GPIOG, GPIO PIN 13, GPIO PIN RESET);
 /*Configure GPIO pin : PA0 */
 GPIO InitStruct.Pin = GPIO PIN 0;
 GPIO_InitStruct.Mode = GPIO_MODE_INPUT;
 GPIO InitStruct.Pull = GPIO NOPULL;
 HAL_GPIO_Init(GPIOA, &GPIO_InitStruct);
 /*Configure GPIO pin : PG13 */
 GPIO InitStruct.Pin = GPIO_PIN_13;
 GPIO InitStruct.Mode = GPIO MODE OUTPUT PP;
 GPIO InitStruct.Pull = GPIO NOPULL;
 GPIO InitStruct.Speed = GPIO SPEED FREQ LOW;
 HAL_GPIO_Init(GPIOG, &GPIO_InitStruct);
/* USER CODE BEGIN MX GPIO Init 2 */
/* USER CODE END MX_GPIO_Init_2 */
/* USER CODE BEGIN 4 */
/* USER CODE END 4 */
 * @brief This function is executed in case of error occurrence.
 * @retval None
void Error Handler(void)
 /* USER CODE BEGIN Error_Handler_Debug */
/* User can add his own implementation to report the HAL error return state */
 __disable_irq();
 while (1)
/* USER CODE END Error_Handler_Debug */
#ifdef USE FULL ASSERT
/**
 * @brief Reports the name of the source file and the source line number
       where the assert_param error has occurred.
 * @param file: pointer to the source file name
 * @param line: assert_param error line source number
```

```
* @retval None
*/
void assert_failed(uint8_t *file, uint32_t line)
{
    /* USER CODE BEGIN 6 */
    /* User can add his own implementation to report the file name and line number,
    ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
    /* USER CODE END 6 */
}
#endif /* USE_FULL_ASSERT */
```

Output:

```
Serial Monitor X

Message (Enter to send message to 'Arduino Uno' on 'COM3')

13:00:41.884 -> ADC input voltage:3.300v
13:00:42.893 -> ADC Value In Decimal:4094
13:00:42.930 -> ADC input voltage:3.299v
13:00:43.936 -> ADC Value In Decimal:4095
13:00:43.982 -> ADC input voltage:3.300v
13:00:44.984 -> ADC Value In Decimal:4095
13:00:44.984 -> ADC input voltage:3.300v
13:00:46.005 -> ADC input voltage:3.300v
13:00:46.037 -> ADC input voltage:3.299v
13:00:47.038 -> ADC Value In Decimal:4094
13:00:47.038 -> ADC Value In Decimal:4094
```

Functions used:

```
HAL_UART_Transmit (&handle_variable_name,MSG,sizeof(MSG),Timeout);
HAL_ADC_PollForConversion(&handle_variable_name,Timeout);
HAL_ADC_Start(&handle_variable_name);
HAL_ADC_GetValue(&handle_variable_name);
```

Result:

Basic STM32Cube project for interfacing ADC with UART communication was built using STM32CubeIDE.