1.) Download the firmware file and partition image from Debians Server

https://d-i.debian.org/daily-images/arm64/daily/netboot/SD-card-images/

https://d-i.debian.org/daily-images/arm64/daily/netboot/SD-card-images/firmware.rock64-rk3328.img.gz https://d-i.debian.org/daily-images/arm64/daily/netboot/SD-card-images/partition.img.gz

2.) Merge the firmware file and partition image into bootable Debian image

zcat firmware.rock64-rk3328.img.gz partition.img.gz > rk64 debian.img

Flash bootable Debian image onto SD-Card 3.)

> sudo dd if=/dev/zero of=/dev/sdX bs=446 count=32770 sudo dd if=rk64_debian.img of=/dev/sdX bs=4M conv=fsync flash Debian image to your SD-Card

find device name of your SD-Card wipe the Boot Sector of your SD-Card

replace X with the device letter of your SD-Card

4.) Download the U-Boot package from Debians Server

https://packages.debian.org/bookworm/arm64/u-boot-rockchip/download

extract the idbloader.img and u-boot.itb files from the package, both files are located in u-boot-rockchip_X_arm64.deb/data.tar.xz/./usr/lib/u-boot/rock64-rk3328/

5.) Prepare the eMMC-Module for the Rock64 SBC (16GB eMMC module (30310400 sectors))

sudo fdisk /dev/sdX

type o this will clear out any partitions on the drive type p to list partitions, there should be no partitions left type n, then p for primary, 1 for the first partition on the drive, 32768 for the first sector, and 647168 for the last sector, then type a then type n, then p for primary, 2 for the second partition on the drive, **647169** for the first sector, and **28213246** for the last sector, then type n, then p for primary, 3 for the third partition on the drive, 28213247 for the first sector, and 30310399 for the last sector, then type t, and 3 for the third partition, and 82 for the Hex Code, then write the partition table and exit by typing w

(steps above create 300M for /boot, 14.7GB for / and 1GB for swap)

We will format the newly created partitions later with the Debian Installer.

The 300M partition format as ext2 and set mount point to /boot. The 14.7GB partition format as ext4 and set mount point to /. The 1 GB partition format as swap.

Flash U-Boot (Bootloader) onto the eMMC-Module for the Rock64 SBC 6.)

lsblk sudo dd if=idbloader.img of=/dev/sdX seek=64 conv=notrunc sudo dd if=u-boot.itb of=/dev/sdX seek=16384 conv=notrunc


find device name of your eMMC replace X with the device letter of your eMMC-Module

once finished, unmount the eMMC-Module

7.) Install the eMMC-Module onto your Pine64 Rock64 SBC, insert the SD-Card, connect HDMI, Mouse and Keyboard, USB to serial (UART) adapter, power it up and follow the Debian Installer.

sudo screen /dev/ttyUSB0 1500000

connects you to the serial output of the Rock64 CTRL a k exits screen



Pin 6 -> Ground Pin 8 -> TX Pin 10 -> RX The Debain Installer will fail at "Making the System bootable", ignore this and continue with the next step to finish the installation. (u-boot is installed already)

8.) Once installation is finished, add Firmware for Rockchip CDN DisplayPort Controller

nano /etc/apt/sources.list

amend as below

deb http://deb.debian.org/debian bookworm main

deb http://deb.debian.org/debian bookworm main contrib non-free deb-src http://deb.debian.org/debian bookworm main contrib non-free

deb http://deb.debian.org/debian-security bookworm-security main contrib non-free deb-src http://deb.debian.org/debian-security bookworm-security main contrib non-free

apt update apt install firmware-misc-nonfree

contains -> rockchip/dptx.bin

9.) Perform system update, enable filesystem check at boot and enable sudo

apt update apt upgrade apt full-upgrade apt autoremove apt autoclean

tune2fs -c 1 /dev/mmcblkXp1 tune2fs -c 1 /dev/mmcblkXp2 use Isblk to find correct block device

apt install sudo

adduser youruser sudo

10.) Hide kernel messages during boot

nano /etc/sysctl.conf

amend as below

Uncomment the following to stop low-level messages on console kernel.printk = 3 4 1 3

11.) If you operate more than one Rock64 on the same network, you may need MAC address spoofing

ip link show end0

shows current MAC address.

If the same MAC address is present multiple times on the same network, then do steps below or the network will not work!

sudo nano /etc/network/interfaces

amend as below

This file describes the network interfaces available on your system # and how to activate them. For more information, see interfaces(5).

source /etc/network/interfaces.d/*

The loopback network interface auto lo iface lo inet loopback

The primary network interface allow-hotplug end0 iface end0 inet dhcp

hwaddress ether da:74:87:XX:XX

change the last 3 bits to your liking, **DO NOT** change the first 3 bits (reserved for Manufacturer)

reboot

once board is up, check with ip link show end0 for success

12.) Install U-Boot onto your Rock64 to keep U-Boot up-to-date

apt install u-boot-rockchip u-boot-menu

(flash-kernel is already installed)

u-boot-update

nano/boot/extlinux/extlinux.conf

check boot menu config

lsblk

find correct block device for U-Boot

u-boot-install-rockchip /dev/mmcblkX

flash U-Boot onto block device

reboot

Done, enjoy your setup.