


**INSTRUCTIONS  
FOR USING  
ATTACHMENTS  
WHICH MAY BE APPLIED TO  
SINGER MACHINE No. 66**

### The Binder—Binding.

Raise the needle and fit the binder, as shewn.

Pass the binding through the scroll of the binder and draw it under the needle. Place the edge of



the material to be bound between the scroll of the binder and under the needle, lower the presser-bar lifter and sew as usual.

Bias binding should be cut  $\frac{1}{2}$  of an inch wide.


**To Bind with Dress Braid.**—Proceed as when using bias binding; the only difference is, the dress braid being narrower, the edges will not be turned under, as is the case with bias binding.

**To make French folds.**—Proceed as directed for binding, but pass the cloth beneath the binder-foot, so that the fold is stitched on to the face of the material instead of on the edge.

### The Quilter.

Raise the needle and fit the quilter, as shewn.

The quilter guide can be used at either the right




or left of the needle, and the distance of the guide from the needle determines the width between the rows of stitching. Slide the wire into the holder prepared for it on the foot, and set it to the width desired, then lower the foot on to the material.

**To Quilt.**—For the first row of stitching, let the quilter guide follow the edge of the material, a straight crease or line as preferred. The succeeding rows are made straight and at a uniform distance by keeping the previous row steadily under the guide, as shewn.

### The Foot Hemmer—Hemming.

Raise the needle and fit the foot hemmer, as shewn. Clip off the right hand corner of the material so that its edge will curl easily. Then, with the hemmer foot raised, place the material from left




K1372

to right under the foot and with its edge slightly raised, insert the corner into the mouth of the hemmer, easing it along until it fills the curl and reaches the needle. Lower the foot and make the first few stitches slowly. Guide the material with the thumb and forefinger of the right hand, so that the edge lies flat over the top of the hemmer, and proceed to sew, taking care to keep the hemmer curl just full. Should the edge begin to run out, move the hand to the right; should too much material run in, move to the left.

### Hemming and Sewing on Lace in One Operation.

Start the hem as explained on page 20, and, when it is well started, raise the needle to its highest point. Raise the hemmer to relieve the pressure




K1373

on the hem and pass the end of the lace through the slot in the side of the hemmer and over the hem, as shewn.

Take care that the hem is not displaced in the hemmer and that the needle goes down through the lace and hem together. Then let down the presser bar and guide the lace over the front of the hemmer, taking care to keep it well into the slot.

### The Foot Hemmer—Felling.

The two pieces of cloth should be laid wrong side out, one over the other, with the edge of the




K1374

under piece a little further to the right than the upper piece, as shewn in the illustration. Stitch the two pieces together, using the front projecting part of the hemmer, as shewn in the illustration, as a guide for keeping the seam straight. The seam should be made close, but not too near to the edge of the upper piece, or the cloth will give way at the seam when a strain is put upon it.

### The Foot Hemmer—Felling—continued

Raise the hemmer foot and open the work out flat, wrong side up, so that the edges will stand up



K1375

straight. Then push the edges at the beginning of the seam into the mouth of the hemmer, as far as the needle, and lower the hemmer foot. While stitching, keep the material perfectly flat, using both hands, and see that the seam is in line with the mouth of the hemmer. For the second seam the stitch should be lengthened slightly.

### The Adjustable Hemmer.


Raise the needle and fit the adjustable hemmer, as shewn. This hemmer will make hems from  $\frac{3}{16}$  inch to 1 inch wide.



Loosen the thumb screw at the front of the hemmer and move the slide to the right or left until the small pointer is against the desired width; then tighten the screw. Insert the edge of the cloth between the slide and the number gauge, at their end, and draw it backwards and forwards until the hem is formed, stopping with the end of the cloth under the needle. Lower the presser bar lifter and commence to sew, taking care to so guide the cloth as to keep the hemmer full. Felling can also be done with this hemmer by following the instructions on pages 22 and 23.

### The Adjustable Hemmer— Wide Hemming.

To make a hem more than one inch wide take out the thumb screw and remove the slide and



pointer. Fold and crease down a hem of the desired width; pass the fold under the extension at the right of the hemmer, insert the edge into the folder, as shewn, and proceed to stitch the hem.

### The Under Braider—Braiding.

Raise the needle and fit the quilter foot, as shewn. To attach the under braider, draw the slide (5, Fig. 6) to the left, and insert the downwardly



K15/8

projecting hooks of the attachment under the edge of the throat plate, push the attachment as far as possible to the right and press the small stud into the hole at the right of the throat plate, then close the slide.

The pattern or design to be braided must be stamped or traced on the wrong side of the material. Pass the end of the braid through the blued guide of the under braider and then under the needle. Place the material, wrong side up, above the braid, lower the presser foot and proceed to sew, following the lines of the design.

### The Ruffler—Ruffling.

Raise the needle and attach the ruffler, taking care to connect the lever with the needle clamp, as shewn.




K1648

To make a gather at every stitch, insert the small post into slot 1 of lever (A). Pass the edge of the material under the prong at the front of the ruffler and between the two blued blades until it is slightly past the needle, lower the presser bar lifter and proceed to sew. To make a finer gather, shorten the stitch and shorten the stroke of the ruffling blade by raising the thumb screw (C). To make a fuller gather, lower the thumb screw and lengthen the stitch. By varying these adjustments many pleasing varieties of work can be accomplished with the ruffler.

**The Ruffler—  
Ruffling between Two Pieces of Material.**

Place the lower piece of material below the ruffler. Insert the piece to be ruffled in the ruffler,



as instructed on the preceding page, and pass the upper piece of material above the blued blades in the manner illustrated.


**To Ruffle and Sew on at One Operation.—**  
Place the material below the ruffler and the piece to be ruffled between the blued blades, and proceed as in ruffling.

Apply a little oil to the wearing parts of the ruffler before using.

**CAUTION.—***The ruffler should never, under any circumstances, be operated without cloth between the blued blades.*

**Five Stitch Ruffling or Pleating.**

To make a five stitch ruffle or pleat, insert the small post into slot 5 of lever (A), as shewn.



The ruffling blade ~~will~~ then move forward and back once at every fifth stitch. Finer or fuller pleats may be obtained by merely altering the length of stitch.

**To make Pleated Trimming.—**Insert a narrow tape or ribbon through one or both of the slots in the small guide (B) and beneath the presser foot and needle so that it lies centrally over the material to be pleated.

### The Ruffler with Shirring Plate—Shirring.

Attach the shirring plate as instructed for the under braider, so that the needle will descend in the slot in the front end of the plate.



Remove the lower blued blade of the ruffler by loosening the small screw at the side of the ruffler, then attach the ruffler to the presser bar, as already instructed.

**To Shirr.**—Place the cloth between the blued blade and the shirring plate, lower the presser bar lifter and proceed as in ruffling.

### Balance Wheel Stop Motion.

This device enables the operator to loosen the balance wheel so that it will revolve freely, without operating the stitching mechanism, while a correct treadle motion is being acquired and when winding bobbins. To loosen the wheel hold it with the left hand and with the right hand turn the stop motion screw over towards you, as shown in Fig. 1.



Fig. 1

### To Operate the Treadle Machine.

Loosen the balance wheel, place both feet upon the treadle, and turn the balance wheel towards you at the same time allowing the feet to move freely and lightly with the motion of the treadle. Continue to do this until a regular and easy movement is acquired and you are able to work the treadle so that you can re-start the machine without the balance wheel turning in the wrong direction.

When familiar with the working movement, tighten the balance wheel by turning the stop motion screw from you, and place a piece of calico or cloth under the presser foot (2, Fig. 2). Lower the presser foot upon the material by means of the presser bar lifter (1, Fig. 2) and again work the machine, without it being threaded, until you have become accustomed to guiding the material.




Fig. 2

### To Operate the Hand Machine.

Tighten the balance wheel, and after placing a piece of material under the presser foot (2, Fig. 2) turn the handle from you with an easy and regular motion. Continue to do this until you are able to guide the material correctly with the left hand.

*The advantages of a treadle machine compared with a hand machine are greater speed and, both hands being free, a greater variety of work can be accomplished.*

### To Ensure Perfect Action of the Machine.

The balance wheel must always turn towards you. The presser foot must be raised, except when sewing. Do not work the machine with the bobbin case (1, Fig. 6) and the needle threaded when not sewing. The slide (5, Fig. 6) must be kept closed.

### To Thread the Needle.

(See Fig. 3.)

Pass the thread from the reel through the wire guide (12), down under and from right to left between the tension discs (14), over the small wire spring (5) at the left of the discs, under the slack thread regulator (6), up and from right to left through the hole (11) in the take-up lever, down into the eyelet (7) in front of the face plate, into the wire guide (9) on the sleeve in which the needle bar moves, then from left to right through the eye of the needle leaving an end of thread three or four inches long when the thread take-up lever (11) is at its highest point.

For threading the needle we recommend the use of the Singer Needle Threader. With it the needle is threaded easily and quickly, saving time, trouble and patience.

### To Set the Needle.

(See Fig. 3.)

Raise the needle bar (15) to its highest point and loosen the thumb screw (16); hold the needle with the left hand and, with its flat side towards the balance wheel, insert it into the needle clamp (17) as far as it will go, then tighten the thumb screw




Fig. 3



Fig. 4

### To Take Out the Bobbin.

Draw the slide (5, Fig. 6) to the left and press the forefinger of the right hand upon the bobbin ejector, as shewn in Fig. 4; this will raise the bobbin so that it can be easily taken out.

### To Wind the Bobbin.

(See Fig. 5.)

Loosen the balance wheel, and place a reel of thread on the spool pin. Pass the end of the thread through the wire guide (12, Fig. 3) then into the lower eyelet (5) of the thread guide from below, and into the notch (2) at its top. Now thread the bobbin by passing the thread through the hole in its left disc from the inside, and with the left hand press it on to the bobbin winder spindle (1) and hold; then, with the right hand, turn the small pulley (6) until the hole in the right disc of the bobbin is engaged by the pin in the spindle shoulder. Press the pulley against the ledge of the balance wheel until the latch retains the winder in position; hold the free end of the thread and proceed to wind by turning the balance wheel towards you; then, after a few turns, break off the end of thread and again operate the treadle as in sewing until the bobbin is filled. The winder stops automatically when the bobbin is full.




Fig. 5

wheel until the latch retains the winder in position; hold the free end of the thread and proceed to wind by turning the balance wheel towards you; then, after a few turns, break off the end of thread and again operate the treadle as in sewing until the bobbin is filled. The winder stops automatically when the bobbin is full.

If through any cause the pressure of the rubber-ring against the ledge of the balance wheel is insufficient for winding the bobbin, loosen the screw (3) and press the winder lightly until the rubber ring is in contact with the ledge of the balance wheel; then tighten the screw.

### To Replace the Bobbin in the Bobbin Case.

(See Fig. 6.)

Take the bobbin between the thumb and forefinger of the right hand with the end of the thread drawing from the top to the left, and in this position replace it in the bobbin case, as shewn in Fig. 6. With the left hand draw the thread into the slot (3), then back between the spring and side of bobbin case until it reaches the notch (4) across the bobbin towards the needle and close the slide (5).




Fig. 6

### To Clean the Stitch Forming Mechanism.

If the stitch forming mechanism should become clogged with lint and interfere with the perfect operation of the machine, remove the bobbin case, as described in the following instructions and dislodge the lint accumulated in the machine.

### To Remove the Bobbin Case.

(See Fig. 7).

Raise the needle to its highest point and remove the slide (5, Fig. 6) by raising its front edge.

Insert the nail of the left forefinger under the latch "B" and raise it on to the edge at "A." Hold the bobbin case between the thumb and forefinger of the left hand by its edge nearest the latch "A," as shewn in Fig. 7, and lift it out towards you.




Fig. 7

*Under no circumstances must the screw in latch B be loosened, as this would put the stitch forming mechanism out of adjustment.*

### To Replace the Bobbin.

Raise the needle to its highest point, with the latch (B, Fig. 8), in the position illustrated. Hold the bobbin case between the forefinger and thumb of the left hand, by its edge furthest from the forked part (as shewn in Fig. 8), and insert the latter beneath the throat plate so that the fork straddles the position stud; then with a slight twisting motion of the fork to the left and to the back, lightly press down the bobbin case until the edge of the sewing hook engages in its groove.




Fig. 8




Fig. 9

Having correctly inserted the bobbin case, move the latch (B, Fig. 8) into the notch to hold the bobbin case in position, and then replace the slide from the right, as shown in Fig. 9, being careful to see that the two ends of the flat spring (A, Fig. 9) enter the grooves on the underside of the slide.

### To Prepare for Sewing.

With the left hand hold the end of the needle thread, leaving it quite slack from the hand to the needle, turn the balance wheel towards you until the needle moves down and up again to its highest point, thus catching the under thread; then pull the end of the needle thread you are holding, and the under thread will be brought up with it through the needle hole in the throat plate, as shewn in Fig. 10




Fig. 10

Place both ends of thread and material to be sewn under the presser foot and needle, lower the presser bar lifter and commence to sew by turning the balance wheel towards you.

*NOTE.—Do not try to help the feeding of the work by pulling the material, as this may deflect the needle and cause it to break; the machine feeds without any assistance.*

### To Remove the Work.

Raise the needle bar to its highest point and lift the presser foot; then move the material back and to the left, and sever the threads by passing them over the thread cutter above the presser foot. Leave the ends of the threads a few inches long under the presser foot.

### To Regulate the Tensions.



Correct Stitch

For ordinary stitching, the tension on the upper and under threads should be equal, and just sufficiently strong to lock both threads in the centre of the work, as shewn in the above illustration.

If either tension is stronger than the other, imperfect stitching will be the result, thus:—



Needle thread tension  
too strong



Needle thread tension  
too weak

A correct stitch can usually be obtained by varying the tension on the needle thread (see Fig. 11).—To increase the tension turn the thumb nut in the direction illustrated by the arrow, or to lessen the tension turn the nut in the opposite direction. All machines are correctly adjusted before leaving the factory, and it is therefore seldom necessary to alter the under tension. Should it become necessary to do so, however, tighten the tension spring screw (2, Fig. 6) on the left hand side of the bobbin case to increase the tension or loosen the screw slightly to lessen the tension.




Fig. 11

Care should be taken to use thread and needles suitable for the material being sewn (see Table on inside of back cover.)



Fig. 12

*Position of Screw for Long Stitch*

#### To Alter the Length of Stitch.

Screw the thumb screw inwards (see Fig. 12) to lengthen the stitch, or screw outwards to shorten it.

#### To Change the Pressure on Material.

For ordinary family sewing it is seldom necessary to change the pressure on the material. If sewing fine silk or flimsy material, lighten the pressure by giving the thumb screw (1, Fig. 3) two or three turns upwards. If it be found necessary to increase the pressure, give the thumb screw a few turns downwards.

#### To Turn a Corner.

Stop the machine when the needle is at its lowest point, raise the presser foot and turn the work as desired, using the needle as a pivot, then lower the presser foot.

#### To Sew Flannel or Bias Seams.

Use a short stitch and as light a tension as possible so as to leave the thread loose enough to withstand the strain of stretching the goods.




Fig. 13

#### To Oil the Machine and Stand.

To ensure easy and quiet working of the machine it is necessary that all moving parts in contact with each other should always be covered with a film of oil, and not allowed to become dry. A drop of oil is sufficient at any place. To oil the mechanism in the machine head, remove the face plate (3, Fig. 3) by taking out the thumb screw (8, Fig. 3) and slipping the face plate up and over the head of the screw (2, Fig. 3).

A drop of oil must occasionally be given to the small piece of felt which lubricates the surface of the oscillating hook, and upon the surfaces and rollers at the right of the hook shaft. The machine should be oiled at the places indicated by arrow points in Figs. 13 and 14.

After oiling, run the machine rapidly for a few minutes to work the oil into the bearings. If in constant use, the machine should be oiled two or three times a week.




Fig. 14

To oil the stand, apply a drop of oil to the centres upon which the band wheel and treadle work, and to both ends of the pitman rod which connects the treadle with the band wheel.

Always use best oil as sold only at Singer Shops. Inferior oil clogs the bearings, prevents efficient working, and causes rapid wear of the mechanism.




Fig. 15

turning towards you; a revolution or two of the wheel will bring the belt back into its place.

#### The Belt Shifter

This device simplifies throwing off and replacing the belt. To throw off the belt move the belt shifter to the left (see Fig. 15), working the treadle at the same time. To replace the belt work the treadle slowly with the band wheel

#### H I N T S.

**Machine Working Heavily.**—If the machine works hard after standing for some time, use a little paraffin or benzine in place of oil; run the machine rapidly to clean the bearings and oil with Singer superior machine oil. **The use of inferior oil is usually the cause of the machine working heavily.** See that the leather belt is not too tight; it should be just tight enough not to slip. If too long, shorten and rejoin.

**Skip Stitches.**—A bent or blunt pointed needle is often the cause of this. See that the needle is accurately set (see page 5). Remove the throat plate, and, after seeing that the feed (3, Fig. 2) is clean and working freely, replace the throat plate.

**Thread Breaking.**—If the needle thread breaks this is probably due to one of the following causes :—

The machine being improperly threaded.

The tensions being too tight.

The needle being bent or having a blunt point.

The thread being too coarse for the size of the needle (see Table on inside of back cover.)

The spring (5, Fig. 3) being broken.

If the under thread breaks, adjust the under tension (see page 11); also see that the inside of the bobbin case and under the tension spring are quite free from fluff.

**Needles Breaking.**—See that the needle is not bent, and avoid pulling the material when stitching; either will cause the needle to strike on the throat plate and break. **Use Singer Needles sold only at Singer Shops and by the Company's authorised representatives.** Other makes of needles are often of inferior quality, they become blunt, break easily, and prevent the efficient working of the machine.

*Inferior Needles and Thread are often the causes of breaking. The Eye in Singer Needles is specially finished to prevent cutting of Thread, while the best Thread resists strain and is free from knots. Singer Shops sell the best machine Sewing Thread.*

**Material Puckering.**—This is generally due to irregular tensions. See page 11 for the regulation of tensions.

**Stitches Looping.**—This is regulated by the tensions (see page 11). See that both the bobbin case and the needle are properly threaded, that the thread used is of good quality and the correct size for the needle (see table on inside of back cover). See that the spring (5, Fig. 3) is not broken.

Advice is given free at all Singer Shops as to the proper adjustment of machines.

Free instruction always willingly given in the use of any Singer machine and attachments at any Singer Shop, no matter where the machine may have been purchased.

*Every description of Sewing Machine repaired or exchanged.*