

Zephyr Final Workshop Project

Mission Objective

Build a complete wireless data transmission system using Zephyr RTOS, where:

- The nRF52DK acts as a BLE Peripheral.
- The TMP102 temperature sensor is connected to the nRF52DK.
- The sensor data is sent over BLE to the nRF52840DK.
- The nRF52840DK acts as a BLE Central and receives the data.
- The system supports a shell command (`sensor_read`) to print the latest temperature.
- The nRF52840DK also connects to the host over USB RNDIS.
- A shell is available on the host via Telnet over RNDIS.

Required Hardware

- 1x nRF52DK
- 1x nRF52840DK
- 1x TMP102 sensor (I2C)
- Jumper wires
- 3x USB cables mini
- Linux host machine

TMP102 to nRF52DK Wiring

TMP102 Pin	nRF52DK Pin
VCC	3.3V
GND	GND
SDA	P0.26
SCL	P0.27

Project Setup Summary

Peripheral (nRF52DK)

- Connect TMP102 via I2C

- Act as BLE Peripheral
- Read temperature from TMP102
- Send data using BLE notifications

Central (nRF52840DK)

- Act as BLE Central
- Connect and subscribe to temperature notifications
- Provide a shell command: sensor_read

USB Networking (nRF52840DK)

- Enable RNDIS over USB
- Assign static IP (2.2.2.2)
- Provide shell over Telnet



Host Setup

- Assign static IP to USB network interface: 2.2.2.1/24
- Ping the board at 2.2.2.2
- Access shell with: telnet 2.2.2.2

Extra:

- add UDP socket on the nRF52840DK that will send periodically the temp value
- change the advertisement freq so phone won't see you