

About System Software Disks

The Triton can accept new OS software that is placed onto newly formatted High Density DOS floppies – the files MUST be placed on the root directory of the floppy. This means the files cannot be located in a folder, or the Triton will not "see" them. We recommend that you always use new, freshly formatted floppies – if you don't you may get a checksum error message. If this happens, try again with a brand new floppy.

The files are organized into three folders, one for each disk required. So copy the contents of each folder to a freshly formatted disk - again, DO NOT COPY THE FOLDER ITSELF, ONLY COPY THE CONTENTS OF EACH FOLDER.

How to Update Triton System Software

Note: This updating will not erase any Programs, Combis or Global data in the Triton!

- 1. Hold down the ENTER and LOCATE buttons while turning on the Triton. The display will show "Please insert System 1 disk".
- 2. Insert System Disk #1 of the Version 2.51 Operating Sytem into the drive.
- 3. New System Software installation will begin at this point. DO NOT TOUCH THE KEYBOARD OR INTERRUPT THE POWER WHILE THE SYSTEM IS BEING UPDATED!
- 4. During installation the following messages will appear:
 - "Now loading..."
 - "Now erasing ROM"
 - "Checking the system's checksum"
- 5. Shortly, you will be prompted with "Please change to System 2 disk"
- **6**. Eject Disk 1 and insert System Disk No. 2 into the drive. When it finishes loading you will be prompted for the third and final disk.
- 7. When the following messages appear, installation has been completed successfully and the Triton will restart automatically:
 - "Checking the system's check sum"
 - "System load was completed"
- 8. Enjoy your new System Software!