

POWER\_SUPPLY

File: POWER\_SUPPLY.kicad\_sch

MCU

File: MCU.kicad\_sch

**GRAPHICS** 

File: GRAPHICS.kicad\_sch

MOTOR\_CONTROL

File: MOTOR\_CONTROL\_kicad\_sch

CONNECTIVITY

File: CONNECTIVITY.kicad\_sch

**SENSORS** 

File: SENSORS.kicad\_sch

**MECHANICS** 

File: MECHANICS.kicad\_sch

SUMEC MK IV aka SMD-V3 board

Made by Bismarx aka MenMenson

CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366

Made in Prague, Czech Republic

SPS NA PROSEKU

Sheet:

File: SUMEC\_MK\_IV.kicad\_sch

Title: SUMEC\_MK\_IV


 Size: A4
 Date: 2024-07-15
 Rev. v3.0.0

 KiCad E.D.A. 8.0.3
 Id: 1/8


4

5


# **XT-30M**




# LDO VOLTAGE REGULATOR




#### **USB POWER SWITCH**



#### **MAIN SWITCH**



#### STEPDOWN CONVERTER



SUMEC MK IV aka SMD-V3 board
Made by Bismarx aka MenMenson
CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366
Made in Prague, Czech Republic
SPS NA PROSEKU
Sheet: /POWER\_SUPPLY/
File: POWER\_SUPPLY/kicad\_sch


 Title: SUMEC\_MK\_IV


 Size: A4
 Date: 2024-07-15
 Rev: v3.0.0

 KiCad E.D.A. 8.0.3
 Id: 2/8

# **GUILTY UNTIL PROVEN INNOCENT**

# H-BRIDGE





SUMEC MK IV aka SMD-V3 board
Made by Bismarx aka MenMenson
CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366
Made in Prague, Czech Republic
SPS NA PROSEKU

Sheet: /MOTOR\_CONTROL/


File: MOTOR\_CONTROL.kicad\_sch

| Titl | le: | Sι | IME | C_N | 1K_IV |
|------|-----|----|-----|-----|-------|
|      |     |    |     |     | _     |

 Size: A4
 Date: 2024-07-15
 Rev: v3.0.0

 KjCad E.D.A. 8.0.3
 Id: 3/8

#### IR MODULE



# **LINE SENSORS**

Miniature Reflective
Object Sensor - QRE1113


IR reflectance sensor is comprised of two parts - an IR emitting LED and an IR sensitive phototransistor.

Analog output
A 100Ω resistor is placed in series with the LED to limit current. A 10kΩ resistor pulls the output pin high, but when the light from the LED is reflected back onto the phototransistor the output will begin to go lower.


2 front sensors will be connected to the "QRE MiniBoard", rear sensor will be connected using the same connector.

| MIRRORED | JIO | 1 | 2 | QREIII3 A | 2 | 3 | 4 | QREIII3 B | 4 | QRE


#### **DISTANCE MEASURING**



# **OBJECT DETECTING SENSORS**



### SIDE SENSORS



SUMEC MK IV aka SMD-V3 board

Made by Bismarx aka MenMenson

CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366

Made in Prague, Czech Republic

SPS NA PROSEKU

Sheet: /SENSORS/
File: SENSORS.kicad\_sch

Title: SUMEC\_MK\_IV

Size: A4 Date: 2024-07-15 Rev. v3.00

KjCad E.D.A. 8.0.3 Id: 4/8

#### ESP32-S3-WR00M1-N4

GPIOO has an internal pullup resistor, so if it is left unconnected then it will pull high.

GPI00, GPI045, and GPI046 are connected to the chip's internal weak pull-up/pull-down resistors at chip reset. These resistors determine the default bit values of the strapping pins. Also, these resistors determine the bit values if the strapping pins are connected to an external high-impedance circuit.


#### Default Configuration of Strapping Pins

| Strapping Pin | Default Configuration | Bit Val |
|---------------|-----------------------|---------|
| GPI00         | Pull-up               | 1       |
| GPI03         | Floating              | _       |
| GPI045        | Pull-down             | 0       |
| GPI046        | Pull-down             | 0       |


Typically these can be used, but you need to make sure they are not in the wrong state during boot.

gpio.0 Boot Mode. Weak pullup during reset. (Boot Mode 0=Boot from Flash, 1=Download) gpio.3 JTAG Mode. Weak pull down during reset. (JTAG Config) gpio.45 SPI voltage. Weak pull down during reset. (SPI Voltage 0=3.3v 1=1.8v) gpio.46 Boot mode. Weak pull down during reset. (Enabling/Disabling ROM Messages Print During Booting)

# **ESP32-S3 Datasheet**



### LED SIGNALISATION



working voltage for pins 47 and 48 is 1.8 (test it)

GPIO9: FSPIHD (not sure what it stands for)

GPI010: FSPICS0 (chip select)

GPI011: FSPID (dual SPI)

GPI012: FSPICLK (clock)

GPI013: FSPIQ (quad SPI)

GPI014: FSPIWP ("write protect")

|  | FSPI Bus Signal   | SPI3 Bus Signal | Function  |  |  |
|--|---|-----------------|---|--|--|
|  | FSPICLK   | SPI3_CLK        | Input and output clock in master/slave mode       |  |  |
|  | FSPICS0   | SPI3_CSO        | Input and output CS signal in master/slave mode   |  |  |
|  | FSPICS1 ~ 5   | SPI3_CS1 ~ 2    | Output CS signal in master mode                   |  |  |
|  | FSPID   | SPI3_D          | MOSI/SIOO (serial data input and output, bit0)    |  |  |
|  | FSPIQ   | SPI3_Q          | MISO/SIO1 (serial data input and output, bit1)    |  |  |
|  | FSPIWP         SPI3_WP           FSPIHD         SPI3_HD           FSPIIO4 ~ 7         — |                 | SIO2 (serial data input and output, bit2)         |  |  |
|  |   |                 | SIO3 (serial data input and output, bit3)         |  |  |
|  |   |                 | SIO4 ~ 7 (serial data input and output, bit4 ~ 7) |  |  |
|  | ESPIDOS   | _               | Output data mask signal in master mode            |  |  |

Made by Bismarx aka MenMenson CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366 Made in Prague, Czech Republic

SPS NA PROSEKU


Sheet: /MCU/ File: MCU.kicad\_sch

SUMEC MK IV aka SMD-V3 board

| Size: A4           | Date: 2024-07-15 | Rev: v3.0.0 |
|--------------------|------------------|-------------|
| KiCad E.D.A. 8.0.3 |                  | ld: 5/8     |

FSPID is MOSI, FSPIQ is MISO, FSPICSO is chip select, FSPICLK is the clock.

**USB** 



Made by Bismarx aka MenMenson

CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366

Made in Prague, Czech Republic

SPS NA PROSEKU

Sheet: /CONNECTIVITY/
File: CONNECTIVITY/
File: CONNECTIVITY/
Size: A4 Date: 2024–07–15

KiCad E.D.A. 8.0.3


Id: 6/8

SUMEC MK IV aka SMD-V3 board


# **PUSH BUTTONS**

ASK NAT - test buttons Buttons for BOOT and ENABLE functions. If the device does not support the auto download mode, you need to get into the download mode manually. To do so, press and hold the BOOT button and then press the RESET button once. After that release the BOOT button. **ENABLE** B00T TEST PROGRAM EN=RESET, BOOT=bootloader mode  $\frac{1}{2}$ -0 -C28 C29 Enable (EN) is the 3.3V regulator's enable pin. It's pulled up, so connect to ground to disable the 3.3V regulator. This means that you can use this pin 100nF.boot connected to a pushbutton to restart your ESP32, for

**MOUNTING HOLES / TEST POINTS** 



## **CONNECTORS**





SUMEC MK IV aka SMD-V3 board

Made by Bismarx aka MenMenson

CONTACT: Savva Popov, menmenson09@gmail.com, +420 605 570 366

Made in Prague, Czech Republic

SPS NA PROSEKU

Sheet: /MECHANICS/

File: MECHANICS.kicad\_sch

Title: SUMEC\_MK\_IV

| ······             |                  |  |   |             |  |
|--------------------|------------------|--|---|-------------|--|
| Size: A4           | Date: 2024-07-15 |  |   | Rev: v3.0.0 |  |
| KiCad E.D.A. 8.0.3 |                  |  |   | ld: 7/8     |  |
|                    |                  |  | - | •           |  |

