Spy Cam Installation Manual

for the Raspberry Pi and Raspberry Pi Zero W

Topic: Installation



Table of Contents

Overview	3
Document Scope	3
Features	
Terminology	∠
Prerequisites	5
Required Hardware	5
Required Software	6
Required Security	8
Helpful Links to get you started	8
Pre-Installation	, 9
PROCEDURE 0: Load any Debian based operating system onto the Micro SD Card	9
PROCEDURE 1: Update the Raspberry Pi Operating System	. 10
PROCEDURE 2: Option 1: Download the SpyCam solution from GitHub onto your laptop or host computer.	
PROCEDURE 2: Option 2: Download the SpyCam solution from GitHub onto the RPi	. 12
PROCEDURE 3: (Optional but recommended) Update the configuration file to personalize your installation.	
Installation	. 18
PROCEDURE 1: Run install.sh	. 18
PROCEDURE 2: Stubbed for now	. 20
PROCEDURE 3: Stubbed for now.	. 21
Appendix A: Supplementary Instructions	. 22
PROCEDURE: Format the USB Storage using Linux and Edisk	22

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

Overview

Document Scope

This document is written to instruct the user with basic Raspberry Pi knowledge on how to build a motion-activated security camera on the Raspberry Pi using the packaged tar file named, <code>spycam_scripts.tar</code>. The actual camera to be installed comes from https://elinux.org/RPi-Cam-Web-Interface. This was chosen over the well written and popular MOTIONEYEOS (https://elinux.org/RPi-Cam-Web-Interface. This was chosen over the well written and popular MOTIONEYEOS (https://elinux.org/RPi-Cam-Web-Interface. This was chosen over the well written and popular MOTIONEYEOS is bare metal RPi image and does not provide the needed functionality to automate the IOT features of this solution. If you are a NOOB or new to the Raspberry Pi or if all you are after is a working camera, then I suggest you try MOTIONEYEOS first and play around with it.

The installation guide applies to both the Raspberry Pi 3B and the Raspberry Pi Zero W. This solution assumes the RPi will use the SpyCam over a wireless connection, or wifi to connect to your router. Initial set up for the Raspberry Pi 3B can be over Ethernet. This solution is constructed to allow a headless installation, provided you follow the instructions on how to set up the configuration file before you boot up the RPi. See *PROCEDURE 3* under the Pre-Installation section.

General RPi setup is not explicitly covered in this document, but uses hyperlinks to refer you to vendor downloads and instructions on how to choose and load the operating system onto a Micro SD card. This solution was built on a PI Zero W using Raspbian Stretch as the base Operating System (see https://www.raspberrypi.org/downloads/raspbian/).

Features

Features Overview

- Easy installation. One script does all the work. One configuration file contains all the various settings found in the installed software configuration files. Personalize your setup in a single configuration file and have it update the other configuration files.
- Built in motion detection can send you emails and video attachment of intruder when the motion detection is triggered.
- Installs proven software from credible vendors. This solution installs the RPi Cam as taken from https://elinux.org/RPi-Cam-Web-Interface. It also updates V4L2 binaries and takes care of loading and installing any dependencies.
- Optional IOT baked in. SpyCam turns off when it detects your presence. Turns back on when you leave.
- Optional External USB storage is automatically formatted, mounted and used to hold your historical videos captured by SpyCam.
- Local Video Storage manages its own capacity and grooms off the oldest video when local space starts to fill up the SD card.

Features Details

1. One stop installation. Scripts pull down source(s)¹ and installs the needed binaries. The install script uses a configuration file, found in ./scripts/boot/swat.config to instruct the install.sh what settings to use for your personal setup. After install.sh has run, the configuration file, swat.config is moved to the /boot directory of the RPi image, where you can load the SD into your laptop and change the swat.config using your laptop as the contents of /boot are readable and updatable.

http://git.linuxtv.org/v4l-utils.git https://github.com/silvanmelchior/RPi_Cam_Web_Interface.git

- 2. Built in motion detection can send you emails and video attachment of intruder when the motion detection is triggered. The motion detection continues to capture new video as long as there is motion detected. In order to keep from filling up your email and risk getting you banned as a bot², only the first video captured is sent to you, alerting you to intrusion. You will continue to receive new video emails once a minute until motion is no longer detected.
- 3. Optional IOT intelligence baked in. Camera turns off in your presence. Camera turns back on when you leave. You can choose to use your Cell Phone as a beacon, or use a Bluetooth iBeacon to talk to your RPi SpyCam announcing your presence. The configuration file has an entry for the cell phone IP and Bluetooth addresses. If you fill this in, the SPYCAM will turn off the camera when it detects the Cell Phone. The Cell Phone IP is scraped from the Wireless router; the Bluetooth search is simply looking for the Bluetooth address listed in the configuration file.
- 4. Formats and mounts a USB for secondary storage, providing you attach an empty USB to the RPi before running the install.sh script. The install solution wipes the USB and creates a VFAT mount to /media/cam, PROVIDING THIS IS THE ONLY USB PLUGGED INTO THE RPi when you run install.sh. It technical terms, the install process is looking for /dev/sda as the external storage to format and mount.
- 5. Self-maintaining storage. The videos are captured in /var/www/cam/media. If you start to fill up this directory, a cron job (a scheduled job running as root) will groom off the oldest video once an hour until appropriate available storage on /var is obtained. If you inserted a USB drive to the RPi before running the install.sh, then there should be a mounted drive where the videos are automatically copied from /var/www/cam/media/ to /media/cam/media.
- 6. Headless maintenance baked in. Once you have installed the spycam, there are two options for headless maintenance. You are always free to make changes are you see fit:
 - a. Reminder, you can change the /boot/swat.config file in your laptop, as it is readable from the SD card. To make your changes effective will require 2 reboots, 1 to update the changes and the other to make the changes take effect.
 - b. From the RPi itself, You can change the following by simply making the change to /boot/swat.config, run the command: sudo systemctl start swat.service and rebooting.
 - c. Here are the settings, which are explained in the terminology paragraph, you can change in swat.config:
 - i. export MY_ROUTER_NAME="DEA_Surveillence"
 - ii. export MY_ROUTER_PW="NoDrugs4U"
 - iii. export MY_ROUTER_IP="192.168.1.1"
 - iv. export MY_SERVER_WIFI_IP="192.168.1.184"
 - v. export MY_SERVER_STATIC_IP="192.168.1.194"
 - vi. export MY_EMAIL_MAIL_HUB="mailhub=dea.gov:587"
 - vii. export MY_EMAIL_ADDRESS="bucbowie@dea.gov"
 - viii. export MY_EMAIL_PW="tscggvjtgmylcaca"

Terminology

- 1. Raspberry Pi, Rpi, RPi refer to either the Raspberry Pi 3B or the Raspberry Pi Zero W. The installation itself is agnostic, but there are hardware differences between models Raspberry Pi 3B and the Raspberry Pi Zero W. These differences will be stated, when the content applies only to the Raspberry Pi Zero W.
- 2. Connection is used as a networking term, to refer to whether you are connected to the internet using ethernet (eth0) or wireless (wifi) (wlan0). The Raspberry Pi Zero W, does NOT have an Ethernet adapter built in, so we assume all connectivity on the Pi Zero W will be wifi.
- 3. eth0 is the generic term for the Ethernet connection. Your set up may have the Ethernet adapter using a different alias other than, eth0. From the command line, you can run, ifconfig, to list the networking information, including the Ethernet and Wireless aliases, such as eth0 and wlan0.

 $^{^{2}}$ bot - so many emails in such a short time that the email provider thinks you are remote computer sending spam

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

- 4. wlan0 applies to the generic term for the wireless connection. See terminology item 3 for addition info.
- Configuration File Terms:
 - a. SWAT.CONFIG ROUTER INFO
 - i. MY_ROUTER_NAME is the SSID of your wireless router.
 - ii. MY_ROUTER_PW is the PSK or password to connect to your wireless router.
 - iii. MY_ROUTER_IP is the I.P. address of your wireless router. As most home wireless routes use the wireless router for a DSN server (assigns IP to connecting computers), the suffix of the IP address is generally 1 as in 192.168.1.1.
 - b. SWAT.CONFIG Raspberry Pi INFO
 - i. MY_SERVER_WIFI_IP is the desired wireless IP of your RPi running the SpyCam. It generally refers to the /etc/dhcpcd.conf entry: wlan0.
 - ii. MY_SERVER_STATIC_IP is the ethernet or wired (has a network cable plugged into the network jack) address you wish to use for the RPi running the SpyCam. The process to change the MY_SERVER_STATIC_IP will only work if you are physically using an ethernet connection at the time you are making changes to /boot/swat.config.
 - c. SWAT.CONFIG IOT INFO
 - i. CELL_STATIC_IP is the IP of your Cell Phone. Generally this found on the Cell phone under "About" or "Network". We are looking for an IP Address in the format aaa.bbb.ccc.ddd, where there are 4 numbers separated by 3 periods.
 - ii. CELL_WIFI_MAC_ADDRESS is the MAC address is the MAC address of your Cell Phone wireless network card. Generally found in the same place as the Cell Phone IP. See CELL_STATIC_IP line item above this line.
 - CELL_BLUETOOTH_ADDRESS is the Bluetooth address being broadcast by either your Cell Phone or a separate iBeacon.
 - d. Option SWAT.CONFIG Email INFO
 - MY_EMAIL_HUB is the email provider you have an account with which allows one
 to send emails from a remote server, such as the RPi SpyCam, providing you also specify
 your email credentials. A GMAIL example is smtp.gmail.com:587.
 - MY_EMAIL_ADDRESS is the email address you want your motion detection alerts to go to.
 - iii. MY_EMAIL_PW is the password for your email account you are using to send videos.

Prerequisites

Required Hardware

Hardware	Purpose	Description
	Any Micro SD card with at least 8 GB of space. We	
	prefer the class 10 over the class 1 or 4. The higher	
	end (more expensive) Micro SD cards are faster and	
	last longer. A fine example of the higher end SD card	
	is, Sony 32GB High Speed Class 10 UHS-1 Micro	
	SDHC up to 95MB/s Memory Card (SR32UXA/TQ).	
	In addition to looking for class "10 ", review the	Will hold all the software for the
	transfer speed of the card. The faster the transfer	Raspberry Pi. This holds the software to
	speed, the better performance (up to a point of	boot up, and will hold the scripts we are
Micro SD Card	matching the USB 2 transfer rate.)	going to install on the RPi.
	The computer or server that we are installing the	Can be either the Raspberry PI 3B or the
Raspberry Pi	SpyCam software and scripts.	Raspberry Pi Zero W.
Raspberry Pi		Comes in 2 flavors, the standard camera
Camera	Detect motion and collect video.	and the Pi NOIR, which can detect and

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

	capture InfraRed images. The standard
	camera has a clearer picture display for
	daylight or well lit areas, over the Pi NOIR.
	The Pi NOIR camera can capture InfraRed
	images if there is InfraRed light available. If
	not, the the PI NOIR offers no advantage
	over the standard camera for general use.
	We suggest a 5volt, 2.4 amp power source.
	The Raspberry Pi Zero W can run on 5volt,
	1 amp power, but the camera and optional
	USB attached storage will put a higher
	load or demand on the Raspberry Pi Zero
Plugs into wall and powers the Rpi.	W.
To display the computer's output.	
	Assuming the reader knows what a
	keyboard and mouse are, we point out the
	Raspberry Pi Zero W has only 1 micro USB
	adapter, so we suggest a Bluetooth
	Keyboard and mouse combo, which will
Allow user to directly interact and make changes to	require an Micro USB to USB Female
the RPi.	adapter.
	The Raspberry Pi 3B uses the standard
	HDMI connection size. The Raspberry Pi
	Zero W has a Micro HDMI adapter and
Connects the RPi to the Monitor or "Screen". The	requires an additional adapter listed below
Raspberry Pi Zero W requires the Optional Micro	to connect the Raspberry Pi Zero to the
HDMI to Female HDMI adapter listed below.	HDMI cable itself.
	Any USB 2 or 3 storage device. The
1. To offload the video captured and written locally	Raspberry Pi Zero W will require a Micro
on the Micro SD card.	USB to USB Female adapter, as ALL the
2. Allow user to remove the USB storage and view	adapters on the Raspberry Pi Zero W are
the videos on a different computer.	micro models.
Attaches to the Raspberry Pi Zero W in the Micro	
	Allow user to directly interact and make changes to the RPi. Connects the RPi to the Monitor or "Screen". The Raspberry Pi Zero W requires the Optional Micro HDMI to Female HDMI adapter listed below. 1. To offload the video captured and written locally on the Micro SD card. 2. Allow user to remove the USB storage and view

Required Software

Topic	Software	Purpose
		Any Debian distribution for the Raspberry Pi . Our solution used
		Raspbian, version, Stretch. This can be found at the Raspberry Pi
		download page. See:
Raspberry Pi	The base Operating System	https://www.raspberrypi.org/downloads/raspbian/
Internet	GitHub.com access to download scripts.tar	SpyCam installation package, which includes the installation PDF.
		Initialize or wipe clean the Micro SD card.
	Download link:	Here is the online doc:
SD Formatter	https://www.sdcard.org/downloads/formatter_4/	https://www.sdcard.org/consumers/pdf/2017SDA_brochure_eng.pdf

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

		Flashes or writes software onto the Micro SD card.
		Read more about it here:
Win32 Disk	Download link:	https://www.raspberrypi.org/documentation/installation/installing-
Imager	https://sourceforge.net/projects/win32diskimager/	images/windows.md
FileZilla or a		
File Transfer		
program		Allows file transfer from Laptop or one computer to the Raspberry Pi.
using SCP or	Download link:	Used to copy the downloaded GitHub SpyCam download and loaded
SFTP.	https://filezilla-project.org/download.php?show_all=1	onto the Raspberry Pi.

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

Required Security

Hardware	Needed	Purpose
		The SpyCam must connect to the internet
		using a wireless connection, if the SpyCam
		is to email the user when motion is
		detected. The SpyCam runs without
	Credentials:	internet connectivity. The difference is
	 The SSID or WiFi Router name. 	simply the ability to notify the user of
Wireless Router	2. The Wifi password or PSK.	motion as it happens.
	Credentials to a mail server. Can be smtp.gmail.com	
	or smtp.mail.yahoo.com. This requires a username	Send real time notification of motion, with
Mail server	and some sort of password or authentication token.	video attached to the email.

This package will install a new user named, swat. It will be created as user=swat, password=swat. The swat user will be set up as a service account whose only function is to hold the automation scripts for the root user to run. There is no logging into your system as user swat; it is set up to be secure and only available/used by the system itself.

For the SpyCam itself, it is suggested you change the default password for the pi user. The two best known options for changing the pi user password are:

- 1. Change the default password for user pi from the command line.
- 2. Change the default password for user pi using the raspi-config tool.

Helpful Links to get you started

No point in reinventing the wheel, here is your Google link to search how to change the password for the pi user:

https://www.google.com/search?ei=HheVWpmAK6HZ5gL0jbewCg&q=raspberry+pi+change+password&og=raspberry+pi+change+password&gs_l=psy-

<u>ab.3..0l2j0i22i30k1l5.17637.27543.0.27813.44.36.8.0.0.0.179.3099.25j10.35.0..3..0...1.1.64.psy-ab..1.43.3162...0i131k1j0i67k1j35i39k1j0i131i20i264k1j0i20i264k1j0i13k1j0i13i30k1j0i8i13i30k1j0i13i5i30k1j0i22i10i30k1.0.DE_KaDhezF8</u>

For transferring files from your laptop or host computer to the Raspberry PI, you can GOOGLE that topic. Here is an example link:

https://www.raspberrypi.org/documentation/remote-access/ssh/sftp.md

For installing the Raspbian Operating System onto your Micro SD card, there are many helpful links Google will provide. Here is an example link:

Very Basic (NOOBS): https://www.raspberrypi.org/documentation/installation/noobs.md
Basic (using Raspbian): Format (wipe) the Micro SD card: https://www.raspberrypi-spy.co.uk/2015/03/how-to-format-pi-sd-cards-using-sd-formatter/
AND

https://www.raspberrypi.org/documentation/installation/installing-images/

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1


Pre-Installation

PROCEDURE 0: Load any Debian based operating system onto the Micro SD Card.


Step	V	Action / Expected Result
1.		Action: Load a Debian based operating system onto the Micro SD Card, intended for use by our Raspberry Pi.
		Plenty of fine information on this from the vendor and compliments of the Internet: https://www.raspberrypi.org/documentation/installation/installing-images/
		Expected Result: The Micro SD card should have the base operating system loaded onto it.

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

PROCEDURE 1: Update the Raspberry Pi Operating System



PROCEDURE 2: Option 1: Download the SpyCam solution from GitHub onto your laptop or host computer.



PROCEDURE 2: Option 2: Download the SpyCam solution from GitHub onto the RPi

Step	Ø	Action / Expected Result		
1.		Action: Pull SpyCam solution from GitHub: https://github.com/bucbowie/spycam		
		Command: wget https://github.com/bucbowie/spycam/archive/master.zip		
		Expected Result: You should see something like this:		
		pi@rhea:~ \$ ls -lart total 112		
		-rw-rr 1 pi pi 675 Nov 28 20:22 .profile -rw-rr 1 pi pi 220 Nov 28 20:22 .bash logout		
		-rw-rr 1 pi pi 220 Nov 28 20:22 .bash_logout -rw-rr 1 pi pi 3523 Nov 28 20:22 .bashrc		
		-rw-rr 1 pi pi 12055 Mar 4 12:11 master.zip << This guy!		
2.		Action: Unzip master.zip.		
		Command: # unzip master.zip		
		Expected Result: You should see something like this:		
		pi@rhea:~ \$ unzip master.zip Archive: master.zip		
		71daa0a613b7b14d283ef89da7d25df6bdc2940a creating: spycam-master/		
		creating: spycam-master/ extracting: spycam-master/README.md		
		<pre>inflating: spycam-master/spycam_scripts.tar</pre>		
3.		Action: Change into spycam-master directory and untar spycam_scripts.tar.		
		Commands: # sudo cd spycam-master		
		# sudo tar -xvf ./spycam_scripts.tar		
		Expected Result: You should see something like this:		
		<pre>pi@rhea:~/spycam-master \$ ls -lart total 104</pre>		
		drwxr-xr-x 2 jaskew sudo 4096 Feb 24 06:04 swat_install		
		drwxr-xr-x 4 jaskew sudo 4096 Feb 25 11:27 scripts -rwxr-xr-x 1 jaskew sudo 8650 Feb 28 05:41 install.sh		
		-rw-rr 1 pi pi 71680 Feb 28 06:00 spycam_scripts.tar		
		-rw-rr 1 pi		

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

PROCEDURE 3: (Optional but recommended) Update the configuration file to personalize your installation.

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

		-
Step	V	Action / Expected Result

	1		
1.		Action: Review the spycam/scripts/boot/swat.conf file.	
		Expected Result: You should see something like this:	
		#######################################	1
		# Server Hardware	# #
		######################################	•
		export ETHERNET_DEVICE="eth0"	The Ethernet
		device type found in /etc/dhcpcd.conf	
		·	# Allows you
		to override the Ethernet network of eth0.	
		<pre>export WIFI_DEVICE="wlan0" device type found in /etc/dhcpcd.conf.</pre>	The wireless
			Allows you
		to override the wireless network of wlan0.	AIIOWS YOU
		#	#
		# The next 2 lines are for modifying the router	‡
		# credentials. The settings are found in	
			#
			‡
			‡
			‡ +
		# Example: # export MY ROUTER NAME=""	‡ +
		# export MY ROUTER PW=""	†
		#	# #
		"	The SSID of your
		router.	
		export MY_ROUTER_PW="NoDrugs4U"	The PSK or
		password to your router.	
		export MY_ROUTER_IP="172.16.1.1"	The IP of your
		router.	
		#	‡ 4
		# The next 2 lines are for STATIC IP. If you wish # to use DHCP and have the system set the server IP, #	‡ +
		# to use DMCP and have the system set the server iP, # then blank them out.	† L
		# These settings are found in /etc/dhcpcd.conf.	*
		# You can modify the settings manually if you wish to	#
		I	
		# Example:	‡
		"	
		# export MY_SERVER_STATIC_IP=""	
		#	# # T S :
			If you are using
		STATIC IP, this is the desired Wireless IP export MY SERVER STATIC IP="172.16.1.194"	If you are using
		STATIC IP, this is the desired Ethernet IP	, if you are using
		export MY CAMERA NAME="Puppie Cam `echo \${MY SERVER WI	IFI IP} cut -d"."
		-f4 sed 's/"//' #Unique Camera name	
		#######################################	‡
		"	‡
		#######################################	
		# The next 3 settings are optional and used for the	
		# optional IOT presence detection, where the	‡
		# camera will turn off when your cell phone is	Τ μ
		<pre># detected near by. Same goes for the BLUETOOTH # address, if you are using an iBeacon.</pre>	† L
	1	π address, if you are using an ibeacon.	т

Step	$\overline{\mathbf{V}}$	Action / Expected Result
		# If you do not wish to use the IOT automatic # presence detection to turn off the camera, simply # blank out the values for the next 3 lines. # Example: # export CELL_STATIC_IP="" # # export CELL_STATIC_IP="" # # export CELL_BLUETOOTH_ADDRESS="" # export CELL_BLUETOOTH_ADDRESS="" # IP of your Cell Phone. Optional setting, but used for IOT. export CELL_WIFI_MAC_ADDRESS="80:01:86:74:18:d6" # MAC Address of your Cell Phone Wireless Network Card. export CELL_BLUETOOTH_ADDRESS="04:C2:3D:AE:42:7E" # Bluetooth address of your phone or any iBeacon you wish to use. ####################################
2.		Action: Review swat.config by paragraph. Start with the router information. If you do not want the scripts managing your Router information, simply blank out the values in swat.config and set them in /etc/wpa_supplicant/wpa_supplicant.conf. Expected Result: You should see something like this: export MY_ROUTER_NAME="" export MY_ROUTER_PW="" * The next 2 lines are for modifying the router

Step	\square	Action / Expected Result	
3.		Action: Review swat.config STATIC IP paragraph. If you are not using static IP, but relying on DHCP for the system to assign your RPi an IP address, then set the following to have blanks for the values. Expected Result: You should see something like this: export MY_SERVER_WIFI_IP="" export MY_SERVER_STATIC_IP=""	
		# The IP of your router. # The next 2 lines are for STATIC IP. If you wish # # to use DMCP and have the system set the server IP, # # then blank them out. # # These settings are found in /etc/dhcpcd.conf. # # you can modify the settings manually if you wish to# # bypass this scripts modifying them. # # Example: # export MY_SERVER_WIFI_IP="" # # export MY_SERVER_STATIC IP="" # # Export MY_SERVER_STATIC IP="" # # Export MY_SERVER_WIFI_IP="172.16.1.184" # If you are using STATIC IP, this is the desired Wireless IP # * ********************************	
4.		Action: Review swat.config (optional) IOT Presence detection paragraph. These settings are for the optional IOT detection of your cell phone's IP address or Bluetooth address or the Bluetooth address of any iBeacon you wish to use. If you do not want this option enabled, simply blank out the values. Expected Result: You should see something like this: export CELL_STATIC_IP="" export CELL_WIFI_MAC_ADDRESS="" export CELL_BLUETOOTH_ADDRESS="" * presence detection to turn off the camera, simply * blank out the values for the next 3 lines.	


Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

Step	V	Action / Expected Result
5.		Action: Review swat.config email settings. These settings are optional and allow you to be sent an email with a video attachment when the motion detection is triggered. To disable, simply blank out the values. Expected Result: You should see something like this: Export MY_EMAIL_MAIL_HUB="" Export MY_EMAIL_ADDRESS="" Export MY_EMAIL_ADDRESS="" Export MY_EMAIL_PW="" * Script control ** ** ** ** ** ** ** ** **
6.		Action: Save your results in swat.config. We are done and ready to install.

Installation

PROCEDURE 1: Run install.sh

Step	$\overline{\mathbf{A}}$	Action / Expected Result
1.		Action: From command line, run install.sh
		Command: # sudo ./install.sh
		Expected Result: You should see something like this:



Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

PROCEDURE 2: Stubbed for now

Step	$\overline{\mathbf{V}}$	Action / Expected Result
1.		Action:.
		Command: Grant
		Expected Result: You should see something like this:
2.		End of section

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

PROCEDURE 3: Stubbed for now.

Step	V	Action / Expected Result
1.		Action:.
		Command: Grant
		Expected Result: You should see something like this:
2.		Action:.
		Command: Grant
		Expected Result: You should see something like this:
3.		Action:.
J.		Command: Grant
		Expected Result: You should see something like this:
		Expected Result. Tou should see something like this.
4.		
5.		
6.		
7.		
8.		
9.		
10.		

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

Appendix A: Supplementary Instructions

PROCEDURE: Format the USB Storage using Linux and Fdisk.

Step	V	Action / Expected Result
1.		Action : After plugging in the usb drive, run blkid to verify the partition. Look for the /dev/sd line item.
		Command: blkid
		Expected Result: You should see something like this:
		root@rhea:~# blkid
		<pre>/dev/mmcblk0p1: LABEL="boot" UUID="0298-4814" TYPE="vfat" /dev/mmcblk0p2: LABEL="rootfs" UUID="d4f0fd64-ad9d-4cfd-aa</pre>
		/dev/mmcblk0: PTUUID="b0e18a51" PTTYPE="dos"
		/dev/sda: PTUUID="86298c1d" PTTYPE="dos"
2.		Action: From command line, run fdisk against the USB drive identified in step 1.
		Command: fdisk /dev/sda
		Expected Result: You should see something like this:
		root@rhea:~# fdisk /dev/sda
		Welcome to fdisk (util-linux 2.29.2).
		Changes will remain in memory only, until you decide to write them. Be careful before using the write command.

Step	Ø	Action / Expected Result
3.		Action: Initialize the USB partition and create a new partition
		Commands:
		 # create a new empty DOS partition table
		n # add a new partition
		Expected Result: You should see something like this:
		Command (m for help): n
		Partition type p primary (0 primary, 0 extended, 4 free) e extended (container for logical partitions) Select (default p):
		Choose p , the default, or you can simply press <enter>.</enter>
		Take the defaults for the next 3 choices:
		<pre>Partition number (1-4, default 1): First sector (2048-30302207, default 2048): Last sector, +sectors or +size{K,M,G,T,P} (2048-30302207, default 30302207):</pre>
		Commands:
		t - #change a partition type
		The type we want is: HPFS/NTFS/exFAT
		w - write table to disk and exit
		partprobe - # refresh the system partition table
		mkfs.vfat /dev/sda1 - # Create a Linux/Windows readable partition.

Dept. Research and Development	Raspberry Pi Projects	Author: J. Askew
Date: 2018-03-04	Subject: Spy Cam Installation	Draft-Version 1.1

Step	$\overline{\mathbf{A}}$	Action / Expected Result						
4.		Action: Issue mount to test the newly formatted USB drive.						
		Command: mount -t vfat -o rw, nofail /dev/sdal /media/cam						
		Expected Result: You should see something like this: (Command: df -k)						
		root@rhea:~# df	-k					
		Filesystem	1K-blocks	Used	Available	Use%	Mounted on	
		/dev/root	14791776	4803648	9324204	35%	/	
		devtmpfs	443792	0	443792	0왕	/dev	
		tmpfs	448400	0	448400	0왕	/dev/shm	
		tmpfs	448400	11652	436748	3%	/run	
		tmpfs	5120	4	5116	1%	/run/lock	
		tmpfs	448400	0			/sys/fs/cgr	
		/dev/mmcblk0p1	41853	21329				
		tmpfs	89680	0	89680	0%	/run/user/1	
		tmpfs	89680	0	89680	0%	/run/user/1	
		tmpfs	89680	0	89680	0%	/run/user/1	
		/dev/sda1	15135280	8	15135272	1%	/media/cam	
5.		Action: Update /etc/fstab to persist the mount.						
		Add the following line to the /etc/fstab:						
		Commands: /dev/sda1 /media/cam vfat defaults, noatime, nofail, rw 0 0						

END OF DOCUMENT