#### Lesson 29 RC522 RFID Module

#### Introduction

In this lesson, you will learn to how to apply the RC522 RFID Reader Module on Mega 2560. This module uses the Serial Peripheral Interface (SPI) bus to communicate with controllers such as Arduino, Raspberry Pi, beagle board, etc.

## **Hardware Required**

- √ 1 \*RexQualis Mega 2560
- ✓ 1 \*RC522 RFID module
- ✓ 7 \* F-M Jumper Wires



### **Principle**

#### **RC522**

The MFRC522 is a highly integrated reader/writer for contactless communication at 13.56 MHz. The MFRC522 reader supports ISO 14443A / MIFARE® mode.

The MFRC522's internal transmitter part is able to drive a reader/writer antenna designed to communicate with ISO/IEC 14443A/MIFARE® cards and transponders without additional active circuitry. The receiver part provides a robust and efficient implementation of a demodulation and decoding circuitry for signals from ISO/IEC 14443A/MIFARE® compatible cards and transponders. The digital part handles the complete ISO/IEC 14443A framing and error detection (Parity & CRC). The MFRC522 supports MIFARE® Classic (e.g. MIFARE® Standard) products. The MFRC522 supports contactless communication using MIFARE® higher transfer speeds up to 848 kbit/s in both

directions.

Various host interfaces are implemented:

- ✓ SPI interface
- ✓ Serial UART (similar to RS232 with voltage levels according pad voltage supply)
- ✓ I2C interface.
- ✓ The figure below shows a typical circuit diagram, using a complementary
  antenna connection to the MFRC522.

### **Code interpretation**

#### Typical pin layout used:

Signal	MFRC522 Reader/PCD Pin	Arduino Uno Pin	Arduino Mega Pin	Arduino Nano v3 Pin	Arduino Leonardo/Micro Pin	Arduino Pro Micro Pin							
							RST/Reset	RST	9	5	D9	RESET/ICSP-5	RST
							SPI SS	SDA(SS)	10	53	D10	10	10
SPI MOSI	MOSI	11 / ICSP-4	51	D11	ICSP-4	16							
SPI MISO	MISO	12 / ICSP-1	50	D12	ICSP-1	14							
SPI SCK	SCK	13 / ICSP-3	52	D13	ICSP-3	15							

#include <SPI.h>

#include <MFRC522.h>

```
#define RST_PIN 5 // Configurable, see typical pin layout above

#define SS_PIN 53 // Configurable, see typical pin layout above

MFRC522 mfrc522(SS_PIN, RST_PIN); // Create MFRC522 instance
```

```
/* Set your new UID here! */
#define NEW_UID {0xDE, 0xAD, 0xBE, 0xEF}
MFRC522::MIFARE Key key;
void setup() {
 Serial.begin(9600); // Initialize serial communications with
the PC
                    // Do nothing if no serial port is opened
 while (!Serial);
(added for Arduinos based on ATMEGA32U4)
 SPI.begin();
             // Init SPI bus
 mfrc522.PCD_Init(); // Init MFRC522 card
 Serial.println(F("Warning: this example overwrites the UID of your UID
changeable card, use with care!"));
 // Prepare key - all keys are set to FFFFFFFFFF at chip
delivery from the factory.
 for (byte i = 0; i < 6; i++) {
   key.keyByte[i] = 0xFF;
 }
}
// Setting the UID can be as simple as this:
//void loop() {
// byte newUid[] = NEW_UID;
// if ( mfrc522.MIFARE_SetUid(newUid, (byte)4, true) ) {
```

```
// Serial.println("Wrote new UID to card.");
// }
// delay(2000);
//}
// But of course this is a more proper approach
void loop() {
 // Look for new cards, and select one if present
 if
    (!
                     mfrc522.PICC IsNewCardPresent() | !
mfrc522.PICC ReadCardSerial()) {
   delay(1000);
   return;
 }
 // Now a card is selected. The UID and SAK is in
mfrc522.uid.
 // Dump UID
 Serial.print(F("Card UID:"));
 for (byte i = 0; i < mfrc522.uid.size; i++) {
   Serial.print(mfrc522.uid.uidByte[i] < 0x10 ? " 0" : " ");
   Serial.print(mfrc522.uid.uidByte[i], HEX);
 }
 Serial.println();
 // Dump PICC type
//MFRC522::PICC_Type piccType =
```

```
mfrc522.PICC_GetType(mfrc522.uid.sak);
// Serial.print(F("PICC type: "));
// Serial.print(mfrc522.PICC_GetTypeName(piccType));
// Serial.print(F(" (SAK "));
// Serial.print(mfrc522.uid.sak);
// Serial.print(")\r\n");
// if ( piccType != MFRC522::PICC_TYPE_MIFARE_MINI
     && piccType != MFRC522::PICC_TYPE_MIFARE_1K
//
//
     && piccType != MFRC522::PICC_TYPE_MIFARE_4K) {
      Serial.println(F("This sample only works with MIFARE
Classic cards."));
//
    return;
// }
 // Set new UID
 byte newUid[] = NEW UID;
 if (mfrc522.MIFARE SetUid(newUid, (byte)4, true)) {
   Serial.println(F("Wrote new UID to card."));
 }
 // Halt PICC and re-select it so DumpToSerial doesn't get
confused
 mfrc522.PICC HaltA();
 if
       ( ! mfrc522.PICC IsNewCardPresent()
                                                   ll l
```

```
mfrc522.PICC_ReadCardSerial() ) {
    return;
}

// Dump the new memory contents


Serial.println(F("New UID and contents:"));

mfrc522.PICC_DumpToSerial(&(mfrc522.uid));


delay(3000);
}
```

# **Experimental Procedures**


### **Step 1:Build the circui**



### **Schematic Diagram**




Step 2:Open the code:MF-RC522\_RFID\_Code



Step 3:Attach Arduino Mega 2560 board to your computer via USB cable and check that the 'Board Type' and 'Serial Port' are set correctly.


Step 4:Load the Library:rfid




**Step 5:Upload the code to the RexQualis Mega 2560 board.** 

Step 6:Open the Serial Monitor, then you can see the data as blow:

(How to use the Serial Monitor is introduced in details in Lesson 0 Preface)





You can see the video of the experiment results on YouTube:

https://youtu.be/NeTe0L7ZU30

If it isn't working, make sure you have assembled the circuit correctly, verified and uploaded the code to your board. For how to upload the code and install the library, check Lesson 0 Preface.