INSTRUCTIONS:
Fill out the hazard analysis and risk assessment below.
HA-001 should be for the lane departure warning function as discussed in the lecture.
HA-002 should be for the lane keeping assistance function as discussed in the lecture.
Then come up with your own situations and hazards for the lane assistance system. Fill in the HA-003 and HA-004 rows.
When finished, export your spreadsheet as a pdf file so that a reviewer can easily see your work.

| Hazard ID | rd Situational Analysis | | | | | | | Hazard Identification | | | | | Hazardous Event Classification | | | | | | Determi | nation of ASIL and Safety Goals | | | | |
|--------------|-------------------------|-----------------|-------------------------|------------------------------------|-------------------|-----------------------------|--------------------------|---|--|---|--|--|--|---------------------------------|------------------------------|---|--|---|---|--|-----------------------|---|--|------|
| | Operation | nal Mode O | Operational Scenario | Environmental Details | Situation Details | Other Details (optional) | Item Usage (function) | Situation Description | Function | Deviation | Deviation Details | Hazardous Event (resulting effect) | Event Details | Hazardous Event Description | Exposure (of situation) | Rationale (for exposure) | Severity (of potential harm) | Rationale (for severity) | Controllability (of hazardous event) | Rationale (for controllability) | ASIL Determination | Safety Goal | | |
| HA-001 | OM03 - Non | mal driving OS(| S04 - Highway | EN06 - Rain (slippery road) | SD02 - High speed | | IU01 - Correctly used | Normal Driving on a Highway at High Speed during Rain with active Lane Departure Warning function | Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver with haptic feedback | DV04 - Actor effect is too much | Oscillating steering torque exceeds limit | EV08 - Collision with other vehicle | Vehicle crashes into traffic or road infrastructure with injury to driver and any others present | Driver loses control of vehicle | E3 - Medium probability | Activation of the lane departure warning system during highway driving at high speed is a medium probability event. | S3 - Life-threatening or fatal injuries | On highway, speed of vehicle is expected to be high | C3 - Difficult to control or uncontrollable | Since the steering wheel rotates uncontrollably, it will be difficult for the average driver to control the vehicle at high speed in the rain | С | The oscillating steering torque from the LDW function shall be limited | | |
| HA-002 | OM03 - Norr | mal driving OS | S03 - Country Road | EN01 - Normal conditions | SD02 - High speed | | IU02 - Incorrectly used | Normal Driving on coutry roads during normal conditions with high speed and the system is correctly used. | Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane | | LKA is always active. Driver is taking hands off the wheel. | EV08 - Collision with other vehicle | The lane keeping assistance function is always activated and the driver loses control of the vehicle. | Driver loses control of vehicle | E2 - Low probability | Driver abusing the LKA as Autopilot during highway driving at high speeds is a low probability event | S3 - Life-threatening or fatal injuries | On highway, speed of vehicle is expected to be high | C3 - Difficult to control or uncontrollable | Since driver has his hands off the wheel, he cannot control the vehicle | В | The LKA function shall be time limited and the additional steering torque shall end after a given time interval | | _ |
| HA-003 | OM03 - Non | mal driving OS | S04 - Highway | EN04 - Snowfall (degraded view) | SD02 - High speed | | IU01 - Correctly used | Normal Driving on a Highway at High Speed during Snowfall with active Lane Keeping Assistance function | Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane | DV10 - Actor effect is reverse | Steering torque applied, but in the wrong direction | EV08 - Collision with other vehicle | Vehicle crashes into traffic or road infrastructure with injury to driver and any others present | Driver loses control of vehicle | E2 - Low probability | Activation of the lane departure system while driving on highway during snowfall at high speed is alow probability event | S3 - Life-threatening or fatal injuries | Collision at high speed in highly constrained space | C3 - Difficult to control or uncontrollable | Since LKA generates an entirely unexpected steering input and with little time to react, a driver will typically not be able to control the vehicle | В | The LKA function shall be deactivated during snowfall (degraded view) conditions | | |
| HA-004 | OM03 - Nori | mal driving OS | S03 - Country Road | EN06 - Rain (slippery road) | SD03 - Low speed | | IU01 - Correctly used | Normal Driving on a Country Road at Low Speed during Rain with active Lane Keeping Assistance function | Lane Keeping | DV02 - Function unexpectedly activated | LKA corrects driver input while driver attempts to evade obstacle | EV11 - Car spins out of control | Vehicle crashes into traffic or road infrastructure with injury to driver and any others present | Driver loses control of vehicle | E1 - Very Low probability | Evading obstacle on a country road in the rain at low speed is a very low probability event | S3 - Life-threatening or fatal injuries | The vehicle hitting onto an obstacle on country road. | C3 - Difficult to control or uncontrollable | Driver does not expect extra torque in steering wheel and loses control in already difficult to control situation | А | The LKA function shall be deactivated during heavy steering | | |