ArUserHasRole()

Checks if the user is assigned the given role (asynchronous execution).


This function block can only be used for ${\bf redundancy}$ in certain circumstances. Applicable limitations are listed in the following sections:

Local data

Asynchronous execution

Additional information can be found in the <u>Redundancy</u> section.

Function block



Interface

I/O	Parameter	Data type	Description	
IN	Execute	BOOL	Starts execution	
IN	UserName	STRING [128]	Username	
IN	RoleName	STRING [128]	Role name	
OUT	Done	BOOL	Execution completed	
OUT	Busy	BOOL	Currently executing	
OUT	Error	BOOL	Execution failed	
OUT	ErrorID	DINT	If the function block was executed, then this output is always 0 since the function block does not return error codes.	
OUT	HasRole	BOOL	Returns TRUE if the user is assigned the specified role, otherwise FALSE	

The following status codes can be returned:

Name	Werte	Beschreibung
arUSER ERR PARAMETER	-1070585894	The function block was called with an invalid parameter.
arUSER ERR DOES NOT EXIST		The element (user, role, user-role assignment) passed to the function block as a parameter does not exist. It is therefore not possible to edit the element.
arUSER_ERR_INTERNAL	-1070585889	An unexpected internal error has occurred.