



Client : NRF (National Research Foundation)

Project : African VLBI Network (AVN)

Type : Operations Manual





# **AVN ROACH SETUP GUIDE FOR GHANA**

Document number	A0215-1000-0002 DRAFT A
Revision	DRAFT A
Classification	Commercial in Confidence
Author	Charles Copley

Date 03 August 2015

## **DOCUMENT APPROVAL**

	Name	Designation	Affiliation	Date	Signature
Submitted Charles Copley		AVN science processing	SKA SA		
Approved	Anita Loots	Associate Director	SKA SA		

## **DOCUMENT HISTORY**

Revision	Date Of Issue	ECN Number	Comments
Α			

## **DOCUMENT SOFTWARE**

	Package	Version	Filename
Wordprocessor	Libre Office	3.5.7.2	

## **COMPANY DETAILS**

Name	SKA-SA
Physical/Postal	The Park, 3rd Floor
Address	Park Rd

03 August 2015 Page 2 of 26







	Pinelands
	7405
Tel.	+27 21 506 7300
Fax.	+27 21 506 7375
Website	www.ska.ac.za

03 August 2015 Page 3 of 26







## **TABLE OF CONTENTS**

A.REFERENCES	6
DOCUMENT SCOPE	7
Materials and Tools required	7
PROCEDURE FOR AVN ROACHES BEFORE DEPLOYMENT	7
Hardware setup	7
Software Setup	10
PROCEDURE FOR AVN ROACHES DURING DEPLOYMENT	15
HIGH RESOLUTION SPECTROMETER DESIGN SCREENSHOTS	18

## LIST OF TABLES

## LIST OF FIGURES





### **LIST OF TBDs**

## **ABBREVIATIONS**

AVN African VLBI Network

CDR Critical Design Review

DST Department of Science and Technology

DIRCO Department of Industrial Relations and Cooperation

NRF National Research Foundation

PDR Preliminary Design Review

RFI Request for Information

RFP Request for Proposal

SKA Square Kilometre Array

SKA-SA Square Kilometer Array – South Africa

SOW Statement of Work

VLBI Very Long Baseline Interferometery

WBS Work Breakdown Structure

03 August 2015 Page 5 of 26







## a. REFERENCES

1.1. A0200-0000-001, AVN Ghana: URS - Revision 2 (TBD)

03 August 2015 Page 6 of 26







#### **DOCUMENT SCOPE**

This document is intended for use in ROACH preparation at SKA South Africa in Pinelands and eventual deployment at an AVN site. The resources available there are presumed, though it will be useful as a reference at an AVN site.

#### **MATERIALS AND TOOLS REQUIRED**

- 1. ROACH
- 2. Kettle-cable to power the ROACH
- 3. Control computer
- 4. Kettle cable to power the computer
- 5. Monitor
- 6. Monitor VGA cable
- 7. Kettle cable to power the monitor
- 8. Power supply for the monitor
- Screwdrivers
- 10.3x female-to-male SMA cables (panel to ADC)
- 11. 1x male-to-male SMA cable (Valon to ADC)
- 12. USB mini-B cable for connecting Valon to PC
- 13. USB-to-serial converter & Serial cable (DB-9 plug, female to female)
- 14. Standard Cat5e network flylead
- 15. Computer with Windows operating system
- 16. Computer with Linux operating system (virtualbox is useable if that's all that's available)
- 17. Broadband power meter capable of DC-1GHz operation
- 18. Spectrum analyser capable of DC-1GHz operation
- 19. XAUI 10gbe cable
- 20.2x SMA Cables for Rx to ROACH connection
- 21. SMA Torque wrench
- 22. Masking tape for emergency labelling
- 23.Pen
- 24. Cage Nuts and screws (x10)

#### PROCEDURE FOR AVN ROACHES BEFORE DEPLOYMENT

#### HARDWARE SETUP


- Remove the screws from the top of the ROACH enclosure, and remove the top panel.
   Remove any packing foam and / or masking tape from the inside of the enclosure if any is present.
- Unwrap the Valon from its bubble-wrap and crimp the ends of its included cable with Molex male crimps.
- Connect the Valon to the power supply by inserting the crimped pins into the corresponding holes in the Molex 8981, and the small black connector into the

03 August 2015 Page 7 of 26






corresponding socket on the Valon itself. The red (5V) and black (GND) wires should correspond, as shown.




Verify that the power supply doesn't add unwanted additional phase noise to the Valon.



Verify that the KatADC is plugged into ZDOK0 as shown. If this is not the case, carefully unscrew and shift it, and fasten it down again afterwards. Do not overtighten the screws. The KatADC can handle RF inputs up to 0dBm. Don't apply signals above this limit to either the Q or I inputs.







- Once the Valon is connected as described above, and the KatADC is in the correct place, fasten the plates down.
- Verify that the ribbon cables are correctly placed. These should be fastened with cable-organisers down the side of the ROACH enclosure, but if not, make corrections as necessary. Note the positions of the red wires in the photos below. Verification can be performed visually, continuity testing with a multimeter can be performed if uncertain but should not be necessary. In the photos, the ribbon cables are labelled as follows:


A -

- B FPGA GPIO A
- C Monitor GPIO
- D Chassis LEDs











Attach the RF SMA cables.

Before beginning with software setup, note the serial numbers of the ROACH, the KatADC and the Valon.

#### **SOFTWARE SETUP**

- Connect the kettle cable to the ROACH to provide power.
- Configure the output frequencies and power levels of the Valon.
  - o On a Windows PC (if not already present), download the driver (CDM v2.12.00 WHQL Certified.exe) and control application (5007 Config Mgr Admin Version 1.6.1 Setup.zip) from the following link: (Install the driver first, then the control application)
    - https://github.com/chopley/AVNDigitalBackendDocumentation/tree/master/roac hAcceptanceTests/ValonSoftware
    - After the above software is installed, you may need to reboot the computer before the Valon will be correctly detected.
  - Use the USB mini-B cable to connect the Valon to the PC.
  - Start the 5007 Config Manager software. You may see an error message as shown in the screenshot below. If this is the case, click on "Ignore" to open the

03 August 2015 Page 10 of 26








application anyway



- o In the start menu, right-click on "Computer" and select "Manage".
- Select Device Manager from the list on the left, and look under "Ports" for a USB Serial Port device. In the screenshot below it is shown as COM6, make a note of this number.




Return to the 5007 Config Manager software. In the Comm Ports menu, select the port number corresponding to the USB Serial Port noted earlier, as shown:

03 August 2015 Page 11 of 26









- Under the File menu, click "Read Registers" to load the configuration currently saved in the Valon. If not already the case, set both the Synthsesisers to a Desired Frequency of 800 MHz and output power of Level 1 (corresponding to 1 dBm).
- Under the file menu, click "Write Registers" to save the configuration and "Write Flash" to save it permanently. Verify that it is correctly stored by closing and restarting the application and reading the registers again.
- If this is correct.
- Configure the boot process to auto-power on. This is done by
- Connecting the network cable between the XPORT connector on the back of the ROACH and a network switch
- Connecting the Linux PC (Not the control PC) to the network switch
- Manually setting the PC to have a static IP address = 192.168.4.1

Add the following lines to /etc/network/interfaces

auto eth0

iface eth0 inet static





address 192.168.4.1 netmask 255.255.255.0

#### Then do

\$ sudo /etc/init.d/networking stop
\$ sudo /etc/init.d/networking start

Verify the static IP (192.168.4.1) has been set by using ifconfig

The ROACH XPORT has a default IP address of 192.168.4.20. You can it usina the roach monitor.py (available https://github.com/chopley/AVNDigitalBackendDocumentation/ blob/master/roachAcceptanceTests/roach monitor.py) script once you have set the PC IP address to the static value as above. If you cannot connect, it is likely that your PC is being assigned an IP on a different sub-net and this needs to be remedied. Note: Some distributions (e.g. Ubuntu) use a network manager which may either ignore or overwrite /etc/network/interfaces file. In this case, the distribution's preferred means of setting the IP address must be used.

For Ubuntu you can do the following:

Add the following lines to /etc/network/interfaces

auto eth0

iface eth0 inet static

address 192.168.4.1

netmask 255.255.255.0

- sudo /etc/init.d/networking restart
- Connecting to the ROACH:

\$ python roach\_monitor.py [requires that both the 1gbe and
XPORT lan cables are plugged in]

Toggle the auto-power setting. This is option 8 in the menu which is shown:

ROACH MONITOR CONTROL

\_\_\_\_\_

- 1) Retrieve details
- 2) Reset crashlog counter
- 3) Power-up ROACH
- 4) Reset ROACH, but not Actel
- 5) Toggle safety-shutdown defeat
- 6) Power down ROACH
- 7) Toggle PPC EEPROM boot (config H)
- 8) Toggle auto power-on after hard-reset.

#### =>**8**<enter>

Automatic power-up after reset is currently disabled. ENABLING... done.

 Verify this is working by disconnecting power to the ROACH and reconnecting power. NOTE THAT THE ROACH MUST BE POWERED ON BEFORE







PULLING THE POWER TO IT. IF IT ISN'T POWERED ON IT WILL NOT AUTOMATICALLY RESTART

- Remove the network cable from the XPORT port on the ROACH and connect the 1GbE port as normal.
- On the control PC: verify that the ROACH can get an IP address. If the serial number
  of the ROACH is 040406 then the MAC address of the 1gbe ROACH connector will
  default to 02:00:00:04:04:06. Edit the following file:

sudo vim /etc/dnsmasq.conf

add an appropriate line at

dhcp-host=02:00:00:04:04:06,169.254.128.113 #Roach name

• Restart the dnsmasq service.

sudo /etc/init.d/dnsmasg restart

- Change the boot command in the U-BOOT bootloader. To do this you do the following:
  - Connect the serial port of the ROACH to the Windows PC using the USB-toserial converter and establish a serial connection using Putty or similar software (baud rate 115200). Remember to check the COM port using the technique described above.
  - Power up (or reboot) the ROACH, keeping an eye on the terminal
  - Press a key on to get into the UBOOT configuration. Typing help lists the possible commands.

Input: printenv bootcmd

Output: bootcmd=run mmcboot

Change this to run netboot

Input: setenv bootcmd run netboot

Input: saveenv


- Verify that the ROACH is booting from NFS rebooting on the front panel, or by typing boot in U-BOOT.
- Login to the ROACH. The default login is root with no password.
- Verification procedure:
  - Connect Synth1 from the Valon to the KAT-ADC port labelled CLOCK/FS. This
    provides a 800MHZ at 1dBm clock signal for the KAT-ADC. This is divided by 4
    for the Xilinx Virtex 5clock speed of 200MHZ. Load 'tut3\_katadc.bof' into Roach
    filesystem (/boffiles) if not already present.
- Run 'python tut3\_katadc <roach\_ip\_address>' in a terminal window (X forwarding required if done via ssh).
- A noise spectrum plus the 200 MHz tone of the Valon should be seen within a minute, updating every few seconds. It will look something like this:

03 August 2015









If the Valon needs to be configured, this can be done in Linux using ipython. First plug the Valon into the computer via USB, and run dmesg to determine the ttyUSB\* (usually 0 or 1).

Run sudo chmod 777 /dev/ttyUSB0 (or 1), in order to make the Valon usable by ipython, then from within ipython

```
import valon_synth
a = valon_synth.Synthesizer('/dev/ttyUSB0')
a.get_frequency(valon_synth.SYNTH_A) #show current freq
a.set_freqyency(valon_synth.SYNTH_A, 800) #set freq A to 800 MHz.
# valon_synth.SYNTH_A and valon_synth.SYNTH_B can be used to
# get and set frequencies for the two synthesizers.
```


#### PROCEDURE FOR AVN ROACHES DURING DEPLOYMENT

03 August 2015









- 1) Verify IF Power Level from Receiver output is between -20 and -27dBm by measurement with a broadband power meter. Note down power level.
- 2) Verify IF frequency band is in appropriate band by measurement with a spectrum analyser. Note power level and 3dB frequencies.
- 3) Verify network connections of digital backend equipment
  - a) Connect 1gbe RJ45 cable from ROACH to network switch, and 1gbe RJ45 cable from control PC to network switch. Visually verify that the correct port is connected (there are three).
  - b) Connect station LAN to the control PC. Visually verify that correct port is connected.
  - c) Verify ROACH network connection by powering ROACH, and ping appropriate ROACH IP address from control PC- nominally 169.254.128.91
  - d) Verify ROACH borph is operating over NFS by ssh into ROACH ssh root@169.254.128.91
  - e) Verify ntp time acquisition is working (ntpg -p on Roach and control PC)
  - f) Finally, check all IP addresses are properly allocating. The private LAN should be on subnet 169.254.128.xxx on the PC, and the public LAN should be receiving an IP address.
  - g) Verify that a PC connected on the Private LAN is allocated with an IP, and is able to access the public LAN. Verify by test, i.e connect up a laptop to private network switch, and ping www.google.com
- 4) Connect IF LCP cable (SMA) to Roach I input- SMA cable
- 5) Connect IF RCP cable (SMA) to Roach Q input- SMA cable
- 6) Connect up 1PPS cable to Roach Sync Input. SMA cable





- 7) Connect up 10MHz cable to Roach Clock Input. SMA cable
- 8) Verify infrastructure is ok using the following
  - a) python testRoach10gERebuild.py 'carina'
  - b) All LEDS on the front panel should indicate green status
  - c) Verify 1PPS detection by visual inspection of LED on front panel (4th LED from the Left)
  - d) Verify Pulse detection by visual inspection of LED on the front panel (3rd LED from the left)
- 9) Start up Roach Narrowband Spectrometer mode using ipython
  - a) python initRoach.py 'carina'
  - b) python avnCoarseFFTSnap.py -a 5 'carina'
- 10)Connect 10gbe Cable from ROACH to standard PC and verify operations using wireshark
  - a) This might involve using python testRoach10gERebuild.py 'carina'
- 11) Verify remote access to PC and static IP address is assigned.
- 12) Verify that the correct Valon speed is currently operating
  - a) import corr, logging

logger=logging.getLogger(roach)

roach='carina'

fpga = corr.katcp\_wrapper.FpgaClient('carina',7147,timeout=10,logger=logger)

fpga.est\_brd\_clk()

Out[7]: 200.378118

fpga.read\_uint('clk\_frequency')

Out[9]: 200000000







## HIGH RESOLUTION SPECTROMETER DESIGN SCREENSHOTS




Illustration 1: High Level context of LED, ADC Snap Blocks, and Status Registers

03 August 2015 Page 18 of 26










Illustration 2: Low Level description of the LEDs on the front panel (they are connected to GPIOa pins via ribbon cable inside)








Illustration 3: Layout of Status registers

03 August 2015 Page 20 of 26





## ADC snap blocks




Illustration 4: ADC Snap Block registers

03 August 2015 Page 21 of 26










Illustration 5: Timing description

03 August 2015 Page 22 of 26










Illustration 6: ADC controllers and registers

03 August 2015 Page 23 of 26










Illustration 7: Control register for the design

03 August 2015 Page 24 of 26





03 August 2015 Page 25 of 26

