
Home

Shop

Arduino

Raspberry Pi

NodeMCU



Arduino

How to use it?

Newsfeed

NodeMCU

Raspberry Pi

Raspberry Pi 3 Tutorial 12 – GP10 DHT11 Digital Temperature + Humidity Sensor

- Sushant Narang
- ② June 12, 2016
- Raspberry Pi
- No Comment

Difficulty level: Beginner

Approx reading time:

Components Required:

- 1. Raspberry Pi 3 model B
- 2. MicroSD card 8 or 16 GB (Class 4 and above) with Raspbian
- **3.** Windows PC / Linux PC (Tested on Windows 10, Ubuntu 14.04 LTS)
- **4.** Ethernet cable (Category 5 also called Cat 5)
- 5. Micro USB cable
- 6. Breadboard
- 7. DHT11 Sensor

searcn

Search ...

Search

Recent Posts

How to Control Stepper Motor?

Digital Temperature Probe (DS18B20) - How to Use it?

Dust Sensor - How to Use it?

Pulse Sensor - How to Use it?

Rainfall Sensor - How to Use it?

Pages

Fresher Kit

Tags

8. Jumper Wires (Male to Female, Male to Male)

Way to go ->

- 1. Login to your Pi using PuTTy or your Ubuntu terminal.
- 2. Login to your Pi GUI using VNC server (Linux / Windows).
- 3. In Python 3 (IDLE), create a new file.
- 4. The name could be: DHT11Read.py.
- **5.** In the file **DHT11Read.py**, write the following code with comments (line starting with "#") for clear understanding and save (press **Cntrl** + **S** on your PC keyboard) the file.

```
import Adafruit_DHT

while True:
    humidity, temperature = Adafruit_DHT.read_retry(11, 27) # GPIO2
print ("Humidity = {} %; Temperature = {} C".format(humidity, temperature)
```

Before running the python script do the following:

6. In the terminal type:

```
1 sudo apt-get install git-core
```

7. Download the Adafruit DHT11 library. In the terminal type:

```
1 git clone https://github.com/adafruit/Adafruit_Python_DHT.git
```

8. Navigate to to Adafruit_Python_DHT directory (folder), in the terminal type:

```
1 cd Adafruit_Python_DHT
```

9. Run the following commands in the terminal.

```
1 sudo apt-get install build-essential python-dev # python2
2
```

```
3 sudo apt-get install build-essential python3-dev # python3
```

10. To install the library, in the terminal type:

```
1 sudo python setup.py install # python2
2 
3 sudo python3 setup.py install # python3
```

11. Finally, run the script by clicking on Run -> Run Module in the menu bar or by pressing F5 on your PC keyboard.

```
■ ■ File Edit View Search Terminal Help
pi@raspberrypi:~/Desktop/PyScripts $ python DHT11Read.py
Humidity = 65.0 %; Temperature = 25.0 C
Humidity =
           65.0 %; Temperature
           65.0 %; Temperature
Humidity =
           65.0
                    Temperature
           65.0 %; Temperature
Humidity
Humidity =
           65.0 %; Temperature
           65.0
                    Temperature
Humidity
           65.0
                    Temperature
Humidity =
           65.0 %; Temperature
           65.0
                    Temperature
Humidity
           67.0
                 %;
                    Temperature
           75.0 %; Temperature
Humidity =
           74.0
                    Temperature
           74.0 %; Temperature
                 %; Temperature
lumidity =
Humidity = 73.0 %; Temperature = 26.0 C
Humidity = 164.0 %; Temperature = 13.0 C
Humidity = 73.0 %; Temperature = 26.0
```


Hardware Connections ->

1. Raspberry Pi 3 GPIO Header.


Raspberry Pi 3 GPIO Header					
Pin#	NAME		NAME	Pin‡	
01	3.3v DC Power	00	DC Power 5v	02	
03	GPIO02 (SDA1 , I ² C)	00	DC Power 5v	04	
05	GPIO03 (SCL1 , I ² C)	00	Ground	06	
07	GPIO04 (GPIO_GCLK)	00	(TXD0) GPIO14	08	
09	Ground	00	(RXD0) GPIO15	10	
11	GPIO17 (GPIO_GEN0)	00	(GPIO_GEN1) GPIO18	12	
13	GPIO27 (GPIO_GEN2)	00	Ground	14	
15	GPIO22 (GPIO_GEN3)	00	(GPIO_GEN4) GPIO23	16	
17	3.3v DC Power	00	(GPIO_GEN5) GPIO24	18	
19	GPIO10 (SPI_MOSI)	00	Ground	20	
21	GPIO09 (SPI_MISO)	00	(GPIO_GEN6) GPIO25	22	
23	GPIO11 (SPI_CLK)	00	(SPI_CE0_N) GPIO08	24	
25	Ground	00	(SPI_CE1_N) GPIO07	26	
27	ID_SD (I2C ID EEPROM)	00	(I ² C ID EEPROM) ID_SC	28	
29	GPIO05	00	Ground	30	
31	GPIO06	00	GPIO12	32	
33	GPIO13	00	Ground	34	
35	GPIO19	00	GPIO16	36	
37	GPIO26	00	GPIO20	38	
39	Ground	00	GPIO21	40	

2. DHT11 to Pi connections.

DHT11	Pi
Vcc	5v
Output	GPIO27 (Pin 13)
GND	Ground



fritzing



fritzing

Read full tutorial at

Rating widget:

Communication with NRF24L01+ »

No Comments Yet

Leave a Reply

neave a reepry				
Your email address will not be published.				
	li li			
	Marra			
	Name			
	Email			
	Website			
Post Comment				
2 333 3331113113				
« Raspberry Pi 3 Tutorial 11 -	Raspberry Pi 3 Tutorial 13 -			
GPIO Analog Sensor + MCP3008 /	Wireless Pi to Pi Pythor			

Copyright ©2018. Module143

MCP3004