Contents

Setup	2
Controls	2
Layout basics	2
Non-layered inputs	2
Top encoder section	2
Normal mode	2
Shift mode	2
Button matrix pages	3
Layer Page	3
Normal mode	3
Shift mode	3
Page A	4
Normal mode	4
Shift mode	4

Setup

to write

Controls

Layout basics

Latch layers functionality mimics setting 2, that is, the latch layer button changes the functionality of the buttons A-P. However, instead of cycling through 3 layers by repeatedly pressing the latch layer button, the button brings you to a menu page where each of the buttons A-P represents a unique layer. This makes for a total of 16 layers, with 16 more theoretically possible using the shift button.

Non-layered inputs

Top encoder section

Top encoa	er section						
Normal mode Left controller				Right controller			
jump length global	set loop deck 1	▼ N/A <i>N/A</i>	set loop deck 3	▼ N/A <i>N/A</i>	set loop deck 2	▼ N/A <i>N/A</i>	set loop deck 4
jump longdeck 1	↓ loop size deck 1	₄▶ jump long deck 3	loop size deck 3	jump long deck 2	loop size deck 2	jump long deck 4	loop size deck 4
Shift mode Left controller					Right c	ontroller	
Non shift Non shift	Non shift Non shift	Non shift Non shift	Non shift Non shift	Non shift Non shift	Non shift Non shift	Non shift Non shift	Non shift Non shift
jump short deck 1	move loop	jump short deck 3	move loop deck 3	jump short deck 2	move loop deck 2	jump short deck 4	move loop deck 4

Button matrix pages

Layer Page

=a,o ago							
Normal mode Left controller				Right controller			
A: play cntrl deck 1 & 3	B: slicer deck 1 & 3	C: beat roll deck 1 & 3	D: keycue deck 1 & 3	A: play cntrl deck 2 & 4	B: slicer deck 2 & 4	C: beat roll deck 2 & 4	D: keycue deck 2 & 4
E: hotcues	F: cueloop	blank page	blank page	E: hotcues	F: cueloop	blank page	blank page
deck 1 & 3	deck 1 & 3	N/A	N/A	deck 2 & 4	deck 2 & 4	N/A	N/A
blank page	blank page	blank page	blank page	blank page	blank page	blank page	blank page
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
blank page	blank page	blank page	blank page	blank page	blank page	blank page	blank page
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Shift mode Left controller					Right co	ontroller	
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift
Non shift	Non shift	Non shift	Non shift	<i>Non shift</i>	<i>Non shift</i>	Non shift	Non shift
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift
<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	<i>Non shift</i>	<i>Non shift</i>	<i>Non shift</i>	Non shift
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift
<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	Non shift
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift

Page A

Normal m	ode						
Left controller			Right controller				
Cue	Set master	< nudge	nudge >	Cue	Set master	< nudge	nudge >
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
Play	Sync	slip	reverse	Play	Sync	slip	reverse
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
Cue deck 3	Set master deck 3	< nudge deck 3	nudge > deck 3	Cue deck 4	Set master deck 4	< nudge deck 4	nudge > deck 4
Play	Sync	slip	reverse	Play	Sync	slip	reverse
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4
Shift mode Left controller					Right co	ntroller	
jump start	master tempo	edit grid	load track	jump start	master tempo	edit grid	load track
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
jump start	master tempo	edit grid	load track	jump start	master tempo	edit grid	load track
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4



